

5. [Check if a software update is available](#) for your phone.
6. [Reset the phone.](#)

Connected Bluetooth device

Check the battery level of Bluetooth device and phone, and charge if necessary. [Paired Bluetooth devices](#) may disconnect or create noise when the phone or Bluetooth battery are low.