

App or widget issues

App or widget missing from home screen

If a widget disappeared from your [home screen](#), then [add the widget](#) by touching & holding an empty spot on your home screen.

If an app disappeared from your home screen, the shortcut for opening the app was removed and you just need to [add a shortcut](#).

If an app disappeared from your list of all apps, you need to [reinstall](#) it.

App icons being replaced in favorites

If the apps in your favorites tray are being replaced by apps you haven't selected and you don't want them to change, turn off app suggestions.

1. Touch & hold a blank space on your home screen.
2. Tap  **Home settings** > **Home screen style**.
3. Next to **App tray**, tap .
4. Turn **Suggestions on Home screen** off .

App crashes, won't open, or isn't working

After each step, check to see if the issue is fixed:

1. Turn your phone off and then on again.
Press & hold the **Power** + **Volume up** buttons simultaneously, then tap **Restart**.
2. Check that you have not disabled permissions for the app. If any permissions are turned off, [turn them on](#) and try using the app again.
3. [Update the app](#).
4. Force stop the app. This completely shuts down the app, including any background services that may be causing your issue.
5. Clear the app's cache. This frees up space by removing temporary files.
6. Clear the app's data. This erases all data saved in this app.
7. Contact the app's developer.
 - a. [Open](#) the Play Store app.
 - b. Touch your profile icon  > **Manage apps & device**.
 - c. Touch the app and swipe down to see contact information.
8. If all else fails, [delete the app](#).

Tip: To figure out which third-party app is causing performance problems, [use safe mode](#).