



## **FLEX SENSOR**

## **Quick Setup Guide**

Interfacing the multi-meter: Connect the two wires from the Flex sensor to the two leads of a multi-meter.



Measuring the bending: Bend the sensor and observe the change in resistance on the multi-meter. Note that the sensor accurately measures bending opposite the side with the printed text.





Sensor Products Inc. 300 Madison Avenue Madison, NJ 07940 USA Phone: 1.973.884.1755 Fax: 1.973.884.1699

www.sensorprod.com