





## Partlist

	· action		
Menge	Part	Value	Package
2 17 3 1 1 1 1	C1, C2 C3-C19 C20, C25, C26 C21 C22 C23 C24 C27	22pF 100nF 1μF 10μF 10μF LowESR 22μF 100μF 1μF	C0805k (SMD) C050-024X044 C050-050X075 E2,5-5 CT6032 (SMD) E2-5 E2,5-6 E2,5-5
1 2 3 1 4 1 1 1 2 1 1 1 2 2 2 1	R1 R2, R5 R3, R4, R27 R6 R7, R8, R18, R19 R9 R10 R11 R12, R13 R14 R15 R16 R17 R20, R21 R22, R23 R24, R25, R26 R28	1M 10k 4,7k 10k 68R 1,5k 100R 2,7k 820R 10k 10R 12k 500k 100k 33k 100R 1k	0207/7 0207/7 0207/7 P6M-S (Poti) 0207/7 0207/7 0207/7 0207/7 0207/7 CA6H (Poti) 0207/7 CA6H (Poti) R1206 (SMD) R1206 (SMD) R1206 (SMD) R1206 (SMD)
2 2 1 1 1 1 1 1	D1, D2 D3, D4 LED1, LED2 DS1 IC1 IC2 IC3 IC4 IC5 T1	Z-Diode 3,6V Z-Diode 5,1V LED gelb 3mm LCD 2x16 Zeichen MEGA32-P MAX517 LM334 TSOP1736 LM2940CT5 BSP295 BPW42	SOD80C (SMD) DO35Z10 LED3MM HDM20216H_OHNE DIL40 DIL08 JP2Y TSOP17 78XXS SOT223 (SMD) FOTOTRAN3MM
3 3 7 1 2 3 1 1 2 1	SV1-SV3 ISP, SV4, SV5 JP1, JP2, JP5 JP3, JP4, JP6-JP10 Buchse für IC3 K1, K2 S1-S3 X1 X2 X3, X4 L1 Q1	Wannstecker 10pol Stiftleiste 2reihig 6polig Stiftleiste 1reihig 3polig Stiftleiste 1reihig 2polig Buchsenleiste 3polig Klemme 2polig Taster USB B Stecker PS2 Buchse Klinkenbuchse 3,5mm stereo 10µH Quarz 16MHz	ML10 MA03-2 JP2 JP1 JP2Y AST 025-02 B3F-10XX USB_B_STECKER PS2 Klinkenbuchse L3230M (SMD) HC49U-V