## **ESP Gate Drivers** Core 2Phase 5Phase 2.2uF48 C35 73 VCAP ESP\_MODE **RS232** HX711 input Switch input sensor **Upload POWER** STM Boot Mode **Uart 5v XNOR BUZZER** HX711 10 Peri 3v3 LED **ETC**