

RCX Series

Programming Manual

EGR717B511 E76

Introduction

Our sincere thanks for your purchase of this YAMAHA RCX series robot controller.

This manual describes robot program commands and related information for using YAMAHA RCX series robot controllers. Be sure to read this manual carefully as well as related manuals and comply with their instructions for using the YAMAHA robot controllers safely and correctly.

For details on how to operate YAMAHA robot controllers, refer to the separate controller user's manual that comes with the YAMAHA robot controller.

Applicable controllers: RCX240, RCX141, RCX142, RCX40, RCX221 and RCX222

Model names as used in this manual include the following controllers.

RCX240 ... Includes RCX240, RCX141, RCX142 and RCX40 (4-axis controllers)

RCX14x ... Includes RCX141, RCX142 and RCX40 (4-axis controllers excluding RCX240)*

RCX22x ... Includes RCX221 and RCX222 (2-axis controllers)

* Here, "RCX14x" does not include RCX240 and is used when there is a difference between the RCX240 and other 4-axis controllers due to differences in software versions.

Safety precautions

Be sure to read before using

Before using the YAMAHA robot controller, be sure to read this manual and related manuals, and follow their instructions to use the robot controller safely and correctly.

Warning and caution items listed in this manual relate to YAMAHA robot controllers.

When this robot controller is used in a robot controller system, please take appropriate safety measures as required by the user's individual system.

This manual classifies safety caution items and operating points into the following levels, along with symbols for signal words "CAUTION" and "NOTE".



L CAUTION

"CAUTION" indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or damage to the equipment or software.



NOTE

Primarily explains function differences, etc., between software versions.



Explains robot operation procedures in a simple and clear manner.

Note that the items classified into "CAUTION" might result in serious injury depending on the situation or environmental conditions. So always comply with CAUTION instructions since these are essential to maintain safety.

Keep this manual carefully so that the operator can refer to it when needed. Also make sure that this manual reaches the end user.

■ System design precautions



!\ CAUTION

When the program execution stops before it is complete, the program re-executes the command that has stopped. Keep this point in mind when re-executing the program, for example, when using an arch motion with the MOVE command, a relative movement command such as the MOVEI or DRIVEI command, or a communication command such as the SEND command.

Chapter 1 Writing Programs	
1 The YAMAHA Robot Language	1-1
2 Characters	1-1
3 Program Basics	1-1
4 Program Names	1-2
5 Identifiers	1-7
6 Comment	1-7
7 Command Statement Format	1-8
Chapter 2 Constants	
1 Outline	2-1
2 Numeric constants	2-1
2.1 Integer constants	2-1
2.2 Real constants	2-1
3 Character constants	2-2
Chapter 3 Variables	
1 Outline	3-1
2 User Variables & System Variables	3-2
2.1 User Variables	3-2
2.2 System Variables	3-2
3 Variable Names	3-3
3.1 Dynamic Variable Names	3-3
3.2 Static Variable Names	3-3
4 Variable Types	3-4
4.1 Numeric variables	3-4
4.2 Character variables	3-4
5 Array variables	3-5
6 Value Assignments	3-5

7	Type Conversions	3-6
8	Value Pass-Along & Reference Pass-Along	3-6
9	System Variables	3-7
9	9.1 Point data variable	3-7
9	9.2 Shift coordinate variable	3-8
9	9.3 Point element variable	3-9
9	9.4 Shift element variable	3-10
9	0.5 Parallel input variable	3-10
9	0.6 Parallel output variable	3-11
9	9.7 Internal output variable	3-12
9	9.8 Arm lock output variable	3-13
9	9.9 Timer output variable	3-14
9	9.10 Serial input variable	3-15
9	9.11 Serial output variable	3-16
9	9.12 Serial word input	3-17
9	9.13 Serial double word input	3-17
9	9.14 Serial word output	3-18
9	9.15 Serial double word output	3-18
10	Bit Settings	3-19
11	Valid range of variables	3-20
	Valid range of variables 1.1 Valid range of dynamic variables	3-20 3-20
1	-	
1 ¹	1.1 Valid range of dynamic variables	3-20
1: 1: 1:	1.1 Valid range of dynamic variables 1.2 Valid range of static variables	3-20 3-20
11 11 12	1.1 Valid range of dynamic variables1.2 Valid range of static variables1.3 Valid range of dynamic array variables	3-20 3-20 3-20
1: 1: 1: 12	 1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables Clearing variables 	3-20 3-20 3-20 3-21
1: 1: 12 1: 1:	1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables 2.1 Clearing dynamic variables	3-20 3-20 3-20 3-21 3-21
1: 1: 12 1: 1:	1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables 2 Clearing variables 2.1 Clearing dynamic variables 2.2 Clearing static variables	3-20 3-20 3-20 3-21 3-21
11 12 12 11 11 Ch	1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables 2 Clearing variables 2.1 Clearing dynamic variables 2.2 Clearing static variables 4 Expressions and Operations	3-20 3-20 3-20 3-21 3-21 3-21
11 11 12 11: 11: Ch	1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables 2 Clearing variables 2.1 Clearing dynamic variables 2.2 Clearing static variables 4 Expressions and Operations Arithmetic operations	3-20 3-20 3-21 3-21 3-21
11 11 12 11: 11: Ch	1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables 2 Clearing variables 2.1 Clearing dynamic variables 2.2 Clearing static variables 2.4 Expressions and Operations Arithmetic operations 1. Arithmetic operators	3-20 3-20 3-21 3-21 3-21 4-1
11 11 12 11: 11: Ch	1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables 2 Clearing variables 2.1 Clearing dynamic variables 2.2 Clearing static variables 4 Expressions and Operations 5 Arithmetic operations 6 Arithmetic operators 7 Relational operators	3-20 3-20 3-21 3-21 3-21 4-1 4-1
11 11 12 11: 11: 11: 11: 11: 11: 11:	1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables 2 Clearing variables 2.1 Clearing dynamic variables 2.2 Clearing static variables 4 Expressions and Operations 5 Arithmetic operations 6 Arithmetic operators 7 Relational operators 8 Logic operations	3-20 3-20 3-21 3-21 3-21 4-1 4-1 4-2
11 11 12 11: 11: 11: 11: 11: 11: 11:	1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables 2 Clearing variables 2.1 Clearing dynamic variables 2.2 Clearing static variables 2.2 Clearing static variables Arithmetic operations 1. Arithmetic operators 2. Relational operators 3. Logic operations 4. Priority of arithmetic operation	3-20 3-20 3-21 3-21 3-21 4-1 4-1 4-1 4-2 4-3
11 11 12 11 11 11 11 11 12 2	1.1 Valid range of dynamic variables 1.2 Valid range of static variables 1.3 Valid range of dynamic array variables 2.1 Clearing dynamic variables 2.2 Clearing static variables 2.2 Clearing static variables hapter 4 Expressions and Operations Arithmetic operations 1 Arithmetic operators 2 Relational operators 3 Logic operations 4 Priority of arithmetic operation 5 Data format conversion	3-20 3-20 3-21 3-21 3-21 3-21 4-1 4-1 4-2 4-3 4-3

3 Point data format	4-5
4 DI/DO conditional expressions	4-6
Chapter 5 Multiple Robot Control	
1 Overview	5-1
2 Command list for each group	5-2
Chapter 6 Multi-tasking	
1 Outline	6-1
2 Task definition	6-1
3 Task status and transition	6-2
3.1 Starting tasks	6-2
3.2 Task scheduling	6-3
3.3 Condition wait in task	6-4
3.4 Suspending tasks (SUSPEND)	6-5
3.5 Restarting tasks (RESTART)	6-5
3.6 Deleting tasks	6-6
3.7 Stopping tasks	6-7
4 Multi-task program example	6-8
5 Sharing the robot language and data	6-8
6 Cautionary Items	6-9
Chapter 7 Sequence function	
1 Sequence function	7-1
2 Creating a sequence program	7-1
2.1 Programming method	7-1
2.2 Compiling	7-2
3 Executing a sequence program	7-4
3.1 Sequence program STEP execution	7-4
4 Creating a sequence program	7-5
4.1 Assignment statements	7-5
4.2 Input/output variables	7-5

4.	.3 Timer definition statement		7-7
4.	.4 Logical operators		7-7
4.	5 Priority of logic operations		7-8
4.	.6 Sequence program specifica	ations	7-8
Ch	napter 8 Robot Langua	ige Lists	
Но	w to read the robot languag	ge table	8-1
Со	mmand list in alphabetic or	der	8-3
Fu	nction Specific		8-8
Fu	nctions: in alphabetic order		8-15
Fu	nctions: operation-specific		8-18
1	ABS	Acquires absolute values	8-20
2	ABSINIT / ABSINIT2	Resets the current position of a specified axis	8-21
3	ABSRPOS / ABSRPOS2	Acquires a machine reference	8-23
4	ABSRST	Absolute motor axis return-to-origin operation	8-24
5	ACCEL / ACCEL2	Specifies/acquires the acceleration coefficient parameter	8-25
6	ARCH / ARCH2	Specifies/acquires the acceleration coefficient parameter	8-26
7	ARMCND / ARMCND2	Arm status acquisition	8-28
8	ARMTYPE / ARMTYPE2	SCARA robot hand system	8-29
9	ATN / ATN2	Acquires the arctangent of the specified value	8-30
10	ASPEED / ASPEED2	Sets the automatic movement speed	8-31
11	AXWGHT / AXWGHT2	Sets/acquires the axis tip weight	8-32
12	CALL	Calls a sub-procedure	8-33
13	CHANGE / CHANGE2	Switches the hand	8-34
14	CHGPRI	Changes the priority ranking of a specified task	8-35
15	CHR\$	Acquires a character with the specified character code	8-36
16	COS	Acquires the cosine value of a specified value	8-37
17	CURTRQ / CURTRQ2	Acquires the current torque of the specified axis	8-37
18	CUT	Terminates another sub task which is currently being executed	8-38
19	DATE\$	Acquires the date	8-39
20	DECEL / DECEL2	Specifies/acquires the deceleration rate parameter	8-40
21	DECLARE	Declares that a sub-routine or sub-procedure is to be used within the COMMON program	8-41
22	DEF FN	Defines functions which can be used by the user	8-43

23	DEGRAD	Angle conversion (angle \rightarrow radian)	8-44
24	DELAY	Program execution waits for a specified period of time	8-45
25	DI	Acquires the input status from the parallel port	8-46
26	DIST	Acquires the distance between 2 specified points	8-47
27	DIM	Declares array variable	8-48
28	DO	Outputs to parallel port	8-49
29	DRIVE / DRIVE2	Executes absolute movement of specified axes	8-50
30	DRIVEI / DRIVEI2	Moves the specified robot axes in a relative manner	8-58
31	END SELECT	Ends the SELECT CASE statement	8-63
32	END SUB	Ends the sub-procedure definition	8-64
33	ERR / ERL	Acquires the error code / error line No	8-65
34	EXIT FOR	Terminates the FOR to NEXT statement loop	8-66
35	EXIT SUB	Terminates the sub-procedure defined by SUB to END	8-67
36	EXIT TASK	Terminates its own task which is in progress	8-68
37	FOR to NEXT	Performs loop processing until the variable-specified value is exceeded	8-69
38	GOSUB to RETURN	Jumps to a sub-routine	8-70
39	GOTO	Executes an unconditional jump to the specified line	8-71
40	HALT	Stops the program and performs a reset	8-72
41	HAND / HAND2	Defines the hand	8-73
	41.1 For SCARA Robots		8-73
	41.2 For Cartesian Robots		8-76
42	HOLD	Temporarily stops the program	8-78
43	IF	Evaluates a conditional expression value, and executes the command in accordance with the conditions	8-79
	43.1 Simple IF statement		8-79
	43.2 Block IF statement	Assigns a value to a variable aposition from the programming boy	8-80
	INPUT	Assigns a value to a variable specified from the programming box	
	INT	Truncates decimal fractions	8-82
	JTOXY / JTOXY2	Performs axis unit system conversions (pulse → mm)	8-83
	LABEL Statement	Defines labels at program lines	8-84 8-85
	LEFT\$	Extracts character strings from the left end	
	LEFTY / LEFTY2	Sets the SCARA robot hand system as a left-hand system	8-86 8-87
	LEN	Acquires a character string length Assigns values to variables	8-88
	LET	Arm lock output	8-91
	LOCX	Specifies/acquires point data or shift data for a specified axis	8-92
	1 3 73 73	- Opoomooraouuli oo politi uata ol olilli uata ivi a opecilieti axio	0-02

54	LSHIFT	Left-shifts a bit	8-94
55	MCHREF / MCHREF2	Acquires a machine reference	8-95
56	MID\$	Acquires a character string from a specified position	8-96
57	MO	Outputs a specified value to the MO port (internal output)	8-97
58	MOVE / MOVE2	Performs absolute movement of all robot axes	8-98
59	MOVEI / MOVEI2	Performs absolute movement of all robot axes	8-114
60	OFFLINE	Sets a specified communication port to the "offline" mode	8-119
61	ORD	Acquires a character code	8-120
62	ON ERROR GOTO	Jumps to a specified label when an error occurs	8-121
63	ON to GOSUB	Executes the subroutine specified by the <expression> value</expression>	8-122
64	ON to GOTO	Jumps to the label specified by the <expression> value</expression>	8-123
65	ONLINE	Sets the specified communication port to the "online" mode	8-124
66	ORGORD / ORGORD2	Specifies/acquires the robot's return-to-origin sequence	8-125
67	ORIGIN	Performs an incremental mode axis return-to-origin	8-126
68	OUT	Turns ON the specified port output	8-127
69	OUTPOS / OUTPOS2	Specifies/acquires the OUT enable position parameter of the robot	8-128
70	PATH	Specifies the main robot axis PATH motion path	8-130
71	PATH END	Ends the movement path setting	8-136
72	PATH SET	Starts the movement path setting	8-137
73	PATH START	Starts the PATH motion	8-139
74	PDEF	Defines the pallet used to execute pallet movement commands	8-140
75	PMOVE / PMOVE2	Executes a pallet movement command for the robot	8-141
76	Pn	Defines points within a program	8-145
77	PPNT	Creates pallet point data	8-147
78	PRINT	Displays the specified expression value at the programming box	8-148
79	RADDEG	Performs a unit conversion (radians \rightarrow degrees)	8-149
80	REM	Inserts a comment	8-150
81	RESET	Turns OFF the bits of specified ports, or clears variables	8-151
82	RESTART	Restarts another task during a temporary stop	8-152
83	RESUME	Resumes program execution after error recovery processing	8-153
84	RETURN	Processing which was branched by GOSUB, is returned to the next line after GOSUB	8-154
85	RIGHT\$	Extracts a character string from the right end of another character string	8-155
86	RIGHTY / RIGHTY2	Sets the SCARA robot hand system to "Right"	8-156
87	RSHIFT	Shifts a bit value to the right	8-157
88	Sn	Defines the shift coordinates in the program	8-158

89	SELECT CASE	Executes the specified command block in accordance with the <expression> value</expression>	8-159
90	SEND	Sends <read file=""> data to the <write file=""></write></read>	8-160
91	SERVO / SERVO2	Controls the servo status	8-162
92	SET	Turns the bit at the specified output port ON	8-163
93	SHARED	Enables sub-procedure referencing without passing on the variable	8-164
94	SHIFT / SHIFT2	Sets the shift coordinates	8-165
95	SIN	Acquires the sine value for a specified value	8-166
96	SO	Outputs a specified value to the serial port	8-167
97	SPEED / SPEED2	Changes the program movement speed	8-168
98	START	Starts a new task	8-169
99	STR\$	Converts a numeric value to a character string	8-170
100	SQR	Acquires the square root of a specified value	8-171
101	SUB to END SUB	Defines a sub-procedure	8-172
102	SUSPEND	Temporarily stops another task which is being executed	8-174
103	SWI	Switches the program being executed	8-175
104	TAN	Acquires the tangent value for a specified value	8-176
105	TCOUNTER	Timer & counter	8-177
106	TIME\$	Acquires the current time	8-178
107	TIMER	Acquires the current time	8-179
108	ТО	Outputs a specified value to the TO port	8-180
109	TOLE / TOLE2	Specifies/acquires the tolerance parameter	8-181
110	TORQUE / TORQUE2	Specifies/acquires the maximum torque command value which can be set for a specified axis	8-182
111	TRQSTS / TRQSTS2	Acquires the status when DRIVE statement ends	8-184
112	TRQTIME / TRQTIME2	Sets/acquires the time-out period for the torque limit setting option	8-185
113	VAL	Converts character strings to numeric values	8-187
114	WAIT	Waits until the conditions of the DI/DO conditional expression are met	8-188
115	WAIT ARM / WAIT ARM2	Waits until the robot axis operation is completed	8-189
116	WEIGHT/WEIGHT2	Specifies/acquires the tip weight parameter	8-190
117	WEND	Ends the WHILE statement's command block	8-191
118	WHERE / WHERE2	Acquires the arm's current position (pulse coordinates)	8-192
119	WHILE to WEND	Repeats an operation for as long as a condition is met	8-193
120	WHRXY / WHRXY2	Acquires the arm's current position in Cartesian coordinates	8-194
121	XYTOJ / XYTOJ2	Converts the main group axes Cartesian coordinate data ("mm") to joint coordinate data ("pulse")	8-195
122	_SYSFLG	Axis status monitoring flag	8-195

CI	hapter 9 PATH Statements	
1	Overview	9-1
2	Features	9-1
3	How to use	9-1
4	Cautions when using this function	9-2
CI	hapter 10 Limitless motion	
1	Overview	10-1
2	Operation Procedure	10-1
2	2.1 Parameters	10-1
2	2.2 Robot language	10-1
2	2.3 Sample program	10-2
3	Restrictions	10-3
CI	hapter 11 Data file description	
1	Overview	11-1
1	.1 Data file types	11-1
1	.2 Cautions	11-1
2	Program file	11-2
2	2.1 All programs	11-2
2	2.2 One program	11-3
3	Point file	11-4
3	3.1 All points	11-4
3	3.2 One point	11-6
4	Point comment file	11-8
4	I.1 All point comments	11-8
4	9.2 One point comment	11-8
5	Parameter file	11-10
5	5.1 All parameters	11-10
5	5.2 One parameter	11-12
6	Shift coordinate definition file	11-13
6	3.1 All shift data	11-13
6	S.2 One shift definition	11-14

7 Hand definition file	11-15
7.1 All hand data	11-15
7.2 One hand definition	11-16
8 Pallet definition file	11-17
8.1 All pallet definitions	11-17
8.2 One pallet definition	11-20
9 All file	11-23
9.1 All files	11-23
10 Program directory file	11-24
10.1 Entire program directory	11-24
10.2 One program	11-25
11 Parameter directory file	11-26
11.1 Entire parameter directory	11-26
12 Variable file	11-27
12.1 All variables	11-27
12.2 One variable	11-29
13 Constant file	11-30
13.1 One character string	11-30
14 Array variable file	11-31
14.1 All array variables	11-31
14.2 One array variable	11-32
15 DI file	11-33
15.1 All DI information	11-33
15.2 One DI port	11-34
16 DO file	11-35
16.1 All DO information	11-35
16.2 One DO port	11-36
17 MO file	11-37
17.1 All MO information	11-37
17.2 One MO port	11-38
18 LO file	11-39
18.1 All LO information	11-39
18.2 One LO port	11-40

19 TO file	11-41
19.1 All TO information	11-41
19.2 One TO port	11-42
20 SI file	11-43
20.1 All SI information	11-43
20.2 One SI port	11-44
21 SO file	11-45
21.1 All SO information	11-45
21.2 One SI port	11-46
22 Error message history file	11-47
22.1 All error message history	11-47
23 Error Message History Details File	11-48
23.1 General error message history details	11-48
24 Machine reference file	11-49
24.1 All machine reference file	11-49
25 EOF file	11-50
25.1 EOF data	11-50
26 Serial port communication file	11-51
26.1 Serial port communication file	11-51
27 SIW file	11-52
27.1 All SIW	11-52
27.2 One SIW data	11-53
28 SOW file	11-54
28.1 All SIW	11-54
28.2 One SOW data	11-55
29 Ethernet port communication file	11-56
29.1 Ethernet port communication file	11-56
Chapter 12 User program examples	
1 Basic operation	12-1
1.1 Directly writing point data in program	12-1

CONTENTS	RCX Serie Programming Manua
----------	--------------------------------

1.2	Using point numbers	12-2	
1.3	Using shift coordinates		
1.4	Palletizing		
1.4.	1.4.1 Calculating point coordinates		
1.4.	2 Utilizing pallet movement	12-6	
1.5	DI/DO (digital input and output) operation	12-7	
2 A	pplication	12-8	
2.1	Pick and place between 2 points	12-8	
2.2	Palletizing	12-10	
2.3	Pick and place of stacked parts	12-12	
2.4	Parts inspection (Multi-tasking example)	12-14	
2.5	Sealing	12-17	
2.6	Connection to an external device through RS-232C (example 1)	12-18	
2.7	Connection to an external device through RS-232C (example 2)	12-19	
Cha	pter 13 Online commands		
1 0	nline Command List	13-1	
1.1	Online command list: Function specific	13-1	
1.2	Online command list: In alphabetic order	13-4	
2 K	ey operation	13-6	
2.1	Changing the mode	13-6	
2.2	AUTO mode operation	13-7	
2.3	MANUAL mode operation	13-9	
3 Ut	tility operation	13-12	
3.1	Acquiring the program execution status	13-12	
3.2	Сору	13-12	
3.3	Erase	13-14	
3.4	Rename program name	13-16	
3.5	Changing the program attribute	13-16	
3.6	Initialize	13-17	
3.7	Setting the display language	13-18	
3.8	Setting the coordinates and units in MANUAL mode	13-19	
3.9	Clearing the programming box error message	13-19	
3.10		13-20	
3.11		13-22	
	Checking and setting the time	13-23	
4 Da	ata handling	13-24	
4.1	Assuring the display language	13-24	
	Acquiring the display language	10-24	
4.2	Acquiring the access level	13-24	

4 IO command list		14-5
3 Sending and receiving IO	commands	14-3
2 IO command format		14-1
1 Overview		14-1
Chapter 14 IO commands	•	
6.1 Interrupting the command e	xecution	13-46
6 Control codes		13-46
5.2 Other robot language comm	lana processing	13-45
5.1 Switching the program	and processing	13-44
5 Executing the robot langua	age independently	13-44
4.28 Current torque value acquis		13-43
4.27 Data write processing	ition	13-42
4.26 Data readout processing		13-41
4.25 Acquiring various values		13-39
4.24 Acquiring the option slot sta	ıtus	13-38
4.23 Acquiring the error status by	•	13-37
4.22 Acquiring the emergency st		13-37
4.21 Acquiring the remaining me	• • •	13-36
4.20 Acquiring the hand status		13-36
4.19 Acquiring the shift status		13-35
4.18 Acquiring the tasks operation	n status	13-35
4.17 Acquiring the tasks in RUN	or SUSPEND status	13-34
4.16 Acquiring the current position	ons	13-32
4.15 Acquiring the version inform	ation	13-32
4.14 Acquiring the point coordinate	ates and units	13-31
4.13 Acquiring the speed setting	-	13-31
4.12 Acquiring the sequence pro	gram execution status	13-30
4.11 Acquiring the servo status		13-30
4.10 Acquiring the absolute reser		13-29
4.9 Acquiring return-to-origin st	atus	13-29
4.8 Acquiring the message		13-28
4.7 Acquiring the mode status	'	13-27
4.6 Acquiring the execution leve		13-26
4.4 Acquiring the break point st4.5 Acquiring the controller con		13-26
4.3 Acquiring the arm status 4.4 Acquiring the break point st	atua	13-25 13-25
13 Acquiring the arm status		13_25

CONTENTS

5 IO command description 14-6				
5.1 MOVE command				
5.2 MOVEI command	14-7			
5.3 Pallet movement command	14-7			
5.4 Jog movement command	14-8			
5.5 Inching movement command	14-8			
5.6 Point teaching command	14-9			
5.7 Absolute reset movement command	14-9			
5.8 Absolute reset command	14-10			
5.9 Return-to-origin command	14-10			
5.10 Servo command	14-11			
5.11 Manual movement speed change command	14-12			
5.12 Auto movement speed change command	14-12			
5.13 Program speed change command	14-12			
5.14 Shift designation change command 14-13				
5.15 Hand designation change command 14-13				
5.16 Arm designation change command 14-13				
5.17 Point display unit designation command	14-13			
Chapter 15 Appendix				
1 Reserved word list 15-1				
2 Robot Language Lists: Command list in alphabetic order 15-3				
3 Robot Language Lists: Function Specific 15-8				
4 Functions: in alphabetic order 15-15				
5 Functions: operation-specific 15-18				
6 Execution Level 15-20				

Index

Chapter 1 Writing Programs

1	The YAMAHA Robot Language	1-1
2	Characters	1-1
3	Program Basics	1-1
4	Program Names	1-2
5	Identifiers	1-7
6	Comment	1-7
7	Command Statement Format	1-8

The YAMAHA Robot Language

The YAMAHA robot language was developed by Yamaha Motor Co., Ltd. IM Company for simple and efficient programming to control YAMAHA industrial robots. The YAMAHA robot language is similar to BASIC (Beginner's All-purpose Symbolic Instruction Code) and makes even complex robot movements easy to program. This manual explains how to write robot control programs with the YAMAHA robot language, including actual examples on how its commands are used.

Characters

The characters and symbols used in the YAMAHA robot language are shown below. Only 1-byte characters can be used.

Alphabetic characters

A to Z, a to z

Numbers

0 to 9

Symbols

• katakana (Japanese phonetic characters)



- Katakana (Japanese phonetic characters) cannot be entered from a programming box. Katakana can be used when communicating with a host computer (if it handles katakana).
- Spaces are also counted as characters (1 space = 1 character).

Program Basics



NOTE

For sub-procedure details, refer to the "CALL" and "SUB ~ END SUB" items.



For details regarding user defined functions, refer to the "DEF FN" item.

Programs are written in a "1 line = 1 command" format, and every line must contain a command. Blank lines (lines with no command) will cause an error when the program is compiled (creation of execution objects). The program's final line, in particular, must not be blank.

To increase the program's efficiency, processes which are repeated within the program should be written as subroutines or sub-procedures which can be called from the main routine. Moreover, same processing items which occurs in multiple programs should be written as common routines within a program named [COMMON], allowing those processing items to be called from multiple programs.

User functions can be defined for specific calculations. Defined user functions are easily called, allowing even complex calculations to be easily performed.

Multi-task programs can also be used to execute multiple command statements simultaneously in a parallel processing manner.

Using the above functions allows easy creation of programs which perform complex processing.

Program Names

Each program to be created in the robot controller must have its own name.

Programs can be named as desired provided that the following conditions are satisfied:

- Program names may contain no more than 8 characters, comprising a combination of alphanumeric characters and underscores (_).
- Each program must have a unique name (no duplications).

The 4 program names shown below are reserved for system operations, and programs with these names have a special meaning.

- A) FUNCTION
- B) SEQUENCE
- _SELECT
- D) COMMON

The functions of these programs are explained below.

A) FUNCTION

Functions Pressing the USER key in "PROGRAM" mode or "MANUAL" mode allows the user function to be used. When user functions are used in the "PROGRAM" mode, commands (MOVE, GOTO, etc.) which are frequently used during program editing can be entered by function keys. When used in "MANUAL" mode, DO output is available with the function keys without running the program. The FUNCTION program defines function keys which are used to execute user functions. The desired functions can be freely assigned to the function keys.

SAMPLE ' FOR MANUAL MODE *M F1: DO(20)ALTERNATE DO(20) = ~DO(20) DO (20) ON/OFF highlighting occurs when the key is pressed. *M F2: DO(21)ALTERNATE DO(21) = DO(21) DO(21) is highlighted. *M F6: DO (25) MOMENTARY $DO(25) = 1 \cdots DO(25)$ is set to "1" when the key is pressed. DO $(25) = 0 \cdots DO (25)$ is set to "0" when the key is released. *M F7: MOTION MOVE P, P1 ····· Movement to Point 1 occurs. MOVE P, P2 Movement to Point 2 occurs. ' FOR PROGRAM MODE *P F1: MOVE P, [MOVE P,] is written to the program when the key is pressed. *P F6: MOVE L, [MOVE L,] is written to the program when the key is pressed. *P F2: GOTO *..... [GOTO *] is written to the program when the key is pressed.

Registering editing function keys used in the PROGRAM mode

Format

*P_F <n>: ' <character string>

Values

<character string>.....The character string which is registered and displayed for the function key.



• Although up to 65 characters can be entered for a <character string>, no more than 7 characters are displayed on the Menu.

SAMPLE

*P_F2:'MOVE P,.....Registers "MOVE P," at the [F2] key.

*P_F8:'DELAY.....Registers "DELAY" at the [F8] key.

Registering output command function keys used in the MANUAL mode

Format

*M_F <n>:' <character string> <Output statement 1> <Output statement 2>

Values

<character string>......The character string which is displayed for the function key.

<Input/output statement 1>....Command statement which is executed when the key is pressed.

<Input/output statement 2>Command statement which is executed when the key is released



• Although up to 65 characters can be entered for a <character string>, no more than 7 characters are displayed on the Menu.

SAMPLE

*M_F2:'MOMENT Displays "MOMENT" at the [F2] key.

DO(20)=1 DO (20) is turned ON when the [F2] key is pressed.

DO(20)=0 DO (20) is turned OFF when the [F2] key is released.

*M_F14:'ALTER Displays "ALTER" at the [F14] key.

DO(20)=~DO(20) The DO(20) output status is highlighted when the [F14] key is pressed.

REFERENCE

For details, refer to the relevant controller manual.

B) SEQUENCE

Functions Unlike standard robot programs, the RCX Controller allows the execution of high-speedprocessing programs (sequence programs) in response to robot inputs and outputs (DI, DO, MO, LO, TO, SI, SO). Specify a program name of "SEQUENCE" to use this function, thus creating a pseudo PLC within the controller.

> When the controller is in the AUTO or MANUAL mode, a SEQUENCE program can be executed in fixed cycles (regardless of the program execution status) in response to dedicated DI10 (sequence control input) input signals, with the cycle being determined by the program capacity. For details, see Chapter 7 "4.6 Sequence program specifications".

> This allows sensors, push-button switches, and solenoid valves, etc., to be monitored and operated by input/output signals.

> Moreover, because the sequence programs are written in robot language, they can easily be created without having to use a new and unfamiliar language.

SAMPLE

```
DO(20) = \sim DI(20)
DO(25) = DI(21) AND DI(22)
MO(26) = DO(26) OR DO(25)
```

REFERENCE For details, see Chapter 7 "Sequence function".

SAMPLE

Functions This function allows the user to create a program which is always selected and executed when the robot program is reset. Specify a program name of "_SELECT" to use this function. For example, if multiple programs exist, and there is a need to switch between the programs by using DI inputs, simply create a program-switching program named "_ SELECT". Even if another program is running, the system always returns to this program when a reset input occurs after that program stops. The various reset types and their corresponding processing are as follows (also refer to the program example shown below):

- **NOTE**
- For details regarding the "execution level", refer to the controller manual.
- 1. When a reset is executed from the Programming Box, a query displays, asking if a change to "_SELECT" is desired. If "No" is pressed, a selection screen displays, allowing the user to select whether or not a reset is to be executed.
- 2. When reset by the HALT command in a program, dedicated DI (reset signal) or online command, the system switches to the "_SELECT" program.
- 3. The operation which occurs at power ON varies according to the "execution level". If the execution level has been selected as "execute program reset at power ON", a reset is executed at power ON, and "_SELECT" is then selected.

A program is selected according to the value input from DI3(). When DI3() is 0, the system repeatedly monitors the DI input. When DI3() is from 1 to 3, the matching program is selected. When DI3() is other than the above cases, the system quits the program that is currently running.

- •Using an ON ERROR statement allows running the program in a loop not ending in an error even without the program name specified by a SWI statement.
- An error code issued during execution of the program is input into a variable ERR. "ERR=&0303" means "Program doesn't exist".

```
ON ERROR GOTO *ER1
*ST:
   SELECT CASE DI3() ..... Branching occurs based on the DI3 "()" value.
         GOTO *ST ..... If "0", a return to "*ST" occurs,
                            and the processing is repeated.
      CASE 1
         SWI <PART1> ..... If "1"
      CASE 2
         SWI <PART2> ..... If "2"
      CASE 3
         SWI <PART3> ..... If "3"
      CASE ELSE
         GOTO *FIN ..... For any other value, a jump to
                            "*FIN" occurs, and processing ends.
   END SELECT
   GOTO *ST
*FIN:
HALT
*ER1:
   IF ERR=&H0303 THEN *NEXT L · A return is executed if a "no
                            program exists" error occurs.
   ON ERROR GOTO 0 ..... For any other error, processing ends.
*NEXT L:
RESUME NEXT
```

REFERENCE For details, refer to the command explanations given in this manual.

D) COMMON

Functions A separate "COMMON" program can be created to perform the same processing in multiple robot programs. The common processing routine which has been written in the COMMON program can be called and executed as required from multiple programs. This enables efficient use of the programming space.

> The sample COMMON program shown below contains two processing items (obtaining the distance between 2 points (SUB *DISTANCE), and obtaining the area (*AREA)) which are written as common routines, and these are called from separate programs (SAMPLE 1 and SAMPLE 2).

> When SAMPLE1 or SAMPLE2 is executed, the SUB *DISTANCE (A!,B!,C!) and the *AREA routine specified by the DECLARE statement are executed.

```
SAMPLE
Program name: SAMPLE1
   DECLARE SUB *DISTANCE(A!,B!,C!)
   DECLARE *AREA
   X! = 2.5
   Y! = 1.2
   CALL *DISTANCE(X!,Y!,REF C!)
   GOSUB *AREA
   PRINT C!, Z!
   HALT
Program name: SAMPLE2
   DECLARE SUB *DISTANCE(A!, B!, C!)
   DECLARE *AREA
   X! = 5.5
   Y! = 0.2
   CALL *DISTANCE(X!,Y!,REF C!)
   GOSUB *AREA
   PRINT C!, Z!
   HALT
Program name: COMMON ..... Common routine
   SUB *DISTANCE(A!, B!, C!)
      C! = SQR(A!^2 + B!^2)
   END SUB
   *AREA:
      Z! = X! * Y!
   RETURN
```

REFERENCE For details, refer to the command explanations given in this manual.

5

"Identifiers" are a combination of characters and numerals used for label names, variable names, and procedure names. Identifiers can be named as desired provided that the following conditions are satisfied:

■ Identifiers must consist only of alphanumeric characters and underscores (_). Special symbols cannot be used, and the identifier must not begin with an underscore (_).

- The identifier length must not exceed 16 characters (all characters beyond the 16th character are ignored).
- Up to 500 identifiers may be used.
- Variable names must not be the same as a reserved word, or the same as a name defined as a system variable. Moreover, variable name character strings must begin with an alphabetic character. For label names, however, the "*" mark may be immediately followed by a numeric character.

SAMPLE

LOOP, SUBROUTINE, GET DATA

REFERENCE For details regarding reserved words, see Chapter 15 "1. Reserved word list".

Comment 6

Characters which follow REM or an apostrophe mark (" ' ") are processed as a comment. Comment statements are not executed. Moreover, comments may begin at any point in the line.

```
SAMPLE
```

```
REM *** MAIN PROGRAM ***
   (Main program)
* *** SUBROUTINE ***
   (Subroutine)
      'HALT COMMAND..... This comment may begin at any
                          point in the line.
```

Command Statement Format

Format

[<label>:] <statement> [<operand>]

One robot language command must be written on a single line and arranged in the format shown below:

- Items enclosed in [] can be omitted.
- Items enclosed in < > must be written in a specific format.
- Items not enclosed in < > should be written directly as shown.
- Items surrounded by | | are selectable.
- The label can be omitted. When using a label, it must always be preceded by an asterisk (*), and it must end with a colon (:) (the colon is unnecessary when a label is used as a branching destination).

For details regarding labels, refer to Chapter 8 "45. LABEL Statement".

- Operands may be unnecessary for some commands.
- Programs are executed in order from top to bottom unless a branching instruction is given.

1 line may contain no more than 75 characters.

Chapter 2 Constants

1	Outline	2-1
2	Numeric constants	2-1
3	Character constants	2-2

Constants can be divided into two main categories: "numeric types" and "character types". These categories are further divided as shown below.

Category	Туре	Details/Range
Numeric type	Integer type	Decimal constants -1,073,741,824 to 1,073,741,823
	•···	Binary constants &B0 to &B11111111
		Hexadecimal constants &H80000000 to &H7FFFFFFF
_	Real type	Single-precision real numbers -999,999.9 to +999,999.9
		Exponential format single-precision real numbers -1.0*10 ³⁸ to +1.0*10 ³⁸
Character type	Character string	Alphabetic, numeric, special character, or katakana (Japanese) character string of 75 bytes or less.

Numeric constants

2.1 Integer constants

1. Decimal constants

Integers from -1,073,741,824 to 1,073,741,823 may be used.

2. Binary constants

Unsigned binary numbers of 8 bits or less may be used. The prefix "&B" is attached to the number to define it as a binary number.

Range: &B0 (decimal: 0) to &B11111111 (decimal: 255)

3. Hexadecimal constants

Signed hexadecimal numbers of 32 bits or less may be used. The prefix "&H" is attached to the number to define it as a hexadecimal number.

Range: &H80000000 (decimal: -2,147,483,648) to &H7FFFFFF (decimal: 2,147,483,647)

2.2 Real constants

1. Single-precision real numbers

Real numbers from -999999.9 to +999999.9 may be used.

• 7 digits including integers and decimals. (For example, ".0000001" may be used.)

2. Single-precision real numbers in exponent form

Numbers from $-1.0*10^{38}$ to $+1.0*10^{38}$ may be used.

• Mantissas should be 7 digits or less, including integers and decimals.

Examples: -1. 23456E-12

3. 14E0

1. E5



• An integer constant range of -1,073,741,824 to 1,073,741,823 is expressed in signed hexadecimal number as &HC0000000 to &H3FFFFFFF.

Outline 2-1

2

3

4

5

6

7

3

Character constants

Character type constants are character string data enclosed in quotation marks ("). The character string must not exceed 75 bytes in length, and it may contain upper-case alphabetic characters, numerals, special characters, or katakana (Japanese) characters.

To include a double quotation mark (") in a string, enter two double quotation marks in succession.

SAMPLE

- "YAMAHA ROBOT"
- "EXAMPLE OF" "A" " " EXAMPLE OF "A"
- PRINT "COMPLETED"
- "YAMAHA ROBOT"

Chapter 3 Variables


1	Outline	3-1
2	User Variables & System Variables	3-2
3	Variable Names	3-3
4	Variable Types	3-4
5	Array variables	3-5
6	Value Assignments	3-5
7	Type Conversions	3-6
8	Value Pass-Along & Reference Pass-Alo	ng 3-6
9	System Variables	3-7
10	Bit Settings	3-19
11	Valid range of variables	3-20
12	Clearing variables	3-21

There are "user variables" which can be freely defined, and "system variables" which have predefined names and functions.

User variables consist of "dynamic variables" and "static variables". "Dynamic variables" are cleared at program editing, compiling, program resets, and program switching. "Static variables" are not cleared unless the memory is cleared. The names of dynamic variables can be freely defined, and array variables can also be used.

Variables can be used simply by specifying the variable name and type in the program. A declaration is not necessarily required. However, array variables must be pre-defined by a DIM statement.

User variables & system variables



REFERENCE For details regarding the above array, see Chapter 3 "5 Array variables".

Outline 3-1

2

3

1

5

6

7

2

User Variables & System Variables

2.1 User Variables

Numeric type variables consist of an "integer type" and a "real type", and these two types have different usable numeric value ranges. Moreover, each of these types has different usable variables (character string variables, array variables, etc.), and different data ranges, as shown below.

	Category	Variable Type	Details/Range
_	Dynamic variables	Numeric type	Integer type variables -1,073,741,824 to 1,073,741,823 (Signed hexadecimal constants: &HC0000000 to &H3FFFFFFF)
			Real variables (single-precision) -1.0*10 ³⁸ to +1.0*10 ³⁸
		Character type	Character string variables Alphabetic, numeric, special character, or katakana (Japanese) character string of 75 bytes or less.
	Static variables	Numeric type	Integer type variables -1,073,741,824 to 1,073,741,823
	••••	-	Real variables (single-precision) -1.0*10 ³⁸ to +1.0*10 ³⁸
_	Array variables	Numeric type	Integer array variables -1,073,741,824 to 1,073,741,823
		=	Real number array variables (single-precision) -1.0*10 ³⁸ to +1.0*10 ³⁸
		Character type	Character string array variables Alphabetic, numeric, special character, or katakana (Japanese) character string of 75 bytes or less.

NOTE

 Array variables are dynamic variables.

2.2 System Variables

As shown below, system variables have pre-defined names which cannot be changed.

Category	Туре	Details	Specific Examples
Input/output variables	Input variable	External signal / status inputs	DI, SI, SIW, SID
	Output variable	External signal / status outputs	DO, SO, SOW, SOD
Point variable		Handles point data	Pnnnn
Shift variable		Specifies the shift coordinate No. as a numeric constant or expression.	Sn
Element variables	Point element variable	Handles point data for each axis, hand system flag, or for the X-arm or Y-arm rotation information.	
	Shift element variable	Handles shift data in element units.	LOCx (shift expression)

REFERENCE

For details, see Section "9 System Variables".

3.1

2

Dynamic variables can be named as desired, provided that the following conditions are satisfied:

■ The name must consist only of alphanumeric characters and underscores (_). Special symbols cannot be used.

- The name must not exceed 16 characters (all characters beyond the 16th character are ignored).
- The name must begin with an alphabetic character.

Dynamic Variable Names

COUNT O Use is permitted
COUNT123 O Use is permitted
2COUNT X Use is not permitted

Variable names must not be the same as a reserved word.
Variable names must not begin with characters used for system variable names (pre-defined variables). These characters include the following: FN, DIn, DOn, MOn, LOn, TOn, SIn, SOn, Pn, Sn, Hn ("n" denotes a numeric value).

SAMPLE	
COUNT	······O Use is permitted
ABS	······× (Reserved word)
FNAME	$\cdots\cdots \times (FN: pre-defined variable)$
S91	······× (Sn: pre-defined variable)

REFERENCE For details regarding reserved words, see Chapter 15 "1 Reserved word list".

3.2 Static Variable Names

Static variable names are determined as shown below, and these names cannot be changed.

Variable Type	Variable Name
Integer variable	SGIn (n: 0 to 7)
Real variable	SGRn (n: 0 to 7)

Static variables are cleared only when initializing is executed by a SYSTEM mode or online command.

REFERENCE

For details regarding the clearing of static variables, see Section "12 Clearing variables".

4 Variable Types

The type of variable is specified by the type declaration character attached at the end of the variable name.

However, because the names of static variables are determined based on their type, no type declaration statement is required.

Type Declaration Character	Variable Type	Specific Examples
\$	Character type variables	STR1\$
%	Integer type variables	CONT0%, ACT%(1)
!	Real type variables	CNT1!, CNT1



- If no type declaration character is attached, the variable is viewed as a real type.
- Variables using the same identifier are recognized to be different from each other by the type of each variable.

cacii vanabic.		
• ASP_DEF%	Integer variable	ACD DEFOY LACD DEF 1997
• ASP_DEF	Real variable	\rightarrow ASP_DEF% and ASP_DEF are different variables.
• ASP_DEF!	Real variable \	
/ (SI _DLI	Kear variable	\rightarrow ASP_DEF! and ASP_DEF are the same variables.

4.1 Numeric variables

NOTE

• When a real number is assigned to an integer type variable, the decimal value is rounded off to the nearest whole number. For details, refer to Chapter 4 "1.5 Data format conversion".



NOTE

 The "!" used in real variables may be omitted.

Integer variables

Integer variables and integer array elements can handle an integer from -1,073,741,824 to 1,073,741,823 (in signed hexadecimal, this range is expressed as &HC00000000 to &H3FFFFFFF).

```
Examples: R1\% = 10
R2\%(2) = R1\% + 10000
```

Real variables

Real variables and real array elements can handle a real number from $-1.0*10^{38}$ to $1.0*10^{38}$.

```
Examples: R1! = 10.31
R2!(2) = R1% + 1.98E3
```

4.2 Character variables

Character variables and character array elements can handle a character string of up to 75 characters.

Character strings may include alphabetic characters, numbers, symbols and katakana (Japanese phonetic characters).

```
Examples:R1$ = "YAMAHA"
R2$(2) = R1$ + "MOTOR" "YAMAHA MOTOR"
```

5 Array variables

Both numeric and character type arrays can be used at dynamic variables.

Using an array allows multiple same-type continuous data to be handled together.

Each of the array elements is referenced in accordance with the parenthesized subscript which appears after each variable name. Subscripts may include integers or <expressions> in up to 3 dimensions.

In order to use an array, a DIM statement must be declared in advance, and the maximum number of elements which can be used is the declared subscripts $+ 1 (0 \sim \text{number of declared subscripts})$.



- Array variables are all dynamic variables (for details regarding dynamic variables, see Chapter 3
 "11 Valid range of variables".)
 - The length of an array variable that can be declared with the DIM statement depends on the program size.

Format

SAMPLE

Value Assignments

An assignment statement (LET) can also be used to assign a value to a variable.



• "LET" directly specifies an assignment statement, and it can always be omitted.

Format

```
[LET] <variable> = <expression>
```

Write the value assignment target variable on the left side, and write the assignment value or the <expression> on the right side. The <expression> may be a constant, a variable, or an arithmetic expression, etc.

REFERENCE For details, refer to Chapter 8 "49 LET (Assignment Statement)"

Type Conversions

When different-type values are assigned to variables, the data type is converted as described below.

- When a real number is assigned to an integer type:
 The decimal value is rounded off to the nearest whole number.
- When an integer is assigned to a real type:
 The integer is assigned as it is, and is handled as a real number.
- When a numeric value is assigned to a character string type:
 The numeric value is automatically converted to a character string which is then assigned.
- When a character string is assigned to numeric type:

 This assignment is not possible, and an error will occur at the compiling operation. Use the "VAL" command to convert the character string to a numeric value, and that value is then assigned.

Value Pass-Along & Reference Pass-Along

A variable can be passed along when a sub-procedure is called by a CALL statement. This passalong can occur in either of two ways: as a value pass-along, or as a reference pass-along.

Value pass-along

With this method, the variable's value is passed along to the sub-procedure. Even if this value is changed within the sub-procedure, **the content of the call source variable is not changed.**


A value pass-along occurs when the CALL statement's actual argument specifies a constant, an expression, a variable, or an array element (array name followed by (<subscript>)).

Reference pass-along

With this method, the variable's reference (address in memory) is passed along to the sub-procedure. If this value is changed within the sub-procedure, **the content of the call source variable** is also changed.

A reference pass-along occurs when the CALL statement's actual argument specifies an entire array (an array named followed by parenthetical content), or when the actual argument is preceded by "REF".

Value pass-along & reference pass-along



Execution result: the X% value remains as "5".

```
Reference pass-along

X%=5

CALL *TEST( REF X% )

PRINT X%

HALT

SUB ROUTINE

SUB *TEST( A% )

A%=A%*10

END SUB
```

Execution result: the X% value becomes "50".

33302-R7-00

characters used for these system variable names.

Variable Type	Format	Meaning
Point variable	Pnnn / P " [" <expression>"] "</expression>	Specifies a point number.
Shift variable	Sn / S " [" <expression>"] "</expression>	Specifies the shift number as a constant or as an expression.
Point element variable	LOCx (<point expression="">)</point>	Handles point data for each axis, hand system flag, or for the X-arm or Y-arm rotation information.
Shift element variable	LOCx (<shift expression="">)</shift>	Handles shift data with the element range.
Parallel input variable	DI(mb), DIm(b)	Parallel input signal status.
Parallel output variable	DO(mb), DOm(b)	Parallel output signal setting and status.
Internal output variable	MO(mb), MOm(b)	Controller's internal output signal setting and status
Arm lock output variable	LO(mb), LOm(b)	Axis-specific movement prohibit.
Timer output variable	TO(mb), TOm(b)	For sequence program's timer function.
Serial input variable	SI(mb), SIm(b)	Serial input signal status.
Serial output variable	SO(mb), SOm(b)	Serial output signal setting and status.
Serial word input	SIW(m)	Serial input's word information status
Serial double-word input	SID(m)	Serial input's double-word information status.
Serial word output	SOW(m)	Serial output's word information status
Serial double-word output	SOD(m)	Serial output's double-word information status.

The following system variables are pre-defined, and other variable names must not begin with the

9.1 Point data variable

This variable specifies a point data number with a numeric constant or expression.

Format Pnnnn or P" ["<expression>"]"



•In controllers whose software version is earlier than 8.28, point numbers from 0 to 4000 can be specified with point variables.



n: Point number 0 to 9

Each bracket in quotation marks ("[" "]") must be written. Brackets are not used to indicate an item that may be omitted.

Functions A point data number is expressed with a 'P' followed by a number of 4 digits or less, or an expression surrounded by brackets ("[" <expression> "]").

Point numbers from 0 to 9999 can be specified with point variables.

Examples: P0 P110 P[A] P[START POINT] P[A(10)]

9.2 Shift coordinate variable

This variable specifies a shift coordinate number with a numeric constant or expression.

Format

Sn or S "["<expression>"]"



n: Shift number 0 to 9

Each bracket in quotation marks ("[" "]") must be written. Brackets are not used to indicate an item that may be omitted.

Functions A shift number is expressed with an 'S' followed by a 1-digit number or an expression surrounded by brackets ("[" <expression>"]").

```
Examples: S1
S[A]
S[BASE]
S[A(10)]
```



• The "shift coordinate range" for each shift number can be changed from the programming box.

Point element variable



 Hand system flags are only available from software version 8.08 onwards.



NOTE

- Hand system flags are only valid on SCARA robots, and the point data must be specified in "mm" units.
- The hand system flag value may be 0 (no designation), 1 (righthanded system) or 2 (lefthanded system).
- X-arm and Y-arm rotation information is only available in software Ver. 10.66 onwards.
- X-arm and Y-arm rotation information is only available on a YK500TW model robot with "mm" units point data. Attempting to use this information on any other robot model will result in the "5.37: Specification mismatch" error, and execution is stopped.
- For details regarding the X-arm and Y-arm rotation information, see Chapter 4 "3. Point data format".

Format

LOCx (<point expression>)



xX,Y,Z,R,A,B (axis setting), F (hand system flag setting), F1 (X-arm rotation information), F2 (Y-arm rotation information).

Functions Extracts the point-data-specified axis coordinates, hand system flag, X-arm rotation information, and Y-arm rotation information, or changes the value.

Specifies point data for each axis, hand system flag, or for the X-arm or Y-arm rotation information.

Examples: A(1) = LOCX(P10)

 \rightarrow The X-axis data of P10 is assigned to array variable A(1). LOCZ(P[A]) = 100.0

 \rightarrow The Z-axis data of P[A] is set to 100.0. LOCF(P100) = 1

→ Changing the P100 hand system flag to a right-handed system (The P100 point data must be in "mm" units) LOCF1(P100) = 1

 \rightarrow Changes the P100 X-arm rotation information to 1. (The P100 point data must be in "mm" units) LOCF2(P100) = 1

→ Changes the P100 Y-arm rotation information to 1. (The P100 point data must be in "mm" units) B=LOCX (WHERE)

 \rightarrow Assigns the current X-axis motor pulse value to array variable "B". C(3) = LOCX(WHRXY)

 \rightarrow Assigns the current arm position's X-axis to array variable C(3).

D=LOCX (JTOXY (WHERE))

E=LOCX (XYTOJ (WHRXY))



 Because JTOXY is a command for handling a <point expression>, a "JTOXY(LOCx(WHERE))" or "XYTOJ(LOCx(WHRXY))" command will result in an error.



NOTE

WHRXY / WHRXY2 are available from following software version.

RCX14x version 8.64 onwards RCX22x version 9.11 onwards

9.4 Shift element variable

This variable is used with shift data for each element.

Format

LOCx (<shift expression>)

Values

x: Axis setting X,Y,Z,R

Functions Extracts the shift-data-specified axis coordinates, or changes the value.

```
Examples: A(1) = LOCX(S1)

\rightarrow The X data of S1 is assigned to array variable <math>A(1).

LOCR(S[A]) = 45.0

\rightarrow The R data of S[A] is set to 45.0°.
```

9.5 Parallel input variable

This variable is used to indicate the status of parallel input signals.

Format 1

 $DIm([b, \cdot \cdot \cdot, b])$

Format 2

 $DI(mb, \cdot \cdot \cdot, mb)$

Values

```
Examples: A%=DI1()

→ Input status of ports DI(17) to DI(10)
is assigned to variable A%.

A 0 to 255 integer can be assigned to A%.

A%=DI5(7,4,0)

→ Input status of DI(57), DI(54) and
DI(50) is assigned to variable A%.
(If all above signals are 1(ON), then A%=7.)

A%=DI(27,15,10)

→ Input status of DI(27), DI(15) and
DI(10) is assigned to variable A%.
(If all above signals except DI(10) are 1 (ON), then A%=6.)

WAIT DI(21)=1

→ Waits for DI(21) to change to 1(ON).
```



- When specifying multiple bits, specify them from left to right in descending order (large to small).
- A '0' is entered if there is no actual input board.

9.6

Parallel output variable

Specifies the parallel output signal or indicates the output status.

Format 1

```
DOm([b, \cdot \cdot \cdot, b])
```

Format 2

```
DO(mb, \cdot \cdot \cdot, mb)
```

Values

```
Examples: A%=DO2()
         \rightarrow Output status of DO(27) to DO(20) is
           assigned to variable A%.
        A%=DO5(7,4,0)
         \rightarrow Output status of DO(57), DO(54) and
           DO(50) is assigned to variable A%.
         (If all above signals are 1(ON), then A%=7.)
        A%=DO(37,25,20)
         \rightarrow Output status of DO(37), DO(25) and
           DO(20) is assigned to variable A%.
         (If all above signals except DO(20) are 1
         (ON), then A%=6.)
        DO3 () =B%
         \rightarrow Changes to a status in which the DO(37)
           to DO(30) output can be indicated by B%.
         For example, if B% is "123": If a binary
         number is used, "123" will become
         "01111011", DO(37) and DO(32) will become
         "0", and the other bits will become "1".
```



• When specifying multiple bits, specify them from left to right in descending order (large to small).

 \rightarrow DO(45) and DO(40) become "1", and DO(44) becomes "0".

• A '0' is entered if there is no actual input board.

DO4(5,4,0) = &B101

9.7 Internal output variable

Specifies the controller's internal output signals and indicates the signal status.

Format 1

 $MOm([b, \cdot \cdot \cdot, b])$

Format 2

 $MO(mb, \cdot \cdot \cdot , mb)$

Values

m: port number 0 to 7, 10 to 17, 20 to 27

b: bit definition 0 to 7

• If the bit definition is omitted, bits 0 to 7 are all selected.

Functions Internal output variables which are used only in the controller, can be changed and referenced. These variables are used for signal communications, etc., with the sequence program. Ports 0 and 1 are for dedicated internal output variables which can only be referenced (they cannot be changed).

Port 0 indicates the status of origin sensors for axes 1 to 8 (in order from bit 0).

Each bit sets to '1' when the origin sensor turns ON, and to '0' when OFF.

Port 1 indicates the HOLD status of axes 1 to 8 (in order from bit 0). Each bit sets to '1' when the axis is in HOLD status, and to '0' when not.

Bit	7	6	5	4	3	2	1	0
Port 0	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1
	Origin sensor statuses 0: OFF / 1: ON							
Port 1	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1
	Hold s	tatus 0: F	RELEASE	/ 1: HOLD	(Axis 1 is	not used)		



- Axes where no origin sensor is connected are always ON.
- Being in HOLD status means that the axis movement is stopped and positioned within the target point tolerance while the servo is still turned ON.
- When the servo turns OFF, the HOLD status is released.
- Axes not being used are set to '1'.

Examples: A%=MO2 () → Internal output status of MO(27) to MO(20) is assigned to variable A%. A%=MO5(7,4,0) \rightarrow Internal output status of MO(57), MO(54) and MO(50) is assigned to variable A%. (If all above signals are 1 (ON), then A%=7.) A%=MO(37,25,20) \rightarrow Internal output status of MO(37), MO(25) and MO(20) is assigned to variable A%. (If all above signals except MO(25) are 1 (ON), then A%=5.)



When specifying multiple bits, specify them from left to right in descending order (large to small).

9.8

Arm lock output variable

Specifies axis-specific movement prohibit settings.

Format 1

```
LOm([b, \cdot \cdot \cdot, b])
```

Format 2

 $LO(mb, \cdot \cdot \cdot, mb)$

Values

m: port number 0

b: bit definition 0 to 7

• If the bit definition is omitted, bits 0 to 7 are all selected.

Functions The contents of this variable can be output and referred to as needed. There is only 1 port, and bits 0 to 7 respectively correspond to axes 1 to 8. When this bit is ON, movement on the corresponding axis is prohibited.

```
Examples: A%=LO0()
         → Arm lock status of LO(07) to LO(00) is
           assigned to variable A%.
          A%=LOO(7,4,0)
         \rightarrow Arm lock status of LO(07), LO(04) and
           LO(00) is assigned to variable A%.
         (If all above signals are 1 (ON), then A%=7.)
        A%=LO0(06,04,01)
         \rightarrow Arm lock status of LO(06), LO(04) and
           LO(01) is assigned to variable A%.
         (If all above signals except LO(01) are 1
         (ON), then A%=6.)
```



- When specifying multiple bits, specify them from left to right in descending order (large to small).
- Servo OFF to ON switching is disabled if an arm lock is in effect at even 1 axis.
- When performing JOG movement in the MANUAL mode, axis movement is possible at axes where an arm lock status is not in effect, even if an arm lock status is in effect at another axis.
- When executing movement commands from the program, etc., the "12.3 XX.Arm lock" error will occur if an arm lock status is in effect at the axis in question. (XX: arm lock enabled axis. Example: M1 S1)

System Variables 3-13

9.9 Timer output variable

This variable is used in the timer function of a sequence program.

Format 1

 $TOm([b, \cdot \cdot \cdot, b])$

Format 2

 $TO(mb, \cdot \cdot \cdot , mb)$

Values

- m : port number 0
- b: bit definition 0 to 7
- If the bit definition is omitted, bits 0 to 7 are all selected.

Functions The contents of this variable can be changed and referred to as needed.

Timer function can be used only in the sequence program. If this variable is output in a normal program, it is an internal output.

For details regarding sequence program usage examples, refer to the timer usage examples given in Chapter 7 "4.2 Input/output variables".

```
Examples: A%=TOO()

→ Status of TO(07) to TO(00) is assigned
to variable A%.

A%=TOO(7,4,0)

→ Status of TO(07), TO(04) and TO(00) is
assigned to variable A%.

(If all above signals are 1 (ON), then A%=7.)

A%=TO(06,04,01)

→ Status of TO(06), TO(04) and TO(01) is
assigned to variable A%.

(If all above signals except TO(01) are 1
(ON), then A%=6.)
```



• When specifying multiple bits, specify them from left to right in descending order (large to small).

9.10

Serial input variable

This variable is used to indicate the status of serial input signals.

Format 1

```
SIm([b, \cdot \cdot \cdot, b])
```

Format 2

```
SI(mb, \cdot \cdot \cdot, mb)
```



```
m : port number ...... 0 to 7, 10 to 17, 20 to 27 b : bit definition ...... 0 to 7
```

• If the bit definition is omitted, bits 0 to 7 are all selected.

```
Examples: A%=SI1()
    → Input status of ports SI(17) to SI(10)
    is assigned to variable A%.
    A%=SI5(7,4,0)
    → Input status of SI(57), SI(54) and
        SI(50) is assigned to variable A%.
    (If all above signals are 1(ON), then A%=7.)
    A%=SI(27,15,10)
    → Input status of SI(27), SI(15) and
        SI(10) is assigned to variable A%.
    (If all above signals except SI(10) are 1
        (ON), then A%=6.)
    WAIT SI(21)=1
    → Waits until SI(21) sets to 1 (ON).
```



- When specifying multiple bits, specify them from left to right in descending order (large to
- A '0' is entered if there is no actual serial board.

9

1

5

6

7

9.11 Serial output variable

This variable is used to define the serial output signals and indicate the output status.

Format 1

 $SOm([b, \cdots, b])$

Format 2

 $SO(mb, \cdot \cdot \cdot, mb)$



- m: port number 0 to 7, 10 to 17, 20 to 27
- b: bit definition 0 to 7
- If the bit definition is omitted, bits 0 to 7 are all selected.

```
Examples: A%=SO2()

→ Output status of SO(27) to SO(20) is assigned to variable A%.

A%=SO5(7,4,0)

→ Output status of SO(57), SO(54) and
```

- SO(50) is assigned to variable A%.

 (If all above signals are 1(ON), then A%=7.)

 A%=SO(37,25,20)
 - →Output status of SO(37), SO(25) and SO(20) is assigned to variable A%. (If all above signals except SO(25) are 1 (ON), then A%=5.)
- SO3()=B%

 →Changes to a status in which the DO(37)

 to DO(30) output can be indicated by B%.

 For example, if B% is "123": If a binary number is used, "123" will become

 "01111011", DO(37) and DO(32) will become

 "0", and the other bits will become "1".

 SO4(5,4,0)=&B101
- $\rightarrow\,\text{DO}\,(45)$ and DO(40) become "1", and DO(44) becomes "0".



- When specifying multiple bits, specify them from left to right in descending order (large to small).
- External output is unavailable if the serial port does not actually exist.

This variable indicates the status of the serial input word information.

Format

SIW(m)



NOTE

 The serial word input function is available from software version 8.08 onwards.



m: Port No. 2 to 15

The acquisition range is 0 (&H0000) to 65535 (&HFFFF).

Examples: A%=SIW(2)

ightarrow The input state from SIW (2) is assigned to variable A%.

A%=SIW(15)

 \rightarrow The input state from SIW (15) is assigned to variable A%.



- The information is handled as unsigned word data.
- '0' is input if the serial port does not actually exist.

9.13 Serial double word input

This variable indicates the state of the serial input word information as a double word.

Format

SID(m)



NOTE

 The serial double word input function is available from software version 8.08 onwards.



m: Port No. 2, 4, 6, 8, 10, 12, 14

The acquisition range is -1073741824 (&HC0000000) to 1073741823 (&H3FFFFFFF).

Examples: A%=SID(2)

→ The input state from SIW (2) , SIW (3) is assigned to variable A%.

A%=SID(14)

→The input state from SIW (14), SIW (15) is assigned to variable A%.



- The information is handled as signed double word data.
- '0' is input if the serial port does not actually exist.
- An error will occur if the value is not within the acquisition range (&H80000000 to &HBFFFFFFF, &H40000000 to &H7FFFFFFF.)
- The lower port number data is placed at the lower address.

For example, if SIW(2) = &H2345, SIW(3) = &H0001, then SID(2) = &H000123245.

9.14 Serial word output

Outputs to the serial output word information or indicates the output status.

Format

SOW (m)



NOTE

 The serial word output function is available from software version 8.08 onwards.



m: Port No. 2 to 15

The output range is 0 (&H0000) to 65535 (&HFFFF).

Note that if a negative value is output, the low-order word information will be output after being converted to hexadecimal.

Examples: A%=SOW(2)

 \rightarrow The output status from SOW (2) is assigned to variable A%.

SOW (15) = A%

→ The contents of variable A% are assigned in SOW (15).

If the variable A% value exceeds the output range, the low-order word information will be assigned. SOW(15) = -255

- \rightarrow The contents of -255 (&HFFFFFF01) are assigned to SOW (15).
- -255 is a negative value, so the low-order word information (&HFF01) will be assigned.



- The information is handled as unsigned word data.
- If a serial board does not actually exist, the information is not output externally.
- If a value exceeding the output range is assigned, the low-order 2-byte information is output.

9.15 Serial double word output

Output the status of serial output word information in a double word, or indicates the output status.

Format

SOD(m)



OTE

 The serial double word output function is available from software version 8.08 onwards.



m: Port No. 2, 4, 6, 8, 10, 12, 14

The output range is -1073741824 (&HC0000000) to 1073741823 (&H3FFFFFF).

Examples: A%=SOD(2)

 \rightarrow The input status from SOW (2) is assigned to variable A%. SOD (14) = A%

 \rightarrow The contents of variable A% are assigned in SOD (14).

- The information is handled as signed double word data.
- If a serial board does not actually exist, the information is not output externally.
- An error will occur if the value is not within the output range (&H80000000 to &HBFFFFFFF, &H40000000 to &H7FFFFFFF.)
- The lower port number data is placed at the lower address. For example, if SOW(2) =&H2345,SOW(3) =&H0001, then SOD(2) =&H000123245.

Bit Settings

10

Bits can be specified for input/output variables by any of the following methods.

1. Single bit

To specify only 1 of the bits, the target port number and bit number are specified in parentheses. The port number may also be specified outside the parentheses.

Programming example: DOm(b)DOm(b) Example: DO(25) Specifies bit 5 of port 2. DO2(5)

2. Same-port multiple bits

To specify multiple bits at the same port, those bit numbers are specified in parentheses (separated by commas) following the port number.

The port number may also be specified in parentheses.

```
Programming example: DOm(b,b,...,b) DO(mb,mb,...,mb)

Example: DO2(7,5,3) Specifies DO(27), DO(25), DO(23)

DO(27,25,23)
```

3. Different-port multiple bits

To specify multiple bits at different ports, the port number and the 2-digit bit number must be specified in parentheses and must be separated by commas.

```
Programming example: DO(mb,mb,...,mb)

Example: DO(37,25,20) Specifies DO(37), DO(25), DO(20).
```

4. All bits of 1 port

To specify all bits of a single port, use parentheses after the port number. Methods 2 and 3 shown above can also be used.

```
Programming example: DOm()

Example: DO2() Specifies all the DO(27) to DO(20) bits

→The same result can be obtained by the following:

DO(27,26,25,24,23,22,21,20)

or,

DO2(7,6,5,4,3,2,1,0)
```

Bit Settings 3-19

2

3

4

5

6

7

11 Valid range of variables

Variable branching occurs as shown below.

11.1 Valid range of dynamic variables

Dynamic variables are divided into global variables and local variables, according to their declaration position in the program. Global and local variables have different valid ranges.

Variable Type	Explanation
Global variables	Variables are declared outside of sub-procedures (outside of program areas enclosed by a SUB statement and END SUB statement). These variables are valid throughout the entire program.
Local variables	Variables are declared within sub-procedures and are valid only in these sub-procedures.

11.2 Valid range of static variables

Static variable data is not cleared when a program reset occurs. Moreover, variable data can be changed and referenced from any program.

The variable names are determined as shown below (they cannot be named as desired).

Variable type	Variable name
Integer variable	SGIn (n: 0 to 7)
Real variable	SGRn (n: 0 to 7)

11.3 Valid range of dynamic array variables

Dynamic array variables are classified into global array variables and local array variables according to their declaration position in the program.

Variable Type	Explanation
Global variables	Variables are declared outside of sub-procedures (outside of program areas enclosed by a SUB statement and END SUB statement). These variables are valid throughout the entire program.
Local variables	Variables are declared within sub-procedures and are valid only in these sub-procedures.



- For details regarding arrays, refer to Chapter 3 "5 Array variables".
- A variable declared at the program level can be referenced from a sub-procedure without being passed along as a dummy argument, by using the SHARED statement (for details, refer to Chapter 8 "91 SHARED").

Clearing variables 12

12.1 Clearing dynamic variables

In the cases below, numeric variables are cleared to zero, and character variables are cleared to a null string. The variable array is cleared in the same manner.

- When a program is edited.
- When program switching occurs (including SWI command execution).
- When program compiling occurs.
- When a program reset occurs.
- When dedicated input signal DI15 (program reset input) was turned on while the program was stopped in AUTO mode.
- When either of the following was initialized in SYSTEM mode.
 - 1. Program memory (SYSTEM>INIT>MEMORY>PROGRAM)
 - 2. Entire memory (SYSTEM>INIT>MEMORY>ALL)
- When any of the following online commands was executed. @RESET, @INIT PGM, @INIT MEM, @INIT ALL, @SWI
- When the HALT statement was executed in the program.

12.2 Clearing static variables

In the cases below, integer variables and real variables are cleared to zero.

- When the following was initialized in SYSTEM mode. Entire memory (SYSTEM>INIT>MEMORY>ALL)
- When any of the following online commands was executed. @INIT MEM, @INIT ALL



Static variable values are not cleared even if the program is edited.

Chapter 4 Expressions and Operations

1	Arithmetic operations	4-1
2	Character string operations	4-4
3	Point data format	4-5
4	DI/DO conditional expressions	4-6

Arithmetic operations

Arithmetic operators 1.1

Operators	Usage Example	Meaning
+	A+B	Adds A to B
-	A-B	Subtracts B from A
*	A*B	Multiplies A by B
/	A/B	Divides A by B
۸	A^B	Obtains the B exponent of A (exponent operation)
-	-A	Reverses the sign of A
MOD	A MOD B	Obtains the remainder A divided by B

When a "remainder" (MOD) operation involves real numbers, the decimal value is rounded off to the nearest whole number which is then converted to an integer before the calculation is executed. The result represents the remainder of an integer division operation.

Examples: A=15 MOD 2
$$\rightarrow$$
 A=1 (15/2=7...1)
A=17.34 MOD 5.98 \rightarrow A=2 (17/5=3...2)

1.2 Relational operators

Relational operators are used to compare 2 values. If the result is "true", a "-1" is obtained. If it is "false", a "0" is obtained.

Operators	Usage Example	Meaning
=	A=B	"-1" if A and B are equal, "0" if not.
<>, ><	A<>B	"-1" if A and B are unequal, "0" if not.
<	A <b< td=""><td>"-1" if A is smaller than B, "0" if not.</td></b<>	"-1" if A is smaller than B, "0" if not.
>	A>B	"-1" if A is larger than B, "0" if not.
<=, =<	A<=B	"-1" if A is equal to or smaller than B, "0" if not.
>=, =>	A>=B	"-1" if A is equal to or larger than B, "0" if not.

Examples:
$$A=10>5$$
 \rightarrow Since 10 > 5 is "true", $A=-1$.



• When using equivalence relational operators with real variables and real arrays, the desired result may not be obtained due to the round-off error.

Examples:A=2
$$B=SQR(A!)$$
 IF $A!=B!*B!$ THEN... \rightarrow In this case, $A!$ will be unequal to $B!*B!$.

1.3 Logic operations

Logic operators are used to manipulate 1 or 2 values bit by bit. For example, the status of an I/O port can be manipulated.

- Depending on the logic operation performed, the results generated are either 0 or 1.
- Logic operations with real numbers convert the values into integers before they are executed.

Operators	Functions	Meaning
NOT, ~	Logical NOT	Reverses the bits.
AND, &	Logical AND	Becomes "1" when both bits are "1".
OR,	Logical OR	Becomes "1" when either of the bits is "1".
XOR	Exclusive OR	Becomes "1" when both bits are different.

Examples: A%=NOT 13.05 \rightarrow "-14" is assigned to A% (reversed after being rounded off to 13).

Bit	7	6	5	4	3	2	1	0
13	0	0	0	0	1	1	0	1
NOT 13=-14	1	1	1	1	0	0	1	0

Examples: A%=3 AND 10 \rightarrow "2" is assigned to A%

Bit	7	6	5	4	3	2	1	0
3	0	0	0	0	0	0	1	1
10	0	0	0	0	1	0	1	0
3 AND 10 = 4	0	0	0	0	0	0	1	0

Examples: A%=3 OR 10 \rightarrow "11" is assigned to A%

Bit	7	6	5	4	3	2	1	0
3	0	0	0	0	0	0	1	1
10	0	0	0	0	1	0	1	0
3 OR 10 = 11	0	0	0	0	1	0	1	1

Examples: A%=3 XOR 10 \rightarrow "9" is assigned to A%

Bit	7	6	5	4	3	2	1	0
3	0	0	0	0	0	0	1	1
10	0	0	0	0	1	0	1	0
3 OR 10 = 11	0	0	0	0	1	0	0	1

1.4 Priority of arithmetic operation

Operations are performed in the following order of priority. When two operations of equal priority appear in the same statement, the operations are executed in order from left to right.

Priority Rank	Arithmetic Operation
1	Expressions included in parentheses
2	Functions, variables
3	^ (exponents)
4	Independent "+" and "-" signs (monominal operators)
5	* (multiplication), / (division)
6	MOD
7	+ (addition), - (subtraction)
8	Relational operators
9	NOT, ~ (Logical NOT)
10	AND, & (logical AND)
11	OR, , XOR (Logical OR, exclusive OR)

1.5 Data format conversion

Data format is converted in cases where two values of different formats are involved in the same operation.

1. When a real number is assigned to an integer, decimal places are rounded off.

Examples: A%=125.67
$$\rightarrow$$
 A%=126

2. When integers and real numbers are involved in the same operation, the result becomes a real number.

```
Examples: A(0) = 125 * 0.25 \rightarrow A(0) = 31.25
```

3. When an integer is divided by an integer, the result is an integer with the remainder discarded.

Examples:
$$A(0) = 100/3$$
 \rightarrow $A(0) = 33$

2 Character string operations

2.1 Character string connection

Character strings may be combined by using the "+" sign.

```
A$="YAMAHA"
B$="ROBOT"
C$="LANGUAGE"
D$="MOUNTER"
E$=A$+" "+B$+" "+C$
F$=A$+" "+D$
PRINT E$
PRINT F$

Results: YAMAHA ROBOT LANGUAGE
YAMAHA MOUNTER
```

2.2 Character string comparison

Characters can be compared with the same relational operators as used for numeric values. Character string comparison can be used to find out the contents of character strings, or to sort character strings into alphabetical order.

- In the case of character strings, the comparison is performed from the beginning of each string, character by character.
- If all characters match in both strings, they are considered to be equal.
- Even if only one character in the string differs from its corresponding character in the other string, then the string with the larger (higher) character code is treated as the larger string.
- When the character string lengths differ, the longer of the character strings is judged to be the greater value string.

All examples below are "true".

```
Examples: "AA"<"AB"

"X&">"X#"

"DESK"<"DESKS"
```

Point data format



NOTE

- For controllers with software versions of 8.28 and earlier, the point numbers which can be specified by point variables are 0 to 4000.
- The XYZRAB data format is used for both the joint coordinate format and the Cartesian coordinate format.
- Plus (+) signs can be omitted.
- Hand system flags are only available from software version 8.08 onwards.
- X-arm and Y-arm rotation information is only available in software Ver.10.66 onwards.
- X-arm and Y-arm rotation information is not available on any robot model except the YK500TW.

There are two types of point data formats: joint coordinate format and Cartesian coordinate format. Point numbers are in the range of 0 to 9999.

Coordinate Format	Data Format	Explanation
Joint coordinate format	± nnnnnnn	This is a decimal integer constant of 7 digits or less with a plus or minus sign, and can be specified from -6144000 to 6144000. Unit: [pulses]
Cartesian coordinate format	± nnn.nn to ± nnnnnnn	This is a decimal fraction of a total of 7 digits including 2 or less decimal places. Unit: [mm] or [degrees]

When setting an extended hand system flag for SCARA robots, set either 1 or 2 at the end of the data. If a value other than 1 or 2 is set, or if no value is designated, 0 will be set to indicate that no hand system flag is set.

Hand System	Data Value
RIGHTY (right-handed system)	1
 LEFTY (left-handed system)	2

On the YK500TW model robot, the X-arm and Y-arm movement range is extended beyond 360 degrees (The movable range for both the X-arm and Y-arm is -225° to +225°).

Therefore, attempts to convert Cartesian coordinate data ("mm" units) to joint coordinate data (pulse units) will result in multiple solutions, making the position impossible to determine.

In order to obtain the correct robot position and arm posture when converting to joint coordinates, X-arm and Y-arm rotation information is added after the "mm" units point data's extended hand system flag.

The Cartesian coordinate data ("mm" units) is then converted to joint coordinate data (pulse units) according to the specified X-arm and Y-arm rotation information.

To set extended X-arm and Y-arm rotation information at the YK500TW model robot, a "-1", "0", or "1" value must be specified after the hand system flag. Any other value, or no value, will be processed as "0".

Arm rotation information	Data Value
"mm" \rightarrow pulse converted angle data x (*1) range: -180° < x <= 180°	0
"mm" \rightarrow pulse converted angle data x (*1) range: 180° < x <= 540°	1
"mm" \rightarrow pulse converted angle data x (*1) range: -540° < x <= -180°	-1

^{*1:} The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.

DI/DO conditional expressions

DI/DO conditional expressions may be used to set conditions for WAIT statements and STOPON options in MOVE statements.

Numeric constants, variables and arithmetic operators that may be used with DI/DO conditional expressions are shown below.

• Constant

Decimal integer constant, binary integer constant, hexadecimal integer constant

Variables

Global integer type, global real number type, input/output type

• Operators

Relational operators, logic operators

- Operation priority
 - 1. Relational operators
 - 2. NOT, ~
 - 3. AND, &
 - 4. OR, |, XOR

Examples: WAIT DI(31) = 1 OR DI(34) = 1

 \rightarrow The program waits until either DI31 or DI34 turns ON.

Chapter 5 Multiple Robot Control

1	Overview 5-1
2	Command list for each aroup5-2

The YAMAHA robot RCX controller can be used to control multiple robots.

The multitask function also enables multiple robots to move asynchronously.

To use this function, settings for two robots or settings for auxiliary axes must be made in the system prior to shipment.

A robot axis is classified into one of the groups below.


- Main group (6 axes)
- Main group (6 axes) + sub-group (2 axes) (when using the YC-LINK option)
- Main group (4 axes) + sub-group (4 axes) (when using the YC-LINK option)
- Main group (2 axes) + sub-group (2 axes)
- Main group (3 axes) + sub-group (3 axes)
 (This setting is possible only when using the YC-LINK option and a compatible software version:
 Ver.8.69 or newer for RCX14x, and Ver.9.16 or newer for RCX22x.)

A main group is composed of one main robot and main auxiliary axes, and a sub group is composed of one sub robot and sub auxiliary axes.


When using one robot without auxiliary axis, settings are made only for the main group robot. When no settings have been made for main auxiliary axes and sub auxiliary axes, the main group is composed only of the one main robot, and the sub group is composed only of the one sub robot.

Axes configuration


1. For main group only




2. For main group & sub-group



3. For 1 robot with no additional axes used



4. When no main additional axes & sub additional axes are set



33501-R7-00

__

5

4

5

6

7

Command list for each group

The special commands and functions for robot movement and coordinate control are shown below.

Operator	Main group		Sub group	
Robot movement	DRIVE MOVE PMOVE WAIT ARM	DRIVEI MOVEI SERVO	DRIVE2 MOVE2 PMOVE2 WAIT ARM2	DRIVEI2 MOVEI2 SERVO2
Coordinate control	CHANGE LEFTY SHIFT	HAND RIGHTY	CHANGE2 LEFTY2 SHIFT2	HAND2 RIGHTY2
Status change	ACCEL ASPEED DECEL OUTPOS TOLE	ARCH AXWEIGHT ORGORD SPEED WEIGHT	ACCEL2 ASPEED2 DECEL2 OUTPOS2 TOLE2	ARCH2 AXWEIGHT2 ORGORD2 SPEED2 WEIGHT2
Point operation	JTOXY XYTOJ	WHERE	JTOXY2 WXTOJ2	WHERE2
Parameter reference	ACCEL AXWEIGHT ORGORD TOLE	ARCH DECEL OUTPOS WEIGHT	ACCEL2 AXWEIGHT2 ORGORD2 TOLE2	ARCH2 DECEL2 OUTPOS2 WEIGHT2
Status reference	ABSRPOS ARMTYPE	ARMCND MCHREF	ABSRPOS2 ARMTYPE2	ARMCND2 MCHREF2
PATH control	PATH PATH SET	PATH END PATH START		
Torque control	DRIVE (with torque limit setting option)		DRIVE2 (with torque limit setting option)	
	TORQUE TRQTIME	TRQSTS CURTRQ	TORQUE2 TRQTIME2	TRQSTS2 CURTRQ2

- MOVE, MOVEI commands are used at main robot operations, and MOVE2, MOVEI2 commands are used at sub-robot operations.
- An axis specified as an auxiliary axis cannot be moved with the MOVE (MOVE2), MOVEI (MOVEI2) and PMOVE (PMOVE2) commands. Use the DRIVE (DRIVE2) or DRIVEI (DRIVEI2) command to move it.
- When specifying all axes with the SERVO or SERVO2 command, the servos of all axes in the main group and sub group can be switched ON or OFF.



- The restrictions shown below apply to the following software versions: RCX14x...version prior to Ver.8.64; RCX22x...versions prior to Ver.9.11.
- The MOVE statement's linear and circular interpolations are only possible at Task 1 (main task) and by direct command.
- The MOVE2 statement can be used only for PTP control. It cannot be used for linear and circular interpolations.

Chapter 6 Multi-tasking

1	Outline 6-1
2	Task definition6-1
3	Task status and transition6-2
4	Multi-task program example6-8
5	Sharing the robot language and data 6-8
6	Cautionary Items6-9

Л

5

6

7

The multi-task function performs multiple processing simultaneously in a parallel manner, and can be used to create programs of higher complexity. Before using the multi-tasking function, read this section thoroughly and make sure that you fully understand its contents.

Multi-tasking allows executing two or more tasks in parallel. However, this does not mean that multiple tasks are executed simultaneously because the controller has only one CPU to execute the tasks. In multi-tasking, the CPU time is shared among multiple tasks by assigning a priority to each task so that they can be executed efficiently.

- A maximum of 8 tasks (task 1 to task 8) can be executed in one program.
- Tasks can be prioritized and executed in their priority order (higher priority tasks are executed first).
- The priority level of task 1 is fixed at 32, while the priority of task 2 to task 8 can be set to any level between 17 and 47.
- Smaller values have higher priority, and larger values have lower priority (High priority: 17 ⇔ 47: low priority).



• In RCX14x software version prior to Ver.8.64, and in RCX22x software versions prior to Ver.9.11, the MOVE statement's linear and circular interpolations are possible only at Task 1 (main task).

Task definition

A task is a set of instructions within a program which are executed as a single sequence. As explained below, a task is defined by assigning a label to it.

- 1. Assign a label to the first line of the command block which is to be defined as a task.
- 2. At the Task 1 (main task) START statement, specify the label which was assigned at step 1 above. Task Nos. are then assigned, and the program starts.

The task definition may call for 2 to 8 subtasks. Task 1 (main task) is automatically defined.



Although all tasks are written within a single program, parallel processing occurs at each of the tasks.



2

 Several tasks with motion command can cause unintentional motion.
 When creating a program, consider conditions where motion commands written in each task are executed.

```
SAMPLE
' MAIN TASK(TASK1)
START *IOTASK,T2 ·········· *IOTASK is started as Task 2
*ST1:
MOVE P,P1,P0
   IF DI(20) = 1 THEN
      HALT
   ENDIF
GOTO *ST
HALT
 SUB TASK (TASK2)
*IOTASK: ···········
                  ······ Task 2 begins from here
   IF DI(21)=1 THEN
      DO(30)=1
   ELSE
      DO(30)=0
   ENDIF
GOTO *IOTASK ...... Task 2 processing ends here
EXIT TASK
```

Task status and transition

There are 6 types of task status.

1. STOP status

A task is present but the task processing is stopped.

2. RUN status

A task is present and the task processing is being executed by the CPU.

3. READY status

A task is present and ready to be allocated to the CPU for task processing.

4. WAIT status

A task is present and waiting for an event to begin the task processing.


5. SUSPEND status

A task is present but suspended while waiting to begin the task processing.

6. NON EXISTENT status

No tasks exist in the program. (The START command is used to perform a call).

Task state transition



33601-R7-00

3.1 Starting tasks

When the program is being executed in the AUTO mode, Task 1 (main task) is automatically selected and placed in a RUN status when the program begins. Therefore, the delete, forced wait, forced end commands, etc., cannot be executed for Task 1.

Other tasks (2 to 8 subtasks) will not be called simply by executing the program. The START command must be used at Task 1 in order to call, start, and place these tasks in a READY status.




• The RESTART, SUSPEND, EXIT TASK, and CUT commands cannot be executed at Task 1.

Task scheduling determines the priority to be used in allocating tasks in the READY(execution enabled) status to the CPU and executing them.

When there are two or more tasks which are put in the READY status, ready queues for CPU allocation are used to determine the priority for executing the tasks. One of these READY status tasks is then selected and executed (RUN status).


Only tasks with the same priority ranking are assigned to a given ready queue. Therefore, where several tasks with differing priority rankings exist, a corresponding number of ready queues are created. Tasks within a given ready queue are handled on a first come first serve (FCFS) basis. The task where a READY status is first established has priority. The smaller the number, the higher the task priority level.



33602-R7-00

A RUN status task will be moved to the end of the ready queue if placed in a READY status by any of the following causes:

- A WAIT status command was executed.
- The CPU occupation time exceeds a specified time.
- A task with a higher priority level is put in READY status. 3)





 When the prescribed CPU occupation time elapses, the active command is ended, and processing moves to the next task. However, if there are no other tasks of the same or higher priority (same or higher ready queue), the same task will be executed again.

Task status and transition • 6-3

3.3 Condition wait in task

A task is put in the WAIT status (waiting for an event) when a command causing a wait status is executed for that task. At this time, the transition to READY status does not take place until the wait condition is canceled.

1. When a command causing a wait status is executed, the following transition happens.

- Task for which a command causing a wait status is executed → WAIT status
- Task at the head of the ready queue with higher priority → RUN status



• For example, when a MOVE statement (a command that establishes a WAIT status) is executed, the CPU sends a "MOVE" instruction to the driver, and then waits for a "MOVE COMPLETED" reply from the driver. This is a "waiting for an event" status. In this case, a WAIT status is established at the task which executed the MOVE command, and that task is moved to the end of the ready queue. A RUN status is then established at the next task.

NOTE

• If multiple tasks are in WAIT status awaiting the same condition event, or different condition events occur simultaneously, all tasks for which the waited events occur are put in READY status.



2. When an event waited by the task in the WAIT status occurs, the following status transition takes place by task scheduling.

- Task in the WAIT status for which the awaited event occurred → READY status However, if the task put in the READY status was at the head of the ready queue with the highest priority, the following transition takes place.
- 1) Task that is currently in RUN status → READY status
- 2) Task at the head of the ready queue with higher priority → RUN status
- In the above MOVE statement example, the task is moved to the end of the ready queue. Then, when a "MOVE COMPLETED" reply is received, this task is placed in READY status.

Tasks are put in WAIT status by the following commands.

Event		Command			
Wait for axis movement to complete	Axis movement command	MOVE DRIVE PMOVE WAIT ARM	MOVEI DRIVEI PMOVE2 WAIT ARM2	MOVE2 DRIVE2 SERVO	MOVEI2 DRIVEI2 SERVO2
	Parameter command	ACCEL AXWEIGHT OUTPOS ORGORD	ACCEL2 AXWEIGHT2 OUTPOS2 ORGORD2	ARCH DECEL TOLE WEIGHT	ARCH2 DECEL2 TOLE2 WEIGHT2
	Robot status change command	CHANGE LEFTY ASPEED	CHANGE2 LEFTY2 ASPEED2	SHIFT RIGHTY SPEED	SHIFT2 RIGHTY2 SPEED2
Wait for time to elapse		DELAY, SET (Time should be specified.), WAIT (Time should be specified.)			
Wait for condition to be met		WAIT			
Wait for data to send or to be received		SEND			
Wait for print buffer to become empty		PRINT			
Wait for key input		INPUT			



• The tasks are not put in WAIT status if the event has been established before the above commands are executed.


The SUSPEND command temporarily stops tasks other than task 1 and places them in SUSPEND status. The SUSPEND command cannot be used for task 1.

When the SUSPEND command is executed, the status transition takes place as follows.

■ Task that executed the SUSPEND command → RUN status

■ Specified task → SUSPEND status

Suspending tasks (SUSPEND)



33604-R7-00

3.5 Restarting tasks (RESTART)


Tasks in the SUSPEND status can be restarted with the RESTART command. However, the RESTART command cannot be used for task 1.

When the RESTART command is executed, the status transition takes place as follows.

■ Task for which the RESTART command was executed → RUN status

■ Specified task → READY status

Restarting tasks (RESTART)



33605-R7-00

Task status and transition • 6-5

2

3

4

5

6

7

3.6 Deleting tasks


■ Task self-delete (EXIT TASK)

Tasks can delete themselves by using the EXIT TASK command and set to the NON EXISTENT (no task registration) status. The EXIT TASK command cannot be used for task 1.

When the EXIT TASK command is executed, the status transition takes place as follows.

- Task that executed the EXIT TASK command
- → NON EXISTENT status
- Task at the head of the ready queue with higher priority
- → RUN status

Task self-delete (EXIT TASK)



33606-R7-00

Other-task delete (CUT)

A task can also be deleted and put in the NON EXISTENT (no task registration) status by the other tasks using the CUT command. The CUT command cannot be used for task 1.


When the CUT command is executed, the status transition takes place as follows.

- Task that executed the CUT command
- → RUN

Specified task

→ NON EXISTENT

Other-task delete (CUT)





- If a SUSPEND command is executed for a WAIT-status task, the commands being executed by that task are ended.
- None of these commands can be executed for Task 1.

All tasks stop if any of the following cases occurs.

HALT command is executed. (stop & reset)

The program is reset and all tasks other than task 1 are put in the NON EXISTENT status. Task 1 is put in the STOP status.

2. HOLD command is executed. (temporary stop)

All tasks are put in the STOP status. When the program is restarted, the tasks in the STOP status set to the READY or SUSPEND status.

STOP key on the programming box is pressed or the interlock signal is cut off. Just as in the case where the HOLD command is executed, all tasks are put in the STOP status. When the program is restarted, the tasks in the STOP status set to the READY status (or, the task is placed in a SUSPEND status after being placed in a READY status).

4. When the emergency stop switch on the programming box is pressed or the emergency stop signal is cut off.

All tasks are put in STOP status. At this point, the power to the robot is shut off and the servo sets to the non-hold state.

After the canceling emergency stop, when the program is restarted, the tasks in STOP status are set to the READY or SUSPEND status. However, a servo ON is required in order to restart the robot power supply.



• When the program is restarted without being reset after the tasks have been stopped by a cause other than 1., then each task is processed from the status in which the task stopped. This holds true when the power to the controller is turned off and then turned on.

Multi-task program example

Tasks are executed in their scheduled order. An example of a multi-task program is shown below.

```
SAMPLE
'TASK1
START *ST2,T2
START *ST3,T3
*ST1:
  DO(20) = 1
  WAIT MO(20) = 1
  MOVE P,P1,P2,Z=0
   IF MO(21)=1 THEN *FIN
GOTO *ST1
*FIN:
CUT T2
HALT
'TASK2
*ST2:
        ····· Task 2 begins here.
   IF DI(20) = 1
     MO(20) = 1
     DELAY 100
  ELSE
     MO(20) = 0
  ENDIF
GOTO *ST2
EXIT TASK ..... Ends here.
 TASK3
        ...... Task 3 begins here.
*ST3:
   IF DI(21) = 0 THEN *ST3
  IF DI(30) = 0 THEN *ST3
  IF DI(33) = 0 THEN *ST3
  MO(21) = 1
EXIT TASK ..... Ends here.
```

Sharing the robot language and data



CAUTION

 Several tasks with motion command can cause unintentional motion.
 When creating a program, consider conditions where motion commands written in each task are executed. Point data, shift coordinate definition data, hand definition data, pallet definition data, all robot languages, input/output signals, all global variables and other variables are shared among all tasks. Execution of each task can be controlled while using the same variables and data shared with the other tasks.



• In this case, however, use sufficient caution when rewriting the variable and data because improper changes may cause trouble in the task processing.

2

3

4

5

6

7

A silence stop may occur if subtasks are continuously started (START command) and ended (EXIT TASK command) by a main task in an alternating manner.

This occurs for the following reason: if the main task and subtask priority levels are the same, a task transition to the main task occurs during subtask END processing, and an illegal task status then occurs when the main task attempts to start a subtask.

Therefore, in order to properly execute the program, the subtask priority level must be set higher than that of the main task. This prevents a task transition condition from occurring during execution of the EXIT TASK command.

In the sample program shown below, the priority level of task 1 (main task) is set as 32, and the priority level of task 2 is set as 31 (the lower the value, the higher the priority).

```
SAMPLE
FLAG1 = 0
*MAIN TASK:
   IF FLAG1=0 THEN
      FLAG1 = 1
      START *TASK2, T2, 31 ······ Task 2 (*TASK2) is started at the
                              priority level of 31.
   ENDIF
GOTO *MAIN TASK
'========
      TASK2
'=======
*TASK2:
   DRIVE (1, P1)
   WAIT ARM(1)
   DRIVE(1,P2)
   WAIT ARM(1)
   FLAG1 = 0
EXIT TASK
HALT
```

Chapter 7 Sequence function

1	Sequence function7-1
2	Creating a sequence program7-1
3	Executing a sequence program7-4
4	Creating a sequence program7-5

 The "DO12: Sequence program running" dedicated signal output occurs while a sequence program is being executed. Besides normal robot programs, this RCX controller can execute high-speed processing programs (sequence programs) in response to the robot input/output (DI, DO, MO, LO TO, SI, SO) signals. This means that when a sequence program is running, it is running simultaneously with the robot program (2 programs are running).

When the dedicated "DI10: sequence control input" is ON, the sequence program runs according to its own cycle in the AUTO or MANUAL mode, regardless of robot program starts and stops.

The sequence program starts running as soon as the controller is turned on (normally, the MANUAL mode), so it can be used to monitor the status of sensors, push button switches, solenoid valves, etc. The sequence program can be written in the same robot language used for robot programs. This eliminates the need to learn a new language and making it easier to program.

General-purpose outputs are not reset while the sequence function is running, even if a program reset is executed. However, a setting can be specified which allows these outputs to be reset at the sequence program compiling operation. For details regarding settings required to execute a sequence program, see section "3 Executing Sequence Programs".


2 Creating a sequence program

2.1 Programming method

The following explains how to create a sequence program in order to make use of the sequence function.

First, enter "PROGRAM" mode and create a file with the file name "SEQUENCE". The controller automatically recognizes that a file with this name is a sequence program.

Naming a sequence program file



2

3

4


5

6

7

Next, input a program. This is no different from the standard robot program creation method. Commands which can be input are explained later in this manual.

Creating a sequence program




34702-R7-00

2.2 Compiling

After editing the program, it must be compiled as a sequence program. Compiling is performed in the same way as for robot programs. Press the F5 key on the highest-level screen in "PROGRAM" mode.

Sequence program




34703-R7-00

A check message appears asking if you want to compile the sequence program. Press the F4 key to compile the program. To cancel this compiling, press the F5 key. The display changes to the compiling screen for normal robot programs.

Press the F4 key to compile the sequence program.


Compile the sequence program before compiling the main program.

Compiling the sequence program



If there is a syntax error in the program, an error message appears and the program will be listed from the line with the error When the compiling ends without any error, the program will be listed from its first line.

Compiling error




34705-R7-00



- The sequence execution program is erased and the letter "s" disappears in the following cases. In these cases the sequence function cannot be used in "UTILITY" mode.
 - 1. When the sequence program was erased
 - 2. When the sequence program was edited
 - 3. When normal robot program compiling was performed for the sequence program (The same processing occurs even if the mode is changed to AUTO while in the SEQUENCE program is selected.)
 - 4. Program data was initialized.
 - 5. A "9.39: Sequence object destroyed.

When you display the directory after the compiling the sequence program, a letter "s" appears to the left of the program name "SEQUENCE". This means that the sequence program has been compiled successfully and is ready for use.

Sequence execution program after compiling




3 Executing a sequence program

The following conditions must be satisfied to execute a sequence program. If any of these conditions is not met, the sequence program cannot be executed.

- 1. The sequence execution program has been created by compiling.
- 2. The sequence function is enabled in "UTILITY" mode. (For details regarding the UTILITY mode, refer to the controller manual.)
- 3. The external sequence control input (DI10) contact is closed.
- 4. The current operation mode is "MANUAL" or "AUTO".

When all of the above conditions are met, the sequence program can now be executed. While the program is running, the letter "s" will appear at the left end of the second line of the screen.

Sequence program execution in progress



34707-R7-00


For details regarding the UTILITY mode setting procedure, refer to the controller manual.

3.1 Sequence program STEP execution

The sequence program may be executed line by line while checking one command line at a time. To do this, press the F5 key on the compile screen. Sequence program compiling is canceled and the normal robot compile screen then appears.

Press the F4 key to compile and create a normal execution program. Then, execute this program with the STEP statement in "AUTO" mode to check the operation.

Sequence program STEP execution



Creating a sequence program

When creating a sequence program, you may use only assignment statements comprised of input/output variables and logical operators. An error will occur during compiling if any statement other than assignment statements is used in the program, and the compiling cannot be completed.

4.1 Assignment statements

coutput variable> <internal auxiliary output variable> <arm lock output variable> <timer output variable>



<expression> Any one of the following can be used.

- Parallel input/output variables
- Internal auxiliary output variables
- Arm lock output variables
- Timer output variables
- Serial input/output variable
- The logic operation expression shown above

4.2 Input/output variables

Each variable must be specified in a 1-bit format

```
·Correct examples DO(35)
MO(24)
DI(16)
·Incorrect examples DO(37, 24)
DI3(4)
MO3()
```

Parallel input variables

Format	
DI(mb)	m: Port number ······ 0 to 7, 10 to 17, 20 to 27 b: bit definition ···· 0 to 7

These variables show the status of the parallel input signal.

Parallel output variables

```
DO(mb) m: Port number ...... 0 to 7, 10 to 17, 20 to 27 b: bit definition .... 0 to 7
```

A parallel output is specified, or the output status is referenced. Ports 0 and 1 are for referencing only, and no outputs can occur there.

4

5

6

7

Internal output variables

```
MO(mb) m: Port number ...... 0 to 7, 10 to 17, 20 to 27 b: bit definition ..... 0 to 7
```

These variables are used within the controller and are not output externally. Ports 0 and 1 are for referencing only, and no outputs can occur there.

Arm lock output variables

```
LO(mb) m: port number ..... 0
b: bit definition .... 0 to 7
```

These variables are used to prohibit the arm movement. Movement is prohibited when ON. LO(00) to LO(07) corresponds to arm 1 to arm 8.

Timer output variables

```
TO(mb) m: port number ..... 0
b: bit definition .... 0 to 7
```

There are a total of 8 timer output variables: TO(00) to TO(07). The timer of each variable is defined by the timer definition statement TIM00 to 07.

Serial input variables

```
Format

SI(mb) m: Port number ...... 0 to 7, 10 to 17, 20 to 27
b: bit definition .... 0 to 7
```

Indicates a serial input signal status. Only referencing can occur. No settings are possible.

Serial output variables

```
SO(mb) m: Port number ...... 0 to 7, 10 to 17, 20 to 27 b: bit definition .... 0 to 7
```

Sets or references a serial output signal status. Ports 0 and 1 are for referencing only, and no outputs can occur there.


Timer example

SAMPLE

 $TIM02 = 2500 \cdots$ Timer 02 is set to 2.5 seconds. $TO(02) = DI(23) \cdots$ Timer starts when DI(23) switches ON.

- When DI(23) is ON, after 2.5 seconds, TO(02) is set ON.
- When DI(23) is OFF, TO(02) is also OFF.
- When DI(23) isn't ON after 2.5 second or more, TO(02) does not change to ON.

Timer usage example: Timing chart



33701-R7-00

4.3 Timer definition statement

Format

TIMmb=<time> m: Port number 0

b: bit definition ··· 0 to 7

Values

<time> 100 to 999,900msec (0.1 to 999.9 second)

Meaning

The timer definition statement sets the timer value of the timer output variable. This definition statement may be anywhere in the program.

When the timer definition statement is omitted, the timer setting value of the variable is 0. TIM00 to 07 correspond to the timer output variables TO(00) to (07).

However, since the units are set every 100msec, values less than 99msec are truncated.

4.4 Logical operators

Operators	Functions	Meaning
NOT, ~	Logical NOT	Reverses the bits.
AND, &	Logical AND	Becomes "1" when both bits are "1".
OR,	Logical OR	Becomes "1" when either of the bits is "1".

4.5 Priority of logic operations

Priority Ranking	Operation Content
1	Expressions in parentheses
2	NOT, ~ (Logical NOT)
3	AND, & (Logical AND)
4	OR, (Logical OR)


Example with a ladder statement substitution

```
DO(23) = DI(16) & DO(35)

MO(34) = DO(25) | ~DI(24)

DO(31) = (DI(20) | DO(31)) & ~DI(21)
```

Ladder diagram



33702-R7-00



- NOT cannot be used prior to the first parenthesis " (" or on the left of an expression. For example, the following commands cannot be used.
 - •DO(21)=~(DI(30) | DI(32))
 - •~DO(30)=DI(22)&DI(27)
- Numeric values cannot be assigned on the right of an expression.
 - •MO(35)=1
 - •DO(26)=0
- There is no need to define a "HALT" or "HOLD" statement at the end of the program.
- The I/O and internal auxiliary output variables used in sequence programs are shared with robot programs, so be careful not to make improper changes when using the same variables between them.

4.6 Sequence program specifications

Item	Specification	
Commands	Logical NOT, AND, OR	
I/O	Same as robot language	
Program capacity	4096 bytes (A maximum of 512 variables can be specified.)	
Scan time	10 to 30ms depending on the number of steps (This changes automatically.)	

Chapter 8 Robot Language Lists

HOW TO	read the robot language tak	oie 8-1
Command list in alphabetic order8-3		
Functio	on Specific	8-8
Functio	ons: in alphabetic order	8-15
Functio	ons: operation-specific	8-18
1	ABS	8-20
2	ABSINIT / ABSINIT2	8-21
3	ABSRPOS / ABSRPOS2	8-23
4	ABSRST	8-24
5	ACCEL / ACCEL2	8-25
6	ARCH / ARCH2	8-26
7	ARMCND / ARMCND2	8-28
8	ARMTYPE / ARMTYPE2	8-29
9	ATN / ATN2	8-30
10	ASPEED / ASPEED2	8-31
11	AXWGHT / AXWGHT2	8-32
12	CALL	8-33
13	CHANGE / CHANGE2	8-34
14	CHGPRI	8-35

15	CHR\$8-36
16	COS8-37
17	CURTRQ / CURTRQ2 8-37
18	CUT 8-38
19	DATE\$ 8-39
20	DECEL / DECEL2 8-40
21	DECLARE 8-41
22	DEF FN 8-43
23	DEGRAD 8-44
24	DELAY 8-45
25	DI 8-46
26	DIST 8-47
27	DIM 8-48
28	DO 8-49
29	DRIVE / DRIVE2 8-50
30	DRIVEI / DRIVEI2 8-58
31	END SELECT 8-63
32	END SUB 8-64
33	ERR / ERL8-65
34	EXIT FOR 8-66
35	EXIT SUB 8-67
36	EXIT TASK 8-68
37	FOR to NEXT8-69
38	GOSUB to RETURN 8-70
39	GOTO 8-71
40	HALT 8-72
41	HAND / HAND2 8-73
42	HOLD8-78
43	IF 8-79
44	INPUT8-81
45	INT8-82
46	JTOXY / JTOXY28-83
47	LABEL Statement8-84
48	LEFT\$ 8-85
49	LEFTY / LEFTY2 8-86
50	LEN 8-87

51	LET 8-88
52	LO8-91
53	LOCx8-92
54	LSHIFT 8-94
55	MCHREF / MCHREF2 8-95
56	MID\$ 8-96
57	MO 8-97
58	MOVE / MOVE2 8-98
59	MOVEI / MOVEI28-114
60	OFFLINE 8-119
61	ORD 8-120
62	ON ERROR GOTO 8-121
63	ON to GOSUB 8-122
64	ON to GOTO 8-123
65	ONLINE 8-124
66	ORGORD / ORGORD2 8-125
67	ORIGIN 8-126
68	OUT 8-127
69	OUTPOS / OUTPOS2 8-128
70	PATH 8-130
71	PATH END 8-136
72	PATH SET 8-137
73	PATH START 8-139
74	PDEF 8-140
75	PMOVE / PMOVE2 8-141
76	Pn 8-145
77	PPNT 8-147
78	PRINT 8-148
79	RADDEG 8-149
80	REM 8-150
81	RESET 8-151
82	RESTART 8-152
83	RESUME 8-153
84	RETURN 8-154
85	RIGHT\$ 8-155
86	RIGHTY / RIGHTY2 8-156

87	RSHIFT 8-157
88	\$n 8-158
89	SELECT CASE 8-159
90	SEND 8-160
91	SERVO / SERVO2 8-162
92	SET 8-163
93	SHARED 8-164
94	SHIFT / SHIFT2 8-165
95	SIN 8-166
96	\$O 8-167
97	SPEED / SPEED2 8-168
98	START 8-169
99	STR\$ 8-170
100	SQR 8-171
101	SUB to END SUB 8-172
102	SUSPEND 8-174
103	SWI 8-175
104	TAN 8-176
105	TCOUNTER 8-177
106	TIME\$8-178
107	TIMER 8-179
108	TO 8-180
109	TOLE / TOLE28-181
110	TORQUE / TORQUE2 8-182
111	TRQSTS / TRQSTS28-184
112	TRQTIME / TRQTIME2 8-185
113	VAL 8-187
114	WAIT 8-188
115	WAIT ARM / WAIT ARM2 8-189
116	WEIGHT/WEIGHT2 8-190
117	WEND 8-191
118	WHERE / WHERE2 8-192
119	WHILE to WEND 8-193
120	WHRXY / WHRXY2 8-194
121	XYTOJ / XYTOJ2 8-195
122	_ SYSFLG 8-195


The key to reading the following robot language table is explained below.

How to read the robot language table

(4) (5) (1)(2)(3)Declares the array variable name and the DIM 27 6 Command number of elements.

(1) No.

Indicates the Item No. where this robot language is explained in detail.



(2) Function

Explains the function of the robot language.

(3) Condition

Lists the conditions under which command execution is enabled.

- Condition 1: Commands that can be executed by both direct commands and online commands.
- Condition 2: In addition to Condition 1, commands that execute task 1 (main task) only.
- Condition 3: In addition to condition 1, commands containing operands that cannot be executed by direct commands or online commands.
- Condition 4: In addition to condition 1, commands which are executed after positioning is completed.
- Condition 5: MOVE L and MOVE C can be executed by both direct commands and online commands, although they are executed after positioning is completed.

The STOPON option cannot be executed by direct commands and online commands.

Condition 6: Commands that cannot be executed by direct commands and online commands.

Regarding robot languages which can be used as both commands and functions, the "execution enabled" conditions for a "command execution" may differ from those for a "function execution". In such cases, the respective conditions for the command and function are divided by a slash mark (/). For example, if condition 4 is applies for a "Command", but there are no conditions for the "Function", this would be expressed as follows: 4/-

9

10

15

(4) Direct

If "O" is indicated at this item, both direct commands and online commands can be used.



• Direct commands are input directly from the programming box while in the AUTO mode, and are used to perform temporary operations. For details, refer to the controller manual.

(5) Type

Indicates the robot language type as "Command" or "Function".

When a command is used as both a "Command" and "Function", this is expressed as follows: Command/Function

Command list in alphabetic order

No.	Command	Function	Condition	Direct	Туре
Α					
1	ABS	Acquires the absolute value of a specified value.	-	-	Functions
2	ABSINIT	Resets the current position of a specified main group axis.	4	0	Command Statements
2	ABSINIT2	Resets the current position of a specified sub group axis.	4	0	Command Statements
3	ABSRPOS	Acquires the machine reference of the specified main group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)	-	-	Functions
3	ABSRPOS2	Acquires the machine reference of the specified sub group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)	-	-	Functions
4	ABSRST	Executes a return-to-origin at the robot absolute motor axes.	4	0	Command Statements
5	ACCEL	Specifies/acquires the acceleration coefficient parameter of the main group.	4/-	0	Command Statements/ Functions
5	ACCEL2	Specifies/acquires the acceleration coefficient parameter of the sub group.	4/-	0	Command Statements/ Functions
6	ARCH	Specifies/acquires the arch position parameter of the main group.	4/-	0	Command Statements/ Functions
6	ARCH2	Specifies/acquires the arch position parameter of the sub group.	4/-	0	Command Statements/ Functions
7	ARMCND	Acquires the current arm status of the main robot.	-	-	Functions
7	ARMCND2	Acquires the current arm status of the sub robot.	-	-	Functions
8	ARMTYPE	Acquires the current "hand system" setting of the main robot.	-	-	Functions
8	ARMTYPE2	Acquires the current "hand system" setting of the sub robot.	-	-	Functions
10	ASPEED	Changes the AUTO movement speed of the main group.	4	0	Command Statements
10	ASPEED2	Changes the AUTO movement speed of the sub group.	4	0	Command Statements
9	ATN	Acquires the arctangent of the specified value.	-	-	Functions
9	ATN2	Acquires the arctangent of the specified X-Y coordinates.	-	-	Functions
11	AXWGHT	Specifies/acquires the axis tip weight parameter of the main group.	4/-	0	Command Statements/ Functions
11	AXWGHT2	Specifies/acquires the axis tip weight parameter of the sub group.	4/-	0	Command Statements/ Functions
С					
12	CALL	Executes (calls) another program.	6	X	Command Statements
13	CHANGE	Switches the main robot hand.	4	0	Command Statements
13	CHANGE2	Switches the sub robot hand.	4	0	Command Statements
14	CHGPRI	Changes the priority ranking of a specified task.	6	X	Command Statements
15	CHR\$	Acquires a character with the specified character code.	-	-	Functions
16	COS	Acquires the cosine value of a specified value.	-	-	Functions
17	CURTRQ	Acquires the current torque value of the specified main group axis.	-	×	Functions
17	CURTRQ2	Acquires the current torque value of the specified sub group axis.	-	×	Functions
18	CUT	Terminates a task currently being executed or temporarily stopped.	6	×	Command Statements
D					
19	DATE\$	Acquires the date as a "yy/mm/dd" format character string.	_	_	Functions
	_,ψ	1	<u> </u>	L	L

of the main group. 20 DECEL2 Specifies/acquires the deceleration rate parameter of the sub group. 23 DEGRAD Converts a specified value to radians (↔RADDEG). 24 DELAY Waits for the specified period (units: ms). 27 DIM Declares the array variable name and the number of elements. 28 DO Communication of the distance between 2 specified points. 29 DRIVE Moves a specified main group axis to an absolute position. 29 DRIVE (With T-option) Executes an absolute movement command for a specified sub group axis to an absolute position. 30 DRIVEI Moves a specified main group axis to a relative position. 4 Communication of the sub group axis to a relative position. 4 Communication of the sub group axis to a relative position. 5 DECEL2 Specified Sub group axis to a relative position. 5 DECEL2 Specified Sub group axis to a relative position. 6 Communication of the sub group axis to a relative position. 7 DECEL2 Specified Sub group axis to a relative position. 8 DECEL2 Specified Sub group axis to a relative position. 9 DECEL2 Specified Sub group axis to a relative position. 9 DECEL2 Specified Sub group axis to a relative position. 9 DECEL2 Specified Sub group axis to a relative position. 9 DECEL2 Specified Sub group axis to a relative position. 9 DECEL2 Specified Sub group axis to a relative position.	and Statements/ unctions and Statements/ unctions unctions unctions and Statements
of the sub group. 23 DEGRAD Converts a specified value to radians (↔RADDEG). 24 DELAY Waits for the specified period (units: ms). 27 DIM Declares the array variable name and the number of elements. 28 DO Outputs a specified value to the DO port. 29 DRIVE Moves a specified main group axis to an absolute position. 29 DRIVE (With T-option) Executes an absolute movement command for a specified sub group axis to an absolute position. 4 Comm. 29 DRIVE Moves a specified sub group axis to an absolute position. 4 Comm. 29 DRIVE2 Moves a specified sub group axis to an absolute position. 4 Comm. Comm.	unctions unctions nand Statements
DELAY Waits for the specified period (units: ms). Declares the array variable name and the number of elements. Acquires the distance between 2 specified points. Acquires the distance between 2 specified points. DO Outputs a specified value to the DO port. Moves a specified main group axis to an absolute position. With T-option) Executes an absolute movement command for a specified axis. PRIVE Moves a specified sub group axis to an absolute position. Moves a specified sub group axis to an absolute position. Moves a specified sub group axis to an absolute position. Moves a specified main group axis to a relative position. Moves a specified main group axis to a relative position.	nand Statements nand Statements unctions nand Statements nand Statements nand Statements nand Statements nand Statements
Declares the array variable name and the number of elements. Acquires the distance between 2 specified points. Acquires the distance between 2 specified points. Dutputs a specified value to the DO port. Declares the array variable name and the number of elements. Putput Specified points. Dutputs a specified value to the DO port. Moves a specified main group axis to an absolute position. Declares the array variable name and the number of elements. Futput Specified points. Committee of the DO port. Declares the array variable name and the number of elements. Futput Specified points. Committee of the DO port. Declares the array variable name and the number of elements. Futput Specified points. Declares the array variable name and the number of elements. Futput Specified points. Declares the array variable name and the number of elements. Futput Specified points. Declares the array variable name and the number of elements. Futput Specified points. Declares the array variable name and the number of elements. Futput Specified points. Declares the array variable name and the number of elements. Futput Specified points. Declares the array variable name and the number of elements. Futput Specified points. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of elements. Declares the array variable name and the number of element	unctions nand Statements nand Statements nand Statements nand Statements nand Statements
elements. 26 DIST Acquires the distance between 2 specified points. 28 DO Outputs a specified value to the DO port. 1 Comm. 29 DRIVE Moves a specified main group axis to an absolute position. 4 Comm. 29 DRIVE (With T-option) Executes an absolute movement command for a specified axis. 29 DRIVE2 Moves a specified sub group axis to an absolute position. 4 Comm. 30 DRIVEI Moves a specified main group axis to a relative position. 4 Comm.	unctions nand Statements nand Statements nand Statements nand Statements nand Statements
28 DO Outputs a specified value to the DO port. 1 Comm. 29 DRIVE Moves a specified main group axis to an absolute position. 4 Comm. 29 DRIVE (With T-option) Executes an absolute movement command for a specified axis. 4 Comm. 29 DRIVE2 Moves a specified sub group axis to an absolute position. 4 Comm. 30 DRIVEI Moves a specified main group axis to a relative position. 4 Comm.	nand Statements nand Statements nand Statements nand Statements nand Statements
29 DRIVE Moves a specified main group axis to an absolute position. 4 Comm. 29 DRIVE (With T-option) Executes an absolute movement command for a specified axis. 4 Comm. 29 DRIVE2 Moves a specified sub group axis to an absolute position. 4 Comm. 30 DRIVEI Moves a specified main group axis to a relative position. 4 Comm.	nand Statements nand Statements nand Statements nand Statements
29 DRIVE (With T-option) Executes an absolute movement command for a specified axis. 4 Command for a specified axis. 29 DRIVE2 Moves a specified sub group axis to an absolute position. 4 Command for a specified sub group axis to a relative position. 30 DRIVEI Moves a specified main group axis to a relative position. 4 Command for a specified sub group axis to a relative position.	nand Statements nand Statements nand Statements
command for a specified axis. 29 DRIVE2 Moves a specified sub group axis to an absolute position. 4 Command for a specified sub group axis to a relative position. 4 Command for a specified axis.	nand Statements
30 DRIVEI Moves a specified main group axis to a relative position. 4 Comm	nand Statements
or Times a specime man group and to a relative production	
30 DRIVEI2 Moves a specified sub group axis to a relative position. 4 O Comm	and Statements
E	
	unctions
	unctions
	and Statements
36 EXIT TASK Terminates its own task which is in progress. 6 × Comm.	nand Statements
F	
37 FOR to NEXT Controls repetitive operations. Executes the FOR to NEXT 6 × comments statement repeatedly until a specified value is reached.	nand Statements
G	
38 GOSUB to Jumps to a subroutine with the label specified by a GOSUB statement, and executes that subroutine.	nand Statements
39 GOTO Unconditionally jumps to the line specified by a label. 6 × Comm	and Statements
Н	
40 HALT Stops the program and performs a reset. 6 × Comm	nand Statements
41 HAND Defines the main robot hand. 4 O Comm	nand Statements
41 HAND2 Defines the sub robot hand. 4 O Comm	and Statements
42 HOLD Temporarily stops the program. 6 × Comm	nand Statements
I	
43 IF Allows control flow to branch according to conditions. 6 × Comm.	and Statements
44 INPUT Assigns a value to a variable specified from the programming box.	nand Statements
45 INT Acquires an integer for a specified value by Fu truncating all decimal fractions.	unctions
J	
46 JTOXY Converts joint coordinate data to main group Fu	unctions
46 JTOXY2 Converts joint coordinate data to sub group Fι Cartesian coordinate data. (↔XYTOJ2)	unctions
L	
48 LEFT\$ Extracts a character string comprising a specified Funumber of digits from the left end of a specified character string.	unctions
49 LEFTY Sets the main robot hand system to "Left". 4 O Comm	

No.	Command	Function	Condition	Direct	Туре
49	LEFTY2	Sets the sub robot hand system to "Left".	4	0	Command Statements
50	LEN	Acquires the length (number of bytes) of a specified character string.	-	-	Functions
51	LET	Executes a specified assignment statement.	1	0	Command Statements
52	LO	Outputs a specified value to the LO port to enable/ disable axis movement.	1	0	Command Statements
53	LOCx	Specifies/acquires point data or shift data for a specified axis.	-	-	Command Statements/ Functions
54	LSHIFT	Shifts a value to the left by the specified number of bits. (⇔RSHIFT)	-	-	Functions
M					
55	MCHREF	Acquires the return-to-origin or absolute-search machine reference for a specified main group axis.	-	-	Functions
55	MCHREF2	Acquires the return-to-origin or absolute-search machine reference for a specified sub group axis.	-	-	Functions
56	MID\$	Extracts a character string of a desired length from a specified character string.	-	-	Functions
57	MO	Outputs a specified value to the MO port.	1	0	Command Statements
58	MOVE	Performs absolute movement of all main robot axes.	5	0	Command Statements
58	MOVE2	Performs absolute movement of all sub robot axes.	5	0	Command Statements
59	MOVEI	Performs relative movement of all main robot axes.	4	0	Command Statements
59	MOVEI2	Performs relative movement of all sub robot axes.	4	0	Command Statements
0					
60	OFFLINE	Sets a specified communication port to the "offline" mode.	1	0	Command Statements
62	ON ERROR GOTO	If an error occurs during program execution, this command allows the program to jump to the error processing routine specified by the label without stopping the program, or it stops the program and displays the error message.	6	×	Command Statements
63	ON to GOSUB	Jumps to a subroutine with labels specified by a GOSUB statement in accordance with the conditions, and executes that subroutine.	6	×	Command Statements
64	ON to GOTO	Jumps to label-specified lines in accordance with the conditions.	6	×	Command Statements
65	ONLINE	Sets the specified communication port to the "online" mode.	1	0	Command Statements
61	ORD	Acquires the character code of the first character in a specified character string.	-	-	Functions
66	ORGORD	Specifies/acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the main group.	4/-	0	Command Statements/ Functions
66	ORGORD2	Specifies/acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the sub group.	4/-	0	Command Statements/ Functions
67	ORIGIN	Executes a return-to-origin for incremental specs. axes.	4	0	Command Statements
68	OUT	Turns ON the bits of the specified output ports and the command statement ends.	6	×	Command Statements
69	OUTPOS	Specifies/acquires the OUT enable position parameter of the main group.	4/-	0	Command Statements/ Functions
69	OUTPOS2	Specifies/acquires the OUT enable position parameter of the sub group.	4/-	0	Command Statements/ Functions
P					
70	PATH	Sets the movement path.	6	×	Command Statements
71	PATH END	Ends the movement path setting.	6	×	Command Statements
72	PATH SET	Starts the movement path setting.	6	×	Command Statements

Function	Condition	Direct	Туре
ts the PATH motion.	6	×	Command Statements
nes the pallet used to execute pallet movement mands.	1	0	Command Statements
cutes the main robot pallet movement command.	4	0	Command Statements
cutes the sub robot pallet movement command.	4	0	Command Statements
nes points within a program.	1	0	Command Statements
ates point data specified by a pallet definition ober and pallet position number.	-	-	Functions
lays a character string at the programming box screen.	1	0	Command Statements
verts a specified value to degrees. (↔DEGRAD)	-	-	Functions
resses a comment statement.	6	X	Command Statements
ns the bit of a specified output port OFF.	1	0	Command Statements
tarts another task during a temporary stop.	6	×	Command Statements
sumes program execution after error recovery	6	X	Command Statements
cessing.			
racts a character string comprising a specified aber of digits from the right end of a specified racter string.	-	-	Functions
s the main robot hand system to "Right".	4	0	Command Statements
s the sub robot hand system to "Right".	4	0	Command Statements
ts a value to the right by the specified number of $(\leftrightarrow LSHIFT)$	-	-	Functions
nes the shift coordinates within the program.	4	0	Command Statements
ws control flow to branch according to conditions.	6	×	Command Statements
ds a file.	1	0	Command Statements
trols the servo ON/OFF of specified main group s or all main group axes.	4	0	Command Statements
s or all sub group axes.	4	0	Command Statements
ns the bit at the specified output port ON.	3	In part ×	Command Statements
s the shift coordinates for the main robot by using shift data specified by a shift variable.	4	0	Command Statements
s the shift coordinates for the sub robot by using shift data specified by a shift variable.	4	0	Command Statements
uires the sine value for a specified value.	-	-	Functions
puts a specified value to the SO port.	1	0	Command Statements
nges the main group's program movement speed.	4	0	Command Statements
inges the sub group's program movement speed.	4	0	Command Statements
cifies the task number and priority ranking of a cified task, and starts that task.	6	×	Command Statements
verts a specified value to a character string (↔VAL)	-	-	Functions
uires the square root of a specified value.	-	-	Functions
porarily stops another task which is being executed.	6	×	Command Statements
tches the program being executed, performs piling, then begins execution from the first line.	2	0	Command Statements
piling,		then begins execution from the first line.	then begins execution from the first line.

TOLE Specifies/acquires the main group tolerance d/- Command Statement Functions TORQUE Specifies/acquires the sub group tolerance d/- Command Statement Functions TORQUE Specifies/acquires the maximum torque command value which can be set for a specified main group axis. TORQUE Specifies/acquires the maximum torque command value which can be set for a specified gub group axis. TORQUE Specifies/acquires the maximum torque command value which can be set for a specified sub group axis. TRQSTS Acquires the command end status for the DRIVE command with torque limit option executed at the main group. TRQSTS Acquires the command end status for the DRIVE command with torque limit option executed at the sub group. TRQTIME Specifies/acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement. TRQTIME Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. TRQTIME Converts the numeric value of a specified character string to an actual numeric value. (↔STR\$) W TIME WAIT Waits until the conditions of the DI/DO conditional expression are met (with time-out). Waits until the main group robot axis operation is completed. 6 × Command Statement parameter. Specifies/acquires the main robot tip weight parameter. Specifies/acquires the main robot tip weight parameter. Punctions WEIGHT Specifies/acquires the sub robot tip weight parameter. Functions The Command Statement parameter. Reads out the current position of the main group robot arm in joint coordinates (pulses). WHERE Reads out the current position of the sub group robot arm in joint coordinates (pulses).	No.	Command	Function	Condition	Direct	Туре
character string. Acquires the current time in seconds, counting from 12:00 midnight. To Outputs a specified value to the TO port. TOLE Specifies/acquires the main group tolerance parameter. TOLE Specifies/acquires the sub group tolerance parameter. TORQUE Specifies/acquires the maximum torque command value which can be set for a specified main group axis. TORQUE Specifies/acquires the maximum torque command value which can be set for a specified main group axis. TORQUE Specifies/acquires the maximum torque command value which can be set for a specified sub group axis. TRQSTS Acquires the command end status for the DRIVE command with torque limit option executed at the main group. TRQSTS Acquires the command end status for the DRIVE command with torque limit option executed at the sub group. TRQSTS Acquires the command end status for the DRIVE command with torque limit option executed at the sub group. TRQSTS Acquires the current limit time-out period at the specified wain group axis when using a torque limit option in the DRIVE statement. TRQTIME Specifies/acquires the current limit time-out period at the specified was group axis when using a torque limit setting option in the DRIVE statement. TRQTIME2 Specifies/acquires the current limit time-out period at the specified was group axis when using a torque limit setting option in the DRIVE statement. TRQTIME3 VAL Converts the numeric value of a specified character string to an actual numeric value. («-STR\$) W Waits until the conditions of the DI/DO conditional expression are met (with time-out). Waits until the sub group robot axis operation is completed. MAIT ARM2 Waits until the main group robot axis operation is completed. WAIT ARM2 Waits until the sub group robot axis operation is completed. Waits with the main group robot axis operation is completed. WHERE Reads out the current position of the main group robot arm in joint coordinates (pulses). WHERE Reads out the current position of the main group arm as Cartesian coordinate data (-W	105	TCOUNTER		-	-	Functions
12:00 midnight 12:00 midnight 10:00 midnight 10:00 1	106	TIME\$		-	-	Functions
TOLE Specifies/acquires the main group tolerance 4/- Command Statement Functions TOLE2 Specifies/acquires the sub group tolerance parameter. TOROUE Specifies/acquires the maximum torque command value which can be set for a specified main group axis. TOROUE2 Specifies/acquires the maximum torque command value which can be set for a specified main group axis. TOROUE2 Specifies/acquires the maximum torque command value which can be set for a specified sub group axis. TRQSTS Acquires the command end status for the DRIVE command with torque limit option executed at the main group. TRQSTS Acquires the command end status for the DRIVE command with torque limit option executed at the sub group. TRQTIME Specifies/acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement. TRQTIME2 Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. TRQTIME3 Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. TRQTIME4 Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. TRQTIME5 Specifies/acquires the numeric value (←STR\$) W TARQTIME5 Specifies/acquires the properties of the DRIVD Conditional expression are met (with time-out). Waits until the conditions of the DRIVD conditional expression are met (with time-out). TRQTIME6 Waits until the sub group robot axis operation is completed. Waits until the sub group robot axis operation is completed. Waits until the sub group robot axis operation is completed. Waits until the sub group robot axis operation is completed. Waits until the sub group robot axis operation is completed. Waits until the sub group robot axis operation is completed. Waits until the sub group robot axis operation is completed. Waits until th	107	TIMER		-	-	Functions
Parameter Prunctions Pru	108	ТО	Outputs a specified value to the TO port.	1	0	Command Statements
Disparameter Functions	109	TOLE	l ' - '	4/-	0	Command Statements/ Functions
Value which can be set for a specified main group axis. Specifies/acquires the maximum torque command under which can be set for a specified sub group axis. Ocommand Statement	109	TOLE2	, , , , , , , , , , , , , , , , , , ,	4/-	0	Command Statements/ Functions
value which can be set for a specified sub group axis. 111 TRQSTS Acquires the command end status for the DRIVE command with torque limit option executed at the main group. 112 TRQSTS2 Acquires the command end status for the DRIVE command with torque limit option executed at the sub group. 112 TRQTIME Specifies/acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement. 112 TRQTIME2 Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. 112 TRQTIME2 Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. 113 VAL Converts the numeric value of a specified character string to an actual numeric value. (←STR\$) W 114 WAIT Waits until the conditions of the DI/DO conditional expression are met (with time-out). Waits until the wait group robot axis operation is completed. 6 × Command Statement expression are met (with time-out). Waits until the sub group robot axis operation is completed. 6 × Command Statement parameter. Specifies/acquires the main robot tip weight parameter. Specifies/acquires the sub robot tip weight parameter. Specifies/acquires the sub robot tip weight parameter. Specifies/acquires the sub robot tip weight parameter. Reads out the current position of the main group robot arm in joint coordinates (pulses). WHERE Reads out the current position of the main group arm as Cartesian coordinates (pulses). WHRXY Reads out the current position of the sub group robot arm in joint coordinates (pulses). WHRXY2 Reads out the current position of the sub group robot warm as Cartesian coordinate (mm, degrees). WHRXY2 Reads out the current position of the sub group arm as Cartesian coordinate to the main group arm as Cartesian coordinate (mm, degrees). WHRXY2 Reads out the current position of the sub group arm as Cartesian coor	110	TORQUE		4/-	0	Command Statements/ Functions
command with torque limit option executed at the main group. 111 TRQSTS2 Acquires the command end status for the DRIVE command with torque limit option executed at the sub group. 112 TRQTIME Specifies/acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement. 112 TRQTIME2 Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. 113 VAL Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. 113 VAL Converts the numeric value of a specified character Functions string to an actual numeric value. (←STR\$) 114 WAIT Waits until the conditions of the DI/DO conditional expression are met (with time-out). 115 WAIT ARM Waits until the main group robot axis operation is completed. 6 × Command Statement expression are met (with time-out). 116 WEIGHT Specifies/acquires the main robot tip weight 4/- Command Statement Specifies/acquires the sub robot tip weight 4/- Command Statement Specifies/acquires the sub robot tip weight 4/- Command Statement Specifies/acquires the sub robot tip weight 4/- Command Statement Specifies/acquires the sub robot tip weight 4/- Command Statement Specifies/acquires the sub robot tip weight 4/- Command Statement Specifies/acquires the sub robot tip weight 4/- Command Statement Specifies Specifies/acquires the sub robot tip weight 4/- Command Statement Specifies Specifies/acquires the sub robot tip weight 4/- Command Statement Specifies Specifies/acquires the sub robot tip weight 4/- Command Statement Specifies Spe	110	TORQUE2		4/-	0	Command Statements/ Functions
command with torque limit option executed at the sub group. TRQTIME Specifies/acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement. Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. V TRQTIME2 Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. V THE Converts the numeric value of a specified character string to an actual numeric value. (←STR\$) W THE WAIT Waits until the conditions of the DI/DO conditional expression are met (with time-out). WAIT ARM Waits until the main group robot axis operation is completed. WEIGHT Specifies/acquires the main robot tip weight parameter. Specifies/acquires the sub robot tip weight parameter. WEIGHT2 Specifies/acquires the sub robot tip weight parameter. WHERE Reads out the current position of the main group robot arm in joint coordinates (pulses). WHERE Reads out the current position of the sub group robot main group arm in goint coordinates (pulses). WHERE Reads out the current position of the main group arm as Cartesian coordinates (pulses). WHRXY Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees). WHRXY Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees). X 121 XYTOJ Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY). 122 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data to the sub group's joint coordinate data to the sub group's joint coordinate data (←JTOXY).	111	TRQSTS	command with torque limit option executed at the	-	-	Functions
the specified main group axis when using a torque limit option in the DRIVE statement. Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement. V 113 VAL Converts the numeric value of a specified character string to an actual numeric value. (←STR\$) Walts until the conditions of the DI/DO conditional expression are met (with time-out). 115 WAIT ARM Waits until the main group robot axis operation is completed. 6 × Command Statement expression are met (with time-out). 115 WAIT ARM2 Waits until the sub group robot axis operation is completed. 6 × Command Statement with the WEIGHT Specifies/acquires the main robot tip weight 4/- Command Statement Functions 116 WEIGHT2 Specifies/acquires the sub robot tip weight 4/- Command Statement parameter. 118 WHERE Reads out the current position of the main group robot arm in joint coordinates (pulses). 118 WHERE2 Reads out the current position of the sub group robot arm in joint coordinates (pulses). 119 WHILE to WEND Controls repeated operations. 6 × Command Statement parameter. Functions arm in joint coordinates (mm, degrees). 120 WHRXY2 Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees). X 121 XYTOJ Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY). 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY).	111	TRQSTS2	command with torque limit option executed at the	-	-	Functions
the specified sub group axis when using a torque limit setting option in the DRIVE statement. V 113 VAL Converts the numeric value of a specified character string to an actual numeric value. (←STR\$) W 114 WAIT Waits until the conditions of the DI/DO conditional expression are met (with time-out). 115 WAIT ARM Waits until the main group robot axis operation is completed. 6 × Command Statement with the WeIGHT Specifies/acquires the main robot tip weight parameter. 116 WEIGHT Specifies/acquires the sub robot tip weight parameter. 118 WHERE Reads out the current position of the main group robot arm in joint coordinates (pulses). 118 WHERE Reads out the current position of the sub group robot arm in joint coordinates (pulses). 119 WHILE to WEND Controls repeated operations. 6 × Command Statement arm in joint coordinates (pulses). 120 WHRXY Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees). X 121 XYTOJ Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←→JTOXY2). 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2). Functions	112	TRQTIME	the specified main group axis when using a torque	1/-	0	Command Statements/ Functions
VAL	112	TRQTIME2	at the specified sub group axis when using a torque	1/-	0	Command Statements/ Functions
String to an actual numeric value. (←→STR\$) W 114 WAIT Waits until the conditions of the DI/DO conditional expression are met (with time-out). 6 X Command Statement conditions completed. 6 X Command Statement conditions conditions. 6 X Command Statement conditions. Functions. Functions. Command Statement conditions. Functions. Command Statement completed. 4/- O Command Statement command statement conditions. Command Statement conditions. Functions.	٧					
WAIT Waits until the conditions of the DI/DO conditional expression are met (with time-out). Secure of the parameter of the parameter of the parameter.	113	VAL		-	-	Functions
expression are met (with time-out). 115 WAIT ARM Waits until the main group robot axis operation is completed. 6 × Command Statement WAIT ARM2 Waits until the sub group robot axis operation is completed. 6 × Command Statement Specifies/acquires the main robot tip weight parameter. 116 WEIGHT Specifies/acquires the main robot tip weight parameter. 117 WEIGHT2 Specifies/acquires the sub robot tip weight parameter. 118 WHERE Reads out the current position of the main group robot arm in joint coordinates (pulses). 118 WHERE Reads out the current position of the sub group robot arm in joint coordinates (pulses). 119 WHILE to WEND Controls repeated operations. 6 × Command Statement param as Cartesian coordinates (mm, degrees). 120 WHRXY Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees). 120 WHRXY2 Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees). 121 XYTOJ Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY). 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY). 122 Functions	W				•	
115 WAIT ARM2 Waits until the sub group robot axis operation is completed. 6	114	WAIT		6	×	Command Statements
Specifies/acquires the main robot tip weight parameter. Specifies/acquires the sub trunctions Specifies/acquires the sub group robot parameter. Specifies/acquires the sub group robot parameter. Sunctions Specifies/acquires the sub group acquires parameter. Specifies/acquires the sub group acquires the sub group acquires parameter. Specifies/acquires the sub group acquires parameter. Specifies acquires the sub group acquires the sub group acquires the sub group acquires parameter. Specifies acquires the sub group acquires parameter. Specifies	115	WAIT ARM	Waits until the main group robot axis operation is completed.	6	×	Command Statements
parameter. Punctions	115	WAIT ARM2	<u> </u>	6	×	Command Statements
parameter. Reads out the current position of the main group robot arm in joint coordinates (pulses). Reads out the current position of the sub group robot arm in joint coordinates (pulses). Reads out the current position of the sub group robot arm in joint coordinates (pulses). Punctions Functions Functions WHILE to WEND Controls repeated operations. Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees). WHRXY Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees). X Table Type Type Type Type Type Type Type Typ	116	WEIGHT	parameter.	4/-	0	
robot arm in joint coordinates (pulses). 118 WHERE2 Reads out the current position of the sub group robot arm in joint coordinates (pulses). 119 WHILE to WEND Controls repeated operations. 120 WHRXY Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees). 120 WHRXY2 Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees). X 121 XYTOJ Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (→JTOXY). 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (→JTOXY2). Functions	116		parameter.	4/-	0	Command Statements/ Functions
arm in joint coordinates (pulses). 119 WHILE to WEND Controls repeated operations. 120 WHRXY Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees). 120 WHRXY2 Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees). X 121 XYTOJ Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY). 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2). 122 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2).	118		robot arm in joint coordinates (pulses).	-	-	Functions
120 WHRXY Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees). 120 WHRXY2 Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees). X 121 XYTOJ Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY). 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2). 122 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2).	118	WHERE2		-	-	Functions
arm as Cartesian coordinates (mm, degrees). Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees). X 121 XYTOJ Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY). 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2). Functions Functions	119	WHILE to WEND	Controls repeated operations.	6	×	Command Statements
as Cartesian coordinates (mm, degrees). X 121 XYTOJ Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY). - - Functions 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2). - - Functions	120		arm as Cartesian coordinates (mm, degrees).	-	-	
121 XYTOJ Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY). - - Functions 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2). - - Functions		WHRXY2		_	-	Functions
to the main group's joint coordinate data (←JTOXY). 121 XYTOJ2 Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2). Functions	X					
to the sub group's joint coordinate data (↔JTOXY2).	121	XYTOJ		-	-	Functions
122 _SYSFLG Axis status monitoring flag. - - Functions	121	XYTOJ2		-	-	Functions
	122	_SYSFLG	Axis status monitoring flag.	-	-	Functions

Function Specific

Program commands

General commands

No.	Command	Function	Condition	Direct	Туре
27	DIM	Declares the array variable name and the number of elements.	6	×	Command Statements
51	LET	Executes a specified assignment statement.	1	0	Command Statements
80	REM	Expresses a comment statement.	6	×	Command Statements

Arithmetic commands

No.	Command	Function	Condition	Direct	Туре
1	ABS	Acquires the absolute value of a specified value.	-	-	Functions
9	ATN	Acquires the arctangent of the specified value.	-	-	Functions
9	ATN2	Acquires the arctangent of the specified X-Y coordinates.	-	-	Functions
16	cos	Acquires the cosine value of a specified value.	-	-	Functions
23	DEGRAD	Converts a specified value to radians (↔RADDEG).	-	-	Functions
26	DIST	Acquires the distance between 2 specified points.	-	-	Functions
45	INT	Acquires an integer for a specified value by truncating all decimal fractions.	-	-	Functions
54	LSHIFT	Shifts a value to the left by the specified number of bits. (↔RSHIFT)	-	-	Functions
79	RADDEG	Converts a specified value to degrees. (↔DEGRAD)	-	-	Functions
87	RSHIFT	Shifts a value to the right by the specified number of bits. (↔LSHIFT)	-	-	Functions
95	SIN	Acquires the sine value for a specified value.	-	-	Functions
100	SQR	Acquires the square root of a specified value.	-	-	Functions
104	TAN	Acquires the tangent value for a specified value.	-	-	Functions

Date / time

No.	Command	Function	Condition	Direct	Туре
19	DATE\$	Acquires the date as a "yy/mm/dd" format character string.	-	1	Functions
105	TCOUNTER	Outputs count-up values at 10ms intervals starting from the point when the TCOUNTER variable is reset.	-	-	Functions
106	TIME \$	Acquires the current time as an "hh:mm:ss" format character string.	-	-	Functions
107	TIMER	Acquires the current time in seconds, counting from 12:00 midnight.	-	-	Functions

Character string operation

No.	Command	Function	Condition	Direct	Туре
15	CHR\$	Acquires a character with the specified character code.	-	-	Functions
48	LEFT\$	Extracts a character string comprising a specified number of digits from the left end of a specified character string.	-	-	Functions
50	LEN	Acquires the length (number of bytes) of a specified character string.	-	-	Functions
56	MID \$	Extracts a character string of a desired length from a specified character string.	-	-	Functions
61	ORD	Acquires the character code of the first character in a specified character string.	-	-	Functions
85	RIGHT \$	Extracts a character string comprising a specified number of digits from the right end of a specified character string.	-	-	Functions
99	STR\$	Converts a specified value to a character string (↔VAL)	-	-	Functions
113	VAL	Converts the numeric value of a specified character string to an actual numeric value. (→STR\$)	-	-	Functions

Point, coordinates, shift coordinates

No.	Command	Function	Condition	Direct	Туре
13	CHANGE	Switches the main robot hand.	4	0	Command Statements
13	CHANGE2	Switches the sub robot hand.	4	0	Command Statements
41	HAND	Defines the main robot hand.	4	0	Command Statements
41	HAND2	Defines the sub robot hand.	4	0	Command Statements
46	JTOXY	Converts joint coordinate data to main group Cartesian coordinate data. (↔XYTOJ)	-	-	Functions
46	JTOXY2	Converts joint coordinate data to sub group Cartesian coordinate data. (↔XYTOJ2)	-	-	Functions
49	LEFTY	Sets the main robot hand system to "Left".	4	0	Command Statements
49	LEFTY2	Sets the sub robot hand system to "Left".	4	0	Command Statements
76	Pn	Defines points within a program.	1	0	Command Statements
77	PPNT	Creates point data specified by a pallet definition number and pallet position number.	-	-	Functions
86	RIGHTY	Sets the main robot hand system to "Right".	4	0	Command Statements
86	RIGHTY2	Sets the sub robot hand system to "Right".	4	0	Command Statements
88	Sn	Defines the shift coordinates in the program.	4	0	Command Statements
94	SHIFT	Sets the shift coordinates for the main robot by using the shift data specified by a shift variable.	4	0	Command Statements
94	SHIFT2	Sets the shift coordinates for the sub robot by using the shift data specified by a shift variable.	4	0	Command Statements
121	XYTOJ	Converts the point variable Cartesian coordinate data to the main group's joint coordinate data $(\leftrightarrow JTOXY)$.	-	-	Functions
121	XYTOJ2	Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (↔JTOXY2).	-	-	Functions
53	LOCx	Specifies/acquires point data or shift data for a specified axis.	-	-	Command Statements/ Functions

Branching commands

No.	Command	Function	Condition	Direct	Туре
34	EXIT FOR	Terminates the FOR to NEXT statement loop.	6	×	Command Statements
37	FOR to NEXT	Controls repetitive operations. Executes the FOR to NEXT statement repeatedly until a specified value is reached.	6	×	Command Statements
38	GOSUB to RETURN	Jumps to a subroutine with the label specified by a GOSUB statement, and executes that subroutine.	6	×	Command Statements
39	GOTO	Unconditionally jumps to the line specified by a label.	6	×	Command Statements
43	IF	Allows control flow to branch according to conditions.	6	X	Command Statements
63	ON to GOSUB	Jumps to a subroutine with labels specified by a GOSUB statement in accordance with the conditions, and executes that subroutine.	6	×	Command Statements
64	ON to GOTO	Jumps to label-specified lines in accordance with the conditions.	6	×	Command Statements
89	SELECT CASE to END SELECT	Allows control flow to branch according to conditions.	6	×	Command Statements
119	WHILE to WEND	Controls repeated operations.	6	X	Command Statements

Error control

No.	Command	Function	Condition	Direct	Туре
62	ON ERROR GOTO	If an error occurs during program execution, this command allows the program to jump to the error processing routine specified by the label without stopping the program, or it stops the program and displays the error message.	6	×	Command Statements
83	RESUME	Resumes program execution after error recovery processing.	6	×	Command Statements
33	ERL	Gives the line No. where an error occurred.	-	-	Functions
33	ERR	Gives the error code number of an error which has occurred.	-	-	Functions

Program & task control

Program control

No.	Command	Function	Condition	Direct	Туре
12	CALL	Executes (calls) another program.	6	×	Command Statements
40	HALT	Stops the program and performs a reset.	6	×	Command Statements
42	HOLD	Temporarily stops the program.	6	×	Command Statements
103	SWI	Switches the program being executed, performs compiling, then begins execution from the first line.	2	0	Command Statements

Task control

No.	Command	Function	Condition	Direct	Туре
14	CHGPRI	Changes the priority ranking of a specified task.	6	×	Command Statements
18	CUT	Terminates a task currently being executed or temporarily stopped.	6	×	Command Statements
36	EXIT TASK	Terminates its own task which is in progress.	6	×	Command Statements
82	RESTART	Restarts another task during a temporary stop.	6	×	Command Statements
98	START	Specifies the task number and priority ranking of a specified task, and starts that task.	6	×	Command Statements
102	SUSPEND	Temporarily stops another task which is being executed.	6	×	Command Statements

Robot control

Robot operations

No.	Command	Function	Condition	Direct	Туре
2	ABSINIT	Resets the current position of a specified main group axis.	4	0	Command Statements
2	ABSINIT2	Resets the current position of a specified sub group axis.	4	0	Command Statements
4	ABSRST	Executes a return-to-origin at the robot absolute motor axes.	4	0	Command Statements
13	CHANGE	Switches the main robot hand.	4	0	Command Statements
13	CHANGE2	Switches the sub robot hand.	4	0	Command Statements
29	DRIVE	Moves a specified main group axis to an absolute position.	4	0	Command Statements
29	DRIVE2	Moves a specified sub group axis to an absolute position.	4	0	Command Statements
30	DRIVEI	Moves a specified main group axis to a relative position.	4	0	Command Statements
30	DRIVEI2	Moves a specified sub group axis to a relative position.	4	0	Command Statements
41	HAND	Defines the main robot hand.	4	0	Command Statements
41	HAND2	Defines the sub robot hand.	4	0	Command Statements
49	LEFTY	Sets the main robot hand system to "Left".	4	0	Command Statements
49	LEFTY2	Sets the sub robot hand system to "Left".	4	0	Command Statements
58	MOVE	Performs absolute movement of all main robot axes.	5	0	Command Statements
58	MOVE2	Performs absolute movement of all sub robot axes.	5	0	Command Statements
59	MOVEI	Performs relative movement of all main robot axes.	4	0	Command Statements
59	MOVEI2	Performs relative movement of all sub robot axes.	4	0	Command Statements
67	ORIGIN	Executes a return-to-origin for incremental specs. axes.	4	0	Command Statements
75	PMOVE	Executes the main robot pallet movement command.	4	0	Command Statements
75	PMOVE2	Executes the sub robot pallet movement command.	4	0	Command Statements
86	RIGHTY	Sets the main robot hand system to "Right".	4	0	Command Statements
86	RIGHTY2	Sets the sub robot hand system to "Right".	4	0	Command Statements
91	SERVO	Controls the servo ON/OFF of specified main group axes or all main group axes.	4	0	Command Statements
91	SERVO2	Controls the servo ON/OFF of specified sub group axes or all sub group axes.	4	0	Command Statements

Status acquisition

No.	Command	Function	Condition	Direct	Туре
3	ABSRPOS	Acquires the machine reference of the specified main group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)	-	-	Functions
3	ABSRPOS2	Acquires the machine reference of the specified sub group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)	-	-	Functions
7	ARMCND	Acquires the current arm status of the main robot.	-	-	Functions
7	ARMCND2	Acquires the current arm status of the sub robot.	-	-	Functions
8	ARMTYPE	Acquires the current "hand system" setting of the main robot.	-	-	Functions
8	ARMTYPE2	Acquires the current "hand system" setting of the sub robot.	-	-	Functions
55	MCHREF	Acquires the return-to-origin or absolute-search machine reference for a specified main group axis.	-	-	Functions

No.	Command	Function	Condition	Direct	Туре
55	MCHREF2	Acquires the return-to-origin or absolute-search machine reference for a specified sub group axis.	-	-	Functions
111	TRQSTS	Acquires the command end status for the DRIVE command with torque limit option executed at the main group.	-	-	Functions
111	TRQSTS2	Acquires the command end status for the DRIVE command with torque limit option executed at the sub group.	-	-	Functions
118	WHERE	Reads out the current position of the main group robot arm in joint coordinates (pulses).	-	-	Functions
118	WHERE2	Reads out the current position of the sub group robot arm in joint coordinates (pulses).	-	-	Functions
120	WHRXY	Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees).	-	-	Functions
120	WHRXY2	Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees).	-	-	Functions
115	WAIT ARM	Waits until the main group robot axis operation is completed.			
115	WAIT ARM2	Waits until the sub group robot axis operation is completed.	6	×	Command Statements

Status change

No.	Command	Function	Condition	Direct	Туре
5	ACCEL	Specifies/acquires the acceleration coefficient parameter of the main group.	4/-	0	Command Statements/ Functions
5	ACCEL2	Specifies/acquires the acceleration coefficient parameter of the sub group.	4/-	0	Command Statements/ Functions
6	ARCH	Specifies/acquires the arch position parameter of the main group.	4/-	0	Command Statements/ Functions
6	ARCH2	Specifies/acquires the arch position parameter of the sub group.	4/-	0	Command Statements/ Functions
10	ASPEED	Changes the AUTO movement speed of the main group.	4	0	Command Statements
10	ASPEED2	Changes the AUTO movement speed of the sub group.	4	0	Command Statements
11	AXWGHT	Specifies/acquires the axis tip weight parameter of the main group.	4/-	0	Command Statements/ Functions
11	AXWGHT2	Specifies/acquires the axis tip weight parameter of the sub group.	4/-	0	Command Statements/ Functions
20	DECEL	Specifies/acquires the deceleration rate parameter of the main group.	4/-	0	Command Statements/ Functions
20	DECEL2	Specifies/acquires the deceleration rate parameter of the sub group.	4/-	0	Command Statements/ Functions
66	ORGORD	Specifies/acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the main group.	4/-	0	Command Statements/ Functions
66	ORGORD2	Specifies/acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the sub group.	4/-	0	Command Statements/ Functions
69	OUTPOS	Specifies/acquires the OUT enable position parameter of the main group.	4/-	0	Command Statements/ Functions
69	OUTPOS2	Specifies/acquires the OUT enable position parameter of the sub group.	4/-	0	Command Statements/ Functions

No.	Command	Function	Condition	Direct	Туре
74	PDEF	Defines the pallet used to execute pallet movement commands.	1	0	Command Statements
97	SPEED	Changes the main group's program movement speed.	4	0	Command Statements
97	SPEED2	Changes the sub group's program movement speed.	4	0	Command Statements
109	TOLE	Specifies/acquires the main group tolerance parameter.	4/-	0	Command Statements/ Functions
109	TOLE2	Specifies/acquires the sub group tolerance parameter.	4/-	0	Command Statements/ Functions
116	WEIGHT	Specifies/acquires the main robot tip weight parameter.	4/-	0	Command Statements/ Functions
116	WEIGHT2	Specifies/acquires the sub robot tip weight parameter.	4/-	0	Command Statements/ Functions

Path control

No.	Command	Function	Condition	Direct	Туре
70	PATH	Sets the movement path.	6	×	Command Statements
71	PATH END	Ends the movement path setting.	6	×	Command Statements
72	PATH SET	Starts the movement path setting.	6	×	Command Statements
73	PATH START	Starts the PATH motion.	6	X	Command Statements

Torque control

No.	Command	Function	Condition	Direct	Туре
17	CURTRQ	Acquires the current torque value of the specified main group axis.	-	×	Functions
17	CURTRQ2	Acquires the current torque value of the specified sub group axis.	-	×	Functions
29	DRIVE	(With T-option) Executes an absolute movement command for a specified axis.	4	0	Command Statements
110	TORQUE	Specifies/acquires the maximum torque command value which can be set for a specified main group axis.	4/-	0	Command Statements/ Functions
110	TORQUE2	Specifies/acquires the maximum torque command value which can be set for a specified sub group axis.	4/-	0	Command Statements/ Functions
112	TRQTIME	Specifies/acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement.	1/-	0	Command Statements/ Functions
112	TRQTIME2	Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement.	1/-	0	Command Statements/ Functions

Input/output & communication control

Input/output control

No.	Command	Function	Condition	Direct	Туре
24	DELAY	Waits for the specified period (units: ms).	6	×	Command Statements
28	DO	Outputs a specified value to the DO port.	1	0	Command Statements
52	LO	Outputs a specified value to the LO port to enable/ disable axis movement.	1	0	Command Statements
57	МО	Outputs a specified value to the MO port.	1	0	Command Statements

No.	Command	Function	Condition	Direct	Туре
68	OUT	Turns ON the bits of the specified output ports and the command statement ends.	6	×	Command Statements
81	RESET	Turns the bit of a specified output port OFF.	1	0	Command Statements
92	SET	Turns the bit at the specified output port ON.	3	In part ×	Command Statements
96	so	Outputs a specified value to the SO port.	1	0	Command Statements
108	ТО	Outputs a specified value to the TO port.	1	0	Command Statements
114	WAIT	Waits until the conditions of the DI/DO conditional expression are met (with time-out).	6	×	Command Statements

Programming box

No.	Command	Function	Condition	Direct	Туре
44	INPUT	Assigns a value to a variable specified from the programming box.	1	0	Command Statements
 78	PRINT	Displays a character string at the programming box screen.	1	0	Command Statements

Communication control

No.	Command	Function	Condition	Direct	Туре
65	ONLINE	Sets the specified communication port to the "online" mode.	1	0	Command Statements
60	OFFLINE	Sets a specified communication port to the "offline" mode.	1	0	Command Statements
90	SEND	Sends a file.	1	0	Command Statements

Other

Other

No.	Command	Function	Condition	Direct	Туре
122	_SYSFLG	Axis status monitoring flag.	-	-	Functions

Functions: in alphabetic order

No.	Function	Type	Function
Α			
1	ABS	Arithmetic function	Acquires the absolute value of a specified value.
3	ABSRPOS	Arithmetic function	Acquires the machine reference of the specified main group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)
3	ABSRPOS2	Arithmetic function	Acquires the machine reference of the specified sub group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)
5	ACCEL	Arithmetic function	Acquires the acceleration coefficient parameter of the main group.
5	ACCEL2	Arithmetic function	Acquires the acceleration coefficient parameter of the sub group.
6	ARCH	Arithmetic function	Acquires the arch position parameter of the main group.
6	ARCH2	Arithmetic function	Acquires the arch position parameter of the sub group.
7	ARMCND	Arithmetic function	Acquires the current arm status of the main robot.
7	ARMCND2	Arithmetic function	Acquires the current arm status of the sub robot.
8	ARMTYPE	Arithmetic function	Acquires the current "hand system" setting of the main robot.
8	ARMTYPE2	Arithmetic function	Acquires the current "hand system" setting of the sub robot.
9	ATN	Arithmetic function	Acquires the arctangent of the specified value.
9	ATN2	Arithmetic function	Acquires the arctangent of the specified X-Y coordinates.
11	AXWGHT	Arithmetic function	Acquires the axis tip weight parameter of the main group.
11	AXWGHT2	Arithmetic function	Acquires the axis tip weight parameter of the sub group.
С			
15	CHR\$	Character string function	Acquires a character with the specified character code.
16	cos	Arithmetic function	Acquires the cosine value of a specified value.
17	CURTRQ	Arithmetic function	Acquires the current torque value of the specified main group axis.
17	CURTRQ2	Arithmetic function	Acquires the current torque value of the specified sub group axis.
D			
19	DATE\$	Character string function	Acquires the date as a "yy/mm/dd" format character string.
20	DECEL	Arithmetic function	Acquires the deceleration rate parameter of the main group.
20	DECEL2	Arithmetic function	Acquires the deceleration rate parameter of the sub group.
23	DEGRAD	Arithmetic function	Converts a specified value to radians (↔RADDEG).
26	DIST	Arithmetic function	Acquires the distance between 2 specified points.
E			
33	ERL	Arithmetic function	Gives the line No. where an error occurred.
33	ERR	Arithmetic function	Gives the error code number of an error which has occurred.
ı			
45	INT	Arithmetic function	Acquires an integer for a specified value by truncating all decimal fractions.
J			
46	JTOXY	Point function	Converts joint coordinate data to main group Cartesian coordinate data. (↔XYTOJ)

No.	Function	Туре	Function
46	JTOXY2	Point function	Converts joint coordinate data to sub group Cartesian coordinate data. (↔XYTOJ2)
L	<u>'</u>	<u>'</u>	
48	LEFT\$	Character string function	Extracts a character string comprising a specified number of digits from the left end of a specified character string.
50	LEN	Arithmetic function	Acquires the length (number of bytes) of a specified character string.
53	LOCx	Point function	Acquires point data or shift data for a specified axis.
54	LSHIFT	Arithmetic function	Shifts a value to the left by the specified number of bits. $(\leftrightarrow\! RSHIFT)$
M			
55	MCHREF	Arithmetic function	Acquires the return-to-origin or absolute-search machine reference for a specified main group axis.
55	MCHREF2	Arithmetic function	Acquires the return-to-origin or absolute-search machine reference for a specified sub group axis.
56	MID\$	Character string function	Extracts a character string of a desired length from a specified character string.
0			
61	ORD	Arithmetic function	Acquires the character code of the first character in a specified character string.
66	ORGORD	Arithmetic function	Acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the main group.
66	ORGORD2	Arithmetic function	Acquires the axis sequence parameter for performing return-to- origin and absolute search operations in the sub group.
69	OUTPOS	Arithmetic function	Acquires the OUT enable position parameter of the main group.
69	OUTPOS2	Arithmetic function	Acquires the OUT enable position parameter of the sub group.
Р			
77	PPNT	Point function	Creates point data specified by a pallet definition number and pallet position number.
R			
79	RADDEG	Arithmetic function	Converts a specified value to degrees. (↔DEGRAD)
85	RIGHT\$	Character string function	Extracts a character string comprising a specified number of digits from the right end of a specified character string.
87	RSHIFT	Arithmetic function	Shifts a value to the right by the specified number of bits. (↔LSHIFT)
S			
95	SIN	Arithmetic function	Acquires the sine value for a specified value.
100	SQR	Arithmetic function	Acquires the square root of a specified value.
99	STR\$	Character string function	Converts a specified value to a character string (↔VAL)
Т			
104	TAN	Arithmetic function	Acquires the tangent value for a specified value.
105	TCOUNTER	Arithmetic function	Outputs count-up values at 10ms intervals starting from the point when the TCOUNTER variable is reset.
106	TIME\$	Character string function	Acquires the current time as an "hh:mm:ss" format character string.
107	TIMER	Arithmetic function	Acquires the current time in seconds, counting from 12:00 midnight.
109	TOLE	Arithmetic function	Acquires the main group tolerance parameter.

No.	Function	Туре	Function
109	TOLE2	Arithmetic function	Acquires the sub group tolerance parameter.
110	TORQUE	Arithmetic function	Acquires the maximum torque command value which can be set for a specified main group axis.
110	TORQUE2	Arithmetic function	Acquires the maximum torque command value which can be set for a specified sub group axis.
111	TRQSTS	Arithmetic function	Acquires the command end status for the DRIVE command with torque limit option executed at the main group.
111	TRQSTS2	Arithmetic function	Acquires the command end status for the DRIVE command with torque limit option executed at the sub group.
112	TRQTIME	Arithmetic function	Acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement.
112	TRQTIME2	Arithmetic function	Acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement.
٧			
113	VAL	Arithmetic function	Converts the numeric value of a specified character string to an actual numeric value. (↔STR\$)
W			
116	WEIGHT	Arithmetic function	Acquires the main robot tip weight parameter.
116	WEIGHT2	Arithmetic function	Acquires the sub robot tip weight parameter.
118	WHERE	Point function	Reads out the current position of the main group robot arm in joint coordinates (pulses).
118	WHERE2	Point function	Reads out the current position of the sub group robot arm in joint coordinates (pulses).
120	WHRXY	Point function	Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees).
120	WHRXY2	Point function	Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees).
Χ			
121	XYTOJ	Point function	Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY).
121	XYTOJ2	Point function	Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (↔JTOXY2).
122	SYSFLG	Arithmetic function	Axis status monitoring flag.

Functions: operation-specific

Point related functions

No.	Function name	Function
46	JTOXY	Converts joint coordinate data to main group Cartesian coordinate data. (↔XYTOJ)
46	JTOXY2	Converts joint coordinate data to sub group Cartesian coordinate data. (↔XYTOJ2)
53	LOCx	Acquires point data or shift data for a specified axis.
77	PPNT	Creates point data specified by a pallet definition number and pallet position number.
118	WHERE	Reads out the current position of the main group robot arm in joint coordinates (pulses).
118	WHERE2	Reads out the current position of the sub group robot arm in joint coordinates (pulses).
120	WHRXY	Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees).
120	WHRXY2	Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees).
121	XYTOJ	Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY).
121	XYTOJ2	Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2).

Parameter related functions

No.	Function name	Function
3	ABSRPOS	Acquires the machine reference of the specified main group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)
3	ABSRPOS2	Acquires the machine reference of the specified sub group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)
5	ACCEL	Acquires the acceleration coefficient parameter of the main group.
5	ACCEL2	Acquires the acceleration coefficient parameter of the sub group.
6	ARCH	Acquires the arch position parameter of the main group.
6	ARCH2	Acquires the arch position parameter of the sub group.
7	ARMCND	Acquires the current arm status of the main robot.
7	ARMCND2	Acquires the current arm status of the sub robot.
8	ARMTYPE	Acquires the current "hand system" setting of the main robot.
8	ARMTYPE2	Acquires the current "hand system" setting of the sub robot.
11	AXWGHT	Acquires the axis tip weight parameter of the main group.
11	AXWGHT2	Acquires the axis tip weight parameter of the sub group.
17	CURTRQ	Acquires the current torque value of the specified main group axis.
17	CURTRQ2	Acquires the current torque value of the specified sub group axis.
20	DECEL	Acquires the deceleration rate parameter of the main group.
20	DECEL2	Acquires the deceleration rate parameter of the sub group.
50	LEN	Acquires the length (number of bytes) of a specified character string.
55	MCHREF	Acquires the return-to-origin or absolute-search machine reference for a specified main group axis.
55	MCHREF2	Acquires the return-to-origin or absolute-search machine reference for a specified sub group axis.
61	ORD	Acquires the character code of the first character in a specified character string.
66	ORGORD	Acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the main group.
66	ORGORD2	Acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the sub group.
69	OUTPOS	Acquires the OUT enable position parameter of the main group.
69	OUTPOS2	Acquires the OUT enable position parameter of the sub group.
109	TOLE	Acquires the main group tolerance parameter.
109	TOLE2	Acquires the sub group tolerance parameter.
110	TORQUE	Acquires the maximum torque command value which can be set for a specified main group axis.

No.	Function name	Function
110	TORQUE2	Acquires the maximum torque command value which can be set for a specified sub group axis.
111	TRQSTS	Acquires the command end status for the DRIVE command with torque limit option executed at the main group.
111	TRQSTS2	Acquires the command end status for the DRIVE command with torque limit option executed at the sub group.
112	TRQTIME	Acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement.
112	TRQTIME2	Acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement.
116	WEIGHT	Acquires the main robot tip weight parameter.
116	WEIGHT2	Acquires the sub robot tip weight parameter.

Numeric calculation related functions

No.	Function name	Function
1	ABS	Acquires the absolute value of a specified value.
9	ATN	Acquires the arctangent of the specified value.
9	ATN2	Acquires the arctangent of the specified X-Y coordinates.
16	cos	Acquires the cosine value of a specified value.
23	DEGRAD	Converts a specified value to radians (↔RADDEG).
26	DIST	Acquires the distance between 2 specified points.
45	INT	Acquires an integer for a specified value by truncating all decimal fractions.
54	LSHIFT	Shifts a value to the left by the specified number of bits. (↔RSHIFT)
79	RADDEG	Converts a specified value to degrees. (↔DEGRAD)
87	RSHIFT	Shifts a value to the right by the specified number of bits. (\leftrightarrow LSHIFT)
95	SIN	Acquires the sine value for a specified value.
100	SQR	Acquires the square root of a specified value.
104	TAN	Acquires the tangent value for a specified value.
113	VAL	Converts the numeric value of a specified character string to an actual numeric value. (↔STR\$)

Character string calculation related functions

No.	Function name	Function
15	CHR\$	Acquires a character with the specified character code.
19	DATE \$	Acquires the date as a "yy/mm/dd" format character string.
48	LEFT \$	Extracts a character string comprising a specified number of digits from the left end of a specified character string.
56	MID \$	Extracts a character string of a desired length from a specified character string.
85	RIGHT \$	Extracts a character string comprising a specified number of digits from the right end of a specified character string.
99	STR\$	Converts a specified value to a character string (↔VAL)

Parameter related functions

No.	Function name	Function
122	_SYSFLG	Axis status monitoring flag.
33	ERL	Gives the line No. where an error occurred.
33	ERR	Gives the error code number of an error which has occurred.
105	TCOUNTER	Outputs count-up values at 10ms intervals starting from the point when the TCOUNTER variable is reset.
106	TIME \$	Acquires the current time as an "hh:mm:ss" format character string.
107	TIMER	Acquires the current time in seconds, counting from 12:00 midnight.

ABS

Format

ABS (<expression>)

Explanation Returns a value specified by an <expression> as an absolute value.

SAMPLE

A=ABS(-326.55) The absolute value of -362.54 $(=362.54) \ \ \, \text{is assigned to} \\ \ \, \text{variable A}.$

Б

C

D

Е

F

G

П

ī

J

K

L

ABSINIT / ABSINIT2

Resets the current position of a specified axis



NOTE

ABSINIT / ABSINIT2 are available in the following software versions:

RCX240 Ver. 10.66 onwards, RCX22x Ver.9.39 onwards,

• The ABSINIT / ABSINIT2 statements can be used only when the "Limitless motion" parameter is set to "VALID" in the robot axis parameters. (For details, refer to the User's Manual.)



CAUTION

• When the <expression> is 0, the "17.42: Cannot reset position" error will occur if the robot's current position is at a position where a reset is impossible.

Format

main group

1.ABSINIT (<axis number>)

2.ABSINIT (<axis number>) = <expression>

Format

sub group

1.ABSINIT2 (<axis number>)

2.ABSINIT2 (<axis number>) = <expression>

(Values)

<axis number>......main group: 1 to 6

sub group: 1 to 4

<expression>......0 to 1

Explanation


Resets the current position of the axis specified by <axis number>.

If the <expression> is "0", a reset is possible only if the robot is positioned as shown in the figure below. To perform multi-turn movement in the same direction, the command statement must be executed after each 360° of movement, and the current position must be reset.

If the <expression> is "1", a reset occurs regardless of the robot's current coordinates. In this case, the robot's absolute function is disabled.

The format 1 operation is identical to a format 2 operation where the $\langle expression \rangle = 0$.

"Reset possible" range within a mechanical angle of 360° (16384 [pulse] x speed reduction ratio)



Reset execution position

For a minus axis polarity: 257 to 1791 [pulse] For a plus axis polarity: -1791 to -257 [pulse]

* When an origin point shift has been set in the axis parameters, that shift value is added to the above range.

33829-R7-00

ABSINIT / ABSINIT2

ADCINITY 1	SAMPLE	
ABSINIT 1 Resets the main group's 1st axis at the position where a current position reset is possible for that axis. (The same applies for ABSINIT 1, 0.) ABSINIT2 1 Resets the sub group's 1st axis at the position where a current position reset is possible for that axis. (The same applies for ABSINIT2 1, 0.)	ABSINIT 1	a current position reset is possible for that axis. (The same applies for ABSINIT 1, 0.) Resets the sub group's 1st axis at the position where a current position reset is possible for that axis. (The same applies



- Following the reset, the current position and target position values become values from which a distance equivalent to the motor's number-of-turns has been subtracted.
- The reset time per axis is approximately 100ms.
- If a "Limitless motion INVALID" axis is specified, the "5.37: Specification mismatch" error message displays, and execution is stopped.

Restrictions

- 1. Only the axis of a single-axis rotary type robot can be specified. Linear robot and dual robot axes cannot be used.
- 2. The ABSINIT / ASBSINIT2 statements cannot be used at YC-Link specification axes.
- 3. The ABSINIT / ASBSINIT2 statements cannot be used at electric gripper specification axes.

B

C

U

Ε

F

G

H

ı

V

L

ABSRPOS / ABSRPOS2

Acquires a machine reference

Format main group

ABSRPOS (<axis 1>)

sub group **Format**

ABSRPOS2 (<axis 2>)

Values <axis 1>.....main group: 1 to 6 <axis 2>.....sub group: 1 to 4

Explanation The machine reference value for a specified <axis number> is acquired (units: %). This function is valid only for axes where the return-to-origin method is set as "mark method". It is not valid at axes where the return-to-origin method is set as "sensor" or "stroke end".

• At axes where return-to-origin method is set to "mark" method, absolute reset is possible when the machine reference value is in a 44 to 56% range.

SAMPLE A=ABSRPOS(4) ····· The machine reference value for the main group's axis 4 is assigned to variable A.

ABSRST

Absolute motor axis return-to-origin operation

Format

ABSRST

Explanation This statement executes a direct return-to-origin operation for the robot's absolute motor axes (absolute reset).

The return-to-origin will fail if the robot stops en route.

In systems with a two-robot setting, the main robot group return-to-origin occurs first, followed by the sub robot group return-to-origin.



- This command is valid at axes where the return-to-origin method is set to other than "mark".
- This command cannot be executed if a return-to-origin is incomplete at an axis where the return-to-origin method is set as "mark".
- In systems with both absolute motor axes and incremental motor axes, a return-to-origin will occur only at the absolute motor axes when the ABSRST command is executed.
- The ORIGIN command must be used to perform a return-to-origin at incremental motor axes. Moreover, the return-to-origin operations occur in the parameter-specified sequence, and the incremental motor axes will not operate.

SAMPLE

*ABS RST:

IF DI(20)=1 THEN..... ABSRST executed when DI (20) is "1". **ABSRST**

ENDIF

*START:ABSRST······ Absolute motor return-to-origin occurs.

Related commands

ORIGIN, ORGORD, ORGORD2, MCHREF, MCHREF2

ACCEL / ACCEL2

Specifies/acquires the acceleration coefficient parameter

Format

- 1. ACCEL <expression>
- 2. ACCEL (<axis number>) = <expression>

NOT

 ACCEL2 can be used only if a "sub group" setting has been specified in the system generation. Format sub group

- 1. ACCEL2 <expression>
- 2. ACCEL2 (<axis number>)=<expression>

Values <axis number>.....main group: 1 to 6 sub group: 1 to 4

<expression>......1 to 100 (units: %)

Explanation Directly changes the acceleration coefficient parameters to the value specified by the <expression>. In format 1, the change occurs at all the group axes.

In format 2, the change occurs at the axis specified in <axis number>.



• If an axis that is set to "no axis" in the system generation is specified, a "5.37: Specification mismatch" error message displays and command execution is stopped.

• Changes the value which has been set at SYSTEM > PARAMETER > AXIS > ACCEL. Program-declared values have priority.

Functions

Format main group

ACCEL (<axis 1>)

Format sub group

ACCEL2 (<axis 2>)

 Values
 <axis 1>......main group: 1 to 6

 <axis 2>......sub group: 1 to 4

Explanation The acceleration parameter value is acquired for the axis specified at <axis number>.

SAMPLE

A=50 ACCEL AThe ac

ACCEL A The acceleration coefficient for all axes becomes 50%.

' CYCLE WITH INCREASING ACCELERATION

FOR A=10 TO 100 STEP 10... The acceleration coefficient parameter is increased from 10% to 100% in 10% increments.

ACCEL A MOVE P,P0 MOVE P,P1

NEXT A

A=ACCEL(3) The acceleration coefficient parameter for the main group's axis 3 is assigned to variable A.

HALT "END TEST"

ACCEL / ACCEL2 8-25

A

main group

В

C

D

E

F

G

ы

ı

J

M

ARCH / ARCH2

Specifies/acquires the acceleration coefficient parameter

Format

main group

- 1. ARCH <expression>
- 2. ARCH (<axis number>)=<expression>

NOTE

• ARCH2 can be used only if a "sub group" setting has been specified in the system generation.

Format

sub group

- 1. ARCH2 <expression>
- (<axis number>) = <expression> 2. ARCH2

(Values)

<axis number>.....main group: 1 to 6

sub group: 1 to 4

<expression>......1 to 6144000 (Unit: pulses)

Explanation Changes the parameter's arch position to the value indicated in the <expression>.

In format 1, the change occurs at all the group axes.

In format 2, the change occurs at the arch position parameter for the axis specified in <axis number> to the value specified in <expression>.

MEMO

• If an axis that is set to "no axis" in the system generation is specified, a "5.37: Specification mismatch" error message displays and command execution is stopped.

Functions

Format

main group

ARCH (<axis 1>)

Format

sub group

ARCH2 (<axis 2>)

Values

<axis 1>.....main group: 1 to 6

<axis 2>.....sub group: 1 to 4

Explanation Acquires the arch position parameter value of the axis specified at <axis number>.

```
SAMPLE
DIM SAV(3)
GOSUB *SAVE ARCH
FOR A=1000 TO 10000 STEP 1000
   GOSUB *CHANGE ARCH
  MOVE P, P0, Z=0
  DO3 (0) =1 · · · · · Chuck CLOSE
  MOVE P, P1, Z=0
  DO3 (0) = 0 ..... Chuck OPEN
NEXT A
GOSUB *RESTORE_ARCH
HALT
*CHANGE ARCH:
FOR B=1 TO 4····· The arch position parameters
                         ARCH (1) to (4) are assigned to
                         array variables SAV (0) to (3).
  ARCH(B) = A
NEXT B
RETURN
*SAVE ARCH:
FOR B=1 TO 4
   SAV(B-1) = ARCH(B)
NEXT B
RETURN
*RESTORE ARCH:
FOR B=1 TO 4
  ARCH(B) = SAV(B-1)
NEXT B
RETURN
```

A

В

C

D

E

F

G

ш

(

λA

ARMCND / ARMCND2

Arm status acquisition

Format main group

ARMCND

Format sub group

ARMCND2

Explanation This function acquires the current arm status of the SCARA robot. The arm status is "1" for a left-handed system and "0" for a right-handed system.

This function is enabled only when a SCARA robot is used.

В

C

D

Ε

F

G

Œ

L

ARMTYPE / ARMTYPE2

SCARA robot hand system

Format main group

ARMTYPE

Format sub group

ARMTYPE2

Explanation This function acquires the hand system currently selected for the SCARA robot.

The arm type is "0" for a right-handed system, and "1" for a right-handed system. This function is enabled only when a SCARA robot is used.

SAMPLE
A=ARMTYPE The main robot's arm type
value is assigned.
IF A=0 THEN The arm type is a right-handed system.
MOVE P, P100, Z=0
ELSE The arm type is a left-handed system.
MOVE P, P200, Z=0
ENDIF

A

В

C

D

E

F

Ġ

Н

λA

ATN / ATN2

Acquires the arctangent of the specified value

NOTE

• ATN2 are available in the following software

RCX240 Ver. 10.67 onwards,

Format

ATN (<expression>)

Format

ATN2 (<expression 1>) (<expression 2>)

Explanation ATN:

Acquires the arctangent values of the specified <expression> values. The acquired values are radians within the following range: $-\pi/2$ to $+\pi/2$

ATN2:

Acquires the arctangent values of the specified <expression 1> and <expression 2> X-Y coordinates. The acquired values are radians within the following range: $-\pi$ to $+\pi$

SAMPLE

A(0) = A*ATN(Y/X) The product of the expression (Y/X) arctangent value and variable A is assigned to array A (0). A(0) = ATN(0.5) The 0.5 arctangent value is assigned to array A (0). A(0)=ATN2(B,C)-D The difference between the X-Y coordinates (B,C) arctangent value and variable D is

assigned to array A (0). $A(1) = RADDEG(ATN2(B,C)) \cdots$ The X-Y coordinates (B,C) arctangent value is converted to degrees, and is then assigned to array A (1).

Related commands

COS, DEGRAD, RADDEG, SIN, TAN

ASPEED / ASPEED2

Sets the automatic movement speed

NOTE

• ASPEED2 can be used only if a "sub group" setting has been specified in the system generation.



NOTE

 Automatic movement speed

Specified programming box operation or by the ASPEED / ASPEED2 commands.

• Program movement speed

Specified by SPEED/ SPEED2 commands or MOVE/MOVE2, DRIVE/ DRIVE2 speed settings.

main group **Format** ASPEED <expression>

Format

ASPEED2 <expression>

Values

<expression>.....

. 1 to 100 (units: %)

Explanation Directly changes the automatic movement speed to the value indicated in the <expression>.

> This speed change applies to all the robot axes and auxiliary axes. The operation speed is determined by the product of the automatic movement speed (specified by programming box operation and by the ASPEED/ASPEED2 commands), and the program movement speed (specified by SPEED/SPEED2 commands, etc.).

Operation speed = automatic movement speed x program movement speed.

Example:

Automatic movement speed 80% Program movement speed 50% Movement speed = $40\% (80\% \times 50\%)$

SAMPLE
SPEED 70 ASPEED 100
MOVE P,P0 Movement from the current position to P0 occurs at 70% speed (=100 * 70).
ASPEED 50
MOVE P,P1 Movement from the current position to P1 occurs at 35% speed (=50 * 70).
MOVE P,P2,S=10 Movement from the current position to P2 occurs at 5% speed (=50 * 10).
TIAT O

Related commands

SPEED, SPEED2

sub group

NOTE

 AXWGHT2 can be used only if a "sub group" setting has been specified

in the system generation.

AXWGHT / AXWGHT2

Sets/acquires the axis tip weight

Α

В

C

G

J

M

Format main group

AXWGHT (<axis number>)=<expression>

Format

AXWGHT2 (<axis number>)=<expression>

Values <axis number>.....main group: 1 to 6

<expression>.....Varies according to the specified robot.

Explanation Directly changes the axis tip weight parameter for the group's axis specified by the <axis number> to the <expression> value.

sub group: 1 to 4

This statement is valid in systems with "MULTI" axes and auxiliary axes (the robot type and auxiliary axes are factory set prior to shipment).

sub group

Functions

Format main group

AXWGHT (<axis 1>)

Format sub group

AXWGHT2 (<axis 2>)

Values <axis 1>.....main group: 1 to 6 <axis 2>.....sub group: 1 to 4

Explanation Acquires the value axis tip weight parameter value for the axis specified by the <expression>.

This statement is valid in systems with "MULTI" axes and auxiliary axes.

Related commands WEIGHT, WEIGHT2

CALL Calls a sub-procedure



NOTE

- When a value is passed on to a sub-procedure, the original value of the actual argument will not be changed even if it is changed in the subprocedure.
- When a reference is passed on to a subprocedure, the original value of the actual argument will also be changed if it is changed in the sub-procedure.
- For details, see Chapter 3 "8 Value Pass-Along & Reference Pass-Along".



Format

CALL <label> [(<actual argument> [, <actual argument>...])]

Explanation This statement calls up sub-procedures defined by the SUB to END SUB statements. The <label> specifies the same name as that defined by the SUB statement.

- 1. When a constant or expression is specified as an actual argument, its value is passed on to the sub-procedure.
- 2. When a variable or array element is specified as an actual argument, its value is passed on to the sub-procedure. It will be passed on as a reference if "REF" is added at the head of the actual argument.
- 3. When an entire array (array name followed by parentheses) is specified as an actual argument, it is passed along as a reference.
- CALL statements containing one actual argument can be used up to 15 times in succession. Note that this number is reduced if commands which use stacks such as an IF statement or GOSUB statement are used, or depending on the number of arguments in the CALL statement.

• Always use the END SUB statement to end a sub-procedure which has been called with the CALL statement. If another statement such as GOTO is used to jump out of the sub-routine, a "5.12: Stack overflow" error, etc., may occur.

```
SAMPLE 1
X%=4
Y%=5
CALL *COMPARE ( REF X%, REF Y% )
HALT
' SUB ROUTINE:
                COMPARE
SUB *COMPARE ( A%,
   IF A% < B% THEN
      TEMP%=A%
      A%=B%
      B%=TEMP%
   ENDIF
END SUB
```

```
SAMPLE 2
I = 1
CALL
      *TEST(I)
HALT
' SUB ROUTINE:
                TEST
SUB *TEST
   X = X + 1
   IF X < 15 THEN
      CALL *TEST(X)
   ENDIF
END SUB
```

Related commands

SUB, END SUB, CALL, DECLARE, EXIT SUB, SHARED

CHANGE / CHANGE2

Switches the hand

Format main group

CHANGE Hn

Format sub group

CHANGE2 Hn

values n: The range of hand Nos. which can specified for the main group differs from that for the sub group.

main group 0 to 3 sub group 4 to 7

Explanation CHANGE / CHANGE2 are used to switch the robot hand.

Before hand switching can occur, the hands must be defined at the HAND / HAND2 statements. For details, see section "39 HAND / HAND2".

C

D

Ε

F

G

H

ı

M

CHGPRI

Changes the priority ranking of a specified task

Format

CHGPRI Tn, p

Values

```
n: Task No ......2 to 8
p: Task priority ranking .......17 to 47
```

Explanation Directly changes the priority ranking of the specified task ("n") to "p".

The priority ranking of the main task (Task 1) is fixed as 32.

The smaller the priority number, the higher the priority (high priority: 17 ⇔ low priority: 47).

When a READY status occurs at a task with higher priority, all tasks with lower priority also remain in a READY status.

```
SAMPLE
```

```
START *SUBTASK, T2, 33
*ST:
   MOVE P, P0, P1
   IF DI(20) = 1 THEN
      CHGPRI T2,32
   ELSE
      CHGPRI T2,33
   ENDIF
GOTO *ST
HALT
' SUBTASK ROUTINE
*SUBTASK:
   IF LOCZ(WHERE) > 10000 THEN
      DO(20) = 1
      GOTO *SUBTASK
   ENDIF
   DO(20) = 0
GOTO *SUBTASK
EXIT TASK
```

Related commands

CUT, EXIT TASK, RESTART, SUSPEND, START

CHR\$

Acquires a character with the specified character code

Format

CHR\$ (<expression>)

Values <expression>......0 to 255

Explanation Acquires a character with the specified character code. An error occurs if the <expression> value is outside the 0 to 255 range.

SAMPLE

A\$=CHR\$(65) ····· "A" is assigned to A\$.

Related commands ORD

8

Acquires the cosine value of a specified value

Format

COS (<expression>)

Values

<expression>......Angle (units: radians)

Explanation Acquires a cosine value for the <expression> value.

SAMPLE

A(0)=B*COS(C) ····· The product of the C42 variable's cosine value and variable B is assigned to array A (0).

A(1)=COS(DEGRAD(20)) ······ The 20.0 ° cosine value is assigned to array A (1).

Related commands

ATN, DEGRAD, RADDEG, SIN, TAN

17

CURTRQ / CURTRQ2

Acquires the current torque of the specified axis

Format

main group

CURTRQ (<expression>)



 CURTRQ / CHKTRQ2 are available in the following software versions:

RCX240 Ver. 10.65 onwards, RCX22x Ver. 9.36 onwards

• If the specified axis has been set to "no axis" in the system generation, or if that axis uses the YC-Link or a power gripper, a "5.37: Specification mismatch" error message displays and command execution is stopped.

Format

sub group

CURTRQ2 (<expression>)

(Values)

<expression>.....1 to 6

Explanation Acquires the current torque value (-100 to 100) of the axis specified by the <expression>. The current torque value is expressed as a percentage of the maximum torque command value. Plus/minus signs indicate the direction.

SAMPLE

A = CURTRQ(3) The current torque value of the main group's axis 3 is assigned to variable "A".

COS 8-37

CUT

Terminates another sub task which is currently being executed

Format

CUT Tn

Values

n: Task No2 to 8

Explanation Directly terminates another task which is currently being executed or which is temporarily stopped.

This statement cannot terminate its own task, nor can it terminate Task 1.

```
SAMPLE
' TASK1 ROUTINE
*ST:
   MO(20) = 0
   START *SUBTASK2,T2
   MOVE P, P0
   MOVE P, P1
   WAIT MO(20) = 1
   CUT T2
GOTO *ST
HALT
'TASK2 ROUTINE
*SUBTASK2:
   P100=JTOXY (WHERE)
   IF LOCZ(P100) >= 100.0 THEN
      MO(20) = 1
   ELSE
      DELAY 100
   ENDIF
GOTO *SUBTASK2
EXIT TASK
```

Related commands

EXIT TASK, CUT, RESTART, START, SUSPEND

Format

DATE\$

Explanation Acquires the date as a "yy/mm/dd" format character string.

"yy" indicates the year (last two digits), "mm" indicates the month, and "dd" indicates the day.

Date setting is performed at SYSTEM mode initial processing.

SAMPLE

A\$=DATE\$ PRINT DATE\$ HALT

Related commands

TIME\$

D

DECEL / DECEL2

Specifies/acquires the deceleration rate parameter



NOTE

- The DECEL/DECEL2 statements are only available in software version 8.15 onwards.
- DECEL2 can be used only if a "sub group" setting has been specified in the system generation.

Format

main group

- 1. DECEL <expression>
- 2. DECEL (<axis number>) = <expression>

Format

sub group

sub group

- 1. DECEL2 <expression>
- 2. DECEL2 (<axis number>) = <expression>

Values

<axis number>.....main group: 1 to 6

sub group: 1 to 4

<expression>......1 to 100 (units: %)

Explanation Changes the deceleration rate parameter to the <expression> value.

In format 1, the change occurs at all the group axes.

In format 2, the change occurs at the axis specified in <axis number>.



- If an axis that is set to "no axis" in the system generation is specified, a "5.37: Specification mismatch" error message displays and command execution is stopped.
- Command statements ACCEL/ACCEL2 can be used to change the acceleration parameter.

Functions

main group **Format**

DECEL (<axis 1>)

DECEL2 (<axis 2>)

Values <axis 1>.....main group: 1 to 6 <axis 2>sub group: 1 to 4

Explanation Acquires the deceleration rate parameter value for the axis specified by the <expression>.

SAMPLE

A = 50

Format

DECEL A

DECEL(3) = 100

' CYCLE WITH INCREASING DECELERATION

FOR A =10 TO 100 STEP 10

DECEL A

MOVE P , PO

MOVE P , P1

NEXT A

A=DECEL(3) ····· The deceleration rate parameter for the main group's axis 3 is

assigned to variable A.

HALT "END TEST "

8-40 Chapter 8 Robot Language Lists

DECLARE

Declares that a sub-routine or sub-procedure is to be used within the COMMON program

Format

- 1. DECLARE < label > [, < label > · ··]
- 2. DECLARE SUB <name> [(<dummy argument> [, <dummy argument>]...)]



•Only the following external labels can be used: GOSUB, CALL, ON to GOSUB.

Values	<label>Label of the sub-routine defined in the COMMON</label>
	program.
	<name>Name of the sub-procedure defined in the COMMON</name>
	program.
	<pre><dummy argument="">Sub-procedure argument. Only the "number of</dummy></pre>
	arguments" and the "data type" are significant.

Explanation Directly declares that a label or sub-procedure exists in the COMMON program. If a sub-procedure is declared, the argument's data type is also checked.

This statement cannot be defined within a sub-procedure.

Because the DECLARE statement declares the existence of a label or sub-procedure within the COMMON program, it cannot be used within the COMMON program itself. The DECLARE statement is valid throughout the entire program.

```
SAMPLE
COMMON program shared label
Program name: DIST1
______
  MAIN PROGRAM
DECLARE *DISTANCE, *AREA
X!=2.5
Y!=1.2
GOSUB *DISTANCE
GOSUB *AREA
HALT
Program name: COMMON
______
  'COMMON' PROGRAM
'-----
*DISTANCE:
 PRINT SQR(X!^2+Y!^2)
RETURN
*AREA:
 PRINT X!*Y!
RETURN
```

D

```
Α
```

В

C

D

E

F

G

Н

K

L

```
SAMPLE
External program shared sub-procedure
Program name: DIST2
MAIN PROGRAM
DECLARE SUB *DISTANCE(X!,Y!,D!)
 DECLARE SUB *AREA(X!,Y!,A!)
 CALL *DISTANCE(2. 5,1. 2,REF D!)
 PRINT D!
 CALL *AREA(2. 5,1. 2,REF A!)
 PRINT A!
 HALT
 Program name: COMMON
'-----
   'COMMON' PROGRAM
______
 SUB *DISTANCE(X!,Y!,D!)
   D! = SQR(X!^2 + Y!^2)
 END SUB
 SUB *AREA(X!,Y!,A!)
   A!=X!*Y!
 END SUB
```

Related commands

CALL, EXIT SUB, GOSUB, ON to GOSUB, SUB, END SUB

Defines functions which can be used by the user

\$

Values

<name>Function name. Max. of 16 chars., including "FN". <dummy argument>Numeric or character string variable.

Explanation Defines the functions which can be used by the user. Defined functions are called in the FN <name> (<variable>) format.



- The <dummy argument> names are the same as the variable names used in the <function definition expression>. The names of these variables are valid only when the <function definition expression> is evaluated. There may be other variables with the same name in the program.
- When calling a function that uses a <dummy argument>, specify the constant, variable, or expression type which is the same as the <dummy argument> type.
- If a variable used in the <function definition expression> is not included in the <dummy argument> list, the current value of that particular variable is used for the calculation.
- A space must be entered between "DEF" and "FN". If no space is entered, DEFFN will be handled as a variable.
- The DEF FN statement cannot be used in sub-procedures.
- Definition by the DEF FN statement must be declared before statements which use functions.

```
DEF FNPAI=3.141592
DEF FNASIN(X)=ATN(X/SQR(-X^2+1))

Both the <dummy argument>
and <function definition
expression> use "X".

A=FNASIN(B)*10 "X" is not required for calling.
```

A

В

C

D

E

F

G

ш

K

1

DEF FN ● 8-43

Format

DEGRAD (<expression>)

Values <expression>.....Angle (units: degrees)

Explanation The <expression> value is converted to radians. To convert radians to degrees, use RADDEG.

SAMPLE

A=COS(DEGRAD(30)) \cdots A 30° cosine value is assigned to variable A.

Related commands ATN, COS, RADDEG, SIN, TAN

Λ

В

C

D

E

E

G

H

I

J

K

L

DELAY

Program execution waits for a specified period of time

				٦
Fc	7	0.0		9
l Ka	ИΠ		C I	ı

DELAY <expression>

Values

<expression>......1 to 3600000 (units: ms)

Explanation A "program wait" status is established for the period of time specified by the <expression>. The minimum wait period is 10ms.

SAMPLE

DELAY 3500 3,500ms (3.5 secs) wait

DELAY A*10

D

DI

Format

- 1. [LET] <expression> = DIm([b, · · · ,b])
- 2. [LET] <expression> = DI(mb, · · · , mb)

Values

mPort No.: 0 to 7, 10 to 17, 20 to 27 b Bit definition: 0 to 7

Explanation Indicates the parallel input signal status.

If multiple bits are specified, they are expressed from the left in descending order (large to small).

Enter "0" if no input port exists.

If the [b,...,b] data is omitted, all 8 bits are processed.

SAMPLE

A%=DI2() The input status from DI (27) to DI (20) is assigned to variable A%.

A%=DI5(7,4,0) The DI (57), DI (54), DI (50) input status is assigned to variable A% (when all the above signals are "1" (ON), A% = 7). A%=DI(37,25,20) The DI (37), DI (25), DI (20) input status is assigned to variable A% (when all the above signals except DI (20) are "1" (ON), A% = 6).

Reference

For details, refer to Chapter 3 "9.5 Parallel input variable".

Acquires the distance between 2 specified points

Format

DIST (<point expression 1>,<point expression 2>)

Values

<point expression 1>.....Cartesian coordinate system point <point expression 2>.....Cartesian coordinate system point

Explanation Acquires the distance (X,Y,Z)between the 2 points specified by <point expression 1> and <point expression 2>. An error occurs if the 2 points specified by each <point expression> do not have a Cartesian coordinates.

SAMPLE

A=DIST(P0,P1) The distance between P0 and P1 is assigned to variable A.

D

27

Declares array variable

Format

DIM <array definition> [, <array definition>, …]

Array definition

Values <constant>Array subscript: 0 to 32,767 (positive integer)

Explanation Directly declares the name and length (number of elements) of an array variable. A maximum of 3 dimensions may be used for the array subscripts. Multiple arrays can be declared in a single line by using comma (, ,) breakpoints to separate the arrays.

 \bullet Array subscripts can be "0 to a specified value", with their total number being the <constant> + 1.

.....

• A "9.31: Memory full" error may occur depending on the size of each dimension defined in an array.

SAMPLE

```
DIM A%(10) ...... Defines a integer array variable A% (0) to A% (10).

(Number of elements: 11).

DIM B(2,3,4) .... Defines a real array variable B (0, 0, 0) to B (2, 3, 4).

(Number of elements: 60).

DIM C%(2,2),D!(10) ... Defines an integer array C% (0,0) to C% (2,2) and a real array D! (0) to D! (10).
```

U

A

B

C

D

F

Ţ

G

Н

1

J

Format

1. [LET] DOm ([b, \cdots , b]) = <expression> DO $(mb, \cdot \cdot \cdot, mb)$ 2. [LET] = <expression>

Values

b: Bit definition 0 to 7

The output value is the lower left-side bit of the integer-converted <expression> value.

Explanation Directly outputs the specified value to the DO port.

If multiple bits are specified, they are expressed from the left in descending order (large to small).

No output will occur if a nonexistent DO port is specified.

If the [b,...,b] data is omitted, all 8 bits are processed.

Outputs are not possible to DO0() and DO1(). These ports are for referencing only.

SAMPLE

DO2() = &B10111000 ····· DO (27, 25, 24, 23) are turned ON, and DO (26, 22, 21, are turned OFF. $DO2(6,5,1) = \&B010 \cdots DO(25)$ are turned ON, and DO (26, 21) are turned OFF. DO3() = 15 ····· DO (33, 32, 31, 30) are turned ON, and DO (37, 36, 35, 34) are turned OFF. $DO(37,35,27,20) = A \cdots$ The contents of the 4 lower bits acquired when variable A is converted to an integer are output to DO (37, 35, 27, 20) respectively.

Related commands

RESET, SET

DRIVE / DRIVE2

Executes absolute movement of specified axes

Format

main group

DRIVE(<axis number>, <expression>)[,(<axis number>, <expression>)...] [, option]

Format

sub group

DRIVE2(<axis number>, <expression>)[,(<axis number>, <expression>)...] [, option]

(Values)

<axis number>.....main group: 1 to 6

sub group: 1 to 4

<expression>......Motor position (mm, degrees, pulses) or point expression

Explanation Executes absolute movement commands for specified axes within a group.

This command is also used in the same way for the group's auxiliary axes.

- Movement type: PTP movement of specified axis.
- Point setting method: By direct numeric value input and point definition.
- Options: Speed setting, STOPON conditions setting, torque limit setting, XY setting. movement direction setting.

Movement type

PTP (Point to Point) movement of specified axis:

PTP movement begins after positioning of all axes specified at <axis number> is complete (within the tolerance range), and the command terminates when the specified axes enter the OUT position range. When two or more axes are specified, they will reach their target positions simultaneously.


If the next command following the DRIVE / DRIVE2 command is an executable command such as a signal output command, that next command will start when the movement axis enters the OUT position range. In other words, that next command starts before the axis arrives within the target position tolerance range.


Example:

Signal output (DO, etc.)	Signal is output when axis enters within OUT position range.
DELAY	DELAY command is executed and standby starts, when axis enters the OUT position range.
HALT	Program stops and is reset when axis enters the OUT position range. Therefore, axis movement also stops.
HOLD	Program temporarily stops when axis enters the OUT position range. Therefore, axis movement also stops.
WAIT	WAIT command is executed when axis enters the OUT position range.

The WAIT ARM / WAIT ARM2 statements are used to execute the next command after the axis enters the tolerance range.

DRIVE command





33819-R7-00

SAMPLE

DRIVE(1,P0)......Axis 1 moves from its current position to the position specified by P0.

Point data setting types

• Direct numeric value input

The motor position is specified directly in <expression>.

If the motor position's numeric value is an integer, this is interpreted as a "pulse" units. If the motor position's numeric value is a real number, this is interpreted as a "mm/degrees" units, and each axis will move from the 0-pulse position to a pulse-converted position.

However, when using the optional XY setting, movement occurs from the coordinate origin position.

A

В

C

D

Ė

r

K

L

DRIVE / DRIVE2

Point definition

Point data is specified in <expressions>. The axis data specified by the <axis number> is used. If the point expression is in "mm/degrees" units, movement for each axis occurs from the 0-pulse position to the pulse-converted position.

However, when using the optional XY setting, movement occurs from the coordinate origin position.

SAMPLE

DRIVE(1,P1)	····· Main	group's ax	xis 1 moves	from its current
	posi	tion to the	e position	specified by P1.

DRIVE (4, P90) Axis 4 moves from its current position to the position specified by P90 (deg) relative to the 0 pulse position. (When axis 4 is a rotating axis.)

Option types

Speed setting

Format

- SPEED =<expression> 1.
- 2. S =<expression>

Values <expression>......1 to 100 (units: %)

(Explanation) The program's movement speed is specified as an <expression>.

The actual speed is determined as shown below.

• Robot's max. speed (mm/sec, or deg/sec) × automatic movement speed (%) × program movement speed (%).

This option is enabled only for the specified DRIVE/ DRIVE2 statement.

SAMPLE

DRIVE2(1,10000), S=10 ····· Sub group's axis 1 moves from its current position to the 10000 pulses position at 10% of the automatic movement speed.

Format

- 1. DSPEED =<expression>
- 2. DS =<expression>

Values

> The axis movement speed is specified in <expression>. The actual speed is determined as shown below.

• Robot's max. speed (mm/sec, or deg/sec) × axis movement speed (%).

This option is enabled only for the specified DRIVE/ DRIVE2 statement.

• Movement always occurs at the DSPEED <expression> value (%) without being affected by the automatic movement speed value (%).

SAMPLE

Explanation

DRIVE2(1,10000), DS=0.1 ·· Sub group's axis 1 moves from its current position to the 10000 pulses position at 0.1% of the robot's maximum speed.



NOTE • If point data is specified

> with both integers and real numbers in the same statement, all values are handled in "mm/degrees" units.

> > NOTE

specified speed.

• This defines the maximum speed, and does not guarantee that all

movement will occur at



NOTE

Speed setting (DSPEED) is available only in the following software versions:

RCX14x Ver. 8.71 onwards, RCX22x Ver. 9.18 onwards

• SPEED option and DSPEED option cannot be used together

STOPON conditions setting

Format

STOPON <conditional expression>

Explanation

Stops movement when the conditions specified by the conditional expression are met. Because this is a deceleration type stop, there will be some movement (during deceleration) after the conditions are met.

If the conditions are already met before movement begins, no movement occurs, and the command is terminated.

This option is enabled only by program execution.

SAMPLE

DRIVE(1,10000),STOPON DI(20)=1 Axis 1 moves from

 This parameter is only available in the following

RCX14x Ver. 8.63 onwards

RCX22x Ver. 9.08 onwards

•On earlier version

controllers, -1 is "true" and

a value other than -1 is

"false" (not changeable).

software versions:

CAUTION

- The torque limit setting's "torque offset setting" is available from software version 8.18 onwards.
- The torque limit setting cannot be used at axes where YC-Link is connected, or at axes where a power gripper is being used. Attempts to specify this setting at these axes results in a "5.37 Specification mismatch" message, and command execution is stopped.
- The torque limit setting range differs depending on the robot model.
 Setting a torque limit higher than the maximum level may cause robot malfunctions or failure.
- If the specified torque limit value is too small, the axis movement may not occur. Moreover, vertical axes may fall.

When the conditional expression used to designate the STOPON condition is a numeric
expression, the conditions for determining a TRUE or FALSE status can be changed at the
controller's "TRUE conditions" in the "Other parameters" mode.

These conditions apply to all the IF, WHILE, WAIT, STOPON, etc., conditional expressions. For details, refer to the controller manual.

1) -1 (default setting) An expression value of "-1" indicates a TRUE status, and "0" indicates

a FALSE status. A "6.35: Incorrect condition expression" error occurs if the expression value is other than "-1" or "0".

2) not 0 Any expression value other than "0" indicates a TRUE status, and "0" $\,$

indicates a FALSE status.

Torque limit setting

Format

1. T =<torque limit value>

2. T = (<torque limit value> [, <torque offset value>])

Values <torque limit value>......1 to 100 (units: %) <torque offset value>.....-100 to 100

Explanation

The axis moves while limiting the motor torque.

Specify the torque offset value for the axis, to which a constant load is applied, such as axis with the vertical specifications.

- Torque limit value: Rated torque x <torque limit value>/100
- Torque offset value: Value displayed on the current command monitor (Axis stops in the servo hold state.)

When this value is omitted or format 1 is used, the torque offset value is set to "0".

MEMO

• The current command monitor can be displayed by pressing the [DISPLAY] key at the programming box. For details, refer to the controller manual.

D

E

F

ш

J

. .

























NOTE

- Conditions for ending this command (described at right) are only valid from software version 8.45 onwards. On earlier version controllers, this command ends at the following times:
- 1. When, at the point when the time required to move to the target position has elapsed. the axis has reached the target position.
- 2. When, at the point when the time required to move to the target position has elapsed, the axis torque has already reached the limit value for 1 second or longer.
- 3. When, at the point when the time required to move to the target position has elapsed, the torque has reached the limit value, with this status continuing for 1 second or longer.



CAUTION

• In driver versions prior to Ver.2.17, the maximum torque instruction is enabled at the point when it is changed by the TORQUE / TORQUE2 statement.

When the DRIVE / DRIVE2 statement is executed with this option specified, the axis moves to the target position while controlling the torque by changing the maximum torque for the axis to the <torque limit value>.

The maximum movement speed at this time is 10% of the normal operating speed. No errors will occur even if the axis strikes an obstacle during movement, and the axis torque (thrust) will not exceed the limit value.

• Command END conditions

- The command ends when the axis has reached the target position.
- The command ends when the time (timeout period) specified by the TRQTIME / TRQTIME2 statement has elapsed while the axis torque (thrust) has reached the limit value.

• TRQSTS command value

- 1 is set at the TRQSTS function when this command has ended due to a timeout during which the axis torque has reached its limit value.
- 2. "0" is set if the command was ended for any other reason.

Cautions

- 1. Maximum torque command values which have been changed by the TORQUE / TORQUE2 statements do not immediately become effective. They become effective at the next movement command (MOVE or DRIVE statement, etc.).
- Even after this command ends, the maximum torque limit and torque control status remain in effect. The same applies if a stop occurs due to an interlock, etc., while this command is being executed.
- 3. Torque control is canceled when an axis related operation is executed. Such operations include servo ON/OFF switching, and a MOVE command execution, etc.
- To cancel the maximum torque limit, use the TORQUE statement to specify a new maximum torque command value.
- Maximum torque limit is cancelled at the following times regardless of whether or not a TORQUE statement is used:
 - When the controller power is turned ON.
 - When the servo is turned OFF.
 - When a return-to-origin or an absolute reset (except by the mark method) is executed.
 - When parameter data has been changed or initialized.

Restrictions

- 1. Two or more axes cannot be specified with this option.
- 2. Maximum movement speed is set as 10% of the normal operating speed.
- 3. Manual movement is not possible at axes which are under torque control (axes where this command has been executed).

SAMPLE TRQTIME(3) = 2500 ······ Sets the axis 3 torque control time-out period as 2.5 seconds. DRIVE(3,P1), $T = (20,15) \cdot \cdot \cdot$ Sets the maximum torque value to 20% of the rated torque, and the torque offset to 15, and moves the axis 3 from its current position to the point specified by P1 (pushing action). IF TRQSTS(3) = 1 THEN····· Checks to see if a time-out has occurred. DO(21) = 1 ····· Time-out occurred (pushing is complete). (Result is output to DO(21) in this example.) ELSE DO(21) = 0 ····· Time-out has not occurred. (Reached target position but failed to complete pushing.) (Result is output to DO(21) in this example.) ENDIF TORQUE(3) = 100 ······ Maximum torque command value is returned to original value (100%). DRIVE(3, P0) ····· Torque limit and torque control end, and movement to P0 occurs.

XY setting

Format

XY

Explanation

Moves multiple specified axes to a position specified by Cartesian coordinates.

All the specified axes arrive at the target position at the same time.

If all axes which can be moved by MOVE / MOVE2 statements have been specified, operation is identical to that which occurs when using MOVE / MOVE2 statements.

The following restrictions apply to this command:

- 1. Axes specified by <axis number> must include the axis 1 and 2.
- 2. This command can be specified at SCARA robots and XY robots.
- 3. Point settings must be in "mm" or "deg" units (real number setting).

SAMPLE

The "movement direction

setting" option is available

in the following software

RCX240 Ver.10.66 onwards

RCX22x Ver.9.39 onwards

versions:

D

Movement direction setting

Format

PLS MNS

Explanation

<With a "movement direction setting">

- Movement occurs in the specified direction. A PLS setting always results in plus-direction movement, and a MNS setting always results in minus-direction movement.
- If the target position and the current position are the same, a 1-cycle movement amount occurs in the specified direction, then operation stops.

< Without a "movement direction setting">

- Movement occurs in the direction in which the movement distance is shortest.
- If the target position and the current position are the same, no movement occurs.

Cautions

- 1. When using this option, the maximum movement distance per operation is the distance equivalent to 1 cycle (360°). If movement which exceeds the 1-cycle distance is desired, the movement must be divided into 2 or more operations.
- When using this option, the DRIVE statement's soft limit values are as shown below.

Plus-direction soft limit: 67,000,000 [pulse] Minus-direction soft limit: -67,000,000 [pulse]

• Restrictions

- 1. Only the axis of a single-axis rotary type robot can be specified.
- 2. Simultaneous movement of multiple axes is not possible when a movement direction has been specified. If such movement is attempted, the "5.37: Specification mismatch" error will occur (see below).

Example: DRIVE (3,P1), (4,P1), PLS

- 3. The PLS and MNS options cannot both be specified simultaneously.
- 4. Attempting to use this option for a "limitless motion INVALID" axis will result in the "2.29: Cannot move without the limit" error.
- 5. If a stop is executed by pressing the [STOP] key, etc., during movement which uses this option (including during a deceleration), the movement distance when restarted will be equivalent to a 1-cycle distance (360°).

```
SAMPLE
DRIVE (4,270.00), PLS
     ......When the robot current position is 260°:
            Moves 10° in the plus direction from the
            current position.
            When the robot current position is 280°:
            Moves 350° in the plus direction from the
            current position.
DRIVE (4,270.00), MNS
     ......When the robot current position is 260°:
            Moves 350° in the minus direction from the
            current position.
            When the robot current position is 280°:
           Moves 10° in the minus direction from the
            current position.
DRIVE (4,270.00)
     ......When the robot current position is 260°:
           Moves 10° in the plus direction from the
            current position.
            When the robot current position is 280°:
           Moves 10° in the minus direction from the
            current position.
DRIVE2 (3,270.00), PLS
     ......When the robot current position is 260°:
            Moves 10° in the plus direction from the
            current position.
            When the robot current position is 280°:
           Moves 350° in the plus direction from the
            current position.
DRIVE2 (3,270.00), MNS
     ......When the robot current position is 260°:
            Moves 350° in the minus direction from the
            current position.
            When the robot current position is 280°:
           Moves 10° in the minus direction from the
            current position.
DRIVE2 (3,270.00)
     ......When the robot current position is 260°:
            Moves 10° in the plus direction from the
            current position.
            When the robot current position is 280°:
            Moves 10° in the minus direction from the
```

Related commands

TORQUE, TORQUE2, TRQTIME, TRQTIME2, TRQSYS, TRQSYS2, CURTRQ, CURTRQ2

current position.

DRIVEI / DRIVEI2

Moves the specified robot axes in a relative manner

Format

main group

DRIVEI(<axis number>, <expression>)[,(<axis number>, <expression>)...] [,option]

Format

sub group

DRIVEI2(<axis number>, <expression>)[,(<axis number>, <expression>)...][,option]

Values

<axis number>.....1 to 4

<expression>......Motor position (mm, deg, pulses) or point expression.

Explanation Directly executes relative movement of each axis of a group, including the group's auxiliary axes.

.....

• Movement type: PTP movement of a specified axis

• Point data setting: Direct coordinate data input, point definition Speed setting, STOPON conditions setting

MEMO



NOTE

This parameter is available in the following software version:

RCX14x Ver. 8.66 onwards RCX22x Ver. 9.13 onwards

• In version prior to those shown above, a RESET must be performed at the controller.

 When DRIVEI motion to the original target position is interrupted and then restarted, the target position for the resumed movement can be selected as the "MOVEI/DRIVEI start position" in the controller's "other parameters". For details, refer to the controller manual.

1) KEEP (default setting) Continues the previous (before interruption) movement. The original

target position remains unchanged.

2) RESET Relative movement begins anew from the current position. The new

target position is different from the original one (before interruption).

(Backward compatibility)

Movement type

PTP (point-to-point) of specified axis

PTP movement begins after positioning of all axes specified at <axis number> is complete (within the tolerance range), and the command terminates when the specified axes enter the OUT position range. When two or more axes are specified, they will reach their target positions simultaneously.

If the next command following the DRIVEI / DRIVEI2 command is an executable command such as a signal output command, that next command will start when the movement axis enters the OUT position range. In other words, that next command starts before the axis arrives within the target position tolerance range.


Example:


Signal output (DO, etc.)	Signal is output when axis enters within OUT position range.
DELAY	DELAY command is executed and standby starts, when axis enters the OUT position range.
HALT	Program stops and is reset when axis enters the OUT position range. Therefore, axis movement also stops.
HOLD	Program temporarily stops when axis enters the OUT position range. Therefore, axis movement also stops.
WAIT	WAIT command is executed when axis enters the OUT position range.

The WAIT ARM / WAIT ARM2 statements are used to execute the next command after the axis enters the tolerance range.

DRIVEI command

WAIT ARM statement





33820-R7-00



 The "limitless motion" function is available in the following software versions:

RCX240 Ver.10.66 onwards RCX22x Ver.9.39 onwards

Limitless motion related cautions

• When the "limitless motion" parameter is enabled, the DRIVEI / DRIVEI2 statement soft limit check values are as follows:

Plus-direction soft limit: 67,000,000 [pulse]
Minus-direction soft limit: -67,000,000 [pulse]

•When using the DRIVEI / DRIVEI2 statements, the above values represent the maximum movement distance per operation.

SAMPLE

DRIVEI(1,P0).....The axis 1 moves from its current position to the position specified by P0.

A

В

C

D

-

G

Ы

J

Ė

30

NOTE

units.

• If point data is specified

with both integers and

real numbers in the same statement, all values are

handled in "mm/degrees"

Point data setting types

Direct numeric value input

The motor position is specified directly in <expression>.

If the motor position's numeric value is a real number, this is interpreted as a "mm / deg" units, and each axis will move from the 0-pulse position to a pulse-converted position.

SAMPLE	
DRIVEI(1,10000)	The axis 1 moves from its
	current position to the
DRIVET (4 90 00)	"+10000 pulses" position The axis 4 moves from its current
DRIVER (1, 30:00)	position to the +90° position
	(when axis 4 is a rotating axis).

Point definition

Point data is specified in <expression>. The axis data specified by the <axis number> is used. The motor position is determined in accordance with the point data defined by the point expression. If the point expression is in "mm/degrees" units, movement for each axis occurs from the 0-pulse position to the pulse-converted position.

SAMPLE
DRIVEI(1,P1) The axis 1 moves from its current position the distance specified by P1.
DRIVEI(4, P90) The axis 4 moves from its current position the number of degrees specified by P90 (when axis 4 is a rotating axis).

Option types

Speed setting

Format

- 1. SPEED=<expression>
- S=<expression> 2.



• This defines the maximum speed, and does not guarantee that all movement will occur at specified speed.



<expression>......1 to 100 (units: %)

Explanation

The program's movement speed is specified by the <expression>.

The actual speed is as follows:

 \bullet Robot's max. speed (mm/sec, or deg/sec) \times automatic movement speed (%) \times program movement speed (%).

This option is enabled only for the specified DRIVEI / DRIVEI2 statement.

SAMPLE

DRIVEI(1,10000), S=10 ····· The axis 1 moves from its current position to the +10000 pulses position at 10% of the automatic movement speed.

Format

- 1. DSPEED=<expression>
- 2. DS=<expression>

Values

Explanation

The axis movement speed is specified as an <expression>.

The actual speed is determined as shown below.

• Robot's max. speed (mm/sec, or deg/sec) × axis movement speed (%). This option is enabled only for the specified DRIVEI / DRIVEI2 statement.

• Movement always occurs at the DSPEED <expression> value (%) without being affected by the automatic movement speed value (%).

SAMPLE

DRIVEI(1,10000), DS=0.1 $\cdot\cdot$ The axis 1 moves from its current position to the +10000 pulses position at 0.1% of the automatic movement speed.





 Speed setting (DSPEED) is available only in the following software versions:

RCX14x Ver. 8.71 onwards, RCX22x Ver. 9.18 onwards

• SPEED option and DSPEED option cannot be used together.

DRIVEI / DRIVEI2 8-61

D

STOPON conditions setting

Format

STOPON < conditional expression>

Explanation

Stops movement when the conditions specified by the conditional expression are met. Because this is a deceleration type stop, there will be some movement (during deceleration) after the conditions are satisfied.

If the conditions are already satisfied before movement begins, no movement occurs, and the command is terminated.

This option is enabled only by program execution.



NOTE

 This parameter is only available in the following software versions:

RCX14x Ver. 8.63 onwards RCX22x Ver. 9.08 onwards

 On earlier version controllers, -1 is "true" and a value other than -1 is "false" (not changeable). When the conditional expression used to designate the STOPON condition is a numeric
expression, the conditions for determining a TRUE or FALSE status can be changed at the
controller's "TRUE conditions" in the "Other parameters" mode. These conditions apply to all
the IF, WHILE, WAIT, STOPON, etc., conditional expressions. For details, refer to the controller
manual.

1) -1 (default setting) An expression value of "-1" indicates a TRUE status, and "0" indicates

a FALSE status.

A "6.35: Incorrect condition expression" error occurs if the expression

value is other than "-1" or "0".

2) not 0 Any expression value other than "0" indicates a TRUE status, and "0"

indicates a FALSE status.

SAMPLE

DRIVEI(1, 10000), STOPON DI(20) = 1

END SELECT

Ends the SELECT CASE statement

```
Format
SELECT [CASE] <expression>
   CASE <expression's list 1>
      [command block 1]
   CASE <expression's list 2>
      [command block 2]
   [CASE ELSE
      [command block n]
END SELECT
```

Explanation Directly ends the SELECT CASE command block. For details, see section "87 SELECT CASE".

```
SAMPLE
WHILE -1
SELECT CASE DI3()
   CASE 1,2,3
      CALL *EXEC(1,10)
   CASE 4,5,6,7,8,9,10
      CALL *EXEC(11,20)
   CASE ELSE
      CALL *EXEC(21,30)
END SELECT
WEND
HALT
```

Related commands

SELECT CASE

END SUB

Ends the sub-procedure definition

```
Format
```

```
SUB <label> [(<dummy argument> [, <dummy argument>...])]
  <command block>
END SUB
```

Explanation Ends the sub-procedure definition which begins at the SUB statement. For details, see section "99 SUB to ENDSUB".

```
SAMPLE 1
 I=1
 CALL *TEST
 PRINT I
 HALT
 ' SUB ROUTINE: TEST
 SUB *TEST
   I = 50
 END SUB
```

Related commands

CALL, EXIT SUB, SUB to END SUB

ERR / ERL

Acquires the error code / error line No

Format

ERR

ERL

Explanation Variables ERR and ERL are used in error processing routines specified by the ON ERROR GOTO statement.

> ERR gives the error code of the error that has occurred, and ERL gives the line number in which the error occurred.

SAMPLE 1

IF ERR <> &H604 THEN HALT IF ERL=20 THEN RESUME NEXT

Related commands

ON ERROR GOTO, RESUME

EXIT FOR

Terminates the FOR to NEXT statement loop

Format

EXIT FOR

Explanation Directly terminates the FOR to NEXT statement loop, then jumps to the command which follows the NEXT statement.

This statement is valid only between the FOR to NEXT statements.



• The FOR to NEXT statement loop will end when the FOR statement condition is satisfied or when the EXIT FOR statement is executed. A "5.12: Stack overflow" error, etc., will occur if another statement such as GOTO is used to jump out of the loop.

.....

SAMPLE

```
*ST:
WAIT DI(20)=1
FOR A%=101 TO 109
  MOVE P, P100, Z=0
  DO(20) = 1
  MOVE P,P[A%],Z=0
  DO(20) = 0
  IF DI(20)=0 THEN EXIT FOR
NEXT A%
GOTO
      *ST
HALT
```

Related commands

FOR, NEXT

EXIT SUB

Terminates the sub-procedure defined by SUB to END

Format

EXIT SUB

Explanation The EXIT SUB statement terminates the sub-procedure defined by the SUB to END SUB statements, then jumps to the next command in the CALL statement that called up the sub-procedure.

> This statement is valid only within the sub-procedure defined by the SUB to END SUB statements.



• To end the sub-procedure defined by the SUB to END SUB statements, use the END SUB statement or EXIT SUB statement. A "5.12: Stack overflow" error, etc., will occur if another statement such as GOTO is used to jump out of the loop.

```
SAMPLE
MAIN ROUTINE
CALL
     *SORT2(REF X%, REF Y%)
HALT
' SUB ROUTINE: SORT
SUB *SORT2(X%, Y%)
   IF X%>=Y% THEN EXIT SUB
   TMP%=Y%
   Y%=X%
   X%=TMP%
END SUB
```

Related commands

CALL, SUB to END SUB, END SUB

Format

EXIT TASK

Explanation Terminates its own task which is currently being executed.

This statement is valid for all tasks other than task 1 (Task 1 cannot be terminated).



• Even if a task that has started as a subtask jumps to another task processing routine with a statement such as GO TO, that processing routine is then executed as this subtask processing.

```
SAMPLE
'TASK1 ROUTINE
*ST:
   MO(20) = 0
   START *SUBTASK2,T2
   MOVE P, P0, P1
   WAIT MO(20)=1
   GOTO *ST
HALT
' TASK2 ROUTINE
*SUBTASK2:
   P100=JTOXY (WHERE)
   IF LOCZ(P100)>=100.0 THEN
      MO(20) = 1
      EXIT TASK
   ENDIF
   DELAY 100
GOTO *SUBTASK2
EXIT TASK
```

Related commands

CUT, RESTART, START, SUSPEND, CHGPRI

A

В

C

D

E

F

G

Ŀ

M

FOR to NEXT

Performs loop processing until the variable-specified value is exceeded

Format

```
FOR <control variable> = <start value> TO <end value> [STEP] <step>]
   <command block>
NEXT [<control variable>]
```

Explanation These direct statements repeatedly execute commands between the FOR to NEXT statements for the <start value> to <end value> number of times, while changing the <control variable> value in steps specified by <STEP>. If <STEP> is omitted, its value becomes "1".

The <STEP> value may be either positive or negative.

The <control variable> must be a numeric <simple variable> or <array variable>.

The FOR and NEXT statements are always used as a set.

```
SAMPLE
```

```
'CYCLE WITH CYCLE NUMBER OUTPUT TO DISPLAY
FOR A=1 TO 10
   MOVE P, PO
   MOVE P, P1
   MOVE P, P2
   PRINT"CYCLE NUMBER=";A
NEXT A
HALT
```

Related commands

EXIT FOR

GOSUB to RETURN

Jumps to a sub-routine

```
Format
GOSUB < label>
                     * GOSUB can also be expressed as "GO SUB".
<label>:
RETURN
```

Explanation Jumps to the <label> sub-routine specified by the GOSUB statement.

A RETURN statement within the sub-routine causes a jump to the next line of the GOSUB statement.



- The GOSUB statement can be used up to 29 times in succession. Note that this number of times is reduced if commands containing a stack such as an IF statement or CALL statement are used.
- When a jump to a subroutine was made with the GOSUB statement, always use the RETURN statement to end the subroutine. If another statement such as GOTO is used to jump out of the subroutine, an error such as "5.12: Stack overflow" may occur.

```
SAMPLE
*ST:
MOVE P, P0
GOSUB *CLOSEHAND
MOVE P, P1
GOSUB *OPENHAND
GOTO *ST
HALT
' SUB ROUTINE
*CLOSEHAND:
   DO(20) = 1
RETURN
*OPENHAND:
   DO(20) = 0
RETURN
```

Related commands

RETURN

```
Format
```

GOTO <label> * GOTO can also be expressed as "GO TO".

Explanation Executes an unconditional jump to the line specified by <label>.

To select a conditional jump destination, use the ON to GOTO, or IF statements.

```
SAMPLE
```

```
'MAIN ROUTINE

*ST:

MOVE P,P0,P1

IF DI(20) = 1 THEN

GOTO *FIN

ENDIF

GOTO *ST

*FIN:

HALT
```

A

D)

C

D

E

F

G

Н

HALT

Stops the program and performs a reset

Explanation Directly stops the program and resets it. If restarted after a HALT, the program runs from its beginning.



- If an <expression> or <character string> is written in the statement, the contents of the <expression> or <character string> are displayed on the programming box screen.
- If a "_SELECT" program name exists, processing will switch to that "_SELECT" program after the HALT command is executed.

```
MAIN ROUTINE

*ST:
    MOVE P,P0,P1
    IF DI(20) = 1 THEN
        GOTO *FIN
    ENDIF
GOTO *ST
    *FIN:
    HALT "PROGRAM FIN"
```


In PTP movement specified by movement commands such as MOVE and DRIVE, the next line's command is executed when the axis enters the OUT position range.

Therefore, if a HALT command exists immediately after a PTP movement command, that HALT command is executed before the axis arrives in the target position tolerance range.

Likewise, in interpolation movement during MOVE/MOVE2 commands, the next command is executed immediately after movement starts. Therefore, if a HALT command exists immediately after the interpolation movement command during MOVE/MOVE2, that HALT command is executed immediately after movement starts.

In either of the above cases, use the WAIT ARM/WAIT ARM2 command if desiring to execute the HALT command after the axis arrives within the target position tolerance range.

HALT command



33821-R7-00

Reference

For details regarding "_SELECT", see Chapter 1 "4 Program Names".

A

В

C

ע

Ш

K

L

HAND / HAND2

Defines the hand

Format main group

Definition statement:

HAND Hn = <1st parameter> <2nd parameter> <3rd parameter> [R]
Selection statement:

CHANGE Hn

Format sub group

Definition statement:

HAND2 Hn = <1st parameter> <2nd parameter> <3rd parameter> [R]
Selection statement:

CHANGE2 Hn

Values n: hand No......main group: 0 to 3 \rightarrow HAND is used. sub group: 4 to 7 \rightarrow HAND2 is used.

Explanation The HAND / HAND2 statement only defines the hand. To actually change hands, the CHANGE / CHANGE2 statement must be used.

For CHANGE / CHANGE2 statement details, see section "12 CHANGE / CHANGE2".

MEMO

• If a power OFF occurs during execution of the hand definition statement, the "9.7 Hand check-sum error" may occur.

41.1 For SCARA Robots

1. When the <4th parameter> "R" is not specified


Hands installed on the second arm tip are selected (see below).

<1st parameter> Number of offset pulses between the standard second arm position and the virtual second arm position of hand "n". "+" indicates the counterclockwise direction [pulse].

<2nd parameter> Difference between the hand "n" virtual second arm length and the standard second arm length. [mm]

<3rd parameter> Z-axis offset value for hand "n". [mm]

When the <4th parameter> "R" is not specified:



33801-R7-00

В

•

J

41

В

C

D


E

F


ı


K

L



SAMPLE:HAND





2. When the <4th parameter> "R" is specified

If the R-axis uses a servo motor, the hands that are offset from the R-axis rotating center are selected (see below).

<1st parameter> When the current position of R-axis is 0.00, this parameter shows


the angle of hand "n" from the X-axis plus direction in a Cartesian coordinate system. ("+"indicates the counterclockwise direction.)

[degree]

<2nd parameter> Length of hand "n". [mm] (>0)

<3rd parameter> Z-axis offset amount for hand "n". [mm]


When the <4th parameter> "R" is specified




33803-R7-00

SAMPLE						
HAND H1=	0.00	150.0	0.0	R		
HAND H2=	-90.00	100.00	0.0	R		
P1=	150.00	300.00	0.00	0.00	0.00	0.00
CHANGE H1	L					
MOVE P, P1	L	• • • • • • • • • • • • • • • • • • • •	·· Tip of	hand 1	moves to	P1. 1
CHANGE H2	2					
MOVE P, P1	L	• • • • • • • • • • • • • • • • • • • •	·· Tip of	hand 2	moves to	P1. 2
HALT						

SAMPLE:HAND





33804-R7-00

41.2

HAND / HAND2


For Cartesian Robots

1. When the <4th parameter> "R" is not specified

Hands installed on the second arm tip are selected (see below).

<1st parameter> Hand "n" X-axis offset amount [mm] <2nd parameter> Hand "n" Y-axis offset amount [mm] <3rd parameter> Hand "n" Z-axis offset amount [mm]


When the <4th parameter> "R" is not specified




33805-R7-00

SAMPLE HAND H1= 0.00 0.00 0.00 HAND H2= 100.0 -100.0 -100.0 P1= 200.00 250.00 0.00 0.00 0.00 0.00 CHANGE H2 MOVE P, P1 ····· Tip of hand 2 moves to P1. 1 CHANGE H1 MOVE P, P1 ····· Tip of hand 1 moves to P1. 2 HALT

SAMPLE:HAND





■ 2. When the <4th parameter> "R" is specified


If the R-axis uses a servo motor, the hands that are offset from the R-axis rotating center are selected (see below).

[degree]

<2nd parameter> Length of hand "n". [mm] (>0)

<3rd parameter> Z-axis offset amount for hand "n". [mm]


When the <4th parameter> "R" is specified




33807-R7-00

SAMPLE						
HAND H1=	0.00	100.00	0.00	R		
HAND H2=	90.00	150.00	0.00	R		
P1=	200.00	250.00	0.00	0.00	0.00	0.00
CHANGE H2	2					
MOVE P, P1			·Tip o	f hand 2	moves to	P1. 1
CHANGE H1	<u>-</u>					
MOVE P, P1			·Tip o	f hand 1	moves to	P1. 2
HALT						

SAMPLE:HAND





D

G

Н

L

Format HOLD [<expression> <character string>

Explanation Temporarily stops the program. When restarted, processing resumes from the next line after the HOLD statement. If an <expression> or <character string> is written in the statement, the contents of the <expression> or <character string> display on the programming box screen.

```
SAMPLE
' MAIN ROUTINE
*ST:
   MOVE P, P0, P1
   IF DI(20)=1 THEN
      HOLD "PROGRAM STOP"
   ENDIF
GOTO *ST
HALT
```


In PTP movement specified by movement commands such as MOVE and DRIVE, the next line's command is executed when the axis enters the effective OUT position range.

Therefore, if a HOLD command exists immediately after a PTP movement command, that HOLD command is executed before the axis arrives in the target position tolerance range.

Likewise, in interpolation movement during MOVE/MOVE2 commands, the next command is executed immediately after movement starts. Therefore, if a HOLD command exists immediately after the interpolation movement command during MOVE/MOVE2, that HOLD command is executed immediately after movement starts.

In either of the above cases, use the WAIT ARM/WAIT ARM2 command if desiring to execute the HOLD command after the axis arrives within the target position tolerance range.

HOLD command



33822-R7-00

Evaluates a conditional expression value, and executes the command in accordance with the conditions





 This parameter is only available in the following software versions:

RCX14x Ver. 8.63 onwards RCX22x Ver. 9.08 onwards

•On earlier version controllers, -1 is "true" and a value other than -1 is "false" (not changeable).

• When the conditional expression used to designate the IF statement conditions is a numeric expression, the conditions for determining a TRUE or FALSE status can be changed at the controller's "TRUE conditions" in the "Other parameters" mode. These conditions apply to all the IF, WHILE, WAIT, STOPON, etc., conditional expressions. For details, refer to the controller manual.

1) -1 (default setting) An expression value of "-1" indicates a TRUE status, and "0" indicates

a FALSE status.

A "6.35 Incorrect condition expression" error occurs if the expression

value is other than "-1" or "0".

2) not 0 Any expression value other than "0" indicates a TRUE status, and "0"

indicates a FALSE status.

Simple IF statement 43.1

Format

```
IF <conditional expression> THEN | <label 1> | [ELSE | <label 2> |]
                                        <command statement 1>
                                                               <command statement 2>
```

Explanation If the condition specified by the <conditional expression> is met, processing jumps either to the <label 1> which follows THEN, or to the next line after <command statement 1> is executed.

> If the condition specified by the <conditional expression> is not met, the following processing occurs:

- 1. Processing either jumps to the <label 2> specified after the ELSE statement, or to the next line after <command statement 2> is executed.
- 2. If nothing is specified after the ELSE statement, no action is taken, and processing simply jumps to the next line.

```
SAMPLE
```

```
' MAIN ROUTINE
*ST:
   MOVE P, P0, P1
   IF DI(20)=1 THEN *L1 ···· If DI (20)
                                      is "1", a jump to
                          *L1 occurs.
  DO(20) = 1
   DELAY 100
*L1:
   IF DI(21)=1 THEN *ST ELSE *FIN
         ...... If DI (21) is "1", a jump to
                          *ST occurs. If other than "1",
                          a jump to *FIN occurs.
*FIN:
HALT
```

IF 8-79

43

IF

43.2 **Block IF statement**



NOTE

 This parameter is only available in the following software versions:

RCX14x Ver. 8.63 onwards RCX22x Ver. 9.08 onwards

•On earlier version controllers, -1 is "true" and a value other than -1 is "false" (not changeable).

Format

```
IF <conditional expression 1> THEN
   <command block 1>
[ELSEIF <conditional expression 2> THEN
   <command block 2>]
[ELSE
   <command block n>]
ENDIF
```

Explanation If the condition specified by <conditional expression 1> is met, this statement executes the instructions specified in <command block 1>, then jumps to the next line after ENDIF.

> When an ELSEIF statement is present and the condition specified by <conditional expression 2> is met, the instructions specified in <command block 2> are executed. If all the conditions specified by the conditional expression are not met, <command block n> is executed.



• The IF statement can be used up to 48 times in succession. Note that the maximum number of times is reduced if commands containing a stack such as a GOSUB or CALL statement are used.

```
SAMPLE
' MAIN ROUTINE
*ST:
   MOVE P, P0, P1
   IF DI (21, 20) = 1 THEN
      DO(20) = 1
      DELAY 100
      WAIT DI(20) = 0
   ELSEIF DI (21,20)=2 THEN
      DELAY 100
   ELSE
      GOTO *FIN
   ENDIF
GOTO *ST
*FIN:
HALT
```

Assigns a value to a variable specified from the programming box

Format					
<pre>INPUT [<pre>cprompt statement></pre></pre>	;]	<pre><variable> <point variable=""> <shift variable=""></shift></point></variable></pre>	[,	<pre><variable> , <point variable=""> <shift variable=""> </shift></point></variable></pre>]

Explanation Assigns a value to the variable specified from the programming box.

The input definitions are as follows:

- 1. When two or more variables are specified by separating them with a comma (,), the specified input data items must also be separated with a comma (,).
- 2. At the rompt statement>, enter a character string enclosed in quotation marks (" ") that will appear as a message requiring data input. When a semicolon (;) is entered following the prompt statement, a question mark (?) and a space will appear at the end of the message. When a comma (,) is entered, nothing will be displayed following the message.
- 3. When the prompt statement> is omitted, only a question mark (?) and a space will be displayed.
- 4. The input data type must match the type of the corresponding variables. When data is input to a point variable or shift variable, insufficient elements are set to
- 5. If only the ENTER key is pressed without making any entry, the program interprets this as a "0" or "null string" input. However, if specifying two or more variables, a comma (,) must be used to separate them.
- 6. If the specified variable is a character type and a significant space is to be entered before and after a comma (,), double quotation mark (") or character string, the character string must be enclosed in double quotation marks ("). Note that in this case, you must enter two double quotation marks in succession so that they will be identified as a double quotation mark input.
- 7. Pressing the ESC key skips this command.



- If the variable and the value to be assigned are different types, an "Input again" message displays and a "waiting for input" status is established.
- When assigning alphanumeric characters to a character variable, it is not necessary to enclose the character string in double quotation marks (").

```
SAMPLE
INPUT
INPUT
        "INPUT POINT NUMBER"; A1
        "INPUT STRING", B$(0), B$(1)
INPUT
INPUT
       P100
HALT
```

Format

INT (<expression>)

Explanation This function acquires an integer with decimal fractions truncated. The maximum integer value which does not exceed the <expression> value is acquired.

SAMPLE

```
A=INT(A(0))

B=INT(-1. 233) \cdots "-2" is assigned to B.
```

_

C

D

E

F

G

Œ

П

J

K

JTOXY / JTOXY2

Performs axis unit system conversions (pulse \rightarrow mm)



NOTE

 X-arm and Y-arm rotation information is only available in software Ver.10.66 onwards.

Format	main group

JTOXY (<point expression>)

Format sub group

JTOXY2 (<point expression>)

Explanation Converts the joint coordinate data (unit: pulses) specified by the <point expression> into Cartesian coordinate data (unit: mm, deg.).

On YK500TW model robots, the X-arm and Y-arm rotation information is also set.

SAMPLE

P10=JTOXY(WHERE) $\cdots \cdots$ Current position data is converted to Cartesian coordinate data.

Related commands XYTOJ, XYTOJ2

Δ

В

C

D

ī

F

G

Ш

i

K

L

M

LABEL Statement

Defines labels at program lines

Format

*<label> :

Explanation Defines a <label> on a program line. A <label> must always begin with an asterisk mark (*), and it must be located at the beginning of the line.

> Although a colon mark (:) is required at the end of the <label> when defining it, this mark is not required when specifying program jump destinations.

- 1. A <label> must begin with an alphabetic or numeric character.
- 2. Alphanumeric and underbars (_) can be used as the remaining <label> characters. Special symbols, etc., cannot be used.
- 3. The <label> must not exceed 16 characters (all characters beyond the 16th character are ignored).

```
SAMPLE
        .....*ST label is defined.
*ST:
 MOVE P, P0
 DO(20) = 1
 MOVE P, P1
 DO(20) = 0
GOTO *ST·····Jumps to *ST.
HALT
```

LEFT\$

Extracts character strings from the left end

Format

(<character string expression> , <expression>)

Values

<expression>......0 to 75

Explanation This function extracts a character string with the digits specified by the <expression> from the left end of the character string specified by <character string expression>. The <expression> value must be between 0 and 75, otherwise an error will occur. If the <expression> value is 0, then LEFT\$ will be a null string (empty character string).

> If the <expression> value has more characters than the <character string expression>, LEFT\$ will become the same as the <character string expression>.

SAMPLE

B\$=LEFT\$(A\$,4)4 characters from the left end of A\$ are assigned to B\$.

Related commands

MID\$, RIGHT\$

LEFTY / LEFTY2

Sets the SCARA robot hand system as a left-hand system

Format

main group

LEFTY

Format sub group

LEFTY2

Explanation This statement specifies left-handed movement to a point specified in Cartesian

This statement only selects the hand system, and does not move the robot. If executed while the robot arm is moving, execution waits until movement is complete (positioned within tolerance range).

This command is only valid for SCARA robots.

SAMPLE

RIGHTY

MOVE P, P1


LEFTY

MOVE P, P1

RIGHTY

HALT

SAMPLE:LEFTY/RIGHTY



33809-R7-00

Related commands

RIGHTY, RIGHTY2

В

C

D

E

F

G

Н

K

L

Format

LEN(<character string expression>)

Explanation Returns the length (number of bytes) of the <character string expression>.

SAMPLE

B=LEN(A\$)

٨

D

E

F

П

K

L

M

LET

Explanation Directly executes the specified assignment statement. The right-side value is assigned to the left side. An assignment statement can also be directly written to the program without using a LET statement.



• If the controller power is turned off during execution of a <point assignment statement> or <shift assignment statement>, a memory-related error such as the "9.2: Point check-sum error" or the "9.6: Shift check-sum error" may occur.

1. Arithmetic assignment statement

Format		
[LET]	<pre><arithmetic variable=""> <point element="" variable=""> <shift element="" variable=""> <parallel output="" variable=""> <internal output="" variable=""> <arm lock="" output="" variable=""> <timer output="" variable=""> <serial output="" variable=""> <serial output="" variable=""></serial></serial></timer></arm></internal></parallel></shift></point></arithmetic></pre>	= <expression></expression>

Values <expression>......Variable, function, numeric value

Explanation The <expression> value is assigned to the left-side variable.

```
A!=B!+1
B%(1,2,3)=INT(10.88)
LOCZ(P0)=A!
LOCX(S1)=100.00
DO2()=&B00101101
MO(21,20)=2
LO(00)=1
TO(01)=0
SO12()=255
```

8

2. Character string assignment statement

Format

[LET] <character string variable> = <character string expression>

Explanation

The <character string expression> value is assigned to the character string variable. Only the plus (+) arithmetic operator can be used in the <character string expression>. Other arithmetic operators and parentheses cannot be used.

SAMPLE

A\$ ="YAMAHA" B\$ ="ROBOT" D\$ = A\$ + "-" + B\$

Execution result: YAMAHA-ROBOT



• The "+" arithmetic operator is used to link character strings.

3. Point assignment statement

Format

[LET] <point variable> = <point expression>

Explanation

Assigns <point expression> values to point variables.

Only 4 arithmetic operators (+, -*, /) can be used in the <point expression>. Multiplication and division are performed only for constant or variable arithmetic operations.

- Addition/subtraction Addition/subtraction is performed for each element of each axis.
- Multiplication Multiplication by a constant or variable is performed for each element of each axis.
- Division Division by a constant or variable is performed for each element of each axis.

Multiplication results vary according to the point data type.

- For pulse units Assigned after being converted to an integer.
- For "mm" units Assigned after being converted to a real number down to the 2nd decimal position.

A

В

C

D

E

F

G

J

M

LET

В

C

ע

E

Н

I

V

L

M

SAMPLE
P1 =P10 ····· Point 10 is assigned to P1. P20=P20+P5 ···· Each element of point 20 and point 5 is summed and assigned to P20.
P30=P30-P3 ····· Each element of point 3 is subtracted from point 30 and assigned to P30.
P80=P70*4····· Each element of point 70 is multiplied by 4 and assigned to P80.
P60=P5/3 ····· Each element of point 5 is divided by 3 and assigned to P60.



- Multiplication & division examples are shown below.
 - Permissible examples P15 * 5, P[E]/A, etc.
 - Prohibited examples P10 * P11, 3/P10, etc.

4. Shift assignment statement

Format

[LET] <shift variable> = <shift expression>

Explanation

Assigns <shift expression> values to shift variables.

Only shift elements can be used in <shift expressions>, and only addition and subtraction arithmetic operators are permitted. Parentheses cannot be used.

• Addition/subtractionAddition/subtraction is performed for each element of each axis.

SAMPLE

S1=S0 "shift 0" is assigned to "shift 1".

S2=S1+S0 Each element of "shift 1" and "shift 0" is summed and assigned to "shift 2".



- Examples of <shift expression> addition/subtraction:
 - Permissible examples S1 + S2
 - Prohibited examples S1 + 3

Format

1. LOO ([b,
$$\cdot \cdot \cdot$$
, b]) =
2. LO (0b, $\cdot \cdot \cdot$, 0b) =

Values

b: Bit definition0 to 7

<expression>......Converted to an integer. The lower bits corresponding to the bits specified on the left side are valid.

Explanation This statement outputs the specified value to the LO port to either prohibit or allow axis movement.

> LO(00) to LO(07) respectively correspond to axes 1 to 8. An arm lock ON status occurs at axes where bits are set, and axis movement is prohibited. Multiple bits must be specified in descending order from left to right (large \rightarrow small).

• This statement is valid at axes where movement is started.

SAMPLE

LOO()=&B00001010.....Prohibits movement at axes 2 and 4. $LO0(2,1) = \&B10 \cdots$ Prohibits movement at axis 3.

Related commands

RESET, SET

LO **8**-91

LOCx

Specifies/acquires point data or shift data for a specified axis



NOTE

X-arm and Y-arm rotation information is only available in software Ver. 10.66 onwards.

Format

1. LOCx (<point expression>) = <expression> (<shift expression>) = <expression> 2. LOCx

Values

Format 1: xX,Y,Z,R,A,B (axis setting), F (hand system flag setting), F1 (X-arm rotation information), F2 (Y-arm rotation information).

Format 2: x.....X,Y,Z,R (axis setting)

<expression>......For axis setting: coordinate value.

For hand system flag setting:

1 (right-handed system) or 2 (left-handed system)

0 (no setting)

For specifies the X-arm rotation information and specifies

the Y-arm rotation information:

0, 1, -1

*1: For details regarding the X-arm and Y-arm rotation information, refer to Chapter 4 "3. Point data format".

Explanation Direct format 1: Changes the value of the point data specified axis, the hand system flag, and the X-arm and Y-arm rotation information.

> Format 2: Changes the value of a specified axis from the shift data value.



• Points where data is to be changed must be registered in advance. An error will occur if a value change is attempted at an unregistered point (where there are no coordinate values).

Functions

Format

- 1. LOCx (<point expression>)
- 2. LOCx (<shift expression>)

Values Format 1: xX,Y,Z,R,A,B (axis setting), F (hand system flag setting), F1 (X-arm rotation information), F2 (Y-arm rotation information).

Format 2: x.....X,Y,Z,R (axis setting)

Explanation Format 1: Acquires the value of the point data specified axis, the hand system flag, and the X-arm and Y-arm rotation information.

Format 2: Acquires a specified axis value from the shift data.

SAMPLE

Related commands

Point element variable, shift element variable

A

В

C

D

E

F

Н

K

L

Format

LSHIFT (<expression 1> ,<expression 2>)

Explanation Shifts the <expression 1> bit value to the left by the amount of <expression 2>. Spaces left blank by the shift are filled with zeros (0).

SAMPLE

A=LSHIFT(&B10111011,2) The 2-bit-left-shifted &B10111011 value (&B11101100) is assigned to A.

Related commands

RSHIFT

R

C

D

E

F

G

Œ

J

M

MCHREF / MCHREF2

Acquires a machine reference

Format	Format			main group

MCHREF (<axis 1>)

Format sub group

MCHREF2 (<axis 2>)

Values <axis 1>......main group: 1 to 6 <axis 2>......sub group: 1 to 4

Explanation This function provides the return-to-origin or absolute-search machine reference (unit: %) for the axis specified by <axis number>.

This function can only be used for axes whose return-to-origin method is set to the sensor or stroke end method.

A=MCHREF(1) The main group's axis 1 return-to-origin machine reference is assigned to variable A.

A

В

C

D

E

F

G

Н

J

М

MID\$

Acquires a character string from a specified position

Format

MID\$ (<character string expression>,<expression 1>[,<expression 2>])

Values

<expression 1>......1 to 75 <expression 2>......0 to 75

Explanation This function extracts a character string of a desired length (number of characters) from the character string specified by <character string expression>. <expression 1> specifies the character where the extraction is to begin, and <expression 2> specifies the number of characters to be extracted.

> An error will occur if the <expression 1> and <expression 2> values violate the permissible value ranges.

> If <expression 2> is omitted, or if the number of characters to the right of the character of <expression 1> is less than the value of <expression 2>, then all characters to the right of the character specified by <expression 1> will be extracted. If <expression 1> is longer than the character string, MID\$ will be a null string (empty character string).

SAMPLE

B\$=MID\$(A\$,2,4) The 2nd to 4th characters to the 5th char.) of A\$ are assigned to B\$.

Related commands

LEFT\$, RIGHT\$

Outputs a specified value to the MO port (internal output)

• For details regarding bit definitions, see Chapter 3 "10 Bit Settings".

Format

- 1. $MOO([b, \cdot \cdot \cdot, b]) = \langle expression \rangle$
- 2. $MO(0b, \cdot \cdot \cdot , 0b) = \langle expression \rangle$

Values

m: port number.....2 to 7, 10 to 17, 20 to 27 b: bit definition0 to 7 <expression>.....The integer-converted lower bits corresponding to the bit definition specified at the left side are valid.

Explanation Outputs a specified value to the MO port.

In order to maintain the sensor status and axis HOLD status at each axis, ports "0" and "1" cannot be used as output ports (these ports are for referencing only).

If multiple bits are specified, they are expressed from the left in descending order (large

If the [b,...,b] data is omitted, all 8 bits are processed.

• Ports "0" and "1" outputs

Bit	7	6	5	4	3	2	1	0
Port 0	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1
	Origin	sensor s	atus 0: Ol	F; 1: ON	•	•	•	-
Port 1	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1
	HOLE) status 0:	No HOLD	/ 1: HOLI	D (1 axis is	not used)	



• For details regarding MO ports "0" and "1", see Chapter 3 "9.7 Internal output variable".

SAMPLE
MO2()=&B10111000 MO (27, 25, 24, 23) are turned ON, and MO (26, 22, 21, 20) are turned OFF.
$MO2(6,5,1)=\&B010\cdots$ MO (25) are turned ON, and MO (26, 21) are turned OFF.
MO3() = 15
$MO(37,35,27,20) = A \cdots$ The contents of the 4 lower bits acquired when variable A is converted to an integer are output to MO (37, 35, 27, 20), respectively.

Related commands

RESET, SET

MOVE / MOVE2

Performs absolute movement of all robot axes

main group

MOVE PTP Ρ \mathbf{L} C

Format

<point definition> [, option [, option]

NOTE

 MOVE2 linear and circular interpolation movement is supported in the following software versions:

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

Format						sub g	group
MOVE2 PTP P L C	, <point< th=""><th>definition></th><th>[,</th><th>option</th><th>[,</th><th>option]</th><th>]</th></point<>	definition>	[,	option	[,	option]]

Explanation Executes direct absolute movement of a group's axes.

The MOVE command is used for axes which have been specified as main robot axes, and the MOVE2 command is used for axes specified as sub robot axes. It is not enabled for other groups, or for auxiliary axes.

• Movement type: PTP, linear interpolation, circular interpolation.

• Point data setting: Direct coordinate data input, point definition.

• Options : Speed setting, arch motion setting, STOPON condition setting, CONT setting, acceleration setting, deceleration setting, plane

coordinate setting, port output setting.

Options	PTP	interpolation	Arcn interpolation	Remarks
Speed setting (SPEED)	0	0	0	Enabled only for specified MOVE statement
Speed setting (VEL)	×	0	0	Enabled only for specified MOVE statement
Arch motion	0	×	×	Enabled only for specified MOVE statement
STOPON condition setting	0	0	×	Enabled only by program execution
CONT setting	0	×	×	Enabled only for specified MOVE statement
Acceleration setting	×	0	×	Enabled only for specified MOVE statement
Deceleration setting	×	0	×	Enabled only for specified MOVE statement
Plane coordinate setting	X	×	0	Enabled only for specified MOVE statement
Port output setting	X	0	0	Enabled only for specified MOVE statement

Movement type

PTP (point-to-point) movement

Execution START condition: Movement of all specified axes is complete (within the tolerance range).

Execution END condition: All specified axes have entered the OUT position range.

When two or more axes are specified, they will reach their target positions simultaneously. The movement path of the axes is not guaranteed.

Caution regarding commands which follow the MOVE P / MOVE2 P command:

If the next command following the MOVE P / MOVE2 P command is an executable command such as a signal output command, that next command will start when the movement axis enters the OUT position range. In other words, that next command starts before the axis arrives within the target position tolerance range.

Example:


Signal output (DO, etc.)	Signal is output when axis enters within OUT position range.
DELAY	DELAY command is executed and standby starts, when axis enters the OUT position range.
HALT	Program stops and is reset when axis enters the OUT position range. Therefore, axis movement also stops.
HOLD	Program temporarily stops when axis enters the OUT position range. Therefore, axis movement also stops.
WAIT	WAIT command is executed when axis enters the OUT position range.


The WAIT ARM / WAIT ARM2 statements are used to execute the next command after the axis enters the tolerance range.



The OUT position value is specified by parameter setting.
 This value can be changed from within the program by using the OUTPOS / OUTPOS2 commands.

MOVE command





33823-R7-00

A

В

C

н

J

M

MOVE P,P0..... The main robot axis moves from its current position to the position specified by P0 (the same occurs for MOVE PTP, P0).



• PTP movement is faster than interpolation movement, but when executing continuous movement to multiple points, a positioning stop occurs at each point.

Linear interpolation movement

Execution START condition: Movement of all specified axes is complete (within the tolerance range).

Execution END condition: Movement of all specified axes has begun.

Execution of the immediately following command occurs immediately after axis movement begins.

When executing linear or circular interpolation in a continuous manner, the 2 movement paths are linked by connecting the deceleration and acceleration sections, enabling continuous movement without intermediate stops.

All movement axes arrive at the same time.

However, the following execution END condition applies if a STOPON condition has been specified:

Execution END condition: Movement of all specified axes is complete (within the tolerance range).

In this case, continuous movement for the 2 linked paths is not possible.

Caution regarding commands which follow a MOVE L / MOVE2 L command:

If the next command following the MOVE L / MOVE2 L command is an executable command such as a signal output command, that next command will start immediately after axis movement begins.

Example:

Signal output (DO, etc.)	Signal is output immediately after movement begins.
DELAY	DELAY command is executed and standby starts immediately after movement begins.
HALT	Program stops and is reset immediately after movement begins. Therefore, axis movement also stops.
HOLD	Program temporarily stops immediately after movement begins. Therefore, axis movement also stops.
WAIT	WAIT command is executed immediately after movement begins.

The WAIT ARM / WAIT ARM2 statements are used to execute the next command after the axis enters the tolerance range.





- On RCX14x controllers earlier than Ver. 8.64, and RCX22x controllers earlier than Ver. 9.11, linear interpolation can be performed by task 1 only.
- Smooth travel paths and constant speeds between paths may not always be possible, depending on the axis movement speed, acceleration, and distance between the target points.
- On robots with an R-axis, the R-axis speed may become too fast and cause an error depending on the R-axis movement distance.
- If a DELAY statement is executed after a MOVE L / MOVE2 L command, a DELAY timer is
 activated after the MOVE L / MOVE2L command is executed. Therefore, if a DELAY is desired
 after reaching the target point, use the WAIT ARM / WAIT ARM2 statement after the MOVE
 command.

The same applies for other commands such as HALT, etc.

 If the direction changes at an acute angle during interpolation movement, the acceleration/ deceleration speed of the connection section may become too fast, causing an error. In this case, specify a slower acceleration/deceleration speed at the connection section, or use the WAIT ARM command to revise the operation pattern.

MOVE command






33824-R7-00

SAMPLE

MOVE L, P0, P1 ····· The main robot axis moves from its current position to the position specified by P0, P1.

SAMPLE:MOVE L



33810-R7-00

A

B

C

D

E

F

1

_

M

Circular interpolation movement

Execution START condition: Movement of all specified axes is complete (within the tolerance range).

Execution END condition: Movement of all specified axes has begun.

Execution of the immediately following command occurs immediately after axis movement begins.

When executing linear or circular interpolation in a continuous manner, the 2 movement paths are linked by connecting the deceleration and acceleration sections, enabling continuous movement without intermediate stops.

All movement axes arrive at the same time.

In circular interpolation, an arc is generated based on 3 points: the current position, an intermediate position, and the target position. **Therefore, circular interpolation must be specified by an even number of points.**

Caution regarding commands which follow a MOVE C / MOVE2 C command:


If the next command following the MOVE C / MOVE2 C command is an executable command such as a signal output command, that next command will start immediately after axis movement begins.


Example:

Signal output (DO, etc.)	Signal is output immediately after movement begins.
DELAY	DELAY command is executed and standby starts immediately after movement begins.
HALT	Program stops and is reset immediately after movement begins. Therefore, axis movement also stops.
HOLD	Program temporarily stops immediately after movement begins. Therefore, axis movement also stops.
WAIT	WAIT command is executed immediately after movement begins.

The WAIT ARM / WAIT ARM2 statements are used to execute the next command after the axis enters the tolerance range.

MOVE command





33825-R7-00


SAMPLE

MOVE L,P20 ······ Linear movement occurs from the current position to P20.

MOVE C,P21,P22,P23,P20 ·· Arc movement occurs through points P21, P22, P23, P20.

MOVE L,P24 ····· Linear movement occurs to P24.

SAMPLE:MOVE C



33811-R7-00



- In continuous interpolation operations, too, there are no stops at intermediate points. However, the maximum speed is slower than the PTP speed.
- On RCX14x controllers earlier than Ver. 8.64, and RCX22x controllers earlier than Ver. 9.11, circular interpolation can be performed by task 1 only.
- Circular interpolation is possible within the following range: radius 1.00mm to 5,000.00mm.
- Circle distortion may occur, depending on the speed, acceleration, and the distance between points.
- On robots with an R-axis, the R-axis speed may become too fast and cause an error, depending on the R-axis movement distance.
- If a DELAY statement is executed after a MOVE L / MOVE2 L command, a DELAY timer is
 activated after the MOVE L / MOVE2L command is executed. Therefore, if a DELAY is desired
 after reaching the target point, use the WAIT ARM / WAIT ARM2 statement after the MOVE
 statement.


The same applies for other commands such as HALT, etc.

- On "Multi" type robots, the "5.37: Specification mismatch" error will occur, and circular interpolation will be disabled.
- If the direction changes at an acute angle during interpolation movement, the acceleration/ deceleration speed of the connection section may become too fast, causing an error. In this case, specify a slower acceleration/deceleration speed at the connection section, or use the WAIT ARM command to revise the operation pattern.


MOVE / MOVE2

Movement command types and the corresponding movement


1. PTP movement




2. Interpolation movement



3. WAIT ARM



4. STOPON conditional expression



- 1) If a DELAY statement is executed after an interpolation operation, a DELAY timer is activated immediately after the movement starts. Therefore, if a DELAY is desired after reaching the target point, use the WAIT ARM /WAIT ARM2 statement after the MOVE / MOVE2 command.
- 2) A deceleration and stop occurs at an intermediate point if the condition specified by the STOPON conditional expression is met (for details, see the "STOPON Condition Setting" item).

33812-R7-00

Point data setting types

Direct numeric value input

(PTP) (Linear interpolation) (Circular interpolation

- If both integers and real numbers are used together (mixed), all coordinate values will be handled in "mm/deg"
- Hand system flags are available from software version 8.08 onwards.
- X-arm and Y-arm rotation information is only available in software Ver. 10.66 onwards.



CAUTION

- When performing linear interpolation with a hand system flag specified, be sure that the same hand system is used at the current position and target position. If the same hand system is not used, an error will occur and robot movement will be disabled.
- When performing a linear interpolation, the current position's X-arm and Y-arm rotation information must be the same as the movement destination's X-arm and Y-arm rotation information. If the two are different, an error will occur and movement will be disabled.

Format

X Y Z R A B [F] [F1] [F2]

Values X, Y, Z, R, A, B......Space-separated coordinate values for each axis. FHand system flag (SCARA robot only) F1X-arm rotation information (YK500TW model only).

F2Y-arm rotation information (YK500TW model only).

Explanation

Directly specifies coordinate values by a numeric value. If an integer is used, this is interpreted as "pulse" units, and if a real number (with decimal point) is used, this is interpreted as "mm/deg" units, with movement occurring accordingly. If both integers and real numbers are used together (mixed), all coordinate values will be handled in "mm/deg" units.

This setting method can be used only for PTP and linear interpolation movement types. Hand system flags can be specified for SCARA robots when directly specifying the coordinate values in "mm" units.

To specify an extended hand system flag for SCARA robots, set either 1 or 2 at "F". If a number other than 1 or 2 is set, or if no number is designated, 0 will be set to indicate that there is no hand system flag.

- 1: Right-handed system is used to move to a specified position.
- 2: Left-handed system is used to move to a specified position.

Direct numeric value inputs can be used to set the X-arm and Y-arm rotation information (*1) only on YK500TW model robots where the coordinate system-ofunits has been set as "mm".

To set extended X-arm and Y-arm rotation information at the YK500TW model robot, a "-1", "0", or "1" value must be specified at F1 and F2. Any other value, or no X-arm and Y-arm rotation information at all, will be processed as "0".

- 0: Indicates arm rotation information where movement to the "0" position has been specified.
- 1: Indicates arm rotation information where movement to the "1" position has
- -1: Indicates arm rotation information where movement to the "-1" position has been specified.
- *1: For details regarding the X-arm and Y-arm rotation information, refer to Chapter 4 "3. Point data format".



 At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

SAMPLE

MOVE P,10000 10000 1000 1000 0 0

·····PTP movement occurs current position to the specified position.

MOVE / MOVE2 8-105

D

CAUTION

• When moving the robot by linear or circular interpolation to a point where a hand system flag is specified, be sure that the same hand system is used at both the current and target positions. If the same hand system is not used, an error will occur and robot movement will be disabled.





CAUTION

• When performing a linear and circular interpolation, the current position's X-arm and Y-arm rotation information must be the same as the movement destination's X-arm and Y-arm rotation information. If the two are different, an error will occur and movement will be disabled.

Point definition

(PTP) (linear interpolation) (Circular interpolation)

Format

<point expression>[,<point expression>...]

Explanation

Specifies a <point expression>. Two or more data items can be designated by separating them with a comma (,).

Circular interpolation must be specified by an even number of points.

 At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

SAMPLE

..... Moves from the current position MOVE to the position specified by P1. P, P20, P0, P100 ····· Moves in sequence from the current position MOVE to positions specified by P20, P0, P100.

D

Option types

Speed setting 1

PTP (linear interpolation) Circular interpolation

Format

- SPEED = <expression> 1.
- 2. $S = \langle expression \rangle$

<expression>......1 to 100 (units: %)

The actual speed will be as follows:

Specifies the program speed in an <expression>.

• [Robot max. speed (mm/sec)] × [automatic movement speed (%)] × [program movement speed (%)].

This option is enabled only for the specified MOVE / MOVE2 statement.

SAMPLE

Explanation

MOVE P,P10,S=10 ····· Moves from the current position to the position specified by P10, at 10% of the program movement speed.

Speed setting 2



Format

VEL = <expression>

<expression>......For SCARA robot: 0.01 to 750

For XY robot: 0.1 to 1000 (units: mm/sec)

Explanation Specifies the maximum composite speed (in "mm/sec" units) of the XYZ axes in an <expression>. This option can be used for linear interpolation and circular interpolation movements of SCARA robots or XY robots.

This option is enabled only for the specified MOVE / MOVE2 statement.

SAMPLE

MOVE L,P10,VEL=100 ······ Moves from the current position to the position specified by P10, at the XYZ maximum composite speed of 100mm/sec.



 This option specifies only the maximum speed and does not guarantee movement at the specified speed.



• This option specifies only the maximum composite speed and does not guarantee movement at the specified speed.

MOVE / MOVE2 8-107

Format

 $x = \langle expression \rangle$

Values

xSpecifies the X,Y,Z,R,A,B axis.

<expression>......An integer value is processed in "pulse" units.

A real number (with decimal point) is process in "mm/

NOTE

The axis arch position parameter can be changed at ARCH / ARCH2. The larger the value, the shorter the movement time.

Explanation

- 1. The "x" specified axis begins moving toward the position specified by the <expression> (see "1" in the Fig. below).
- 2. When the "x" specified axis enters the arch position range, all other axes move toward the target position (see "2" in the Fig. below).
- 3. When all axes other than the "x" specified axis enter the arch position range, the "x" specified axis moves to the target position ("3" in the Fig. below).
- 4. The command ends when all axis enter the OUT position range.

This option can be used only for PTP movement.

If the "x" specified axis is the X or Y axis, the target position and <expression> must be specified as an integer (pulse units) for SCARA robots and XY robots.

<expression> value: SCARA and XY type robots.


Target position value: SCARA type robot.

The values are indicated as the motor position rather than the coordinate values.

SAMPLE

MOVE P, P1, Z=0 ····· Z-axis moves 0 pulses from its current position, then other axes move to P1. Finally, the Z-axis moves to P1.

SAMPLE:MOVE Z



33813-R7-00

STOPON condition setting

PTP linear interpolation Circular interpolation

Format

STOPON < conditional expression>

Explanation

Stops movement when the conditions specified by the conditional expression are met. Because this is a deceleration type stop, there will be some movement (during deceleration) after the conditions are met.

If the conditions are already met before movement begins, no movement occurs, and the command is terminated.

This option can only be used for PTP movement and linear interpolation movement.

This option is only possible by program execution.

SAMPLE

MOVE P, P100, STOPON DI (20) = 1

..... Moves from the current position to the position specified by P100. If the "DI (20) = 1" condition is met during movement, a deceleration and stop occurs, and the next step is then executed.





• This parameter is only available in the following software versions:

RCX14x Ver. 8.63 onwards RCX22x Ver. 9.08 onwards

•On earlier version controllers, -1 is "true" and a value other than -1 is "false" (not changeable).

• When the conditional expression used to designate the STOPON condition is a numeric expression, the conditions for determining a TRUE or FALSE status can be changed at the controller's "TRUE conditions" in the "Other parameters" mode. These conditions apply to all the IF, WHILE, WAIT, STOPON, etc., conditional expressions. For details, refer to the controller user's manual.

1) -1 (default setting)

An expression value of "-1" indicates a TRUE status, and "0" indicates

a FALSE status.

A "6.35 Incorrect condition expression" error occurs if the expression

value is other than "-1" or "0".

Any expression value other than "0" indicates a TRUE status, and "0" 2) not 0

indicates a FALSE status.

NOTE

- •The CONT setting can be used to reduce the PTP movement START positioning time.
- The path to the target point is not guaranteed.

Format

CONT

Explanation

When PTP movement is executed with the CONT setting option, the PTP movement which begins immediately after all movable axes enter the OUT position range (with the command being terminated at that point), will begin without waiting for the movable axes to complete their movement into the tolerance range.


This option can be used only for PTP movement and is enabled only for the specified MOVE / MOVE2 statement.


SAMPLE

MOVE P, P10, P11, CONT

> Moves from the current position to the position specified by P10, and then moves to P11 without waiting for the moving axes to arrive in the tolerance range.

SAMPLE:MOVE CONT





33814-R7-00

Acceleration setting

(PTP) (linear interpolation) (Circular interpolation)

Format

 $ACC = \langle expression \rangle$

Values <expression>......1 to 100 (units: %)

Explanation

Specifies the robot acceleration rate in an <expression>. The actual robot acceleration is determined by the acceleration coefficient parameter setting. This option can be used only for linear interpolation movement and is enabled only for the specified MOVE / MOVE2 statement.

SAMPLE

MOVE L, P100, ACC=10 ····· Moves at an acceleration rate of 10% from the current position to the position specified by P100.

Deceleration setting

PTP (linear interpolation) (Circular interpolation)

Format

<expression> DEC =

Values <expression>......1 to 100 (units: %)

Explanation

Specifies the robot deceleration rate in an <expression>. The actual robot deceleration is determined by the acceleration coefficient parameter setting (the setting is specified as a percentage of the acceleration setting value (100%)). This option can be used only for linear interpolation movement and is enabled only for the specified MOVE / MOVE2 statement.

SAMPLE

MOVE L, P100, DEC=20 ···· Moves deceleration аt a rate of 20% from the current position to the position specified by P100.

NOTE

plane.

•If no coordinate

plane is specified, the

robot moves along a 3-dimensional circle.

When a 2-axis robot is

used, the robot moves along a circle on the XY

Coordinate plane setting

Format

ΧY YZ

ZX

Values

XY.....XY coordinate plane

YZ......YZ coordinate plane

ZX.....ZX coordinate plane

(Explanation)

When circular interpolation is executed by setting coordinates, this option executes circular interpolation so that the projection on the specified coordinate plane becomes a circle.

This option can be used for circular interpolation movement and is enabled only for the specified MOVE / MOVE2 statement.

SAMPLE

P10 = 100.00 100.00 20.00 0.00 0.00 0.00

P11 = 150.00 100.00 0.00 0.00 0.00 0.00

150.00 150.00 20.00 0.00 0.00 0.00

100.00 150.00 40.00 0.00 0.00 0.00 P13 =

MOVE P, P10

MOVE C, P11, P12

MOVE C, P13, P10 Moves continuously along a 3-dimensional circle generated at P10, P11, P12, and P12,

P13, P10.

MOVE C, P11, P12, XY

MOVE C, P13, P10, XY ······ Moves continuously along a circle on an XY plane generated at P10, P11, P12, and P12, P13, P10. Z-axis moves to the position specified by P12 and P10 (the circle's target position).



NOTE

• The port output setting is available from software version 8.22 onwards.

Port output setting

PTP (linear interpolation) (Circular interpolation

Format 1

DO	$ m([b, \dots, b]) = @$	2>
MO SO		
SO		

Format 2

DO	(mb,	 •	,mb)= <express< th=""><th>ion</th><th>1>@<expression< th=""><th>2></th></expression<></th></express<>	ion	1>@ <expression< th=""><th>2></th></expression<>	2>
MO						
SO						

Values

m: port number2 to 7, 10 to 17, 20 to 27

b: bit definition0 to 7

<expression 1>......Value which is output to the specified port (only

integers are valid).

<expression 2>......Position where the port output occurs. This position

can be specified in "mm" units down to the 2nd

decimal position.



Output to ports "0" and "1" is not allowed at DO, MO, and SO.



• For bit setting details, see Chapter 3 "10 Bit Settings".

Explanation

During linear interpolation or circular interpolation movement, this command option outputs the value of <expression 1> to the specified port when the robot reaches the <expression 2> distance (units: "mm") from the start position.

The <expression 2> numeric value represents a circle radius centered on the movement START point.

This command option can only be used with linear or circular interpolation movement, and it can be specified no more than 2 times per each MOVE / MOVE2 statement.

If multiple bits are specified, they are expressed from the left in descending order (large to small).

If the [b,...,b] data is omitted in format 1, all 8 bits are processed.

If no hardware port exists, nothing is output.

SAMPLE 1

```
MOVE P, P0
MOVE L, P1, DO2()=105@25.85
```

...... During linear interpolation movement to P1, 105 (&B01101001) is output to DO2() when the robot reaches a distance of 25.85mm from PO.

SAMPLE 2

```
A! = 10
B! = 20
```

MOVE L, P2, MO(22) = 1@A!, MO(22) = 0@B!

..... After movement START toward P2, MO(22) switches ON when the robot has moved a distance of 10mm, and switches OFF when the robot has moved a distance of 20mm.

Related commands

MOVEI, MOVEI2, DRIVE, DRIVE2, DRIVEI, DRIVEI2, WAIT ARM, WAIT ARM2

MOVE / MOVE2 8-113

D

main group

MOVEI ,<point definition> [, option [, option]...] PTP Ρ

Format

Format

sub group

,<point definition> [, option [, option]]...] MOVEI2 PTP Ρ

Explanation Executes relative position movement commands for the robot.

MOVEI is used for all the main group axes, and MOVEI2 is used for all the sub group

It is not enabled for other groups, or for auxiliary axes.

• Movement type : PTP

• Point data setting: Direct coordinate data input, point definition.

• Options : Speed setting

Options	PTP	Linear interpolation	Arch interpolation	Remarks
Speed setting (SPEED)	0	0	0	Enabled only for specified MOVE statement

MEMO



NOTE

 This parameter is only available in the following software versions:

RCX14x Ver. 8.66 onwards RCX22x Ver. 9.13 onwards

• In versions prior to those shown above, a RESET must be performed at the controller.

• If the MOVEI statement is interrupted and then re-executed, the movement target position can be selected at the "MOVEI/DRIVEI start position" setting at "Other parameters" in the controller. For details, refer to the controller user's manual.

1) KEEP (default setting) Continues the previous (before interruption) movement. The original

target position remains unchanged.

2) RESET Relative movement begins anew from the current position. The new

target position is different from the original one (before interruption).

(Backward compatibility)

Movement type

PTP (point-to-point) movement

Execution START condition: Movement of all specified axes is complete (within the tolerance range).

Execution END condition: All specified axes have entered the OUT position range.

When two or more axes are specified, they will reach their target positions simultaneously. The movement path of the axes is not guaranteed.

Caution regarding commands which follow the MOVEI / MOVEI2 command:


If the next command following the MOVEI / MOVEI2 command is an executable command such as a signal output command, that next command will start when the movement axis enters the OUT position range. In other words, that next command starts before the axis arrives within the target position tolerance range.


Example:

Signal output (DO, etc.)	Signal is output when axis enters within OUT position range.		
DELAY	DELAY command is executed and standby starts, when axis enters the OUT position range.		
HALT	Program stops and is reset when axis enters the OUT position range. Therefore, axis movement also stops.		
HOLD	Program temporarily stops when axis enters the OUT position range. Therefore, axis movement also stops.		
WAIT	WAIT command is executed when axis enters the OUT position range.		

The WAIT ARM / WAIT ARM2 statements are used to execute the next command after the axis enters the tolerance range.

MOVEI command





33826-R7-00

SAMPLE

MOVEI P,P0 From its current position, the main robot axis moves (PTP movement) the amount specified by P0.

Δ

В

C

D

E

r

ы

ı

М

Point data setting types

Direct numeric value input

PTP

Format

X Y Z R A B [F] [F1] [F2]

NOTE

59

- If both integers and real numbers are used together (mixed), all coordinate values will be handled in "mm/deg" units.
- Hand system flags are available from software version 8.08 onwards.
- X-arm and Y-arm rotation information is only available in software Ver. 10.66 onwards.

Values	X, Y, Z, R, A, B	, BSpace-separated coordinate values for each axis	
	F	Hand system flag (SCARA robot only)	
	F1	X-arm rotation information (YK500TW model only).	
	F2	Y-arm rotation information (YK500TW model only).	

Explanation

Directly specifies coordinate values by a numeric value. If an integer is used, this is interpreted as "pulse" units, and if a real number is used, this is interpreted as "mm/deg" units, with movement occurring accordingly.

Hand system flags can be specified for SCARA robots when directly specifying the coordinate values in "mm" units.

To specify an extended hand system flag for SCARA robots, set either 1 or 2 at "F". If a number other than 1 or 2 is set, or if no number is designated, 0 will be set to indicate that there is no hand system flag.

- 1: Right-handed system is used to move to a specified position.
- 2: Left-handed system is used to move to a specified position.

Direct numeric value inputs can be used to set the X-arm and Y-arm rotation information (*1) only on YK500TW model robots where the coordinate system-ofunits has been set as "mm".

To set extended X-arm and Y-arm rotation information at the YK500TW model robot, a "-1", "0", or "1" value must be specified at F1 and F2. Any other value, or no X-arm and Y-arm rotation information at all, will be processed as "0".

- 0: Indicates arm rotation information where movement to the "0" position has been specified.
- 1: Indicates arm rotation information where movement to the "1" position has been specified.
- -1: Indicates arm rotation information where movement to the "-1" position has been specified.
- *1: For details regarding the X-arm and Y-arm rotation information, refer to Chapter 4 "3. Point data format".



 At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

.....

SAMPLE

MOVEI P, 10000 10000 1000 1000 0 0

..... From its current position, the axis moves (PTP movement) the specified amount (pulse units).

Point definition



Format

<point expression>[,<point expression>...]

Explanation

Specifies a <point expression>. Two or more data items can be designated by separating them with a comma (,).



• At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

.....

SAMPLE

MOVEI P,P1 From its current position, the axis moves (PTP movement) the amount specified by P1.

A

В

C

D

Е

F

J

M

• This option specifies only

specified speed.

the maximum speed

and does not guarantee movement at the

Option types

Speed setting

PTP

Format

- 1. SPEED = <expression>
- 2. $S = \langle expression \rangle$

Values <expression>1 to 100 (units: %)

Explanation Specifies the program speed in an <expression>.

The actual speed will be as follows:

• [Robot max. speed (mm/sec)] × [automatic movement speed (%)] × [program movement speed (%)].

This option is enabled only for the specified MOVEI / MOVEI2 statement.

SAMPLE

MOVEI P,P10,S=10 From its current position, the axis moves (PTP movement) the amount specified by P1, at 10% of the program movement speed.

Related commands MOVE, MOVE2, DRIVE, DRIVE2, DRIVE1, DRIVE12, WAIT ARM, WAIT ARM2

A

В

C

D

E

F

G

G

1

J

M

OFFLINE

Sets a specified communication port to the "offline" mode

Format

OFFLINE [| ETH |] [CMU]

• A port can be specified only in the following software versions:

RCX240 Ver. 10.20 onwards RCX22x Ver. 9.27 onwards

• In controller versions prior to those shown above, a port cannot be specified. Only RS-232C operation is available.

Values

<expression>.....ETH, CMU, or no setting

Explanation Changes the communication mode parameter in order to switch the communication mode to OFFLINE.

> ETH.....Changes the Ethernet communication mode parameter to OFFLINE and clears the transmission and reception buffers. CMU or no setting Changes the RS-232C communication mode parameter to OFFLINE, resets the communication error, and clears the reception buffer.

SAMPLE

OFFLINE

SEND CMU TO A\$

SEND CMU TO P10

ONLINE

HALT

Format

ORD (<character string expression>)

Explanation Acquires the character code of the first character in a <character string expression>.

SAMPLE

(=&H42) is assigned to A.

Related commands

CHR\$

ON ERROR GOTO

Jumps to a specified label when an error occurs

Format

- 1. ON ERROR GOTO < label>
- 2. ON ERROR GOTO 0

Values

Error output information...... ERR: Error code number

ERL: Line number where error occurred

Explanation Even if an error occurs during execution of the robot language, this statement allows the program to jump to the error processing routine specified by the <label>, allowing the program to continue without being stopped (this is not possible for some serious errors.)

> If "0" is specified instead of the <label>, the program stops when an error occurs, and an error message displays.

> If ON ERROR GOTO "0" is executed at any place other than an error processing routine, the ON ERROR GOTO command is canceled (interruption canceled).

> The error processing routine can process an error using the RESUME statement and the error output information (ERR, ERL).



- If a serious error such as "17.4: Overload" occurs, the program execution stops.
- The most recently executed "ON ERROR GOTO < label>" statement is valid.
- If an error occurs during an error processing routine, the program will stop.
- "ON ERROR GOTO <label>" statements cannot be used within error processing routines.

SAMPLE

ON ERROR GOTO *ER1

FOR A = 0 TO 9

P[A+10] = P[A]

NEXT A

*L99: HALT

' ERROR ROUTINE

*ER1:

IF ERR = &H0604 THEN *NEXT1 Checks to see if a "Point doesn't exist"

error has occurred.

IF ERR = &H0606 THEN *NEXT2 Checks to see if a "Subscript out of range" error has occurred.

ON ERROR GOTO 0 Displays the error message and stops the program.

*NEXT1:

RESUME NEXT·····Jumps to the next line after the error line and resumes program execution.

*NEXT2:

RESUME *L99Jumps to label *L99 resumes program execution.

Related commands

RESUME

ON to GOSUB

Executes the subroutine specified by the <expression> value

```
Format
```

ON<expression>GOSUB<label 1> [,<label 2>...] * GOSUB can also be expressed as "GO SUB".

Values

<expression>.....0 or positive integer

Explanation The <expression> value determines the program's jump destination.

An <expression> value of "1" specifies a jump to <label 1>, "2" specifies a jump to <label 2>, etc.

Likewise, (<expression> value "n" specifies a jump to <label n>.)

If the <expression> value is "0" or if the <expression> value exceeds the number of existing labels, no jump occurs, and the next command is executed.

After executing a jump destination subroutine, the next command after the ON to GOSUB statement is executed.

SAMPLE

```
' MAIN ROUTINE
```

*ST:

ON DI3() GOSUB *SUB1, *SUB2, *SUB3 ····· *SUB1 to *SUB3 are executed.

GOTO *ST Returns to *ST.

HALT

' SUB ROUTINE

*SUB1:

MOVE P, P10, Z=0

RETURN

*SUB2:

DO(30) = 1

RETURN

*SUB3:

DO(30) = 0

RETURN

Related commands

GOSUB, RETURN, DECLARE

Format

```
ON<expression>GOTO<label 1> [,<label 2>...]
              * GOTO can also be expressed as "GO TO".
```

Values

<expression>.....0 or positive integer

Explanation The <expression> value determines the program's jump destination.

An <expression> value of "1" specifies a jump to <label 1>, "2" specifies a jump to <label 2>, etc.

Likewise, (<expression> value "n" specifies a jump to <label n>.)

If the <expression> value is "0" or if the <expression> value exceeds the number of existing labels, no jump occurs, and the next command is executed.

```
SAMPLE
```

```
' MAIN ROUTINE
*ST:
ON DI3() GOTO *L1, *L2, *L3.....Jumps to *L1 to *L3
                                  in accordance with
                                  the DI3() value.
GOTO *ST ..... Returns to *ST.
HALT
' SUB ROUTINE
*L1:
  MOVE P, P10, Z=0
  GOTO *ST
*L2:
  DO(30) = 1
  GOTO *ST
*L3:
  DO(30) = 0
  GOTO *ST
```

Related commands

GOTO, DECLARE

8

NOTE

A port can be specified

only in the following software versions:

RCX240 Ver. 10.20 onwards

RCX22x Ver. 9.27 onwards

• In controller versions prior to those shown above, a

port cannot be specified.

Only RS-232C operation is

available.

ONLINE

Sets the specified communication port to the "online" mode

Format

ONLINE [| ETH |] [CMU]

Values

<expression>.....ETH, CMU, or no setting

Explanation Changes the communication mode parameter in order to switch the communication mode to ONLINE.

> ETHChanges the Ethernet communication mode parameter to ONLINE and clears the transmission and reception buffers.

> CMU or no setting......Changes the RS-232C communication mode parameter to ONLINE, resets the communication error, and clears the reception buffer.

SAMPLE

HALT

ONLINE SEND CMU TO A\$ SEND CMU TO P10 OFFLINE

ORGORD / ORGORD2

Specifies/acquires the robot's return-to-origin sequence

Explanation Sets the axis sequence parameter for the robot's return-to-origin and absolute search operations.

sub group: n to nnnn (n : 0 to 4)

The 1 to 6 axes are expressed as "1 to 6" values, respectively, and the <expression> value must be 1-digit to 6-digit integer (1 to 4 for the sub group).

The same axis cannot be specified twice.

After the specified axes are returned to their origin points in sequence, from left to right, the remaining axes return to their origin points simultaneously.

If the <expression> value is "0", all axes will be returned to their origin points simultaneously.

Functions

Format
ORGORD

Format
ORGORD2

Main group
Sub group

Explanation Acquires the axis sequence parameter for return-to-origin and absolute search operations.

SAMPLE
A=3
ORGORD A A return-to-origin is executed first for axis 3.
ABSRST After the main group's axis 3 return-
to-origin is completed, a return-to-
origin is executed for the remaining
axes, followed by an absolute reset.
MOVE P, P0
A=ORGORD The main group's return-to-
origin sequence parameter is
assigned to variable A.
HALT

Related commands

ABSRST, ORIGIN

Q

W

Χ

Y

ORIGIN

Performs an incremental mode axis return-to-origin

Format

ORIGIN

Explanation This statement performs a return-to-origin for an incremental mode axis, or an absolute search for a semi-absolute axis.

> If the movement is stopped at an intermediate point, an "incomplete return-to-origin" status will occur.

> When two robots are specified, the return-to-origin and absolute search are first performed for the main group and then for the sub robot group.

SAMPLE ORIGIN ······ Performs an incremental mode return-to-origin.

Related commands ABSRST, ORGORD, ORGORD2, MCHREF, MCHREF2

A value other than "0" must be set for the execution <level> in order to execute the ORIGIN command. For details regarding how to check and change the execution <level> value, see section 13 "3.10 Setting the UTILITY mode", and section 15 "6 Execution Level".



Turns ON the specified port output



The OUT statement is available in software version 8.22 onwards.

Format	
OUT	DOm([b, · · · ,b]) [, <time>] DO(mb, · · · ,mb) MOm([b, · · · ,b]) MO(mb, · · · ,mb) SOm([b, · · · ,b]) SO(mb, · · · ,mb) LO0([b, · · · ,b]) LO(0b, · · · ,0b) TO0([b, · · · ,b])</time>

Values

m: port number2 to 7, 10 to 17, 20 to 27

b: bit definition0 to 7

<expression>......1 to 3600000 (units: ms)



CAUTION

Output to ports "0" and "1" are not allowed at DO, MO, and SO.



• For bit setting details, see Chapter 3 "10 Bit Settings".

Explanation This statement turns ON the specified port output and terminates the command. (The program proceeds to the next line.) Output to that port is then turned OFF after the time specified by the <expression> has elapsed. If the operation is stopped temporarily at an intermediate point and then restarted, that port's output is turned OFF when the remaining <expression> specified time has elapsed.

> <expression> values are rounded downward to the nearest even 10 (e.g., 113 \rightarrow 110). Or, if a value is less than 10, it becomes 10.

If this <expression> is omitted, the specified port's output remains ON.

Up to 16 OUT statements using <expressions> can be executed at the same time. Attempting to execute 17 or more OUT statements will activate error "6.26: Insufficient memory for OUT".

If multiple bits are specified, they are expressed from the left in descending order (large to small).

If no hardware port exists, nothing is output.

SAMPLE

OUT DO2(),200.....Turns DO(27 to 20) ON, turns them OFF 200ms later.

OUT DO(37,35,27,20) Turns DO(37, 35, 27, 20) ON.

Related commands

DO, MO, SO, TO, LO

OUTPOS / OUTPOS2

Specifies/acquires the OUT enable position parameter of the robot

Format

main group

- 1. OUTPOS <expression>
- 2. OUTPOS (<axis number>) = <expression>

-

Format

sub group

 The OUTPOS2 statement can be used only when a sub group setting has been specified in the system generation.

NOTE

- 1. OUTPOS2 <expression>
- 2. OUTPOS2 (<axis number>) = <expression>

Explanation Changes the parameter's OUT position to the value indicated by the <expression>. Format 1: The change is applied to the group axes.

Format 2: The change is applied only to the axis specified by <axis number>.



• If an axis that is set to "no axis" in the system generation is specified, a "5.37: Specification mismatch" error message displays and command execution is stopped.

Functions

Format

Format

main group

sub group

OUTPOS(<axis 1>)



NOTE

OUTPOS2(<axis 2>)

 The OUTPOS2 statement can be used only when a sub group setting has been specified in the system generation.



Explanation Acquires the OUT position parameter value for the axis specified by the <expression>.



• If an axis that is set to "no axis" in the system generation is specified, a "5.37: Specification mismatch" error message displays and command execution is stopped.

P

5

U

W

X

```
SAMPLE
' CYCLE WITH DECREASING OUTPOS
DIM SAV(3)
GOSUB *SAVE_OUTPOS
FOR A=1000 TO 10000 STEP 1000
   GOSUB *CHANGE_OUTPOS
   MOVE P, P0
   DO3(0)=1
   MOVE P, P1
   DO3(0) = 0
NEXT A
GOSUB *RESTORE_OUTPOS
HALT
*CHANGE_OUTPOS:
   FOR B=1 TO 4
      OUTPOS(B) = A
   NEXT B
  RETURN
*SAVE OUTPOS:
   FOR B=1 TO 4
      SAV(B-1)=OUTPOS(B)
   NEXT B
   RETURN
*RESTORE OUTPOS:
   FOR B=1 TO 4
      OUTPOS (B) = SAV(B-1)
   NEXT B
   RETURN
```

Ν

0

P

Q

P

S

-

U

W

Χ

Y

PATH

Specifies the main robot axis PATH motion path



NOTE

The PATH statement is available in software version 8.38 onwards.

Tomia							
PATH	L	, <point< th=""><th>definition></th><th>[,</th><th>option</th><th>[,</th><th>option]]</th></point<>	definition>	[,	option	[,	option]]

Explanation Sets the PATH motion path for the main robot axis. This command can only be executed between the PATH SET and PATH END commands. If execution is attempted elsewhere, an error will occur.

• Movement type: Linear interpolation and circular interpolation.

• Point setting: By direct numeric value input and by point definition.

• Options: Speed setting, coordinate plane setting (for circular interpolation only), and port output setting.

PATH motion types

Linear interpolation movement

"PATH L..." is set for linear interpolation movement.

Circular interpolation movement

"PATH C..." is set for circular interpolation movement.

Only the X, Y and Z coordinate values of the specified points are valid for PATH motion. Any other coordinates use the coordinate values of the PATH motion START point.

The motion path can be connected by repeated PATH commands ("PATH L", "PATH C") to allow movement without stopping.













Point data setting types

Direct numeric value input

linear interpolation Circular interpolation

NOTE

X-arm and Y-arm rotation information is only available in software Ver. 10.66 onwards.

Format

X Y Z R A B [F] [F1] [F2]

X, Y, Z, R, A, B.....Space-separated coordinate values for each axis. FHand system flag (SCARA robot only) F1X-arm rotation information (YK500TW model only). F2Y-arm rotation information (YK500TW model only).

Explanation

Directly specifies coordinate data by a numeric value. If an integer is used, this is interpreted as "pulse" units, and if a real number (with decimal point) is used, this is interpreted as "mm" units. If both integers and real numbers are used together (mixed), all coordinate values will be handled in "mm" units.

With this format, only 1 point can be specified as the movement destination coordinates. The only type of movement specified by this point data setting is linear interpolation.

Hand system flags can be specified for SCARA robots when directly specifying the coordinate data in "mm" units.

To specify an extended hand system flag for SCARA robots, set either 1 or 2 at "F". If a number other than 1 or 2 is set, or if no number is set, 0 will be set to indicate that there is no hand system flag.

- 1: Right-handed system is used to move to a specified position.
- 2: Left-handed system is used to move to a specified position.

Direct numeric value inputs can be used to set the X-arm and Y-arm rotation information (*1) only on YK500TW model robots where the coordinate system-ofunits has been set as "mm".

To set extended X-arm and Y-arm rotation information at the YK500TW model robot, a "-1", "0", or "1" value must be specified at "F1" and "F2". Any other value, or no X-arm and Y-arm rotation information at all, will be processed as "0".

- 0: Indicates arm rotation information where movement to the "0" position has been specified.
- 1: Indicates arm rotation information where movement to the "1" position has been specified.
- -1: Indicates arm rotation information where movement to the "-1" position has been specified.
- *1: For details regarding the X-arm and Y-arm rotation information, refer to Chapter 4 "3. Point data format".

The same hand system must always be used between a motion path's START and **END points.** The hand system cannot be changed between these points.

CAUTION

- The hand system used during PATH motion must be the same as the hand system used at the path motion route's start point. The same applies if the path is to pass through points where hand system flags are set. Differing hand systems will cause an error and disable motion.
- •The X-arm and Y-arm rotation information during PATH movement must be the same as the X-arm and Y-arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled.

PATH **8-131**

Moreover, the X-arm and Y-arm rotation information must be the same throughout the movement path, from the path's START to END points. The X-arm and Y-arm rotation information cannot be changed at any point along the path.

PATH

 At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

SAMPLE

PATH L,10000 10000 1000 1000 0 0The target position is "pulse" units, and linear interpolation movement occurs. PATH L,150.00 250.00 10.00 30.00 0.00 0.00 1 The target position is set in the

coordinate values specified by the right-handed system, and linear interpolation movement occurs.



CAUTION

•The hand system used during PATH motion must be the same as the hand system used at the path motion route's start point. The same applies if the path is to pass through points where hand system flags are set. Differing hand systems will cause an error and disable motion.



Point definition

(linear interpolation) (Circular interpolation)

Format

<point definition> [,<point definition>...]

Explanation

Specifies the movement destination as <point expression> value. Two or more data items can be designated by separating them with a comma (,). For circular interpolation movement, 2 points must be specified for each arc.

 At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

CAUTION

•The X-arm and Y-arm rotation information during PATH movement must be the same as the X-arm and Y-arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled.

SAMPLE

PATH L, P1, P2, P3 Specifies sequential linear interpolation movement to positions specified by P1, P2 and P3.

PATH C, P5, P6, P7, P8 ······ Specifies circular interpolation movement through the following points: current position, P5, P6, and P6, P7, P8.

Option types

Speed setting

linear interpolation Circular interpolation

Format

- 1. SPEED = <expression>
- 2. $S = \langle expression \rangle$

<expression>......1 to 100 (units: %)

 This defines the maximum **Explanation** speed, and does not

guarantee that all movement will occur at

specified speed.

The program's movement speed is specified as the <expression> value (units: %). The actual speed is determined as shown below.

• Robot's max. speed (mm/sec) × automatic movement speed (%)× program movement speed (%).

This option is enabled only for the specified PATH statement.

SAMPLE

PATH L, P5, S=40 Movement to the position specified by P5 occurs at 40% of the program movement speed.

Format

VEL = <expression>

<expression>.....The permissible setting range varies according to the robot type (units: mm/sec).

Explanation The movement speed is specified by the <expression> value (units: mm/sec). An error will occur if the speed is too fast.

This command is enabled only for the specified PATH statement.

SAMPLE

PATH L, P10, VEL=150 Movement to the position specified by P10 occurs at a speed of 150mm/sec.

NOTE

• This option specifies only the maximum composite speed and does not guarantee movement at the specified speed.

PATH

 Coordinate plane setting
--

linear interpolation Circular interpolation

Format ΧY

YZZX

Values

XY.....XY coordinate plane

YZ......YZ coordinate plane

ZX.....ZX coordinate plane

Explanation

Specifies the coordinate plane on which to draw a circular arc for circular interpolation movement. If no coordinate plane is specified, 3-dimensional circular interpolation movement is used.

Only circular interpolation movement can be specified by this coordinate plane setting.

This command is enabled only for the specified PATH statement.

SAMPLE

PATH C, P1, P2, XY ······ Circular interpolation movement occurs within the XY plane, with the Z-axis moving to the P2 Z-axis coordinates position.

Port output setting

(linear interpolation) (Circular interpolation

Format 1

DO $|m([b, \dots, b])| = (expression 1> @(expression 2>$ MO SO

Format 2

DO	(mb, •	 ,mb)= <ex< th=""><th>pression</th><th>1></th><th>@<expression< th=""><th>2></th><th></th></expression<></th></ex<>	pression	1>	@ <expression< th=""><th>2></th><th></th></expression<>	2>	
MO							
SO							

Output to ports "0" and "1" is not allowed at DO, MO, and SO.



• For details regarding bit definitions, see Chapter 3 "10 Bit Settings".

Values

m: port number2 to 7, 10 to 17, 20 to 27 b: bit definition0 to 7 <expression 1>......Value which is output to the specified port (only integers are valid).

<expression 2>......Position where the port output occurs. This position can be specified in "mm" units down to the 2nd decimal position.

Explanation

During PATH motion, this command option outputs the value of <expression 1> to the specified port when the robot reaches the <expression 2> distance from the

The <expression 2> numeric value represents a circle radius centered on the movement START point.

If multiple bits are specified, they are expressed from the left in descending order (large to small). If the [b,...,b] data is omitted in format 1, all 8 bits are processed. If no hardware port exists, nothing is output.

SAMPLE

PATH SET

PATH L, P1, DO(20) = 1@10 ····· During linear interpolation movement to P1, "1" is output to DO(20) at a 10mm radius position from the START position.

PATH L, P2, DO(21) = 1@12.5 ··· During linear interpolation movement to P2, "1" output to DO(21) at a 12.5mm radius position from P1.

PATH END PATH START

Related commands

PATH SET, PATH END, PATH START

(Reference)

For PATH function details, see Chapter 9 "PATH Statements".

PATH END

Ends the movement path setting



NOTE

• The PATH END statement is available in software version 8.38 onwards.

Format

PATH END

Explanation Ends the path setting for PATH motion.

The PATH END command must always be paired with a PATH SET command. The PATH motion path end-point is the final point specified by the final PATH command (PATH L, PATH C) which exists between the PATH SET and PATH END commands. Attempting to execute a PATH END command when no PATH SET command has been executed will result in an error.

Related commands

PATH, PATH SET, PATH START

Reference

For PATH function details, see Chapter 9 "PATH Statements".

PATH SET

Starts the movement path setting



NOTE

The PATH SET statement is available in software version 8.38 onwards.

Format

PATH SET [<point definition>]

Explanation Starts the path setting for PATH motion.

Specifies the <point definition> position as the PATH motion start-point. (This only sets the PATH motion start point and does not actually begin robot motion.) If the <point definition> value is omitted, the current robot position is set as the start point. However, if robot movement is in progress, the target position of that movement becomes the start point. (Example: The OUT position range is wider for the MOVE

command which precedes the PATH SET command, so the robot is still moving when the PATH SET command is executed.) The PATH SET command must always be paired with a PATH END.

When a PATH SET command is executed, the previously set PATH motion path data is deleted.

• Point data setting: By direct numeric value input and by point definition

Point data setting types

Direct numeric value input

Format

X Y Z R A B [F] [F1] [F2]



NOTE

- If both integers and real numbers are used together (mixed), all coordinate values will be handled in "mm/deg" units.
- X-arm and Y-arm rotation information is only available in software Ver. 10.66 onwards.



CAUTION

- The hand system used during PATH motion must be the same hand system as that at the PATH motion's start-point. An error will occur if the hand systems are different.
- •The X-arm and Y-arm rotation information during PATH movement must be the same as the X-arm and Y-arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled.

Values

X, Y, Z, R, A, B.....Space-separated coordinate values for each axis.

FHand system flag (SCARA robot only)

F1X-arm rotation information (YK500TW model only).

F2Y-arm rotation information (YK500TW model only).

Explanation

Directly specifies the path's start-point coordinates for PATH motion. If an integer is used, this is interpreted as "pulse" units, and if a real number is used, this is interpreted as "mm" units (valid down to the 2nd decimal position).

Hand system flags can be specified for SCARA robots when directly specifying the coordinate data in "mm" units.

To specify an extended hand system flag for SCARA robots, set either 1 or 2 at "F". If a number other than 1 or 2 is set, or if no number is set, 0 will be set to indicate that there is no hand system flag.

- 1: Indicates that a right-handed system is specified for the PATH motion's start-point.
- 2: Indicates that a left-handed system is specified for the PATH motion's start-point.

Direct numeric value inputs can be used to set the X-arm and Y-arm rotation information (*1) only on YK500TW model robots where the coordinate system-ofunits has been set as "mm".

To set extended X-arm and Y-arm rotation information at the YK500TW model robot, a "-1", "0", or "1" value must be specified at F1 and F2. Any other value, or no X-arm and Y-arm rotation information at all, will be processed as "0".

72

- N
- 0

- S
- 7

U

V

VV



Z

- 0: Indicates that the PATH movement START point's arm rotation information has been set at the "0" position.
- 1: Indicates that the PATH movement START point's arm rotation information has been set at the "1" position.
- -1: Indicates that the PATH movement START point's arm rotation information has been set at the "-1" position.
- *1: For details regarding the X-arm and Y-arm rotation information, refer to Chapter 4 "3. Point data format".



• At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

SAMPLE

```
PATH SET 120 250.00 55.2 20.33 0 0

PATH motion's start-point is specified in "mm" units as follows: (120.00 250.00 55.20 20.33 0.00 0.00).

PATH SET -51200 80521 7045 204410 0 0

PATH motion's start-point is specified in "pulse" units.
```

Point definition

Format

<point definition>

Explanation

The PATH motion's start-point is specified by the <point expression>.

• At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

(CAUTION

disable motion.

CAUTION

The hand system used

during PATH motion must be the same as the hand

system used at the path motion route's start point. Differing hand systems

will cause an error and

MEMO

• The X-arm and Y-arm rotation information during PATH movement must be the same as the X-arm and Y-arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled.

SAMPLE

PATH SET P10 The PATH motion's start-point is set as P10.

PATH SET WHERE.... The PATH motion's start-point is set as the robot's current position.

Related commands

PATH, PATH END, PATH START

Reference

For PATH function details, see Chapter 9 "PATH Statements".

PATH START

Starts the PATH motion



The PATH START statement is available in software version 8.38 onwards.

Format

PATH START

Explanation Starts PATH motion.

Before PATH START can be executed, the PATH motion path must be specified by the PATH SET command, PATH commands (PATH L, PATH C) and the PATH END command. The robot must also be positioned at the motion path's start-point which was specified by the PATH SET command.

The robot's PATH motion speed is the automatic movement speed (%) which was in effect when the PATH START was executed, multiplied by the program movement speed (%) specified by the SPEED command or the (SPEED or S) option of the PATH command. A speed specified by the "VEL" option of the PATH command does not rely on the automatic movement speed.

After PATH motion begins, the PATH START command is terminated when the robot reaches the PATH motion end-point, or when movement is stopped by an interlock, etc.

This command can only be executed in Task 1 (main task).

Related commands

PATH, PATH SET, PATH END

Reference

For PATH function details, see Chapter 9 "PATH Statements".

Format

PDEF(<Pallet definition number>) = <expression 1>, <expression 2> [, <expression 3>]

Values

<Pallet definition number>....0 to 19

<expression 1>.....Number of points (NX) between P[1] and P[2].

<expression 2>.....Number of points (NY) between P[1] and P[3].

<expression 3>.....Number of points (NZ) between P[1] and P[5].

Total number of points: <expression $1> \times <$ expression

 $2 \times$ < expression $3 \times$ must be 32767 or less.

Regarding the P[1] to P[5] definition, see the figure below.

Explanation


Defines the pallets to permit execution of the pallet movement command.

Also changes the dividing conditions of previously defined pallet data.

After specifying the number of points per axis, the equally-spaced points for each axis are automatically calculated and defined in the sequence shown in the figure below. If <expression 3> (Z-axis direction) is omitted, the height direction value becomes "1".

The total number of points defined for a single pallet must not exceed 32,767.

Automatic point calculation



33815-R7-00

The point data for pallet definition uses the following data areas.

Pallet definition	P[1]	P[2}	P[3}	P[4]	P[5]
Pallet 0	P3996	P3997	P3998	P3999	P4000
Pallet 1	P3991	P3992	P3993	P3994	P3995
•	•		•	•	:
Pallet 19	P3901	P3902	P3903	P3904	P3905

SAMPLE

PDEF(1)=3,4,2 ····· Pallet definition 1 is defined as $3 \times 4 \times 2$.

G

K

S

Т

U

Х

Y

PMOVE / PMOVE2

Executes a pallet movement command for the robot

Format

main group

sub group

PMOVE (<pallet definition number> , <pallet position number>) [,option[,option]...]

NOT

 The PMOVE2 statement can be used only when a sub group setting has been specified in the

system generation.

Format

PMOVE2 (<pallet definition number> , <pallet position number>)[,option[,option]...]

Values

<pallet definition number>.....0 to 19
<pallet position number>......1 to 32767

Explanation

Executes a robot axis "pallet move" command. (The specified pallet numbers must be registered in advance.)

The PMOVE command applies to all main robot axes, and the PMOVE2 command applies to all sub robot axes. These commands do not apply to any other group axes, or to auxiliary axes.


• Movement type: PTP

Pallet definition number: Numeric expressionPallet position number: Numeric expression

• Options: Speed setting, arch motion setting, STOPON condition setting

The position numbers for each pallet definition are shown below.

Position numbers for each pallet definition



33816-R7-00

• Although the XYZ axes move to the positions determined by calculated values, the R-axis moves to the position specified by pallet point data P[1].

Options	PTP	Remarks
Speed setting (SPEED)	0	Enabled only for specified PMOVE statement
Arch motion	0	Enabled only for specified PMOVE statement
STOPON condition setting	0	Enabled only by program execution

SAMPLE

PMOVE(1,16) The main robot axis moves from its current position to the position specified by pallet position number 16 of pallet definition number 1.

3

V

W

Χ

Y

Movement type

PTP (point-to-point) movement

PTP movement begins after positioning of all movement axes is complete (within the tolerance range), and the command terminates when the movement axes enter the OUT position range. Although the movement axes reach their target positions simultaneously, their paths are not guaranteed.

Caution regarding commands which follow the PMOVE / PMOVE2 command:


If the next command following the PMOVE / PMOVE2 command is an executable command such as a signal output command, that next command will start when the movement axis enters the OUT position range. In other words, that next command starts before the axis arrives within the target position OUT position range.


Example:

Signal output (DO, etc.)	Signal is output when axis enters within OUT position range.
DELAY	DELAY command is executed and standby starts, when axis enters the OUT position range.
HALT	Program stops and is reset when axis enters the OUT position range. Therefore, axis movement also stops.
HOLD	Program temporarily stops when axis enters the OUT position range. Therefore, axis movement also stops.
WAIT	WAIT command is executed when axis enters the OUT position range.

The WAIT ARM / WAIT ARM2 statements are used to execute the next command after the axis enters the tolerance range.

PMOVE command





This option specifies only

the maximum speed and does not guarantee

movement at the

specified speed.

Option types

Speed setting

Format

- SPEED = < expression >1.
- $S = \langle expression \rangle$ 2.

<expression>......1 to 100 (units: %)

Explanation

Specifies the program speed in an <expression>. The movement speed is the automatic movement speed multiplied by the program movement speed. This option is enabled only for the specified PMOVE / PMOVE2 statement.

SAMPLE

PMOVE (1,3), S=10...... Movement occurs at 10% of the program speed, from the current position to the position specified by pallet position number 3 of pallet definition number 1.

Arch motion setting



Format

 $x = \langle expression \rangle [, x = \langle expression \rangle ...]$

Values xSpecifies the Z,R,A,B axis.

<expression>......An integer value is processed in "pulse" units.

A real number (with decimal point) is process in "mm/ deg" units.


Explanation

- 1. The "x" specified axis begins moving toward the position specified by the <expression>.
- 2. When the "x" specified axis enters the arch position range, all other axes move toward the target position.
- 3. When all axes other than the "x" specified axis enter the arch position range, and the "x" specified axis enters the tolerance range of the position specified by the <expression>, the "x" specified axis then moves to the target position.
- 4. The command ends when all axis enter the OUT position range.

SAMPLE

PMOVE (1,A), Z=0 ······The Z-axis first moves from the current position to the "O pulse" position. Then the other axes move to the position specified by pallet position number A of pallet definition number 1. Finally the Z-axis moves to the position specified by pallet position number A.

PMOVE / PMOVE2



33817-R7-00

STOPON condition setting

PTP

Format

STOPON < conditional expression>

Explanation

Stops movement when the conditions specified by the conditional expression are met. Because this is a deceleration type stop, there will be some movement (during deceleration) after the conditions are met.

If the conditions are already met before movement begins, no movement occurs, and the command is terminated.

This option is only possible by program execution.

SAMPLE

PMOVE (A, 16), STOPON DI (20) = 1

..... Moves from the current position to the position specified by pallet position number 16 of pallet definition number A, then decelerates and stops when the condition "DI(20) = 1" is met.

MEMO



NOTE

 This parameter is only available in the following software versions:

RCX14x Ver. 8.63 onwards RCX22x Ver. 9.08 onwards

•On earlier version controllers, -1 is "true" and a value other than -1 is "false" (not changeable).

 When the conditional expression used to designate the STOPON condition is a numeric expression, the conditions for determining a TRUE or FALSE status can be changed at the controller's "TRUE conditions" in the "Other parameters" mode. These conditions apply to all the IF, WHILE, WAIT, STOPON, etc., conditional expressions. For details, refer to the controller user's manual.

1) -1 (default setting) An expression value of "-1" indicates a TRUE status, and "0" indicates

a FALSE status.

A "6.35 Incorrect condition expression" error occurs if the expression

value is other than "-1" or "0".

2) not 0 Any expression value other than "0" indicates a TRUE status, and "0"

indicates a FALSE status.

Format

x y z r a b [f] [f1] [f2] Pn

In controllers with software versions earlier than 8.28, only point numbers 0 to 4000 can be specified by point variables.



nPoint number: 0 to 9999. x, y, z, r, a, b......Point data: the range varies according to the format.

fHand system flag: 1 or 2 (for SCARA robots only). f1X-arm rotation information: -1, 0, 1 (YK500TW model only).

Explanation Defines the point data.



- If both integers and real numbers are used together (mixed), all coordinate values will be handled in "mm/deg"
- Hand system flags are only available from software version 8.08 onwards.
- X-arm and Y-arm rotation information is only available in software Ver. 10.66 onwards.

- 1. "n" indicates the point number.
- 2. Input data for "x" to "b" must be separated with a space (blank).
- 3. If all input data for "x" to "b" are integers (no decimal points), the movement units are viewed as "pulses". "x" through "b" then correspond to axis 1 through axis 6.
- 4. If there is even 1 real number (with decimal point) in the input data for "x" through "b", the movement units are recognized as "mm". In this case, "x" to "z" correspond to the x, y and z coordinates of a Cartesian coordinate system, while "r" to "b" correspond to axes 4 to 6.
- 5. The input data ranges are as follows:

For "pulse" units: -6,144,000 to 6,144,000 range For "mm" units: -99,999.99 to 99,999.99 range

Hand system flags can be specified for SCARA robots when specifying point definition data in "mm" units.

To specify an extended hand system flag for SCARA robots, set either 1 or 2 at "f". If a number other than 1 or 2 is set, or if no number is designated, 0 will be set, indicating that there is no hand system flag.

- 1: Indicates a right-handed system point setting.
- 2: Indicates a left-handed system point setting.

X-arm and Y-arm rotation information (*1) can be specified on YK500TW where point data is defined in "mm" units.

To set extended X-arm and Y-arm rotation information at the YK500TW model robot, a "-1", "0", or "1" value must be specified at f1 and f2. Any other value, or no X-arm and Y-arm rotation information at all, will be processed as "0".

- 0: Indicates arm rotation information where "0" has been specified.
- 1: Indicates arm rotation information where "1" has been specified.
- -1: Indicates arm rotation information where "-1" has been specified.
- *1: For details regarding the X-arm and Y-arm rotation information, refer to Chapter 4 "3. Point data format".



NOTE

- All input values are handled as constants.
- •If controller power is turned off during execution of a point definition statement, a memory-related error such as "9.2: Point checksum error" may occur.

```
SAMPLE
P1 =
            0
                     0
                             0
                                     0
                                              0
                                                       0
       100.00 200.00
                         50.00
                                           0.00
                                                   0.00
P2 =
                                  0.00
        10.00
P3 =
                 0.00
                          0.00
                                  0.00
                                           0.00
                                                   0.00
P10= P2
FOR A=10 TO 15
   P[A+1] = P[A] + P3
NEXT A
FOR A=10 TO 16
   MOVE P, P1, P[A]
```

Related commands

NEXT A HALT

Point assignment statement (LET)

R

S

T

U

V

W

X

7

PPNT

Creates pallet point data

Format

PPNT(pallet definition number, pallet position number)

Explanation Creates the point data specified by the pallet definition number and the pallet position number.

SAMPLE

P10=PPNT(1,24) Creates, at P10, the point data specified by pallet position number 24 of pallet definition number 1.

Related commands

PDEF, PMOVE, PMOVE2

Ν

0

Р

Q

R

S

V

Χ

Y

```
Format
      [<expression][|,|<expression>...][|,|]
```

Values

PRINT

<expression>.....character string, numeric value, variable.

Explanation Displays a specified variable on the programming box screen.

Output definitions are as follows:

- 1. If numbers or character strings are specified in an <expression>, they display as they are. If variables or arrays are specified, the values assigned to the specified variables or arrays display.
- 2 If no <expression> is specified, only a line-feed occurs.
- 3. If the data length exceeds the screen width, a line-feed occurs, and the data wraps to the next line.
- 4. If a comma (,) is used as a display delimiter, a space (blank) is inserted between the displayed items.
- 5. If a semicolon (;) is used as a display delimiter, the displayed items appear in succession without being separated.
- 6. If the data ends with a delimiter, the next PRINT statement is executed without a line-feed. When not ended with a display delimiter, a line-feed occurs.
- Data communication to the programming box screen occurs in order for the PRINT statement to be displayed there. Therefore, program execution may be delayed when several PRINT statements are executed consecutively.

```
SAMPLE
PRINT A Displays the value of variable A.
PRINT "A1 ="; A1 ..... Displays the value of variable
                         A1 after "A1 =".
PRINT "B(0),B(1) = ";B(0);",";B(1)
PRINT P100 ..... Displays the P100 value.
```

Related commands

INPUT

RADDEG

Performs a unit conversion (radians → degrees)

Format

RADDEG(<expression>)

Values

<expression>.....Angle (units: radians)

Explanation Converts the <expression> value to degrees.

SAMPLE

 $\label{eq:LOCR(P0)=RADDEG(ATN(B))} \begin{tabular}{ll} Converts & the variable B \\ & arctangent value to degrees, \\ & and assigns it to R-data of P0. \end{tabular}$

Related commands

ATN, COS, DEGRAD, SIN, TAN

N

0

P

Q

R

S

T

V

W

X

Y

REM

Format

- 1. REM <character string>
- 2. ' <character string>

Explanation All characters which follow REM or an apostrophe (') are handled as a comment. This comment statement is used only to insert comments in the program, and it does not execute any command. The apostrophe (1) can be entered at any point in the line.

SAMPLE

REM *** MAIN PROGRAM *** *** SUBROUTINE *** ' HALT COMMAND ${\tt HALT}$

CAUTION

and SO.

REFERENCE

• Output to ports "0" and "1"

• For details regarding bit

"10 Bit Settings".

definitions, see Chapter 3

is not allowed at DO, MO,

Turns OFF the bits of specified ports, or clears variables

Format 1 RESET $DOm([b, \cdot \cdot \cdot, b])$ $DO(mb, \cdot \cdot \cdot, mb)$ $MOm([b, \cdot \cdot \cdot, b])$ $MO(mb, \cdot \cdot \cdot, mb)$ TO0([b, · · · ,b]) TO(0b, · · · , 0b) $LOO([b, \cdot \cdot \cdot, b])$ LO(0b, · · · , 0b) $SOm([b, \cdot \cdot \cdot, b])$ $SO(mb, \cdot \cdot \cdot, mb)$

Format 2

RESET TCOUNTER

Values

m: port number2 to 7, 10 to 17, 20 to 27 b: bit definition 0 to 7

Explanation Format 1: Turns the bits of specified ports OFF.

Format 2: Clears the 10ms counter variables (10ms counter variables are used to measure the time in 10ms units).

If multiple bits are specified, they are expressed from the left in descending order (large to small).

If the [b,...,b] data is omitted, all 8 bits are processed.

SAMPLE RESET DO2() Turns OFF DO(27 to 20). RESET DO2(6,5,1) Turns OFF DO(26, 25, 21). RESET (37,35,27,20) Turns OFF DO(37, 35, 27, 20). RESET TCOUNTER......Clears the 10ms counter variables.

Related commands

SET, DO, MO, SO, TO, LO

Restarts another task during a temporary stop

Format

RESTART

RESTART Tn

Values

n: Task number2 to 8

Explanation Restarts another task that has been temporarily stopped (SUSPEND status). RESTART cannot be executed for Task 1.

```
SAMPLE
START *SUBTASK, T2
   FLAG=1
*L0:
   IF FLAG=1 AND DI2(0)=1 THEN
      SUSPEND T2
      FLAG=2
   WAIT DI2(0)=0
   ENDIF
   IF FLAG=2 AND DI2(0)=1 THEN
      RESTART T2
      FLAG=1
      WAIT DI2(1)=0
   ENDIF
   MOVE P, P0
   MOVE P, P1
   GOTO *L0
   HALT
' SUBTASK ROUTINE
*SUBTASK:
   DO2(0)=1
   DELAY 1000
   DO2(0) = 0
   DELAY 1000
   GOTO *SUBTASK
   EXIT TASK
```

Related commands

CUT, EXIT TASK, START, SUSPEND

Reference

For details, refer to the "Multi-Task" item.

8

Ν

O

P

Q

R

S

1/

W

Х

Y

RESUME

Resumes program execution after error recovery processing

Format

- 1. RESUME NEXT
- 2. RESUME < label>



• For details, see Chapter 8 "60 ON ERROR GOTO".



Resumes program execution after recovery from an error.

Depending on its location, a program can be resumed in the following 3 ways:

1. RESUME The program resumes from the command which caused the

error.

2. RESUME NEXT The program resumes from the next command after the

command which caused the error.

3. RESUME < label > The program resumes from the command specified by the

<label>.



- The RESUME statement can also be executed in an error processing routine.
- "Error recovery processing is not possible for serious errors such as "17.4 : Overload", etc.

.....

Related commands

ON ERROR GOTO

N

0

P

Q

R

S

...

Y

Processing which was branched by GOSUB, is returned to the next line after GOSUB

```
Format
GOSUB < label>
                                   * GOSUB can also be expressed as "GO SUB".
<label>:
RETURN
```

Explanation Ends the subroutine and returns to the next line after the jump source GOSUB

All subroutines (jump destinations) specified by a GOSUB statement must end with a RETURN statement. Using the GOTO statement, etc., to jump from a subroutine will cause an error such as the "5.12: Stack overflow", etc.

```
SAMPLE
*ST:
   MOVE P, P0
   GOSUB *CLOSEHAND
   MOVE P, P1
   GOSUB *OPENHAND
GOTO *ST
HALT
' SUB ROUTINE
*CLOSEHAND:
   DO(20) = 1
RETURN
*OPENHAND:
   DO(20) = 0
RETURN
```

Related commands

GOSUB

RIGHT\$

Extracts a character string from the right end of another character string

Format

RIGHT\$(<character string expression>,<expression>)

Values

<expression>......0 to 75

Explanation

This function extracts a character string with the digits specified by the <expression> from the right end of the character string specified by <character string expression>. The <expression> value must be between 0 and 75, otherwise an error will occur. If the <expression> value is 0, then RIGHT\$ will be a null string (empty character string).

If the <expression> value has more characters than the <character string expression>, RIGHT\$ will become the same as the <character string expression>.

SAMPLE

B\$=RIGHT\$(A\$,4) 4 characters from the right end of A\$ are assigned to B\$.

Related commands

LEFT\$, MID\$

Ν

0

P

Q

R

S

. /

V

Χ

Υ

NOTE

system generation.

• RIGHT2 can be used only if a "sub group" setting has been specified in the

RIGHTY / RIGHTY2

Sets the SCARA robot hand system to "Right"

Format main group RIGHTY

Format


RIGHTY2

Explanation This statement specifies right-handed movement to a point specified in Cartesian coordinates. This statement only selects the hand system, and does not move the robot. If executed while the robot arm is moving, execution waits until movement is complete (positioned within tolerance range).

This command is only valid for SCARA robots.

SAMPLE	
RIGHTY	Specifies a robot "right-handed system" setting (see Fig.1 below).
MOVE P,P1	
LEFTY	Specifies a robot "left-handed system" setting (see Fig.2 below).
MOVE P,P1	
RIGHTY	
HALT	

SAMPLE:LEFTY/RIGHTY



33818-R7-00

sub group

Related commands

LEFTY, LEFTY2

RSHIFT

Shifts a bit value to the right

Format

RSHIFT(<expression 1>,<expression 2>)

Explanation Shifts the <expression 1> bit value to the right by the amount of <expression 2>. Spaces left blank by the shift are filled with zeros (0).

SAMPLE

A=RSHIFT(&B10111011,2) ······ The 2-bit-right-shifted &B10111011 value (&B00101110) is assigned to A.

Related commands

LSHIFT

N

0

P

Q

R

S

,

W

X

Y

All input values are

• If the controller power is turned off during

execution of a shift coordinate definition

statement, a memory-

related error such as "9.6:

Shift check-sum error"

may occur.

handled as constants.

Defines the shift coordinates in the program

Format

Sn = x y z r

Values

n0 to 9

x, y, z, r.....-99,999.99 to 99,999.99

Explanation Defines shift coordinate values in order to shift the coordinates for robot movement. Only "mm" units can be used for these coordinate values ("pulse" units cannot be used).

- 1. "n" indicates the shift number.
- 2. The "x" to "r" input data must be separated with spaces (blanks).
- 3. The "x" to "r" input data is recognized as "mm" unit data.
- 4. "x" to "z" correspond to the Cartesian coordinate system's x, y, z coordinate shift values, and "r" corresponds to the xy coordinates' rotational shift values.

SAMPLE

S0 =0.00 0.00 0.00 0.00

50.00 90.00 S1 = 100.00 200.00

P3 = 100.00 0.00 0.00 0.00 0.00 0.00

SHIFT SO

MOVE P, P3

SHIFT S1

MOVE P, P3

HALT

Related commands

Shift assignment statement, SHIFT, SHIFT2



SELECT CASE

Executes the specified command block in accordance with the <expression> value

```
Format
SELECT [CASE] <expression>
   CASE <expression list 1>
      [command block 1]
   [CASE <expression list 2>
      [command block 2]]
   [CASE ELSE
      [command block n]]
END SELECT
```

Explanation These statements execute multiple command blocks in accordance with the <expression> value. The setting method is as follows.

- 1. The <expression list> following CASE statement comprises multiple numerical expressions and character expressions separated from each other by a comma (,).
- 2. If the <expression> value matches one of expressions contained in the <expression list>, the specified command block is executed. After executing the command block, the program jumps to the next command which follows the END SELECT statement.
- 3. If the <expression> value does not match any of the expressions contained in the <expression list>, the command block indicated after the CASE ELSE statement is executed. After executing the command block, the program jumps to the next command which follows the END SELECT statement.
- 4. If the <expression> value does not match any of the expressions contained in <expression list> and no CASE ELSE statement exists, the program jumps to the next command following the END SELECT statement.

```
SAMPLE
WHILE -1
SELECT CASE DI3()
   CASE 1,2,3
      CALL *EXEC(1,10)
   CASE 4,5,6,7,8,9,10
      CALL *EXEC(11,20)
   CASE ELSE
      CALL *EXEC(21,30)
END SELECT
WEND
HALT
```

 Examples of erroneous writing to a read-only file: SEND CMU TO DIR SEND PNT TO SIO

• Examples of data format mismatches: SEND PGM TO PNT SEND SI() TO SFT

Explanation Sends < read file > data to the < write file >.

An entire DO, MO, TO, LO, SO, or SOW port (DO(), MO(), etc.), cannot be specified as a write file.

Moreover, some individual files (DOn(), MOn(), etc.) cannot be specified as a write file. For details, refer to Chapter 11 "Data file description".

Writing to read-only files (indicated by a "x" in the "WRITE" column of the table shown below) is not permitted.

Even if the READ and WRITE files are specified correctly, it may not be possible to execute them if there is a data format mismatch between the files.

NOTE

•Individual "point comment" files (PCn) are only available in the following software versions.

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

	Туре	Ella Mana		Definition Format	DEAD	WDITE
		File Name	All	Individual File	READ	WRITE
	User	All files	ALL		0	0
		Program	PGM	<pre><bbbbbbbb></bbbbbbbb></pre>	0	0
t		Point	PNT	Pn	0	0
) n		Point comment	PCM	PCn	0	0
e		Parameter	PRM	/ccccc/	0	0
		Shift definition	SFT	Sn	0	0
3		Hand definition	HND	Hn	0	0
3		Pallet definition	PLT	PLn	0	0
	Variable,	Variable	VAR	abby	0	0
	Constant	Array variable	ART	abby(x)	0	0
		Constant		"ccc"	0	×
	Status	Program directory	DIR	< <bbbbbbbb>></bbbbbbbb>	0	×
		Parameter directory	DPM		0	×
		Machine reference	MRF		0	×
		Error log	LOG		0	×
		Remaining memory size	MEM		0	×
	Device	DI port	DI()	Dln()	0	×
		DO port	DO()	DOn()	0	0
		MO port	MO()	MOn()	0	0
		TO port	TO()	TOn()	0	0
		LO port	LO()	LOn()	0	0
		SI port	SI()	SIn()	0	×
		SO port	SO()	SOn()	0	0
		SIW port	SIW()	SIWn()	0	×
		SOW port	SOW()	SOWn()	0	0
		RS-232C	CMU		0	0
		Ethernet	ETH		0	0
	Other	File END code	EOF		0	×

N: Number

a: Alphabetic character

b: Alphanumeric character or underscore ()

(): Permitted

c: Alphanumeric character or special symbol

x: Expression (array argument) y: Variable type

× : Not permitted

8-160 Chapter 8 Robot Language Lists



- The following cautions apply when a restart is performed after a stop occurred during execution of the SEND statement:
 - 1. When reading from RS-232C / Ethernet (SEND CMU TO XXX, SEND ETH TO XXX): When the SEND statement is stopped during data reading from the reception buffer, the data acquired up to that point is discarded.
 - 2. When writing to RS-232C / Ethernet (SEND XXX TO CMU, SEND XXX TO ETH): When the SEND statement is stopped during data writing to the transmission buffer, the data is written from the beginning.

SAMPLE
SEND PGM TO CMU··········Outputs all user programs from the RS-232C port.
SEND <prg1> TO CMU ·········· Outputs the PRG1 program from the RS-232C port.</prg1>
SEND CMU TO PNT······ Inputs a point data file from the RS-232C port.
SEND "T1" TO CMU Outputs the "T1" character string from the RS-232C port.
SEND CMU TO A\$ Inputs character string data to variable A\$ from the RS-232C port.

Reference For details, refer to Chapter 11 "Data file description".

Ν

0

P

Q

R

S

A/

Y

Y

SERVO / SERVO2

Controls the servo status

Format			main group
SERVO	ON	[(<axis number="">)]</axis>	
	OFF		
	FREE		
	PWR		

Format sub group SERVO2 ON [(<axis number>)] OFF FREE PWR

(Values) <axis number>.....main group: 1 to 6 sub group: 1 to 4

NOTE

The SERVO2 statement can be used only when a sub group setting has been specified in the system generation.

CAUTION

• Keep out of the robot movement range while the motor power is turned OFF by the SERVO OFF statement. Always check that the Emergency Stop is ON when working within the robot movement area.

Explanation This statement controls the servo ON/OFF at the specified axes or all axes. When the axes have been specified by an <axis number> setting, this statement applies only to the specified axes within the group. If no axes have been specified by an <axis number> setting, this statement applies to all the main and sub group axes. In this case, motor power supply ON/OFF switching occurs simultaneously with the servo ON/OFF operations.

- ONTurns the servo ON. If no axis is specified, the motor power supply also
- OFF......Turns the servo OFF and applies the dynamic brake. Axes equipped with brakes are all locked by the brake. If no axis is specified, the motor power supply also turns OFF.
- FREE.....Turns the servo OFF and releases the dynamic brake. The brakes are released at all axes with brakes. If no axis is specified, the motor power supply also turns OFF.
- PWRTurns only the motor power supply ON.

MEMO

• This statement is executed after positioning of all axes (in the main group and sub group) is complete (within the tolerance range).

• Individual axis servos cannot be turned ON as long as the motor power is OFF.

SAMPLE	ı
SERVO ON Turns servos ON at all axes after turning the motor power ON.	
SERVO OFF Turns the motor power OFF, then turns the servos at all axes OFF. Brakes are applied, and a lock status is established	
at axes equipped with brakes. SERVO FREE(3)	

CAUTION

MO, and SO.

REFERENCE

Output to ports "0" and "1"

are not allowed at DO,

• For bit setting details, see Chapter 3 "10 Bit Settings".

Turns the bit at the specified output port ON

Format SET $DOm([b, \cdot \cdot \cdot, b])$ [, <time>] DO $(mb, \cdot \cdot \cdot, mb)$ $MOm([b, \cdot \cdot \cdot, b])$ $MO (mb, \cdot \cdot \cdot , mb)$ TO0([b, · · · , b]) TO (0b, · · · , 0b) $LOO([b, \cdot \cdot \cdot, b])$ LO $(0b, \cdot \cdot \cdot, 0b)$ $SOm([b, \cdot \cdot \cdot, b])$ SO (mb, \dots, mb)

Values

m: port number2 to 7, 10 to 17, 20 to 27 b: bit definition0 to 7 <time>......10 to 3600000 (units: ms)

Explanation Turns ON the bits of specified ports.

The pulse output time (unit: ms) is specified by the <time> value. When the specified time elapses, the output is turned OFF, and command execution ends.

If multiple bits are specified, they are expressed from the left in descending order (large

If the [b,...,b] data is omitted, all 8 bits are processed.

If no hardware port exists, nothing is output.

SAMPLE SET DO2() Turns ON DO(27 to 20). SET DO2(6,5,1),200 DO(26,25,21) switches ON for 200ms. SET DO(37,35,27,20) Turns DO(37, 35, 27, 20) ON.

Related commands

RESET, DO, MO, SO, TO, LO

SHARED

Enables sub-procedure referencing without passing on the variable

Format

<variable>[()][,<variable>[()]...]

The program level code is a program written outside the sub-procedure.

SAMPLE

Explanation This statement allows variables declared with a program level code to be referenced with a sub-procedure without passing on the variables as dummy arguments.

The program level variable used by the sub-procedure is specified by the <variable>

A simple variable or an array variable followed by parentheses is specified. If an array is specified, that entire array is selected.



- Normally, a <dummy argument> passes along the variable to a sub-procedure, but the SHARED statement allows referencing to occur without passing along the variable.
- The SHARED statement allows variables to be shared only between a program level code and sub-procedure which are within the same program level.

DIM Y! (10) X!=2.5Y!(10)=1.2CALL *DISTANCE CALL *AREA HALT SUB *DISTANCE SHARED X!, Y!() Variable referencing declared by SHARED. PRINT X!^2+Y!(10)^2····· The variable is shared. END SUB SUB *AREA DIM Y! (10)

PRINT X!*Y! (10) The variable is not shared.

Related commands

END SUB

SUB, END SUB

SHIFT / SHIFT2

Sets the shift coordinates

Format

SHIFT <shift variable>

-

NOTE

• The SHIFT2 statement can be used only when a sub group setting has been specified in the system generation.



Format
SHIFT2 <shift variable>

Explanation Sets the shift coordinates in accordance with the shift data specified by the <shift variable>.

- This statement is executed after axis positioning is complete (within the tolerance range).
- The default shift setting is S0 (no shift values).

SAMPLE

SHIFT S1 MOVE P,P10 SHIFT S[A] MOVE P,P20 HALT

Related commands

Shift definition statement, shift assignment statement

Ν

main group

sub group

0

P

a

P

S

Y

Y

Z

SIN(<expression>)

Values

<expression>......Angle (units: radians)

Explanation This function gives the sine value for the <expression> value.

SAMPLE

 $A(0) = SIN(B*2+C) \cdots Assigns the expression B*2+C sine value to array A (0). \\ A(1) = SIN(DEGRAD(30)) \cdots Assigns a 30.0° sine value to$

array A (1).

Related commands ATN, COS, DEGRAD, RADDEG, TAN

N

0

P

Q

R

5

T

V

Y

Outputs a specified value to the serial port

Format

- 1. [LET] $SOm([b, \cdot \cdot \cdot, b]) = \langle expression \rangle$
- [LET] SO $(mb, \dots, mb) = \langle expression \rangle$

Values

m: port number.....2 to 7, 10 to 17, 20 to 27 b: bit definition0 to 7



• Outputs to SOO() and SO1() are not possible.



• For bit setting details, see Chapter 3 "10 Bit Settings".

Explanation Outputs a specified value to the SO port.

Only the <value> data's integer-converted lower bits corresponding to the bits defined at the left side can be output.

If multiple bits are specified, they are expressed from the left in descending order (large to small).

> converted variable A are output to SO (37, 35, 27, 20).

If the [b,...,b] data is omitted, all 8 bits are processed.

If no hardware port exists, nothing is output.

SAMPLE

SO2()=&B10111000SO (27, 25, 24, 23) are turned ON, and SO (26, 22, 21, 20) are turned OFF. SO2(6,5,1)=&B010SO (25) are turned ON, and SO (26, 21) are turned OFF. SO3()=15SO (33, 32, 31, 30) are turned ON, and SO (37, 36, 35, 34) are turned OFF. $SO(37,35,27,20) = A \cdots$ The lower 4 bits of integer-

Related commands

RESET, SET

Q

SPEED / SPEED2

Changes the program movement speed

NOTE

• SPEED2 can be used only if a "sub group" setting has been specified in the system generation.



NOTE

 Automatic movement speed

Specified programming box operation or by the ASPEED / ASPEED2 commands.

Program movement speed

Specified by SPEED/ SPEED2 commands or MOVE/MOVE2, DRIVE/ DRIVE2 speed options.

Format

main group

sub group

SPEED <expression>

Format

SPEED2 <expression>

Values

<expression>.......1 to 100 (units: %)

Explanation Changes the program movement speed to the speed indicated by the <expression>.

This speed change applies to all the robot axes and auxiliary axes.

The operation speed is determined by multiplying the automatic movement speed (specified from the programming box and by the ASPEED/ASPEED2 commands), by the program movement speed (specified by SPEED/SPEED2 commands, etc.).

Operation speed = automatic movement speed x program movement speed.

Example:

Automatic movement speed ... 80%

Program movement speed ... 50%

Movement speed = 40% ($80\% \times 50\%$)

SAMPLE

ASPEED 100

SPEED 70

MOVE P, P0 Moves from current position to P0 at a speed of 70% (=100 * 70).

SPEED 50

MOVE P, P1 Moves from current position to P1 at a speed of 50% (=100 * 50).

MOVE P, P2, S=10 ····· Moves from current position to P2 at a speed of 10% (=100 * 10).

HALT

Related commands

ASPEED, ASPEED2

START Starts a new task

Format

START < label >, Tn[, p]

Values

n: Task number2 to 8 p: Task priority ranking17 to 47

Explanation Starts task "n" specified by the <label> with the "p" priority ranking.

If a priority ranking is not specified, "32" is adopted as the priority ranking for this

The smaller the priority number, the higher the priority (high priority: $17 \leftrightarrow low$ priority: 47).

When a READY status occurs at a task with higher priority, all tasks with lower priority also remain in a READY status.

```
SAMPLE
```

```
START *SUBTASK, T2, 33
*ST:
   MOVE P, P0, P1
GOTO *ST
HALT
'SUBTASK ROUTINE
*SUBTASK:
   P100 = WHERE
   IF LOCZ(P100) > 10000 THEN
      DO(20) = 1
   ELSE
      DO(20) = 0
   ENDIF
GOTO *SUBTASK
EXIT TASK
```

Related commands

CUT, EXIT TASK, RESTART, SUSPEND, CHGPRI

Q

STR\$(<expression>)

Explanation Converts the value specified by the <expression> to a character string. The <expression> specifies an integer or real number value.

SAMPLE

B\$=STR\$(10.01)

Related commands

VAL

8

Acquires the square root of a specified value

Format

SQR(<expression>)

Values

<expression>.....0 or positive number.

Explanation Gives the square root of the <expression> value. An error occurs if the <expression> value is a negative number.

SAMPLE

 $A=SQR(X^2+Y^2)\cdots$ The square root of X^2+Y^2 is assigned to variable A.

Ν

0

P

Q

R

.

U

V

W

Χ

Y

Z

SUB to END SUB

Defines a sub-procedure

Format

```
SUB <label> [(<dummy argument> [, <dummy argument> ...])]
   <command block>
END SUB
```

Explanation Defines a sub-procedure.

The sub-procedure can be executed by a CALL statement. When the END SUB statement is executed, the program jumps to the next command after the CALL statement that was called. Definitions are as follows.

- 1. All variables declared within the sub-procedure are local variables, and these are valid only within the sub-procedure. Local variables are initialized each time the sub-procedure is called up.
- 2. Use a SHARED statement in order to use global variables (program level).
- 3. Use a <dummy argument> when variables are to be passed on. If two or more dummy arguments are used, separate them by a comma (,).
- 4. A valid <dummy argument> consists of a name of variable and an entire array (array name followed by parentheses). An error will occur if array elements (a <subscript> following the array name) are specified.



- Sub-procedures cannot be defined within a sub-procedure.
- The DECLARE statement cannot be used within a sub-procedure.
- A label can be defined within a sub-procedure, but it cannot jump (by a GOTO or GOSUB statement) to a label outside the sub-procedure.
- Local variables cannot be used with PRINT and SEND statements.

```
SAMPLE 1
```

```
A=1
CALL *TEST
PRINT A
HALT
 SUB ROUTINE: TEST
SUB *TEST
  A = 50
              ······ Handled
                                   a s
                                           different
                         variable than the "A" shown
                         above.
END SUB
```



• In the above example, the program level variable "A" is unrelated to the variable "A" within the sub-procedure. Therefore, the value indicated in the 3rd line PRINT statement becomes "1".

```
SAMPLE 2
X% = 4
Y% = 5
CALL *COMPARE( REF X%, REF Y%)
PRINT X%,Y%
Z% = 7
W% = 2
CALL *COMPARE( REF Z%, REF W%)
PRINT Z%, W%
HALT
' SUB ROUTINE: COMPARE
SUB *COMPARE( A%, B%)
   IF A% < B% THEN
     TEMP% = A%
     A% = B%
     B% = TEMP%
   ENDIF
END SUB
```



• In the above example, different variables are passed along as arguments to call the subprocedure 2 times.

Related commands

CALL, DECLARE, EXIT SUB, SHARED

SUSPEND Tn

Values

n: Task number2 to 8

Explanation Temporarily stops (suspends) another task which is being executed.

This statement can also be used for tasks with a higher priority ranking than this task

This statement cannot be specified for the main task (Task number 1).

```
SAMPLE
```

```
START *SUBTASK, T2
SUSFLG=0
*L0:
  MOVE P, P0
  MOVE P, P1
  WAIT SUSFLG=1
  SUSPEND T2
  SUSFLG=0
GOTO *L0
HALT
SUBTASK ROUTINE
*SUBTASK:
  WAIT SUSFLG=0
  DO2(0)=1
  DELAY 1000
  DO2(0) = 0
  DELAY 1000
  SUSFLG=1
  GOTO *SUBTASK
```

Related commands

EXIT TASK

CUT, EXIT TASK, RESTART, SUSPEND

SWI "<"<pre>rogram name>">"

Explanation This statement switches from the current program to the specified program, starting from the first line after compiling is completed.

> Although the output variable status is not changed when the program is switched, the dynamic variables and array variables are cleared. Operation stops if an error occurs during compiling. The program name to be switched to must be enclosed in angular brackets (< >).

This command can be executed only in Task 1 (main task).



- If the program specified as the switching target does not exist, message "3.3: Program doesn't exist" (code: &H0303) displays and operation stops.
- Execution of a SWI statement is always accompanied by compiling, and the time required for this compiling depends on the size of the switching target program.
- If an error occurs during compiling, an error message line displays and the program stops.
- The SWI statement can only be executed within task 1 (main task). If used within tasks 2 through 8, the message "6.1: Illegal command" displays and operation stops.
- The STOP key is disabled during compiling.

SAMPLE

SWI <ABC> Switches the execution program to "ABC".

Q

TAN(<expression>)

Values <expression>.....Angle (units: radians)

Explanation Gives a tangent value for the <expression> value. An error will occur if the <expression> value is a negative number.

SAMPLE

A(0)=B-TAN(C) The difference between the tangent values of variable B and variable C is assigned to array A (0).

 $A(1) = TAN(DEGRAD(20)) \cdots$ The 20.0 ° tangent value is assigned to array A(1).

Related commands ATN, COS, DEGRAD, RADDEG, SIN

P

Q

R

S

U

W

Χ

Y

_

TCOUNTER

Timer & counter

Format

TCOUNTER

Explanation Outputs count-up values at 10ms intervals starting from the point when the TCOUNTER variable is reset (counter variable value 1 = 10ms).

After counting up to 65,535, the count is reset to 0.

SAMPLE

MOVE P, P0

WAIT ARM

RESET TCOUNTER

MOVE P, P1

WAIT ARM

A = TCOUNTER

PRINT TCOUNTER Displays the P0 to P1 movement time at the programming box until movement enters the tolerance range.

Related commands

RESET

O

TIME\$

Explanation Acquires the current time in an hh:mm:ss format character string. "hh" is the hour, "mm" is the minutes, and "ss" is the seconds. The clock can be set in the SYSTEM mode's initial processing.

SAMPLE

A\$=TIME\$ PRINT TIME\$

Related commands DATE\$, TIMER

TIMER

Acquires the current time



CAUTION

• The time indicated by the internal clock may differ somewhat from the actual time.

Format

TIMER

Functions Acquires the current time in seconds, counting from 12:00 midnight. This function is used to measure a program's run time, etc.

The clock can be set in the SYSTEM mode's initial processing.

SAMPLE

A%=TIMER

FOR B=1 TO 10

MOVE P, P0

MOVE P, P1

NEXT

A%=TIMER-A%

PRINT A%/60;":";A% MOD 60

HALT

Related commands

TIME\$

O

- [LET] TOO($[b, \cdot \cdot \cdot, b]$) = <expression>
- [LET] TO $(0b, \dots, 0b) = \langle expression \rangle$

Values

b: bit definition0 to 7

Explanation Outputs the specified value to the TO port. The output value is the expression's integer-converted lower bits corresponding to the bit definition specified at the left

> If multiple bits are specified, they are expressed from the left in descending order (large to small).

If the [b,...,b] data is omitted, all 8 bits are processed.

The OFF/ON settings for bits which are being used in a SEQUENCE program have priority while the SEQUENCE program is running.

SAMPLE

TOO() = &B00000110

Related commands

RESET, SET

TOLE / TOLE2

Specifies/acquires the tolerance parameter

(n)-

• TOLE2 can be used only if a "sub group" setting has been specified in the system generation. Format main group

- 1. TOLE <expression>
- 2. TOLE (<axis number>) = <expression>

Format sub group

- 1. TOLE2 <expression>
- 2. TOLE2 (<axis number>) = <expression>

Values <axis number>.....main group: 1 to 6 sub group: 1 to 4

<expression>......Varies according to the motor which has been specified (units: pulse)

Explanation Changes the tolerance parameter to the <expression> value.

Format 1: The change is applied to all axes of each group.

Format 2: The change is applies to only the group axes specified by <axis number>.

.....

MEMO

- If an axis that is set to "no axis" in the system generation is specified, a "5.37: Specification mismatch" error message displays and command execution is stopped.
- This statement is executed after positioning of the specified axes is complete (within the tolerance range).

Functions

Format

Format

main group

sub group

TOLE(<axis 1>)



 TOLE2 can be used only if a "sub group" setting has been specified in the system generation.

TOLE2(<axis 2>)

Values <axis 1>.....main group: 1 to 6 <axis 2>.....sub group: 1 to 4

Explanation Acquires the tolerance parameter value for the axis specified by <axis number>.

SAMPLE

*CHANGE_TOLE:

FOR B=1 TO 4 TOLE(B)=A

NEXT B RETURN

TOLE / TOLE2 8-181

N

0

P

Q

R

5

T

. . .

Χ

Y

Z

110

NOTE

 TORQUE2 can be used only if a "sub group" setting has been specified

in the system generation.

CAUTION

 In versions prior to Ver.2.17, the maximum

torque command value

becomes valid at the point when it is changed

(specified) by the TORQUE

 If the specified torque limit is too small, the axis may not move.

In this case, press the

emergency stop button before proceeding with

• If the specified value

is less than the rated

torque, an error may not occur even if the robot

MEMO

strikes an obstacle.

the operation.

/ TORQUE2 statement.

TORQUE / TORQUE2

Specifies/acquires the maximum torque command value which can be set for a specified axis

N

0

P

S

٧

Х

Y

Z

Format main group

TORQUE(<axis number>) = <expression>

Format

TORQUE2(<axis number>) = <expression>

Explanation Changes the maximum torque command value for each group's axes which have been specified by <axis number>. The new value is enabled after the next movement command (MOVE or DRIVE statement, etc.) is executed. The torque parameter value

The maximum torque specified by this statement remains valid until any of the following operations occur.


sub group

- Until another TORQUE / TORQUE2 command for the same axis is executed.
- Until a torque limit option is executed in a DRIVE / DRIVE2 statement for the same axis.
- Until controller power is turned off and then on again.
- Until parameters are changed or initialized.
- Until a return-to-origin or an absolute reset & return-to-origin is performed.
- Until the servo is turned off.

does not change.

• If an axis that is set to "no axis" in the system generation is specified, a "5.37: Specification mismatch" error message displays and command execution is stopped.

Functions



Explanation Acquires the torque setting value for the axis specified by <axis number>.

SAMPLE	
TRQTIME(3) = 2500	Sets the torque control time-out period as 2.5 seconds for axis 3.
DRIVE(3,P1),T = (20,15)	Sets the maximum torque value to 20% of the rated torque, and the torque offset to 15, then moves axis 3 from its current position to the point specified by P1 (pushing action).
	Checks if a time-out has occurred. Time-out has occurred (pushing is complete). (Result is output to DO(21) in this example.)
ELSE	-
	Time-out has not occurred. (Reached target position but failed to complete pushing.) (Result is output to DO(21) in this example.)
ENDIF	
TORQUE(3) = 100	Returns the max. torque command value to the original value (100%).
DRIVE(3,P0)	Ends the torque limit and torque control, and moves to PO.
A=TORQUE(2) ······	The torque setting value for the main group's axis 2 is assigned to variable A.

Related commands

DRIVE, DRIVE2, TRQTIME, TRQTIME2, TRQSTS, TRQSTS2, CURTRQ, CURTRQ2

TRQSTS / TRQSTS2

Acquires the status when DRIVE statement ends



NOTE

•The TRQSTS/TRQSTS2 statement is available in software version 8.45 onwards.

Format

- 1. TRQSTS (<axis 1>)
- 2. TRQSTS2 (<axis 2>)

Values

<axis 1>.....main group: 1 to 6 <axis 2>.....sub group: 1 to 4

Explanation Acquires the status at the completion of a "DRIVE statement with torque limit option" that was executed for the main group axis specified by <axis number>.

0The DRIVE statement was ended for a reason other than a torque limit time-out.

1The DRIVE statement was ended by torque limit time-out.

MEMO

• If an axis that is set to "no axis" in the system generation is specified, a "5.37: Specification mismatch" error message displays and command execution is stopped.

.....

SAMPLE

DRIVE(3,P1), T=20 ······ Moves the main group's axis 3 under torque limit control. IF TRQSTS(3)=1 THEN..... Ended by a time-out with the torque limit value reached. GOTO *OK ELSE Movement ended without a timeout occurring. GOTO *NG ENDIF

Related commands

DRIVE, DRIVE2, TRQTIME, TRQTIME2, CURTRQ, CURTRQ2

8-184 Chapter 8 Robot Language Lists

TRQTIME / TRQTIME2

Sets/acquires the time-out period for the torque limit setting option

-<u>`</u>(m)-

OTF

 The TRQTIME/TRQTIME2 statement is available in software version 8.45 onwards.

 TRQTIME2 can be used only if a "sub group" setting has been specified in the system generation. Format main group

TRQTIME(<axis number>) = <time-out period>

Format sub group

TRQTIME2(<axis number>) = <time-out period>

Values <axis number>.....main group: 1 to 6 sub group: 1 to 4

<time-out period>......1 to 9999 (units: ms)

Explanation Specifies the torque control time-out period when using the DRIVE statement's torque limit setting option. This command specifies the time-out period (<time-out period>) for the axis specified by <axis number>.

A DRIVE /DRIVE2 statement executed with a torque limit option ends when the axis has reached the target position, or when the "specified toque limit reached" time has exceeded the time-out period specified by the TRQTIME / TRQTIME2 statement.

A value is then set in the TRQSTS / TRQSTS2 function, depending on whether or not the "specified toque limit reached" period has exceeded the time-out period specified by the TRQTIME / TRQTIME2 statement and this command has ended.

When the controller power is turned on, the time-out period is set to 1 second (1,000ms).



- Although the time-out period is specified in "ms" units, it actually operates in "10ms" units. Therefore, settings are rounded upward to 10ms. For example, if the setting is a value from 1 to 9, this becomes 10ms. However, if "0" is specified, this becomes 1 second (1000ms).
- If an axis that is set to "no axis" in the system generation is specified, a "5.37: Specification mismatch" error message displays and command execution is stopped.

Functions

Format main group
TRQTIME(<axis 1>)

NOTE

- The TRQTIME/TRQTIME2 statement is available in software version 8.45 onwards.
- TRQTIME2 can be used only if a "sub group" setting has been specified in the system generation

Format
TRQTIME2(<axis 2>)

Values <axis 1>.....main group: 1 to 6 <axis 2>.....sub group: 1 to 4

Explanation Acquires the torque limit time-out period for the axis specified by <axis number>. The time-out period is specified in "ms" units.

Р

Q

R

S

T

Χ

Y

Z

sub group

SAMPLE	
TRQTIME (3) = 2500	Sets the torque control time-out period as 2.5 seconds for axis 3.
DRIVE(3,P1),T=(20,15)	Sets the maximum torque value to 20% of the rated torque, and the torque offset to 15, then moves axis 3 from its current position to the point specified by P1 (pushing action).
	Checks if a time-out has occurred. Time-out has occurred (pushing is complete). (Result is output to DO(21) in this example.)
ELSE	
	Time-out has not occurred. (Reached target position but failed to complete pushing.) (Result is output to DO(21) in this example.)
ENDIF	Returns the max. torque
10RQUE(3)=100	command value to the original value (100%).
DRIVE(3, P0)	Ends the torque limit and torque control, and moves to P0.
A%=TRQTIME(3) ·····	The torque limit time-out period for the main group's axis 3 is assigned to variable A.

Related commands DRIVE, DRIVE2, TRQSTS, TRQSTS2, CURTRQ, CURTRQ2

VAL (<character string expression>)

Explanation Converts the numeric value of the character string specified in the <character string expression> into an actual numeric value.

> The value may be expressed in integer format (binary, decimal, hexadecimal), or real number format (decimal point format, exponential format).

> The VAL value becomes "0" if the first character of the character string is "+", "-", "&" or anything other than a numeric character.

> If there are non-numeric characters or spaces elsewhere in the character string, all subsequent characters are ignored by this function.

However, for hexadecimal expressions, A to F are considered numeric characters.

SAMPLE

A=VAL("&B100001")

WAIT <conditional expression> [,<expression>]

Values

<expression>......10 to 3600000 (units: ms)

Meaning)

Establishes a "wait" status until the condition specified by the <conditional expression> is met. Specify the time-out period (unit: ms) in the <expression>.

If a time-out period has been specified, this command terminates if the time-out period elapses before the WAIT condition is met.

The minimum wait time is 10 ms.

MEMO



 This parameter is only available in the following software versions:

RCX14x Ver. 8.63 onwards RCX22x Ver. 9.08 onwards

•On earlier version controllers, -1 is "true" and a value other than -1 is "false" (not changeable).

 When the conditional expression is a numeric expression, the conditions for determining a TRUE or FALSE status can be changed at the controller's "TRUE conditions" in the "Other parameters" mode. These conditions apply to all the IF, WHILE, WAIT, STOPON, etc., conditional expressions. For details, refer to the controller's user manual.

1) -1 (default setting) An expression value of "-1" indicates a TRUE status, and "0" indicates

a FALSE status. A "6.35: Incorrect condition expression" error occurs if

the expression value is other than "-1" or "0".

2) not 0 Any expression value other than "0" indicates a TRUE status, and "0"

indicates a FALSE status.

SAMPLE

WAIT A=10 A wait status continues until variable A becomes 10.

WAIT DI2()=&B01010110 ····· Waits until DI(21),(22),(24),(26) are turned on, a n d

off.

WAIT DI2(4,3,2)=&B101 ······ Waits until DI(22) and DI(24)are turned on, and DI(23) is

turned off.

WAIT DI(31)=1 OR DO(21)=1 A wait status continues until either DI (31) or DO(21) turns ON.

WAIT DI(20)=1,1000 ······· A wait status continues until

DI(20) turns ON. If DI(20) fails to turn ON within 1 second, the command is terminated.

DI(20),(23),(25),(27) is turned

Related commands

DRIVE, DRIVE2, DRIVEI, DRIVEI2, MOVE, MOVE2, MOVEI, MOVEI2







WAIT ARM / WAIT ARM2

Waits until the robot axis operation is completed

Format

Format

Values

main group

WAIT ARM [(<axis number>)]

sub group



WAIT ARM2 [(<axis number>)]

 WAIT ARM2 can be used only if a "sub group" setting has been specified in the system generation.

<axis number>.....main group: 1 to 6 sub group: 1 to 4

P

Explanation Establishes a "wait" status until robot axis movement is completed (within the

positioning tolerance range).

Q

If a specific axis in a group has been specified by <axis number>, this command will apply only to that axis. If there is no <axis number> setting, this command applies to all the group axes.

R

WAIT ARM Waits for main robot movement completion.

WAIT ARM2(2) Waits for sub robot axis 2 movement completion.

Related commands

DRIVE, DRIVE2, DRIVEI, DRIVE12, MOVE, MOVE2, MOVEI, MOVE12

W

X

Y

Specifies/acquires the tip weight parameter

P

Q

T

W



Z

NOTE

 WEIGHT2 can be used only if a "sub group" setting has been specified in the system generation. Format main group

WEIGHT <expression>

Format
WEIGHT2 <expression>

<expression>.....The range varies according to the robot which has been specified.

sub group

sub group

Explanation Changes the tip weight parameter of the main robot or sub robot to the <expression> value. This change does not apply to auxiliary axes.

Functions

Values

Format main group

WEIGHT

NOTE

 WEIGHT2 can be used only if a "sub group" setting has been specified in the system generation. Format

WEIGHT2

Explanation Acquires the tip weight parameter of the robot.

SAMPLE

A=5 B=2

C=WEIGHT

WEIGHT A

MOVE P, P0

WEIGHT B

MOVE P, P1

WEIGHT C

D=WEIGHT The main robot's tip weight parameter is assigned to variable D.

HALT

WEND

Ends the WHILE statement's command block

```
Format
```

```
WHILE <conditional expression>
  <command block>
WEND
```

Explanation Ends the command block which begins with the WHILE statement. A WEND statement must always be paired with a WHILE statement.

Jumping out of the WHILE to WEND loop is possible by using the GOTO statement,

SAMPLE

```
A=0
WHILE DI3(0)=0
   A=A+1
   MOVE P, P0
   MOVE P,P1
   PRINT "COUNTER=";A
WEND
HALT
```

Related commands

WHILE

WHERE / WHERE2

Acquires the arm's current position (pulse coordinates)

Format main group

WHERE

Format sub group

WHERE2

Explanation Acquires the arm's current position in joint coordinates.

P10=WHERE The current position's pulse coordinate value is assigned

to P10.

Related commands WHRXY, WHRXY2

0

P

Q

R

S

Т

U

V

W

X

Y

_

WHILE to WEND

Repeats an operation for as long as a condition is met

Format

```
WHILE <conditional expression>
<command block>
WEND
```

Explanation

Executes the command block between the WHILE and WEND statements when the condition specified by the <conditional expression> is met, and then returns to the WHILE statement to repeat the same operation.

When the <conditional expression> condition is no longer met (becomes false), the program jumps to the next command after the WEND statement.

If the <conditional expression> condition is not met from the beginning (false), the command block between the WHILE and WEND statements is not executed, and a jump occurs to the next statement after the WEND statement.

Jumping out of the WHILE to WEND loop is possible by using the GOTO statement, etc.



NO

 This parameter is only available in the following software versions:

RCX14x Ver. 8.63 onwards RCX22x Ver. 9.08 onwards

 On earlier version controllers, -1 is "true" and a value other than -1 is "false" (not changeable). • When the conditional expression is a numeric expression, the conditions for determining a TRUE or FALSE status can be changed at the controller's "TRUE conditions" in the "Other parameters" mode. These conditions apply to all the IF, WHILE, WAIT, STOPON, etc., conditional expressions. For details, refer to the controller's user manual.

1) -1 (default setting)

An expression value of "-1" indicates a TRUE status, and "0" indicates a FALSE status. A "6.35: Incorrect condition expression" error occurs if the expression value is other than "-1" or "0".

2) not 0

Any expression value other than "0" indicates a TRUE status, and "0" indicates a FALSE status.

SAMPLE 1

```
A=0
WHILE DI3(0)=0
A=A+1
MOVE P,P0
MOVE P,P1
PRINT "COUNTER=";A
WEND
HALT
```

SAMPLE 2

```
A=0
WHILE -1 Becomes an endless loop because the conditional expression is always TRUE (-1).

A=A+1
MOVE P,P0
IF DI3(0)=1 THEN *END
MOVE P,P1
PRINT "COUNTER=";A
IF DI3(0)=1 THEN *END

WEND
*END
HALT
```

N

0

U

Y

W

X

Y

WHRXY / WHRXY2

Acquires the arm's current position in Cartesian coordinates



NOTE

 WHRXY / WHRXY2 are available from following software version.

RCX14x version 8.64 onwards RCX22x version 9.11 onwards

• X-arm and Y-arm rotation information is only available in software Ver.10.66 onwards.

Format	main group
WHRXY	

Format sub group

WHRXY2

Explanation Acquires the arm's current position in Cartesian coordinates.

On YK500TW model robots, the X-arm and Y-arm rotation information is also set.

P10=WHRXY The current position Cartesian coordinate value is assigned to P10.	SAMPLE				
	P10=WHRXY ·····	C001	rdinate	_	

Related commands WHERE, WHERE2

0

S

V

W

X

Y

L

XYTOJ / XYTOJ2

Converts the main group axes Cartesian coordinate data ("mm") to joint coordinate data ("pulse")



X-arm and Y-arm rotation information is only available in software Ver. 10.66 onwards.

Format	main group
XYTOJ (<point expression="">)</point>	

XYTOJ2 (<point expression>)

Format

Explanation This function converts the Cartesian coordinate data (unit: mm, deg.) specified by the <point expression> to joint coordinate data (unit: pulses).

- When the command is executed, the data is converted based on the standard coordinates, shift coordinates and hand definition that were set.
- On SCARA robots, the converted result differs depending on whether right-handed or left-handed is specified.
- On the YK500TW model robot, the result varies, depending on the X-arm and Y-arm rotation information settings.
- To convert joint coordinate data to Cartesian coordinate data, use the JTOXY / JTOXY2 statement.

SAMPLE

P10=XYTOJ(P10) P10 is converted to joint coordinate data.

Related commands JTOXY2

122

SYSFLG

Axis status monitoring flag

Format

SYSFLG

Explanation Used as an axis status monitoring flag in accordance to the value specified by the _ SYSFLG variable.

SAMPLE

SYSFLG = 1

Related commands

RESET

sub group

Chapter 9 PATH Statements

4	Cautions when using this function	9-2
3	How to use	9-1
2	Features	9-1
1	Overview	9-1

This function moves the robot at a specified speed along a path composed of linear and circular segments. Because speed fluctuations during movement are minimal, the PATH function is ideal for applications such as sealing, etc.

2 Features

- Moves the robot at a constant speed along the entire movement path (except during acceleration from a stop, and during deceleration just prior to the operation end).
- Permits easy point teaching because the robot speed is not affected by the point teaching positions' level of precision.
- Permits movement speed changes for the entire movement path, or speed changes for only one portion of the path (using the speed option).
- Using the DO option permits signal outputs to a specified port at any desired position during movement.

3 How to use

The following robot language commands must be used as a set in order to use the PATH function.

As shown below, the motion path is specified between the PATH SET and PATH END statements. Simply specifying a path, however, does not begin robot motion.

Robot motion only occurs when the PATH START statement is executed after the path setting procedure has been completed.

8

9

10

П

12

13


14

Cautions when using this function

- Paths may comprise no more than 300 (total) linear and circular segments.
- The robot must be positioned at the path start point when PATH motion is executed (by PATH START statement).
- At points where circular and linear segments connect, the motion direction of the two connecting segments should be a close match (as close as possible). An excessive difference in their motion directions could cause vibration and robot errors.

Circular and linear segment connection point:


if there is a large difference between the motion directions of the connecting segments



Where a linear segment connects to another linear segment, the motion path passes to the inner side of the connection point. Moreover, as shown in fig. (1) below, the faster the speed, the further to the inner side the path becomes. To prevent significant speed-related path shifts, add more points as shown in fig. (2). Note also, that in some cases, the speed may have to be reduced in order to prevent errors from occurring.

Connection point of 2 linear segments:

suppressing the path shift



- If an error occurs due the robot's inability to move at the specified speed: Robot acceleration/deceleration occurs if the speed setting is changed when PATH motion begins, stops, or at some point along the path. At such times, an error may occur before motion begins if the distance between points is too short for the specified speed to be reached. In such cases, a slower speed must be specified. If the error still occurs after the speed is lowered, adjust the PATH points to increase the length of the linear or circular segments which contain acceleration or deceleration zones.
- The hand system used during PATH motion must be the same as the hand system used at the path's start point. The same applies if the path is to pass through points where hand flags are set. Differing hand systems will cause an error and disable motion.
- The X-arm and Y-arm rotation information during PATH movement must be the same as the X-arm and Y-arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled.
- If the robot is stopped by an interlock function, etc., during PATH motion, this is interpreted as an execution termination, and the remaining path motion will not be completed even if a restart is executed.

Be sure to read the cautions relating to each command.

Chapter 10 Limitless motion

1	Overview 10-1
2	Operation Procedure10-1
3	Restrictions10-3

NOTE

 The limitless motion function is available from the following software versions:

RCX240:

Host Ver. 10.66 onwards. Driver Ver. 4.39 onwards.

RCX22x:

Host Ver.9.39 onwards. Driver Ver.3.40 onwards. Generally speaking, controllers have a soft limit function which allows the soft limits to be specified by parameter settings, and operation beyond the soft limits is normally prohibited. However, the "limitless motion" function permits multi-turn same-direction movement without that soft limit restriction.

2

Operation Procedure

2.1 Parameters

The "limitless motion" parameter can be enabled in the robot axis parameters. (For details, see the controller user's manual.)

2.2 Robot language



CAUTION

- Limitless motion applies to the axis which has been specified as the additional axis in the "system generation" settings (robot factory settings).
- Do not attempt to enable limitless motion at an axis which has not been specified as an additional axis. Doing so will result in the "2.29: Cannot move without the limit" error when movement is attempted using the MOVE statement or a point trace movement. This error also disables movement.

The robot language shown below is required in order to use the limitless motion function. For command details, see Chapter 8 "Robot Language Lists".

	Main robot	DRIVE statement (PLS or MNS option specified)
Debet		DRIVEI statement
Robot movement	Sub robot	DRIVE2 statement (PLS or MNS option specified)
Sub robot		DRIVEI2 statement
Current position react	Man robot	ABSINIT statement
Current position reset	Sub robot	ABSINIT2 statement

10

11

2

13

14

2.3 Sample program

2.3.1 For Axis 4 limitless motion (this requires the RCX240 controller)

The following program executes limitless movement in the plus direction, in 180.0° increments. (Settings: Resolver pulse: 16384, speed reduction ratio: 25, limitless motion specified for the main robot's axis 4, minus axis polarity.)

 $P0 = 0.0 \ 0.0 \ 0.0 \ 0.9 \ 0.0 \ 0.0 \ ... \ 0.9^{\circ} = 1024[pulse]$

P1 = 0.0 0.0 0.0 180.9 0.0 0.0

* It is recommended that the point data which resets the current position is created at the middle of the resettable range. For details regarding the resettable range, refer to "ABSINIT/ABSINIT2" of Chapter 8 "Robot Language Lists".

Axis polarity	Resettable range	Recommended reset range
For a "minus" setting	257 to 1791[pulse]	Approximately 1024 ± 256 [pulse]
For a "plus" setting	-1791 to 257[pulse]	Approximately -1024 ± 256 [pulse]

```
SAMPLE
WHILE -1
DRIVE(4,P1),PLS
WAIT ARM(4)
P100 = WHERE
A*=LOCR(P100) MOD 409600 \cdots409600 [pulse] = Machine angle 360°.
IF(A%<257) OR (A%>1791) THEN... Checks current position to see if
                         it is the reset execution position.
DRIVE(4,P0),PLS ..... Moves to the current position
                         reset execution position.
WAIT ARM(4)
ENDIF
ABSINIT 4..... Resets the main robot's axis
                         4 current position.
WEND
HALT
```

2.3.2 For Axis 2 limitless motion

The following program executes limitless movement in the plus direction, in 180.0° increments. (Settings: Resolver pulse: 16384, speed reduction ratio: 25, limitless motion specified for the main robot's axis 2, minus axis polarity.)

P0 = 0.0 0.9 0.0 0.0 0.0 0.0 0.9°=1024[pulse]

P1 = 0.0 180.9 0.0 0.0 0.0 0.0

* It is recommended that the point data which resets the current position is created at the middle of the resettable range. For details regarding the resettable range, refer to "ABSINIT/ABSINIT2" of Chapter 8 "Robot Language Lists".

Axis polarity	Resettable range	Recommended reset range
For a "minus" setting	257 to 1791[pulse]	Approximately 1024 ± 256 [pulse]
For a "plus" setting	-1791 to 257[pulse]	Approximately -1024 ± 256 [pulse]

SAMPLE WHILE -1 DRIVE(2,P1),PLS WAIT ARM(2) P100 = WHERE A%=LOCY(P100) MOD 409600....409600 [pulse] = Machine angle 360°. IF(A%<257) OR (A%>1791) THEN. Checks current position to see if it is the reset execution position. DRIVE(2,P0),PLS Moves to the current position reset execution position. WAIT ARM(2) ENDIF ABSINIT 2..... Resets the main robot's axis 2 current position. WEND HALT

Restrictions

3

- YAMAHA recommends that the return-to-origin method be specified as "sensor" in the axis parameters.
- The limitless motion function can be used only on single-axis, rotary type robots. It cannot be used on linear robots and dual robots.
- The limitless motion function cannot be used at YC-Link specification axes.
- The limitless motion function cannot be used at electric gripper specification axes.
- The limitless motion function cannot be used at SCARA robot X and Y axes.

8

9

10

11

12

13

14

Chapter 11 Data file description

1	Overview 11-1
2	Program file11-2
3	Point file 11-4
4	Point comment file11-8
5	Parameter file11-10
6	Shift coordinate definition file11-13
7	Hand definition file11-15
8	Pallet definition file11-17
9	All file11-23
10	Program directory file11-24
11	Parameter directory file11-26
12	Variable file 11-27
13	Constant file11-30
14	Array variable file11-31
15	DI file 11-33
16	DO file 11-35
17	MO file11-37
18	LO file 11-39

19	TO file11-41
20	SI file 11-43
21	SO file 11-45
22	Error message history file11-47
23	Error Message History Details File 11-48
24	Machine reference file11-49
25	EOF file 11-50
26	Serial port communication file11-51
27	SIW file 11-52
28	SOW file 11-54
29	Ethernet port communication file 11-56

Overview

Data file types 1.1

This section explains data files used with a SEND statement and READ/WRITE online commands. There are 27 different types of data files.

- Program file 1.
- 2. Point file
- Point comment file 3.
- 4. Parameter file
- Shift coordinate definition file 5.
- Hand definition file 6.
- Pallet definition file 7.
- All file 8.
- 9. Program directory file
- 10. Parameter directory file
- Variable file 11.
- 12. Constant file
- 13. Array variable file
- 14. DI file
- 15. DO file
- 16. MO file
- LO file
- 18. TO file
- SI file 19.
- 20. SO file
- 21. Error message history file
- Machine reference file 22.
- EOF file 23.
- 24. Serial port communication file
- 25. SIW file
- SOW file 26.
- 27. Ethernet port communication file

1.2 **Cautions**

Observe the following cautions when handling data files.

- Only 1-byte characters can be used.
- All data is handled as character strings conforming to ASCII character codes.
- Only upper case alphabetic characters may be used in command statements (lower case characters are prohibited).
- Line lengths must not exceed 75 characters.
- A [cr/lf] data format designation indicates CR code (0Dh) + LF code (0Ah).
- The terms "reading" and "writing" used in this manual indicate the following data flow directions: Reading: controller → external communication device Writing: External communication device → controller

"27. Ethernet port communication file" is available from software version 8.22 onwards.

Overview 11-1

10

П

12

K

14

15

2 Program file

2.1 All programs

Format

PGM

Meaning

- Expresses all programs.
- When used as a readout file, all programs currently stored are read out.

Values

- aCharacter code
- <Program names> are shown with 8 characters or less consisting of alphanumeric characters and underscore (_).
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.
- A TAB code (09H) is converted to a space.

```
SEND PGM TO CMU······ Outputs all programs from communication port.

SENDCMU TO PGM ···· Inputs all programs from communication port.

Response:
NAME=TEST[cr/lf]
A=1[cr/lf]
RESET DO2()[cr/lf]
:
HALT[cr/lf]
[cr/lf]
```

cprogram name>

Meaning

- Expresses a specified program.
- Program name may be up to 8 characters consisting of alphanumeric characters and underscore "_" and must be enclosed by "<" and ">".
- If no program name is specified, the currently selected program is specified.
- An error occurs if the specified program name differs from the program name on the data.

DATA FORMAT



aCharacter code

- <Program names> are shown with 8 characters or less consisting of alphanumeric characters and underscore (_).
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.
- A TAB code is converted to a space.



- At program writing operations, be sure to use the NAME statement to specify the program name. Program writing cannot occur if the program name is not specified.
- When the current mode is "AUTO" or "PROGRAM" mode, and writing into the currently selected program is not possible.
- When a sequence program is being executed, writing into the program name "SEQUENCE" is not possible.

```
SAMPLE
```

```
SEND <TEST1> TO CMU········· Outputs the program "TEST1" from communication port.

SEND CMU TO <TEST1>······ Inputs the program "TEST1" from communication port

Response:
```

```
Response:
NAME=TEST1[cr/lf]
A=1[cr/lf]
RESET DO2()[cr/lf]
:
HALT[cr/lf]
[cr/lf]
```

8

9

0

1

19

13

14

3.1 All points

Point file

Format

PNT

Meaning

- Expresses all point data.
- When used as a readout file, all points currently stored are read out.
- When used as a write file, writing is performed with a point number.

DATA FORMAT (On robots other than YK500TW)

```
Pmmmm=fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t[cr/lf]
[cr/lf]
```

DATA FORMAT(On robot YK500TW, with software Ver.10.66 or later)

```
Pmmmm= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t xr yr [cr/lf]
Pmmmm= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaaa fbbbbbbb t xr yr [cr/lf]
Pmmmm= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbbb t xr yr [cr/lf]
Pmmmm= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaaa fbbbbbbb t xr yr [cr/lf]
[cr/lf]
```

- In controllers whose software version is earlier than 8.28, "mmmm" represents a number from 0 to 4000.
- Hand system flags are available from software version 8.08 onwards.
- Integer point data is recognized in pulse units, and real number point data is recognized in "mm" units.
- •The X-arm and Y-arm rotation information is only available in software



mmmm Point No.: 0 to 9999

xxxxxx/../bbbbbb Represent a numeric value of 8 digits or less. When a dot is

included, this is treated as point data in "mm" units. Each piece of data is separated by one or more spaces.

t Extended hand system flag setting for SCARA robots. 1: right hand system; 2: left hand system.

xr Extended setting's X-arm rotation information.

0: The "mm \rightarrow pulse" converted angle data x (*1) range is -180.00° < x < = 180.00° .

1: The "mm \rightarrow pulse" converted angle data x (*1) range is 180.00° < x < = 540.00°.

-1: The "mm \rightarrow pulse" converted angle data x (*1) range is -540.00° < x < = -180.00°. yr Extended setting's Y-arm rotation information.

0: The "mm \rightarrow pulse" converted angle data x (*1) range is -180.00° < y < = 180.00° .

1: The "mm \rightarrow pulse" converted angle data x (*1) range is $180.00^{\circ} < y < = 540.00^{\circ}$.

-1: The "mm \rightarrow pulse" converted angle data x (*1) range is -540.00° < y < = -180.00°.

- *1: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.
- Hand system flags are valid only for SCARA robots, with the coordinate data specified in "mm"
- If a number other than "1" or "2" is specified for a hand system flag, or if no number is specified, this is interpreted as "0" setting (no hand system flag).

- X-arm and Y-arm rotation information settings are available only on the YK500TW robot model where a "mm" units coordinate system has been set.
 X-arm and Y-arm rotation information is processed as "0" if a numeral other than 0. 1. -1 has been
- X-arm and Y-arm rotation information is processed as "0" if a numeral other than 0, 1, -1 has been specified, or if no numeral has been specified.
- A line containing only [cr/lf] is added at the end of the file to indicate the end of the file.

SAMPLE (On ro	bots oth	ner than	YK500T	W)			
SEND PNT TO C	'MU · · · · · · ·		utputs ommunica	-	-	from	
SEND CMU TO PNTInputs all points from communication port.							
Response:							
P0 = 1	2	3	4	5	6	[cr/lf]	
P1 = 1.00	2.00	3.00	4.00	5.00	6.00	[cr/lf]	
P2 = 1.00 :	0.00	0.00	0.00	0.00	0.00	[cr/lf]	
P9999= -1.00 [cr/lf]	0.00	0.00	0.00	0.00	0.00	[cr/lf]	

SAMPLE (On	robot YK5	OOTW,	with a	softwar	e Ver	1.1	0.66	01	r later)
SEND PNT TO CMUOutputs all points from communication port.									
SEND CMU TO PNTInputs all points from communication port.									
Response:									
P0 =	1 2		3	4	5		(5	[cr/lf]
P1 = 426.2	0 -160.77	0.01	337.21	0.00	0.00	0	1	0	[cr/lf]
P2 = -27.5	7 -377.84	0.36	193.22	0.00	0.00	0	-1	0	[cr/lf]
:									
P9999= -251.6	6 -419.51	0.00	-127.79	0.00	0.00	2	-1	-1	[cr/lf]
[cr/lf]									



NOTE

 Hand system flags are available from software version 8.08 onwards.

In controllers whose

software version is earlier

than 8.28, "mmmm" represents a number from

0 to 4000.

- Integers indicate point data in "pulse" units, and real numbers in "mm" units.
- The X-arm and Y-arm rotation information is only available in software version 10.66 onwards.

3.2 One point

Format

Pmmmm



- Expresses a specified point.
- "mmmm" must be from 0 to 9999

DATA FORMAT (On robots other than YK500TW)

Pmmmm=fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t[cr/lf]

DATA FORMAT (On robot YK500TW, with software Ver.10.66 or later)

Pmmmm= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t xr yr [cr/lf]

Values

- mmmm Point No.: 0 to 9999
- f Coordinate sign: + / / space
- xxxxxx/../bbbbbb Represent a numeric value of 8 digits or less. When a dot is included, this is treated as point data in "mm" units. Each piece of data is separated by one or more spaces.
- tExtended hand system flag setting for SCARA robots. 1: right hand system; 2: left hand system.
- xr......X-arm rotation information for the YK500TW robot.
 - 0: The "mm \rightarrow pulse" converted pulse data x (*1) range is -180.00° < x < = 180.00° .
 - 1: The "mm \rightarrow pulse" converted pulse data x (*1) range is $180.00^{\circ} < x < = 540.00^{\circ}$.
 - -1: The "mm \rightarrow pulse" converted pulse data x (*1) range is -540.00° < x < = -180.00°.
- yrY-arm rotation information for the YK500TW robot.
 - 0: The "mm \rightarrow pulse" converted pulse data x (*1) range is -180.00° < y < = 180.00° .
 - 1: The "mm \rightarrow pulse" converted pulse data x (*1) range is $180.00^{\circ} < y < = 540.00^{\circ}$.
 - -1: The "mm \rightarrow pulse" converted pulse data x (*1) range is -540.00° < y < = -180.00°.
- *1: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.
- Hand system flags are valid only for SCARA robots, with the coordinate data specified in "mm" units.
- If a number other than "1" or "2" is specified for a hand system flag, or if no number is specified, this is interpreted as "0" setting (no hand system flag).
- X-arm and Y-arm rotation information settings are available only on the YK500TW robot model where a "mm" units coordinate system has been set.
- X-arm and Y-arm rotation information is processed as "0" if a numeral other than 0, 1, -1 has been specified, or if no numeral has been specified.

SAMPLE (On robots other than YK500TW)								
SEND P100 TO CMU······Outputs the specified point from communication port.								
SEND CMU TO P100 Inputs the specified point from communication port.								
Response:								
P100= 1 2 3 4 5 6[cr/lf]								

SAMPLE (On ro	bot YF	3500TW,	with	softw	are V	/er.10.	66 o	r later)
SEND P100 TO CMU Outputs the specified point from communication port.								
SEND CMU TO P100 Inputs the specified point from communication port.								
Response: P100= 1	2	3 4	5	6	0	1	0	[cr/lf]

4 Point comment file

4.1 All point comments

Format

PCM

Meaning

- Expresses all point comments.
- When used as a readout file, all point comments currently stored are read out.
- When used as a write file, writing is performed with a point comment number.

DATA FORMAT

PCmmmm= sssssssssssssss[cr/lf]
PCmmmm= sssssssssssssssss[cr/lf]

:
PCmmmm= ssssssssssssssss[cr/lf]
PCmmmm= ssssssssssssssss[cr/lf]

[cr/lf]

NO

 In controllers whose software version is earlier than 8.28, "mmmm" represents a number from 0 to 4000.



A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

SAMPLE

SEND PCM TO CMU...... Outputs all point comments from communication port.

SEND CMU TO PCM..... Inputs all point comments from communication port.

Response:
PC1 = ORIGIN POS[cr/lf]
PC3 = WAIT POS[cr/lf]
:
PC3999 = WORK100[cr/lf]
[cr/lf]

4.2 One point comment

- 0

NOTE

 Handling of individual point comment is available on the following software versions.

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

Format

PCmmmm



- Expresses a specified point comment.
- "mmmm" represents a number from 0 to 9999.

DATA FORMAT

PCmmmm= ssssssssssssss[cr/lf]

SAMPLE

SEND PC1 TO CMU Outputs the specified point comment from communication port. SEND CMU TO PC1 Inputs the specified point comment from communication port.

Response:

PC1 = ORIGIN POS[cr/lf]

4

5 Parameter file

5.1 All parameters

Format

PRM

Meaning

- Expresses all parameters (including settings in "UTILITY" mode).
- When used as a readout file, all parameters currently stored are read out.
- When used as a write file, only the parameters specified by parameter labels are written.

/parameter label/ ' <comment> [cr/lf] RC= xxxxxx [cr/lf] /parameter label/ ' <comment> [cr/lf] R1= xxxxxx R2= yyyyyy [cr/lf] /parameter label/ ' <comment> [cr/lf] A1= xxxxxx A2= yyyyyy A3= zzzzzz A4= rrrrrr[cr/lf] /parameter label/ ' <comment> [cr/lf] .: [cr/lf]

Values

- Parameter labels are shown with 6 alphabetic characters.
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.



- When writing parameter data, be sure that the servo is off.
- Parameters are already compatible with upper versions. However, parameters might not always be compatible with lower versions (upward compatibility).

.....

• When you attempt to load a parameter file of new version into a controller of an earlier version, an error "10.14: Undefined parameter found" may appear. If this happens, you may load the parameter by setting the "Skip undefined parameters" parameter to "VALID". For more details, refer to the "SYSTEM mode" – "Other parameters" section in the robot controller user's manual.

```
SAMPLE
SEND PRM TO CMU·····Outputs all parameters from
                        communication port.
SEND CMU TO PRM .....Inputs all parameters from
                        communication port.
Response:
/RBTNUM/ Robot number (V8.01/R1001)[cr/lf]
R1= 3000 R2= 3010 [cr/lf]
/AXES / Number of axes[cr/lf]
         2 R2 = 2 [cr/lf]
/AXSNUM/ 'Axis number (V1.01/V1.01/V1.01/V1.01/----/---/) [cr/lf]
A1= 5000 A2= 5001 A3= 5010 A4= 5011 [cr/lf]
                0 A7= 0 A8= 0 [cr/lf]
A5= 0 A6=
/ATTRIB/ 'Axis attribute[cr/lf]
A1= 33792 A2= 33792 A3= 33792 A4= 33792 [cr/lf]
     256 A6= 256 A7= 256 A8= 256 [cr/lf]
A5=
/WEIGHT/ 'Tip weight[kg][cr/lf]
       2 R2= 12 [cr/lf]
R1=
/CURPNO/ 'Port number of output[cr/lf]
 RC= 20 [cr/lf]
/CURPT1/ 'Compare point number1[cr/lf]
 RC=0 [cr/lf]
/CURPT2/ 'Compare point number2[cr/lf]
 RC=0 [cr/lf]
[cr/lf]
```

5.2 One parameter

Format

/parameter label/

Meaning

- Parameter labels are shown with 6 alphabetic characters.
- When used as a readout file, only the parameter specified by a parameter label is read out.
- When used as a write file, only the parameter specified by a parameter label is written.

DATA FORMAT 1

```
/parameter label/ ' <comment>[cr/lf]
RC= xxxxxx [cr/lf]
[cr/lf]
```

DATA FORMAT 2

```
/parameter label/ ' <comment>[cr/lf]
R?= xxxxxx [cr/lf]
[cr/lf]
```

DATA FORMAT 3

```
/parameter label/ ' <comment>[cr/lf]
A?= xxxxxx[cr/lf]
[cr/lf]
```

Values

- Parameter labels are shown with 6 alphabetic characters.
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.



- When writing parameter data, be sure that the servo is off.
- Parameters are already compatible with upper versions. However, parameters might not always be compatible with lower versions (upward compatibility).

• When you attempt to load a parameter file of new version into a controller of an earlier version, an error "10.14: Undefined parameter found" may appear.

SAMPLE

```
SEND /ACCEL / TO CMU ······ Outputs the acceleration parameter from communication port.

SEND CMU TO /ACCEL / ······· Inputs the acceleration parameter from communication port.

Response:
/ACCEL / 'Accel coefficient[%]

Al= 100 A2= 100 A3= 100 A4= 100[cr/lf]
[cr/lf]
```

9

9

10

11

12

13

14

15

6.1 All shift data

Format

SFT

Meaning

- Expresses all shift data.
- When used as a readout file, all shift data currently stored are read out.
- When used as a write file, writing is performed with a shift number.

DATA FORMAT				
Sm = fxxxxxx				
SPm = fxxxxxx	fyyyyyy	fzzzzzz	frrrrrr	[cr/lf]
SMm = fxxxxxx	fyyyyyy	fzzzzzz	frrrrrr	[cr/lf]
:				
Sm = fxxxxxx	fyyyyyy	fzzzzzz	frrrrrr	[cr/lf]
SPm = fxxxxxx	fyyyyyy	fzzzzzz	frrrrrr	[cr/lf]
SMm = fxxxxxx [cr/lf]	fyyyyyy	fzzzzzz	frrrrrr	[cr/lf]

Values

- The SPm and SMm inputs are optional in writing files.
 SPm: shift coordinate range plus-side; SMm: shift coordinate range minus-side
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

```
SAMPLE
SEND SFT TO CMU······Outputs all shift data from
                           communication port.
SEND CMU TO SFT ..... Inputs all shift data from
                           communication port.
Response:
                              0.00 [cr/lf]
S0 =
        0.00
               0.00
                       0.00
        0.00
               0.00
                       0.00
                              0.00 [cr/lf]
SP0=
SM0=
                              0.00 [cr/lf]
        0.00
               0.00
                       0.00
S1 =
        1.00
               1.00
                       1.00
                              1.00 [cr/lf]
SM9=
        9.00
               9.00
                              9.00 [cr/lf]
                       9.00
[cr/lf]
```

6.2 One shift definition

Format

Sm

Meaning • Expresses a specified shift definition.

DATA FORMAT

Sm = fxxxxxx fyyyyyy fzzzzzz frrrrrr[cr/lf]

Values mShift No.: 0 to 9

fCoordinate sign: + / - / space

xxxxxx/yyyyy/../rrrrrrRepresent a numeric value of 8 digits or less, having 2 or less places below the decimal point.

SAMPLE

SEND S0 TO CMU \cdots Outputs the specified shift coordinate from communication port. SEND CMU TO S0 \cdots Inputs the specified shift

SEND CMU TO SOcoordinate from communication port.

Response:

S0 =0.00 0.00 0.00 0.00[cr/lf] SP0=0.00 0.00 0.00 0.00[cr/lf] SM0=0.00 0.00 0.00 0.00[cr/lf] [cr/lf]

7.1 All hand data

Format

HND

Meaning

- Expresses all hand data.
- When used as a readout file, all hand data currently stored are read out.
- When used as a write file, writing is performed with a hand number.

```
DATA FORMAT

Hm = fxxxxxx fyyyyyy fzzzzzz {R}[cr/lf]
:
Hm = fxxxxxx fyyyyyy fzzzzzz {R}[cr/lf]
[cr/lf]
```

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

```
SAMPLE
SEND HND TO CMU·····Outputs all hand data from
                           communication port.
SEND CMU TO HND ..... Inputs all hand data from
                           communication port.
Response:
H0 =
        0.00
               0.00
                       0.00 [cr/lf]
H1 =
        1.00
               1.00
                       1.00 [cr/lf]
H2 =
        2.00
               2.00
                       2.00 [cr/lf]
                       3.00 [cr/lf]
H3 =
        3.00
               3.00
                       4.00 [cr/lf]
H4 =
        4.00
               4.00
                       5.00 [cr/lf]
H5 =
        5.00
               5.00
H6 =
        6.00
               6.00
                       6.00 [cr/lf]
H7 =
        7.00
               7.00
                       7.00 [cr/lf]
[cr/lf]
```

0

10

1

12

13

14

7.2 One hand definition

Format

Hm

Meaning • Expresses a specified hand definition.

DATA FORMAT

Hm = fxxxxxx fyyyyyy fzzzzzz {R}[cr/lf]

{R}.....Indicates whether a hand is attached to the R-axis.

SAMPLE

SEND H3 TO CMU $\cdots\cdots$ Outputs the specified hand definition data from communication port.

SEND CMU TO H3 Inputs the specified hand definition data from communication port.

Response:

 $H3 = 3.00 \quad 3.00 \quad 3.00 [cr/lf]$

8.1 All pallet definitions

Format

PLT

Meaning

- Expresses all pallet definitions.
- When used as a readout file, all pallet definitions currently stored are read out.
- When used as a write file, writing is performed with a pallet number.

```
DATA FORMAT (On robots other than YK500TW)

PLm [cr/lf]
PLN = XY [cr/lf]
NX = nnn [cr/lf]
NY = nnn [cr/lf]
NZ = nnn [cr/lf]
P[1] = fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t[cr/lf]
:
P[5] = fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t[cr/lf]
PLm [cr/lf]
:
[cr/lf]
```

DATA FORMAT (On robot YK500TW, with software Ver.10.66 or later) PLm [cr/lf] PLN = XY [cr/lf] NX = nnn [cr/lf] NY = nnn [cr/lf] NZ = nnn [cr/lf] P[1] = fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t xr yr[cr/lf] : P[5] = fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t xr yr[cr/lf] PLm [cr/lf] : [cr/lf]

-1: "mm" \rightarrow pulse converted angle data x (*1) range: -540.00° < x <= -180.00°

NOTE

Ver. 10.66 onwards.

 Hand system flags are available from software version 8.08 onwards.

 X-arm and Y-arm rotation information is only available in software

15

yr Extended setting for Y-arm rotation information.

0: "mm" \rightarrow pulse converted angle data x (*1) range: -180.00° < y <= 180.00°

1: "mm" \rightarrow pulse converted angle data x (*1) range: 180.00° < y <= 540.00°

-1: "mm" \rightarrow pulse converted angle data x (*1) range: -540.00° < y <= -180.00°

- *1: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.
- Hand system flags are enabled only when specifying the coordinate data in "mm" units for SCARA robots.
- Hand system flags and the X-arm and Y-arm rotation information are ignored during movement where pallet definitions are used.
- If a number other than 1 or 2 is set, or if no number is designated, then 0 will be set to indicate that there is no hand system flag.
- X-arm and Y-arm rotation information settings are available only on the YK500TW robot model where a "mm" units coordinate system has been set.
- If a value other than "0", "1", "-1" is specified at the X-arm and Y-arm rotation information, or if no value is specified, this will be processed as "0".
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

SAMPLE									
SEND PLT TO CMU······Outputs all pallet definitions from communication port.									
SEND CMU TO PLT Inputs all pallet definitions from communication port.									
Response:	-								
PL0[cr/lf]									
PLN=XY[cr/lf	1								
NX = 3[cr/1]									
NY = 4[cr/1]									
NZ = 2[cr/1]	f]								
P[1] = 0.00	0.00	0.00	0.00	0.00	0.00	[cr/lf]			
P[2] = 100.00	0.00	0.00	0.00	0.00	0.00	[cr/lf]			
P[3] = 0.00	100.00	0.00	0.00	0.00	0.00	[cr/lf]			
P[4] = 100.00	100.00	0.00	0.00	0.00	0.00	[cr/lf]			
P[5] = 0.00	0.00	50.00	0.00	0.00	0.00	[cr/lf]			
PL1[cr/lf]									
PLN= XY[cr/]									
NX = 3[cr/1]	f]								
NY = 4[cr/l]									
NZ = 2[cr/l]	f]								
P[1] = 0.00			0.00	0.00	0.00	- , -			
P[2] = 100.00			0.00	0.00	0.00	•			
P[3] = 0.00				0.00		/ -			
P[4] = 100.00				0.00	0.00				
	0.00	100.00	0.00	0.00	0.00	[cr/lf]			
[cr/lf]									



NOTE

 Integers indicate point data in "pulse" units, and real numbers in "mm" units.

8.2 One pallet definition

Format

PLm

Meaning

- Expresses a specified pallet definition.
- "m" must be from 0 to 19.

DATA FORMAT (On robots other than YK500TW) PLm [cr/lf] PLN = XY [cr/lf] NX = nnn [cr/lf] NY = nnn [cr/lf] NZ = nnn [cr/lf] P[1] = fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t[cr/lf] : P[5] = fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t[cr/lf] [cr/lf]

DATA FORMAT (On robot YK500TW, with software Ver.10.66 or later) PLm [cr/lf] PLN = XY [cr/lf] NX = nnn [cr/lf] NY = nnn [cr/lf] NZ = nnn [cr/lf] P[1] = fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t xr yr[cr/lf] : P[5] = fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t xr yr[cr/lf] [cr/lf]

Values

Represent a numeric value of 8 digits or less. When a dot is included, this is treated as point data in "mm" units. Each piece of data is separated by one or more spaces.

t An extended hand system flag setting for SCARA robots. 1: Right-handed system, 2: Left-handed system

xr Extended setting for X-arm rotation information.

0: "mm" \rightarrow pulse converted angle data x (*1) range: -180.00° < x <= 180.00° 1: "mm" \rightarrow pulse converted angle data x (*1) range: 180.00° < x <= 540.00°

-1: "mm" \rightarrow pulse converted angle data x (*1) range: -540.00° < x <= -180.00°

yr Extended setting for Y-arm rotation information.

0: "mm" \rightarrow pulse converted angle data x (*1) range: -180.00° < y <= 180.00°

1: "mm" \rightarrow pulse converted angle data x (*1) range: 180.00° < y <= 540.00°

-1: "mm" \rightarrow pulse converted angle data x (*1) range: -540.00° < y <= -180.00°

*1: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.



- Hand system flags are available from software version 8.08 onwards.
- X-arm and Y-arm rotation information is only available in software Ver.10.66 onwards.
- Hand system flags are enabled only when specifying the coordinate data in "mm" units for SCARA robots.
- Hand system flags and the X-arm and Y-arm rotation information are ignored during movement where pallet definitions are used.
- If a number other than 1 or 2 is set, or if no number is designated, then 0 will be set to indicate that there is no hand system flag.
- X-arm and Y-arm rotation information settings are available only on the YK500TW robot model where a "mm" units coordinate system has been set.
- If a value other than "0", "1", "-1" is specified at the X-arm and Y-arm rotation information, or if no value is specified, this will be processed as "0".
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

8

9

10

11

19

13

14

```
SAMPLE
SEND PL2 TO CMU······ Outputs the specified pallet definition
                              from communication port as shown below.
SEND CMU TO PL2 · · · · Inputs the specified pallet definition
                              from communication port as shown below.
Response:
PL2[cr/lf]
PLN=XY[cr/lf]
NX=
        3 [cr/lf]
NY=
        3[cr/lf]
        2[cr/lf]
NZ =
P[1] = 100.00 100.00
                        50.00
                                90.00
                                          0.00
                                                  0.00
                                                         [cr/lf]
P[2] = 200.00 100.00
                        50.00
                                90.00
                                          0.00
                                                  0.00
                                                         [cr/lf]
P[3] = 100.00 200.00
                        50.00
                                90.00
                                          0.00
                                                  0.00
                                                         [cr/lf]
                                                         [cr/lf]
P[4] = 200.00 200.00
                        50.00
                                90.00
                                          0.00
                                                  0.00
P[5] = 100.00
              10.00 100.00
                                90.00
                                          0.00
                                                  0.00
                                                         [cr/lf]
[cr/lf]
```

All files 9.1

Format

ALL

Meaning Expresses the minimum number of data files required to operate the robot system.

•For details of each file, refer to that file's explanation.

DATA FORMAT

```
[PGM] All program format
NAME=< program name >
[cr/lf]
[PNT] All point format
Pmmmm=fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t[cr/lf]
Pmmmm=fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbbb t[cr/lf]
[cr/lf]
[PCM] All point comment format
PCmmmm= ssssssssssssss[cr/lf]
PCmmmm= sssssssssssss[cr/lf]
[cr/lf]
[PRM] All parameter format
/parameter label/'<comment> [cr/lf]
RC= xxxxxx [cr/lf]
/parameter label/'<comment> [cr/lf]
R1= xxxxxx R2= yyyyyy [cr/lf]
[cr/lf]
[END] ALL files end
```



• In writing files, [xxx] determines the data file's format, and this format is saved at the controller. Example: [HND]...All text data up the next [xxx] is saved at the controller as "all hand" format

SAMPLE

```
SEND ALL TO CMU..... Outputs all files of the entire
                         system from communication port.
SEND CMU TO ALL..... Inputs all files of the entire
                         system from communication port.
```

10 Program directory file

10.1 Entire program directory

Format

DIR

Meaning

- Expresses entire program directory.
- When used as a readout file, information on entire program directory is read out.
- Cannot be used as a write file.

DATA FORMAT					
No. Name nnnfgsssssss	Line 1111	Byte bbbbbb	RW/RC		Time[cr/lf] hh:mm[cr/lf]
: nnnfgssssssss END[cr/lf]	1111	bbbbbb	xx	yy/mm/dd	hh:mm[cr/lf]

Values

f"cc	rogram directory number: 3 digits " at program compiling when a program object is reated. "s" at sequence program compiling when a requence object is created.
	nows an asterisk "*" for the currently selected program.
bbbbbbBy	yte size of program: 6 digits le attribute: 2-digit
yy/mm/ddD	W: Readable/writable O: Not writable (read only) ate when the program was updated: 8 digits (including e "/" marks)
	me when the program was updated: 5 digits

SAMPLE								
SEND	SEND DIR TO CMU······Outputs information on all program							
	directory from communication port.							
Resp	onse:							
No.	Name	Line	Byte	RW/F	RO Date	Time[cr/lf]		
10*	12345678	5	21	RW	01/06/20	10:35[cr/lf]		
2	PGM1	5	66	RW	01/06/20	10:35[cr/lf]		
3	PGM2	5	66	RW	01/06/20	10:35[cr/lf]		
4	PGM3	5	66	RW	01/06/20	10:35[cr/lf]		
5	PGM4	5	66	RW	01/06/20	10:35[cr/lf]		
6	PGM5	5	66	RW	01/06/20	10:35[cr/lf]		
7	PGM6	5	66	RW	01/06/20	10:35[cr/lf]		
88	SEQUENCE	1	15	RW	01/06/20	10:35[cr/lf]		
END [END[cr/lf]							

"<<" <pre>" <>" >>"

Meaning

- Expresses information on one program.
- The program name is enclosed in <<>> double brackets.

DATA FORMAT

No. Name Line Byte RW/RO Date Time[cr/lf] nnnfgsssssss 1111 bbbbbb xx yy/mm/dd hh:mm[cr/lf]



nnn	Program directory number: 3 digits
f	"o" at program compiling when a program object is
	created. "s" at sequence program compiling when a
	sequence object is created.
g	Shows an asterisk "*" for the currently selected program.
SSSSSSS	Program name: 8 digits
IIII	Number of program lines: 4 digits
bbbbbb	Byte size of program: 6 digits
xx	File attribute: 2-digit
	RW: Readable/writable
	RO: Not writable (read only)
yy/mm/dd	Date when the program was updated: 8 digits (including
	the "/" marks)
hh:mm	Time when the program was updated: 5 digits



• Indicates the compiled execution program (program objects compiled for a robot program, or sequence objects compiled for a sequence program).

SAMPLE

SEND <<TEST>> TO CMU $\cdot\cdot\cdot\cdot$ Outputs information on the specified program from communication port.

Response:

No. Name Line Byte RW/RO Date Time[cr/lf] 30* PGM2 5 66 RW 01/06/20 10:35[cr/lf]

Ö

9

10

1

12

13

14

15

Parameter directory file 11

Entire parameter directory 11.1

Format

DPM



- Meaning Expresses entire parameter directory.
 - When used as a readout file, information on entire parameter directory is read out.
 - Cannot be used as a write file.

```
DATA FORMAT
/parameter label/ ' <comment>[cr/lf]
/parameter label/ ' <comment>[cr/lf]
/parameter label/ ' <comment>[cr/lf]
 [cr/lf]
```

Values

<comment> Parameter name

- Parameter labels are shown with 6 alphabetic characters.
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

```
SAMPLE
SEND DPM TO CMU······Outputs information on all parameter
                           directory from communication port.
Response:
/RBTNUM/ 'Robot number (V8.01/R1001) [cr/lf]
/AXES / 'Number of axes[cr/lf]
/AXSNUM/ 'Axis number(V1.01/V1.01/V1.01/V1.01/----/) [cr/lf]
/ATTRIB/ 'Axis attribute[cr/lf]
/WEIGHT/ 'Tip weight[kg][cr/lf]
/ORIGIN/ 'Origin sequence[cr/lf]
/RORIEN/ 'R axis orientation[cr/lf]
/CURPNO/ 'Output port number[cr/lf]
/CURPT1/ 'Number of compare point 1[cr/lf]
/CURPT2/ 'Number of compare point 2[cr/lf]
[cr/lf]
```

Format

VAR

Meaning

- Expresses all global variables.
- When used as a readout file, all global variables currently stored are read out.
- When used as a write file, a specified global variable is written.

```
DATA FORMAT

<variable name>t = xxxxxx [cr/lf]

<variable name>t = xxxxxx [cr/lf]

:
<variable name>t = xxxxxx [cr/lf]
   [cr/lf]
```

Values	<variable name=""></variable>	Global variab	le defined in the program. Variable			
	r	name is shown	with 16 characters or less consisting of			
	a	alphanumeric c	haracters and underscore ("_").			
	tT	Type of variable / !: real type, %: integer type,				
	C	character string	type			
	xxxxxx	Differs dependi	ng on the type of variable:			
	I	nteger type:	integer of 8 digits or less			
	г) a a l 4	wool mumber of 7 digits on loss including			

Real type: real number of 7 digits or less including

decimal fractions

Character type: character string of 70 characters or less

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

IL

1

12

13

14

15

10

I

12

13

14

15

```
SAMPLE 1
SEND VAR TO CMU·····Outputs all global variables
                           from communication port.
Response:
SGI0=0[cr/lf]
SGI1=1111[cr/lf]
SGI2=2222[cr/lf]
SGI3=3333 [cr/lf]
SGI4=4444[cr/lf]
SGI5=5555[cr/lf]
SGI6=6666[cr/lf]
SGI7=7777[cr/lf]
SGR0=0[cr/lf]
SGR1=1.1111E3 [cr/lf]
SGR2=2.2222E3[cr/lf]
SGR3=3.3333E3[cr/lf]
SGR4=4.4444E3[cr/lf]
SGR5=5.5555E3[cr/lf]
SGR6=6.6666E3[cr/lf]
SGR7=7.7777E3 [cr/lf]
B1%=111[cr/lf]
B2%=222[cr/lf]
C1$="CNS 1"[cr/lf]
C2$="CNS_2"[cr/lf]
[cr/lf]
```

SAMPLE 2

SEND CMU TO VAR..... Inputs all global variables from communication port.

12.2 One variable

Format

<variable name>t

Meaning • Expressed one variable.

DATA FORMAT

xxxxxx [cr/lf]



- SGIx indicates an integer type static variable.
- SGRx indicates a real type static variable.

Values

<Variable name>Global variable defined in the program. Variable

name is shown with 16 characters or less consisting of alphanumeric characters and underscore ("_").

tType of variable / !: real type, %: integer type, \$:

character string type

.Differs depending on the type of variable:

Integer type: integer of 8 digits or less

real number of 7 digits or less including Real type:

decimal fractions

Character type: character string of 70 characters or less



 Dynamic global variables are registered during compiling. Variables cannot be referred to unless they are registered.

SAMPLE 1

SEND SGI6 TO CMU[cr/lf] \cdots Outputs the specified variable SGI6 from communication port.

Response:

6666 [cr/lf]

SAMPLE 2

SEND CMU TO SGI6[cr/lf] $\cdot \cdot$ Inputs the specified variable SGI6 from communication port.

Response:

6666 [cr/lf] Data input to the controller. OK [cr/lf] ······ Result output from the controller.

Constant file

13.1 One character string

Format

"<character string>"



- Expresses a specified character string.
- When used as a readout file, the specified character string is read out.
- Cannot be used as a write file.

DATA FORMAT

sssss...ssssss[cr/lf]



Output of a double quotation (") is shown with two successive double quotations.

SAMPLE

```
SEND ""YAMAHA ROBOT"" TO CMU
        ...... Outputs the specified character
                        string from communication port.
```

Response:

"YAMAHA ROBOT"[cr/lf]

7

10

11

12

13

14

19

14.1 All array variables

Format

ARY

Meaning

- Expresses all array variables.
- When used as a readout file, all array variables are read out.
- When used as a write file, writing is performed with a specified array variable.

```
DATA FORMAT

<variable name>t(l{,m{,n}}) = xxxxxx [cr/lf]

<variable name>t(l{,m{,n}}) = xxxxxx [cr/lf]

:

<variable name>t(l{,m{,n}}) = xxxxxx [cr/lf]

[cr/lf]
```

Values

■ A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

SAMPLE 1

```
SEND ARY TO CMU·········· Outputs all global array variables from communication port.
Response:
A!(0) = 0[cr/lf]
A!(1) = 1.E2[cr/lf]
A!(2) = 2.E2[cr/lf]
B%(0,0)=0[cr/lf]
B%(0,1)=1111[cr/lf]
B%(1,0) = 2222[cr/lf]
B%(1,1) = 3333[cr/lf]
C$(0,0,0) = "ARY1" [cr/lf]
C$(0,0,1) = "ARY2" [cr/lf]
C$(0,1,0) = "ARY3" [cr/lf]
C$(0,1,1) = "ARY4" [cr/lf]
C$(1,0,0) = "ARY5" [cr/lf]
C$(1,0,1) = "ARY6" [cr/lf]
C$(1,1,0) = "ARY7"[cr/lf]
C$(1,1,1) = "ARY8" [cr/lf]
[cr/lf]
```

SAMPLE 2

SEND CMU TO ARY Inputs all global array variables from communication port.

14.2 One array variable

Format

<variable name>t(l {,m {,n }})

Meaning • Expresses one array variable.

DATA FORMAT

xxxxxx [cr/lf]

Values

<Variable name>Global variable defined in the program. Variable name is shown with 16 characters or less consisting of alphanumeric characters and underscore ("_").

tType of variable / !: real type, %: integer type, \$: character string type

I, m, nIndicate array arguments.

.....

Integer type: integer of 8 digits or less

Real type: real number of 7 digits or less including

decimal fractions

Character type: character string of 70 characters or less

.....



• Array variables defined by the DIM statement are registered during compiling. Array variables cannot be referred to unless they are registered.

SAMPLE 1

SEND C1\$(2) TO CMU[cr/lf] \cdots Outputs the specified array variable C1\$(2) from communication port.

Response:

YAMAHA ROBOT[cr/lf]

SAMPLE 2

SEND CMU TO C1\$(2) [cr/lf] \cdots Inputs the specified array variable C1\$(2) from communication port.

Response:
OK[cr/lf]

Format

DI()

Meaning

- Expresses all DI (parallel input variable) information.
- When used as a readout file, all DI information is read out.
- Cannot be used as a write file.

```
DIO()=&Bnnnnnnn [cr/lf]
DI1()=&Bnnnnnnnn [cr/lf]
:
DI27()=&Bnnnnnnnn [cr/lf]
[cr/lf]
```

Values

n"0" or "1" (total of 8 digits). Corresponds to m7, m6, ..., m0, reading from the left ("m" is the port No.).

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

```
SAMPLE
SEND DI() TO CM ..... Outputs all DI information
                           from communication port.
Response:
DIO()=&B10001001[cr/lf]
DI1()=&B00000010[cr/lf]
DI2() = &B000000000[cr/lf]
DI7()=&B00000000[cr/lf]
DI10()=&B00000000[cr/lf]
DI11()=&B00000000[cr/lf]
DI12()=&B00000000[cr/lf]
DI17()=&B00000000[cr/lf]
DI20()=&B00000000[cr/lf]
DI26()=&B00000000[cr/lf]
DI27() = &B00000000[cr/lf]
[cr/lf]
```

9

10

11

12

13

14

15

15.2 One DI port

Format

DIm()



- Expresses the status of one DI port.
- When used as a readout file, the specified DI port status is read out.
- Cannot be used as a write file.

DATA FORMAT

DIm()=&Bnnnnnnnn[cr/lf]



m0 to 7, 10 to 17, 20 to 27

n"0" or "1" (total of 8 digits). Corresponds to m7, m6, ..., m0, reading from the left ("m" is the port No.).

SAMPLE

SEND DI5() TO CMU $\cdots\cdots$ Outputs the DI5 port status from communication port.

Response:

DI5()=&B00000000[cr/lf]

16.1 All DO information

Format

DO()



- Expresses all DO (parallel output variable) information.
- When used as a readout file, all DO information is read out.
- Cannot be used as a write file.

```
DATA FORMAT
DO0()=&Bnnnnnnn [cr/lf]
DO1()=&Bnnnnnnn [cr/lf]
DO27()=&Bnnnnnnn [cr/lf]
[cr/lf]
```

Values

n"0" or "1" (total of 8 digits). Corresponds to m7, m6, ..., m0, reading from the left ("m" is the port No.).

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

```
SAMPLE
SEND DO() TO CMU ..... Outputs all DO information
                           from communication port.
Response:
DO0()=&B10001001[cr/lf]
DO1()=&B00000010[cr/lf]
DO2() = &B000000000[cr/lf]
DO7()=&B00000000[cr/lf]
DO10()=&B00000000[cr/lf]
DO11()=&B00000000[cr/lf]
DO12()=&B00000000[cr/lf]
DO17()=&B00000000[cr/lf]
DO20()=&B00000000[cr/lf]
DO26() = &B00000000[cr/lf]
DO27() = &B00000000[cr/lf]
[cr/lf]
```

16.2 One DO port

Format

DOm()



- Expresses the status of one DO port.
- When used as a readout file, the specified DO port status is read out.
- When used as a write file, the value is written to the specified DO port. However, writing to DO0() and DO1() is prohibited.
- · Readout file

DATA FORMAT

DOm() = & Bnnnnnnnn [cr/lf]

• Write file

DATA FORMAT

&Bnnnnnnnn[cr/lf] or k[cr/lf]





• Writing to DO0() and DO1() is prohibited. Only referencing is permitted.

SAMPLE 1

SEND DO5() TO CMU······ Outputs the DO5 port status from communication port.

Response:

DO5()=&B00000000[cr/lf]

SAMPLE 2

SEND CMU TO DO5() Inputs the DO5 port status from communication port.

&B00000111

Response:

OK[cr/lf]

17.1 All MO information

Format

MO()

Meaning

- Expresses all MO (internal output variable) information.
- When used as a readout file, all MO information is read out.
- Cannot be used as a write file.

```
DATA FORMAT

MO0()=&Bnnnnnnn [cr/lf]

MO1()=&Bnnnnnnnn [cr/lf]

:

MO27()=&Bnnnnnnnn [cr/lf]
[cr/lf]
```

Values

n"0" or "1" (total of 8 digits). Corresponds to m7, m6, ..., m0, reading from the left ("m" is the port No.).

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

```
SAMPLE
SEND MO() TO CMU ..... Outputs all MO information
                            from communication port.
Response:
MOO() = &B10001001[cr/lf]
MO1() = &B00000010[cr/lf]
MO2() = &B000000000[cr/lf]
MO7()=&B00000000[cr/lf]
MO10() = \&B000000000[cr/lf]
MO11() = &B000000000[cr/lf]
MO12()=&B00000000[cr/lf]
MO17()=&B00000000[cr/lf]
MO20() = &B00000000[cr/lf]
MO26() = \&B000000000[cr/lf]
MO27() = &B00000000[cr/lf]
[cr/lf]
```

17.2 One MO port

Format

MOm ()



- Expresses the status of one MO port.
- When used as a readout file, the specified MO port status is read out.
- When used as a write file, the value is written to the specified MO port. However, writing to MO0() and MO1() is prohibited.
- · Readout file

DATA FORMAT

MOm() = & Bnnnnnnnn [cr/lf]

• Write file

DATA FORMAT

&Bnnnnnnnn[cr/lf] or k[cr/lf]





• Writing to MO0() and MO1() is prohibited. Only reference is permitted.

SAMPLE 1

SEND MO5() TO CMU·······Outputs the MO5 port status from communication port.

Response:

MO5()=&B00000000[cr/lf]

SAMPLE 2

SEND CMU TO MO5() Inputs the MO5 port status from communication port.

&B00000111

Response:

OK[cr/lf]

All LO information 18.1

Format

LO()



- Expresses all LO (internal output variable) information.
- When used as a readout file, all LO information is read out.
- Cannot be used as a write file.

DATA FOMAT

LOO()=&Bnnnnnnn [cr/lf] [cr/lf]



n"0" or "1" (total of 8 digits). Corresponds to 07, 06, ..., 00, reading from the left.

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

SAMPLE

SEND LO() TO CMU ······ Outputs all LO status from communication port.

Response:

LO0()=&B10001001[cr/lf] [cr/lf]

18.2 One LO port

Format

LO0()



- Expresses the status of one LO port.
- When used as a readout file, the specified LO port status is read out.
- When used as a write file, the value is written to the specified LO port.
- · Readout file

DATA FORMAT

LOO()=&Bnnnnnnnn[cr/lf]

• Write file

DATA FORMAT

&Bnnnnnnn[cr/lf] or k[cr/lf]

Values

n"0" or "1" (total of 8 digits). Corresponds to 07, 06, ..., 00, reading from the left.

 $k \ Integer from 0 to 255$

SAMPLE 1

SEND LO0() TO CMU $\cdots\cdots$ Outputs the LO0 port status from communication port.

Response:

LO0()=&B00000000[cr/lf]

SAMPLE 2

SEND CMU TO LO0() Inputs the LO0 port status from communication port.

&B00000111

Response:

OK[cr/lf]

19.1 All TO information

Format

TO()



- Expresses all TO (timer output variable) information.
- When used as a readout file, all TO information is read out.
- Cannot be used as a write file.

DATA FORMAT

TO0()=&Bnnnnnnn [cr/lf] [cr/lf]



n"0" or "1" (total of 8 digits). Corresponds to 07, 06, ..., 00, reading from the left ("m" is the port No.).

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

SAMPLE

SEND TO() TO CMU $\cdots\cdots$ Outputs all TO status from communication port.

Response:

TO0()=&B10001001[cr/lf] [cr/lf] IJ

14

15

19.2 One TO port

Format

TO()



- Expresses the status of one TO port.
- When used as a readout file, the specified TO port status is read out.
- When used as a write file, the value is written to the specified TO port.
- · Readout file

DATA FORMAT

TO 0 () = &Bnnnnnnnn [cr/lf]

• Write file

DATA FORMAT

&Bnnnnnnn[cr/lf] or k[cr/lf]

Values

SAMPLE 1

SEND TOO() TO CMU··········· Outputs the TOO port status from communication port.

Response:

TO0()=&B00000000[cr/lf]

SAMPLE 2

SEND CMU TO TOO() Inputs the TOO port status from communication port.

&B00000111

Response:

OK[cr/lf]

20.1 All SI information

Format

SI()



- Expresses all SI (serial input variable) information.
- When used as a readout file, all SI information is read out.
- Cannot be used as a write file.

```
DATA FORMAT

SIO()=&Bnnnnnnn [cr/lf]

SI1()=&Bnnnnnnn [cr/lf]

:

SI27()=&Bnnnnnnnn [cr/lf]

[cr/lf]
```

Values

n"0" or "1" (total of 8 digits). Corresponds to m7, m6, ..., m0, reading from the left ("m" is the port No.).

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

```
SAMPLE
SEND SI() TO CMU ..... Outputs all SI status from
                            communication port.
Response:
SIO()=&B10001001[cr/lf]
SI1()=&B00000010[cr/lf]
SI2() = \&B000000000[cr/lf]
SI7() = &B000000000[cr/lf]
SI10()=&B00000000[cr/lf]
SI11()=&B00000000[cr/lf]
SI12()=&B00000000[cr/lf]
SI17()=&B00000000[cr/lf]
SI20() = &B000000000[cr/lf]
SI26() = \&B000000000[cr/lf]
SI27() = &B000000000[cr/lf]
[cr/lf]
```

20.2 One SI port

Format

SIm()



- Expresses the status of one SI port.
- When used as a readout file, the specified SI port status is read out.
- Cannot be used as a write file.

DATA FORMAT

SIm() = & Bnnnnnnnn [cr/lf]



SAMPLE

SEND SI5() TO CMU $\cdots\cdots$ Outputs the SI5 port status from communication port.

Response:

SI5()=&B00000000[cr/lf]

Format

SO()

Meaning

- Expresses all SO (serial output variable) information.
- When used as a readout file, all SO information is read out.
- Cannot be used as a write file.

```
DATA FORMAT

SO0()=&Bnnnnnnn [cr/lf]

SO1()=&Bnnnnnnn [cr/lf]

:
SO27()=&Bnnnnnnnn [cr/lf]
[cr/lf]
```

Values

n"0" or "1" (total of 8 digits). Corresponds to m7, m6, ..., m0, reading from the left ("m" is the port No.).

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

```
SAMPLE
SEND SO() TO CMU ······ Outputs all SO status from
                            communication port.
Response:
SO0()=&B10001001[cr/lf]
SO1()=&B00000010[cr/lf]
SO2() = \&B000000000[cr/lf]
SO7() = &B000000000[cr/lf]
SO10()=&B00000000[cr/lf]
SO11()=&B00000000[cr/lf]
SO12()=&B00000000[cr/lf]
SO17()=&B00000000[cr/lf]
SO20() = &B000000000[cr/lf]
SO26() = \&B000000000[cr/lf]
SO27() = &B000000000[cr/lf]
[cr/lf]
```

9

10

11

12

13

14

15

21.2 One SI port

Format

SOm()



- Expresses the status of one SO port.
- When used as a readout file, the specified SO port status is read out.
- When used as a write file, the value is written to the specified SO port. However, writing to SOO() and SO1() is prohibited.
- · Readout file

DATA FORMAT

SOm() = &Bnnnnnnnn [cr/lf]

• Write file

DATA FORMAT

&Bnnnnnnnn[cr/lf] or k[cr/lf]



mPort number: 0 to 7, 10 to 17, 20 to 27
n"0" or "1" (total of 8 digits). Corresponds to m7, m6, ...,
m0, reading from the left ("m" is the port No.).
kInteger from 0 to 255



• Writing to SOO() and SO1() is prohibited. Only reference is permitted.

SAMPLE 1

SEND SO5() TO CMU·······Outputs the SO5 port status from communication port.

Response:

SO5()=&B00000000[cr/lf]

SAMPLE 2

SEND CMU TO SO5() Inputs the SO5 port status from communication port.

&B00000111

Response:

OK[cr/lf]

22.1 All error message history

Format

LOG

- Meaning Expresses all error message history.
 - When used as a readout file, all error message history is read out.
 - Cannot be used as a write file.

```
DATA FORMAT
nnn:yy/mm/dd,hh:mm:ss
                        gg.bb:msg[cr/lf]
nnn:yy/mm/dd,hh:mm:ss
                        gg.bb:msg[cr/lf]
nnn:yy/mm/dd,hh:mm:ss
                        gg.bb:msg[cr/lf]
[cr/lf]
```

Values nnnRepresents an error history serial number and may be up to 500. yy, mm ,dd.....Year/Month/Day hh, mm, ss Hour, Minute, Second gg.....Error message group bb Error message category

msg Error message

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

```
SAMPLE
SEND LOG TO CMU·····Outputs all error message
                          history from communication port.
Response:
  :01/06/14,13:19:20 14.22:No start code (@)[cr/lf]
   :01/06/14,13:18:34 22.3: DC24V power low[cr/lf]
498:01/06/12,21:49:54 5.39:Illegal identifier[cr/lf]
499:01/06/12,21:49:14 14.22:No start code (@)[cr/lf]
500:01/06/12,21:49:00 22.3: DC24V power low[cr/lf]
[cr/lf]
```

23 Error Message History Details File

23.1 General error message history details



NOTE

 The "Error message history details file" is available in the following software versions:

RCX240 Ver. 10.65 onwards RCX22x Ver. 9.36 onwards

Format

LEX

Meaning

- Displays the general error message history details.
- This file cannot be specified as a WRITE file.

DATA FORMAT

nnn.l:yy/mm/dd hh:mm:ss gg.bb:msg,A,N,L,P[cr/lf]
nnn.l:M=x,y,z,r,a,b[cr/lf]

nnn.l:S=x,y,z,r,a,b[cr/lf]

Values

nnn	Represents an error history serial number and may be
	up to 500.
I	Output line number (max. of 3)
yy, mm ,dd	Year/Month/Day
hh, mm, ss	Hour, Minute, Second
gg	Error message group
bb	Error message category
msg	Error message
A	AUTO operation execution status. 1: AUTO operation
	in progress; 0: Other status.
N	Execution program name.
L	Program's execution line No.
P	No. of most recently referenced point.
M=	Indicates that all subsequent coordinates are main
	robot coordinates.
S=	Indicates that all subsequent coordinates are sub robot
	coordinates.
x,y,z,r,a,b	Current position of each axis.



NOTE

• Error information is output only for the connected robot.



NOTE

- Robot coordinates display in pulse units for axes where an "incomplete return-to-origin" status exists. Robot coordinates also display in pulse units on SCARA robots where reference coordinates have not been specified.
- Robot coordinates display in mm/deg units for axes where a "completed return-to-origin" status

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

 $[cr/lf] \dots CR \ code \ (0Dh) + LF \ code \ (0Ah).$

SAMPLE

SEND LEX to CMU·········· Outputs the following general error message history details from the communication port.

Response:

	_						
1	.1:01/06/2	14,13:19:20	14.22: No	START	code (@),	0,TEST	,2,2500[cr/lf]
1	.2:M=	23.80	23.59	0.00	0.00	0.00	0.00[cr/lf]
1	.3:S=	48.20	47.99	0.00	0.00	0.00	0.00[cr/lf]
2	.1:01/06/	12,13:18:34	22.3: 24	VDC low	voltage,0	,TEST	,6,2500[cr/lf]
2	.2:M=	11568	23985	0.00	0.00	0.00	0.00[cr/lf]
2	.3:S=	35693	12582	0.00	0.00	0.00	0.00]cr/lf]
	:						
500.	1:01/06/1	2,21:49:00	22.3: 24V	DC low	voltage,0,	TEST	,6,2500[cr/lf]
500	.2:M=	38.71	38.50	0.00	0.00	0.00	0.00[cr/lf]
500	.3:S=	51.48	51.27	0.00	0.00	0.00	0.00[cr/lf]
[cr	·/1f1						

24.1 All machine reference file

Format

MRF

Meaning

- Expresses the machine reference data obtained after robots have performed return-toorigin and absolute search.
- Reads out all machine reference data when used as a readout file.
- Cannot be used as a write file.

DATA FORMAT

```
M1=nnn% M2=nnn% ··· nnn%[cr/lf]
S1=nnn% S2=nnn% ··· nnn%[cr/lf]
[cr/lf]
```

Values

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

SAMPLE

```
SEND MRF TO CMU \cdots\cdots Outputs all machine reference data from communication port.
```

Response:

```
M1= 55% M2= 23% M3= 33% M4= 26%[cr/lf] [cr/lf]
```

9

10

11

12

13

14

15

EOF data 25.1

Format

EOF



- Meaning This file is a special file consisting only of a ^Z (=1Ah) code. When transmitting data to an external device through the communication port, the EOF data can be used to add a ^Z code at the end of file.
 - When used as a readout file, Z (=1Ah) is read out.
 - Cannot be used as a write file.

DATA FORMAT

^Z (=1Ah)

SAMPLE

```
SEND PGM TO CMU
SEND EOF TO CMU·····Outputs
                                    E \circ F
                                          data
                                                 from
                         communication port.
```

```
NAME=TEST1[cr/lf]
A=1[cr/lf]
HALT[cr/lf]
[cr/lf]
^Z
```



• A "\Z" code may be required at the end of the transmitted file, depending on the specifications of the receiving device and application.

26.1 Serial port communication file

Format

CMU



- Expresses the serial communication port.
- Depends on the various data formats.

SAMPLE

SEND PNT TO CMU······Outputs all point data from communication port. SEND CMU TO PNT Inputs all point data from communication port.

27.1 **All SIW**

Format

SIW()



•SIW is available from software version 8.08 onwards.



- Meaning • Expresses all SIW (serial word input) data.
 - Reads out all SIW information in hexadecimal digit when used as a readout file.
 - Cannot be used as a write file.

```
DATA FORMAT
```

```
SIW(0)=&Hnnnn [cr/lf]
SIW(1)=&Hnnnn [cr/lf]
SIW(15) = & Hnnnn [cr/lf]
[cr/lf]
```

Values

n0 to 9, A to F: 4 digits (hexadecimal)

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

SAMPLE

SEND SIW() TO CMU······Outputs all SIW data from communication port.

Response:

SIW(0) = &H1001[cr/lf]

SIW(1) = &H0010[cr/lf]

SIW(2) = &H0000[cr/lf]

SIW(15) = &H0000[cr/lf][cr/lf]

One SIW data 27.2

Format

SIW(m)



•SIW is available from software version 8.08 onwards.



- Meaning Expresses one SIW status.
 - Reads out all SIW information in hexadecimal digit when used as a readout file.
 - Cannot be used as a write file.

DATA FORMAT

SIW(m)=&Hnnnn [cr/lf]



m0 to 15

n0 to 9, A to F: 4 digits (hexadecimal)

SAMPLE

SEND SIW(5) TO CMU ······Outputs SIW (5) communication port.

Response:

SIW(5) = &H1001[cr/lf]

7

10

11

12

13

14

15

28.1 All SIW

Format

SOW()



 SOW is available from software version 8.08 onwards.



- Expresses all SOW (serial word output) data.
- Reads out all SOW information in hexadecimal digit when used as a readout file.
- Cannot be used as a write file.

DATA FORMAT

```
SOW( 0) = & Hnnnn [cr/lf]
SOW( 1) = & Hnnnn [cr/lf]
:
SOW(15) = & Hnnnn [cr/lf]
[ cr/lf]
```

Values

n0 to 9, A to F: 4 digits (hexadecimal)

• A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

SAMPLE

```
SEND SOW() TO CMU \cdots\cdots Outputs all SOW data from communication port.
```

Response:

```
SOW(0) = &H1001[cr/lf]
```

SOW(1) = &H0010[cr/lf]

SOW(2) = &H0000[cr/lf]

SOW(15)=&H0000[cr/lf]

[cr/lf]

One SOW data 28.2

Format

SOW (m)



SOW is available from software version 8.08 onwards.



- Meaning Expresses one SOW status.
 - When used as a readout file, the specified SOW port status is read out.
 - When used as a write file, the value is written to the specified SOW. However, writing to SOW0() and SOW1() is prohibited.
- Readout file

DATA FORMAT

SOW(m) = & Hnnnn [cr/lf]

Write file

DATA FORMAT

&Hnnnn



m2 to 15

SAMPLE 1

SEND SOW(5) TO CMU ······Outputs S O W (5) from communication port.

Response:

SOW(5) = &H1001[cr/lf]

SAMPLE 2

SEND CMU TO SOW(5) ······ Input t o SOW (5) from communication port.

&H1001

Response:

OK[cr/lf]

29 Ethernet port communication file

29.1 Ethernet port communication file

Format

ETH



• ETH is available from software version 8.22 onwards.

- Meaning Expresses the Ethernet port.
 - Depends on the various data formats.

SAMPLE

SEND PNT TO ETH......Outputs all point data from the Ethernet port.

SEND ETH TO PNT $\cdots\cdots$ Inputs all point data from the Ethernet port.

Chapter 12 User program examples

1	Basic operation12-1
2	Application12-8

4


Basic operation

1.1 Directly writing point data in program

Overview

The robot arm can be moved by PTP (point-to-point) motion by directly specifying point data in the program.

Processing flow



33C01-R7-00

SAMPLE						
MOVE P,	300.00	300.00	50.00	90.00	0.00	0.00
MOVE P,	300.00	100.00	0.00	0.00	0.00	0.00
MOVE P,	200.00	200.00	10.00	-90.00	0.00	0.00
HALT						

8

9

10

11

12

13

4


1.2 Using point numbers

Overview

Coordinate data can be specified by using point numbers in a program. Coordinate data should be entered beforehand in "MANUAL>POINT" mode, for example as shown below.

POINT	DATA						
P0=	0.00	0.00	0.00	0.00	0.00	0.00	
P1=	100.00	0.00	150.00	30.00	0.00	0.00	
P2=	0.00	100.00	50.00	0.00	0.00	0.00	
P3=	300.00	300.00	0.00	0.00	0.00	0.00	
P4=	300.00	100.00	100.00	90.00	0.00	0.00	
P5=	200.00	200.00	0.00	0.00	0.00	0.00	

Processing flow



33C02-R7-00

```
MOVE P,P0
MOVE P,P1
MOVE P,P2
MOVE P,P3
MOVE P,P4
MOVE P,P5
HALT
```

```
FOR J=0 TO 5

MOVE P,P[J]

NEXT J

HALT
```


Although the same operation is executed by both SAMPLE 1 and SAMPLE 2, the program can be shortened by using point Nos. and the FOR statement.

Overview

In the example shown below, after PTP movement from P3 to P5, the coordinate system is shifted +140mm along the X-axis and -100mm along the Y-axis, and the robot then moves from P3 to P5 again. The shift coordinate data is set in S1 and P3, P4, P5 are set as described in the previous section ("1.2 Using point numbers").

SHIFT	DATA				
	0.00			0.00	
S1=	140.00 -	100.00	0.00	0.00	

Shift Coordinate



33C03-R7-00

SAMPLE
SHIFT SO Shift 0.
FOR J=3 TO 5 Repeated movement from P3 to P5.
MOVE P, P[J]
NEXT J
SHIFT S1 Changed to "shift 1".
FOR K=3 TO 5 Repeated movement occurs in
the same manner from P3 to P5.
MOVE P,P[K]
NEXT K

8

9

10

11

12

13

14

0

10

11

12

13

14

15

1.4.1 Calculating point coordinates


Overview

Repetitive movement between a fixed work supply position P0 and each of the equally spaced points on a pallet can be performed with the following program.

In the drawing below, points N1 to N20 are on Cartesian coordinates, consisting of 5 points positioned at a 50mm pitch in the X-axis direction and 4 points at a 25mm pitch in the Y-axis direction. The robot arm moves from point to point in the order of P0-N1-P0-N2...N5-P0-N6-P0... while repeatedly moving back and forth between point P0 and each pallet.


POINT DAT	CA					
Work supp	oly posit	ion:				
P0=	0.0	0.0	0.0	0.0	0.0	0.0
X-axis p	itch:					
P10=	50.0	0.0	0.0	0.0	0.0	0.0
Y-axis p	itch:					
P20=	0.0	25.0	0.0	0.0	0.0	0.0
N1 posit	ion:					
P1 =	100.0	50.0	0.0	0.0	0.0	0.0

Calculating point coordinates



33C04-R7-00

Processing flow



31C05-R7-00

SAMPLE P100=P1 P200=P1

FOR J=1 TO 4

NEXT K

NEXT J

FOR K=1 TO 5 MOVE P,P0 MOVE P,P100 P100=P100+P10

P200=P200+P20 P100=P200

2

13

4

15

Basic operation • 12-5


1.4.2 Utilizing pallet movement

Overview

Repetitive movement between a fixed work supply position P0 and each of the equally spaced points on a pallet can be performed with the following program. In the drawing below, points N1 to N24 are on Cartesian coordinates, consisting of 3 points positioned at a 50mm pitch in the X-axis direction, 4 points at a 50mm pitch in the Y-axis direction, and 2 points at 100mm pitch in the Z-axis direction. The robot arm moves from point to point in the order of P0-N1-P0-N2...-N5-P0-N6... while repeatedly moving back and forth between point P0 and each pallet.


POINT DA	TA					
Work sup	ply posi	tion:				
P0=	0.00	0.00	100.00	0.00	0.00	0.00
Pallet d	definition	ι:				
PLO ((P3996 to	P4000 a	re used)			
NX = 3						
NY= 4						
NZ = 2						
P3996=	100.00	50.00	100.00	0.00	0.00	0.00
P3997=	200.00	50.00	100.00	0.00	0.00	0.00
P3998=	100.00	200.00	100.00	0.00	0.00	0.00
P3999=	200.00	200.00	100.00	0.00	0.00	0.00
P4000=	100.00	50.00	200.00	0.00	0.00	0.00

Utilizing pallet movement



33C06-R7-00

Processing flow



33C07-R7-00

```
FOR I=1 TO 24 ······ Repeated for I = 1 to 24.

MOVE P,P0,Z=0.00 ····· Movement to supply position.

PMOVE (0,I),Z=0.00 ···· Movement to pallet point.

NEXT I


MOVE P,P0,Z=0.00
```

Overview

1.5

The following example shows general-purpose signal input and output operations through the STD.

Processing flow



33C08-R7-00

```
SAMPLE
WAIT DI2( )=0 ····· Wait until DI20 to DI27 become "0".
DELAY 1000
WAIT DI2(0)=1 ...... Wait until DI21 becomes "1".
N=1
*LOOP1:
IF DI2(1)=1 THEN *PROGEND ··· Jumps to *PROGEND if DI21 = 1.
IF N>20 THEN *ALLEND ...... Ended in N > 20 (jumps to *ALLEND).
DELAY 500
N=N+1
GOTO *LOOP1 ..... Loop is repeated.
' END ROUTINE
*PROGEND: .... End processing.
DO2(7,6,1,0)=&B1111..... Set DO27, 26, 21, 20 to "1".
DELAY 2000 ····· Wait 2 seconds
DO2()=0 ...... Set DO20 to "0".
*ALLEND:
HALT
```

Basic operation 12-7

9

10

11

2

13

14


2 Application

2.1 Pick and place between 2 points

Overview

The following is an example for picking up a part at point A and placing it at point B.

Pick and place between 2 points



33C09-R7-00

Precondition

- 1. Set the robot movement path.
 - Movement path: $P3 \rightarrow P1 \rightarrow P3 \rightarrow P4 \rightarrow P2 \rightarrow P4$
 - Locate P3 and P4 respectively at a position 50mm above P1 and P2 and set the P1 and P2 positions by teaching.

2. I/O signal

DO (20)	Chuck (gripper) open/close =	0: open, 1: close	

A 0.1 second wait time is set during chuck open and close.

```
SAMPLE: When calculating to find P3 and P4
   P3=P1 ......P1 coordinates are assigned to P3.
   P4=P2 ····· P2 coordinates are assigned to P4.
   LOCZ(P3) = LOCZ(P3) - 50.0 \cdots P3 is shifted 50mm in Z UP direction.
   LOCZ(P4)=LOCZ(P4)-50.0 ···· P4 is shifted 50mm in Z UP direction.
   MOVE P, P3
   GOSUB *OPEN
   MOVE P, P1
   GOSUB *CLOSE
   MOVE P, P3
   MOVE P, P4
   MOVE P, P2
   GOSUB *OPEN
   MOVE P, P4
   HALT
*OPEN:
             ..... Chuck OPEN routine.
   DO2(0) = 0
   DELAY 100
   RETURN
*CLOSE: ..... Chuck CLOSE routine.
   DO2(0)=1
   DELAY 100
   RETURN
```

RETURN

8

9

10

11

12

13


4

2.2 Palletizing

Overview

The following is an example for picking up parts supplied from the parts feeder and placing them on a pallet on the conveyor. The pallet is ejected when full.

Palletizing



33C10-R7-00

Precondition

1. I/O signal

DI (30)	Component detection sensor	1: Parts are supplied
DI (31)	Pallet sensor	1: Pallet is loaded

DO (30)	Robot hand open/close	0: Open / 1: Close
DO (31)	Pallet eject	1: Eject

Robot hand open/close time is 0.1 second and pallet eject time is 0.5 seconds.

2. The points below should be input beforehand as point data.

P0	Part supply position
P1	Pallet reference position
P10	X direction pitch
P11	Y direction pitch

3. Vertical movement is performed to a position Z=50mm above the pallet and parts feeder.

```
SAMPLE 1: When point is calculated
WHILE -1 ...... All repeated (-1 is always TRUE).
FOR A=0 TO 2
FOR B=0 TO 2
  WAIT DI(31)=1 ..... Wait until a pallet "present"
                        status occurs.
  WAIT DI(30)=1 ..... Wait until the supplied component
                        "present" status occurs.
  DO(30) = 0 \cdots Robot hand OPENS.
  DELAY 100
  MOVE P, P0, Z=50.0 ..... Movement to supply position.
  DO(30)=1····· Robot hand CLOSES.
  DELAY 100
  P100=P1+P10*B+P11*A····· Next point is calculated.
  MOVE P, P100, Z=50.0 ······ Movement to calculated point.
  DO(30) = 0 \cdots Robot hand OPENS.
  DELAY 100
NEXT
NEXT
DRIVE (3,0) .....Only Z-axis moves to 0.
DO(31)=1 ····· Pallet is ejected.
DELAY 500
DO(31) = 0
WEND
        ..... Loop is repeated.
HALT
```

SAMPLE 2: When using the palletizing function * Precondition: Must be defined at pallet "0". WHILE -1 All repeated. FOR A=1 TO 9 WAIT DI(31)=1 Wait until a pallet "present" status occurs. WAIT DI(30)=1 Wait until the supplied component "present" status occurs. $DO(30) = 0 \cdots Robot hand OPENS.$ DELAY 100 MOVE P, P0, Z=50.0 ······ Movement to supply position. DO(30)=1·····Robot hand CLOSES. DELAY 100 $PMOVE(0,A), Z=50.0 \cdots Movement to pallet point.$ $DO(30) = 0 \cdots Robot$ hand OPENS. DELAY 100 DRIVE(3,0)Only Z-axis moves to 0. DO(31)=1 Pallet is ejected. DELAY 500 DO(31) = 0WEND Loop is repeated. HALT

2.3 Pick and place of stacked parts


Overview

The following is an example for picking up parts stacked in a maximum of 6 layers and 3 blocks and placing them on the conveyor.

The number of parts per block may differ from others.

Parts are detected with a sensor installed on the robot hand.

Pick and place of stacked parts



33C11-R7-00

■ Precondition

1. I/O signal


DI (30)	Component detection sensor	1: Parts are supplied
DI (31)	Robot hand open/close	0: Open / 1: Close

- Robot hand open/close time is 0.1 seconds.
- 2. The points below should be input beforehand as point data.

P1	Bottom of block 1
P2	Bottom of block 2
P3	Bottom of block 3
P5	Position on conveyor

3. Movement proceeds at maximum speeds but slows down when in proximity to the part.

Processing flow



33C12-R7-00

4. Use a STOPON condition in the MOVE statement for sensor detection during movement.

11

12

13

14

```
SAMPLE
FOR A=1 TO 3
SPEED 100
GOSUB *OPEN
P6=P[A]
LOCZ(P6) = 0.00
MOVE P, P6, Z=0.0
WHILE -1
   SPEED 20
   MOVE P,P[A],STOPON DI3(0)=1
   IF DI3(0)=0 THEN *L1
   ' SENSOR ON
   P4=JTOXY (WHERE)
   GOSUB *CLOSE
   SPEED 100
   MOVE P, P5, Z=0.0
   GOSUB *OPEN
   MOVE P, P4, Z=0.0
WEND
*L1: 'SENSOR OFF
NEXT A
SPEED 100
DRIVE (3,0)
HALT
*OPEN:
DO3(0) = 0
DELAY 100
RETURN
*CLOSE:
DO3(0)=1
DELAY 100
RETURN
```

2.4 Parts inspection (Multi-tasking example)

Overview


One robot is used to inspect two different parts and sort them according to the OK/NG results.

The robot picks up the part at point A and moves it to the testing device at point B. The testing device checks the part and sends it to point C if OK or to point D if NG.

The part at point A' is picked up and moved to the testing device at point B' in the same way. The testing device checks the part and sends it to point C' if OK or to point D' if NG.

It is assumed that 10 to 15 seconds are required for the testing device to issue the OK/NG results.


Parts inspection (Multi-tasking example)



33C13-R7-00

NOTE

*1: As the start signal, supply a 0.1 second pulse signal to the testing device.




- *2: Chuck open and close time is 0.1 seconds.
- *3: Each time a test is finished, the test completion signal and OK/NG signal are sent from the testing device. After testing, the test completion signal turns ON (=1), and the OK/NGsignal turns ON (=1) when the result is OK and turns OFF (=0) when NG.

Precondition

I/O signal

I/O signal




33C14-R7-00

- 2. The main task (task 1) is used to test part 1 and the subtask (task 2) is used to test part 2.
- An exclusive control flag is used to allow other tasks to run while waiting for the test completion signal from the testing device.

FLAG1	0: Executing Task 1	(Task 2 execution enabled)
	1: Task 1 standby	(Task 2 execution disabled)
FLAG2	0: Executing Task 2	(Task 1 execution enabled)
	1: Task 2 standby	(Task 1 execution disabled)

Processing flow

4. Flow chart



Task 2 (subtask) runs in the same flow.

Application • 12-15


■ Program example

<main task=""> FLAG1=0</main>	
FLAG2=0	
IIDDOG 6 6	
UPPOS=0.0	
START *S1,T2 Subtask Start	
*L1: WAIT DI2(2)=1 Part supply standby *S1:	
WAIT DI2(2)=1 Part supply standby *S1: WAIT FLAG2=0 Other tasks waiting for standby status. WAIT DI3(2)=1	
FLAG1=1 Exclusive control flag set WAIT FLAG1=0	
GOSUB *OPEN Chuck open FLAG2=1	
MOVE P, P1, Z=UPPOS Move to part supply position GOSUB *OPEN	
GOSUB *CLOSE Chuck close MOVE P, P11, Z=UPPOS	
MOVE P,P2,Z=UPPOS Move to testing device GOSUB *CLOSE	
GOSUB *OPEN Chuck open MOVE P, P12, Z=UPPOS	
DRIVEI (3,-10000) Move Z-axis upward Z 10,000 pulses GOSUB *OPEN	
FLAG1=0 Exclusive control flag reset DRIVEI (3,-10000) DO2(0)=1 Testing device start FLAG2=0	
DELAY 100 DO3 (0) =1	
DO2 (0) = 0 DELAY 100	
WAIT DI2(0)=1 Test completion standby DO3(0)=0	
WAIT FLAG2=0 Task completion standby WAIT DI3(0)=1	
FLAG1=1 Exclusive control flag set WAIT FLAG1=0	
MOVE P, P2, Z=UPPOS Move to testing device FLAG2=1	
GOSUB *CLOSE Chuck close MOVE P, P12, Z=UPPOS	
<pre>IF DI2(1)=1 THEN Test GOSUB *CLOSE 'GOOD IF DI3(1)=1 THEN</pre>	
WAIT DI4(2)=0 Part movement standby 'GOOD	
MOVE P, P3, Z=UPPOS Move to OK parts position WAIT DI3(3)=0	
ELSE MOVE P, P13, Z=UPPOS	
'NG ELSE	
WAIT DI2(4)=0 Part movement standby 'NG	
MOVE P, P4, Z=UPPOS Move to NG parts position WAIT DI3(4)=0	
ENDIF MOVE P, P14, Z=UPPOS	
GOSUB *OPEN Chuck open ENDIF DRIVEI (3,-10000) Move Z-axis upward Z 10,000 pulses GOSUB *OPEN	
FLAG1=0 Exclusive control flag reset DRIVEI (3,-10000)	
GOTO *L1 FLAG2=0	
*OPEN: GOTO *S1	
DO2 (1) =0	
DELAY 100	
RETURN	
*CLOSE:	
DO2(1)=1 DELAY 100	
RETURN	

Overview

This section shows an example of the parts sealing operation.

Sealing



33C16-R7-00

Precondition

1. I/O signal

_				
Γ	DO (20)	Valve open/close	1: Open / 0: Close	

2. Set P0 to P7 by teaching.

SAMPLE	
MOVE P,P0,Z=0 SPEED 40	
PATH SETStart of path s	setting
PATH L, P1, DO(20) = 1@10.0 ···· Start of coating	
at 10 mm position	
PATH L,P2 PATH C,P3,P4 PATH L,P5 PATH L,P6,S=30	Path setting (Robot does not operate.)
PATH L, P7, DO(20) = 0@20.0 ···· End of coating at 20 mm position	
PATH END End of path set	ting
PATH START PATH Starts from P0 a	motion (Robot and stops at P7.)
HALT	

NOTE

(cr/lf) indicates CR code
(=0Dh) + LF code (=0Ah).

2.6 Connection to an external device through RS-232C (example 1)

Overview

Point data can be written in a program by using an external device connected to the RCX series controller via the RS-232C port.

Precondition

- 1. Input to the external device from the controller SDATA/X/Y [cr/lf]
- 2. Output to the controller from the external device

POINT	DATA						
P10=	156.42	243.91	0.00	0.00	0.00	0.00	[cr/lf]

```
SAMPLE
' INIT
   VCMD$="SDATA/X/Y"
   P0 = 0.00
                0.00
                        0.00
                                0.00
                                        0.00
                                                0.00
' MAIN ROUTINE
   MOVE P, P0
*ST:
   SEND VCMD$ TO CMU
   SEND CMU TO P10
   MOVE P, P10
GOTO *ST
```



- "SEND xxx TO CMU" outputs the contents specified by "xxx" through the RS-232C.
- "SEND CMU TO xxx" sends data into the files specified by "xxx" through the RS-232C.

2.7 Connection to an external device through RS-232C (example 2)

Overview

Point data can be created from the desired character strings and written in a program by using an external device connected to the RCX series controller via the RS-232C port.

Precondition

1. Input to the external device from the controller SDATA/X/Y [cr/lf]



• (cr/lf) indicates CR code (=0Dh) + LF code (=0Ah).

2. Output to the controller from the external device X=156.42, Y=243.91 [cr/lf]



- "SEND xxx TO CMU" outputs the contents specified by "xxx" through the RS-232C.
- "SEND CMU TO xxx" sends data into the files specified by "xxx" through the RS-232C.
- The LEN () function obtains the length of the character string.
- The MID\$ () function obtains the specified character string from among the character strings.
- The VAL () function obtains the value from the character string.

8

9

10

. .

12

13

14

```
SAMPLE
' INT
  VCMD$="SDATA/X/Y"
  VIN$=""
   VX$=""
   VY$=""
                        0.00 0.00
   P0=
         0.00
                 0.00
                                            0.00
                                                    0.00
   P11= 100.00 100.00
                          0.00
                                    0.00
                                            0.00
                                                    0.00
' MAIN ROUTINE
   MOVE P, P0
*ST:
   SEND VCMD$ TO CMU
   SEND CMU TO VIN$
   I=1
   VMAX=LEN(VIN$)
*LOOP:
   IF I>VMAX THEN GOTO *E LOOP
   C$=MID$(VIN$,I,1)
   IF C$="X" THEN
      I=I+2
      J=I
*X LOOP:
      C\$=MID\$(VIN\$, J, 1)
      IF C$="," THEN
*X1 LP:
        L=J-I
        VX$=MID$(VIN$, I, L)
        I=J+1
        GOTO *LOOP
     ENDIF
      J=J+1
     IF J>VMAX THEN GOTO *X1 LP
     GOTO *X_LOOP
   ENDIF
   IF C$="Y" THEN
      I=I+2
      J=I
*Y LOOP:
      C$=MID$(VIN$, J, 1)
      IF C$=","THEN
*Y1 LP:
        L=J-I
        VY$=MID$(VIN$, I, L)
        I=J+1
        GOTO *LOOP
     ENDIF
      J=J+1
      IF J>VMAX THEN GOTO *Y1 LP
     GOTO *Y_LOOP
   END IF
   I = I + 1
   GOTO *LOOP
*E LOOP:
   WX=VAL(VX$)
   WY=VAL (VY$)
   LOCX (P11) = WX
   LOCY(P11) = WY
   MOVE P, P11
GOTO *ST
```

Chapter 13 Online commands

1	Online Command List13-1
2	Key operation13-6
3	Utility operation13-12
4	Data handling13-24
5	Executing the robot language independently 13-44
6	Control codes 13-46

9

10

13

14

15

Online commands can be used to operate the controller via an RS-232C interface or via an Ethernet (option).

This chapter explains the online commands which can be used. For details regarding the RS-232C connection method, refer to the "RCX Controller User's Manual". For details regarding Ethernet, refer to the "RCX Series Ethernet Manual".

About termination codes

During data transmission, the controller adds the following codes to the end of a line of transmission data.

- RS-232C
 - CR (0Dh) and LF (0Ah) are added to the end of the line when the "Termination code" parameter of communication parameters is set to "CRLF".
 - CR (0Dh) is added to the end of the line when the "Termination code" parameter of communication parameters is set to "CR".
- Ethernet (option)
 - CR (0Dh) and LF (0Ah) are added to the end of the line.

When data is received, then the data up to CR (0Dh) is treated as one line regardless of the "Termination code" parameter setting, so LF (0Ah) is ignored.

The termination code is expressed as [cr/lf] in the detailed description of each online command in "12.2 Key operation" onwards.

1.1 Online command list: Function specific

Key operation

Ope	ration type		Command	Option	Condition
Change mode AUTO mode PROGRAM mod MANUAL mode		node	AUTO		3
		AM mode	PROGRAM		
		L mode	MANUAL		
	SYSTEM	/I mode	SYSTEM		
Program	Reset pr	rogram	RESET		4
	Execute	program	RUN		
	Execute	one line	STEP		
	Skip one	line	SKIP		
	Execute	to next line	NEXT		
	Stop pro	gram	STOP		2
Set break point		BREAK	m, n (m: break point No., n: line)	4	
Switch execution	n task		CHGTSK		3
Change manua	l speed	Main robot	MSPEED	k (k : 1-100)	3
		Sub robot	MSPEED2	k (k : 1-100)	
Move to absolute r	eset position	Main robot	ABSADJ	k, 0 or k, 1 (k : 1-6)	3
		Sub robot	ABSADJ2	k, 0 or k, 1 (k : 1-6)	
Absolute reset o	n each axis	Main robot	ABSRESET	k (k : 1-6)	
		Sub robot	ABSRESET2	k (k : 1-6)	
Return-to-origin		Main robot	ORGRTN	k (k : 1-6)	3
		Sub robot	ORGRTN2	k (k : 1-6)	
Manual movemer	nt (inching)	Main robot	INCH	k+ or k- (k : X, Y, Z, R, A, B)	3
		Sub robot	INCH2	k+ or k- (k : X, Y, Z, R, A, B)	
Manual movem	ent (jog)	Main robot	JOG	k+ or k- (k : X, Y, Z, R, A, B)	3
		Sub robot	JOG2	k+ or k- (k : X, Y, Z, R, A, B)	

Operation t	уре	Command	Option	Condition
Point data teaching	Main robot	TEACH	m (m : point No.)	3
	Sub robot	TEACH2	m (m : point No.)	

Utility

Operation type	Command	Option	Condition
Acquire program execution status	PADDR		4
Copy program 1 to program 2	COPY	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	3
Copy points "m - n" to point "k"		Pm-Pn TO Pk	
Copy point comments "m - n" to point comment "k"		PCm-PCn TO PCk	
Delete program	ERA	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	3
Delete points "m - n"		Pm-Pn	
Delete point comments "m - n"		PCm-PCn	
Delete pallet "m"		PLm	
Rename "program 1" to "program 2"	REN	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	3
Change program attribute	ATTR	<pre><pre><pre><pre><pre><pre>program> TO s (s : RW/RO)</pre></pre></pre></pre></pre></pre>	3
Initialize data Program	INIT	PGM	3
Point		PNT	
Shift		SFT	
Hand		HND	
Pallet		PLT	
Point comment		PCM	
All data except parameters		MEM	
Parameter		PRM	
All data (MEM+PRM)		ALL	
Initialize data Communication parameter	INIT	CMU	3
Initialize data Error log	INIT	LOG	3
Setting Display language	LANGUAGE	k	3
Setting Point units	UNIT	k	3
Clear line message	MSGCLR		1
Setting Access level	ACCESS	k	3
Setting Execution level	EXELVL	k	3
Sequence execution flag	SEQUENCE	k	3
Setting Main hand system	ARMTYP	m, k	3
Sub hand system	ARMTYP2	m, k	
Reset internal emergency stop flag	EMGRST		1
Check or set date	DATE		2
Check or set time	TIME		2

Conditions: 1. Always executable.

- 2. Not executable during inputs from the programming box.
- 3. Not executable during inputs from the programming box, and while the program is running.
- 4. Not executable during inputs from the programming box, while the program is running, and when specific restrictions apply.

Data handling

Operation type	Command	Option	Condition
Acquiring status Display language	?	LANGUAGE	1
Access level		ACCESS	
Arm status		ARM	
Break point status		BREAK	
Controller configuration		CONFIG	
Execution level		EXELVL	
Mode indication		MOD	
Error message		MSG [m, n]	
Return-to-origin status		ORIGIN	
Absolute reset status		ABSRST	
Servo status		SERVO	
Sequence execution flag status		SEQUENCE	
AUTO/MANUAL speed status		SPEED	
Point unit status		UNIT	
Version information		VER	
Current main robot position (pulse coordinate)		WHERE	
Current sub robot position (pulse coordinate)		WHERE2	
Current main robot position (XY coordinate)		WHRXY	
(including extended setting)		Will DC!	
Current sub robot position (XY coordinate) (including extended setting)		WHRXY2	
Task number		TASKS	
Task operation status		TSKMON	
Selected shift status		SHIFT	
Selected hand status		HAND	
Remaining memory capacity		MEM	
Emergency stop status		EMG	
Error status by self-diagnosis		SELFCHK	
Option slot status		OPSLOT	
Main group current torque value		CHKTRQ	
Sub group current torque value		CHKTRQ2	
Numerical data		Numerical expression	
Character string data		Character string expression	
Point data		Point expression	
Shift data		Shift expression	
Data readout	READ		2
Data write	WRITE		2
	. · · · · · · -	<u>l</u>	

Robot language independent execution

Operation type	Command	Option	Condition
Program switching	SWI	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	4
Robot language executable independently			4

Control code

Operation type	Command	Option	Condition
Execution language interruption	^C(=03H)		1

- Conditions: 1. Always executable.
 - 2. Not executable during inputs from the programming box.
 - 3. Not executable during inputs from the programming box, and while the program is
 - 4. Not executable during inputs from the programming box, while the program is running, and when specific restrictions apply.

1.2 Online command list: In alphabetic order

Command	Option	Meaning	Condition
?	ABSRST	Acquire absolute reset status	1
	ACCESS	Acquire access level	1
	ARM	Acquire arm status	1
	BREAK	Acquire break point status	1
	CHKTRQ	Acquire main group current torque value	1
	CHKTRQ2	Acquire sub group current torque value	1
	CONFIG	Acquire controller configuration	1
	EMG	Acquire emergency stop status	1
	EXELVL	Acquire execution level	1
	HAND	Acquire execution level Acquire selected hand status	1
	LANGUAGE	Acquire display language	1
	MEM		1
		Acquire remaining memory capacity	
	MOD	Acquire mode indication	1
	MSG [m, n]	Acquire error message	1
	OPSLOT	Acquire option slot status	1
	ORIGIN	Acquire return-to-origin status	1
	SELFCHK	Acquire error status by self-diagnosis	1
	SEQUENCE	Acquire sequence execution flag status	1
	SERVO	Acquire servo status	1
	SHIFT	Acquire selected shift status	1
	SPEED	Acquire AUTO/MANUAL speed status	1
	TASKS	Acquire task number	1
	TSKMON	Acquire task operation status	1
	UNIT	Acquire point position status	1
	VER	Acquire version	1
	WHERE	Acquire current main robot position (pulse coordinate)	1
	WHERE2	Acquire current sub robot position (pulse coordinate)	1
	WHRXY	Acquire current main robot position (XY coordinate)	1
	WHRXY2	Acquire current sub robot position (XY coordinate)	1
	Shift expression	Acquire shift data	1
	Point expression	Acquire point data	1
	Numeric expression	Acquire point data Acquire numeric data	<u>'</u>
AO / AOI I)	Character string expression	Acquire character string data	1
^C (=03H)		Execution language interruption	1
ABSADJ	k, 0 or k, 1 (k : 1-6)	Move to absolute reset position Main robot	3
ABSADJ2	k, 0 or k, 1 (k : 1-6)	Move to absolute reset position Sub robot	3
ABSRESET	k (k : 1-6)	Absolute reset on each axis Main robot	3
ABSRESET2	k (k : 1-6)	Absolute reset on each axis Sub robot	3
ACCESS	k	Set access level	3
ARMTYP	m, k	Set main hand system	3
ARMTYP2	m, k	Set sub hand system	3
ATTR	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	Change program attribute	3
AUTO		Change mode: AUTO mode	3
BREAK	m, n (m: break point No., n: line)	Set break point	4
CHGTSK		Switch execution task	3
COPY	<pre><pre><pre><pre><pre>program1> to <pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre>	Copy program 1 to program 2	3
	PCm-PCn TO PCk	Copy point comments "m - n" to point comments "k"	3
	Pm-Pn TO Pk	Copy points "m - n" to points "k"	3
DATE		Check or set the date	2
EMGRST		Reset internal emergency stop flag	1
ERA	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	Delete program	3
ERA	PCm-PCn	Delete program Delete point comments "m" to "n"	3
ı	PLm	Delete pallet "m"	3
ı			3
	Pm-Pn	Delete points "m" to "n"	3

Command	Option	Meaning	Condition
EXELVL	k	Execution level	3
INCH	k+ or k- (k : X, Y, Z, R, A, B)	Manual movement (inching) Main robot	3
INCH2	k+ or k- (k : X, Y, Z, R, A, B)	Manual movement (inching) Sub robot	3
INIT	ALL	Initialize all data (MEM+PRM)	3
	СМU	Initialize communication parameter	3
	HND	Initialize hand data	
	LOG	Initialize error history	
	MEM	Initialize all memory data except parameters	
	PCM	Initialize point comment data	
	PGM	Initialize program data	3
	PLT	Initialize pallet data	
	PNT	Initialize point data	3
	PRM	Initialize parameter data	3
	SFT	Initialize shift data	3
JOG	k+ or k- (k : X, Y, Z, R, A, B)	Manual movement (jog) Main robot	3
JOG2	k+ or k- (k : X, Y, Z, R, A, B)	Manual movement (jog) Sub robot	3
LANGUAGE	k	Set display language	3
MANUAL		Change mode: MANUAL mode	3
MSGCLR		Setting Clear line message	1
MSPEED	k (k : 1-100)	Change manual speed Main robot	3
MSPEED2	k (k : 1-100)	Change manual speed Sub robot	3
NEXT		Execute program to next line	4
ORGRTN	k (k : 1-6)	Return-to-origin Main robot	3
ORGRTN2	k (k : 1-6)	Return-to-origin Sub robot	3
PADDR		Acquire program execution status	4
PROGRAM		Change mode: PROGRAM mode	3
READ		Read data	2
REN	<pre><pre><pre><pre><pre>program 1> TO <pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre>	Change program name from "1" to "2"	3
RESET		Reset program	4
RUN		Execute program	4
SEQUENCE	k	Set sequence execution flag	3
SKIP		Program: Skip one line	4
STEP		Program: Execute one line	4
STOP		Stop program	2
SWI	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	Switch programs	4
SYSTEM		Change mode: SYSTEM mode	3
TEACH	m (m: point number)	Point data teaching Main robot	3
TEACH2	m (m: point number)	Point data teaching Sub robot	3
TIME		Check or set time	2
UNIT	k	Set point unit system	3
WRITE		Write data	2
-		Robot language executable independently	·

Conditions: 1. Always executable.

- 2. Not executable during inputs from the programming box.
- 3. Not executable during inputs from the programming box, and while the program is running.
- 4. Not executable during inputs from the programming box, while the program is running, and when specific restrictions apply.

2.1 Changing the mode

Command format

- @AUTO[cr/lf]
- @PROGRAM[cr/lf]
- @MANUAL[cr/lf]
- @SYSTEM[cr/lf]

Response format

OK[cr/lf]

NOTE

- Basically, a response "OK" appears when an instruction from key operation online command is received.
- •An error message responds if online commands cannot be executed due to error.

Meaning Changes the mode.

AUTOChanges to AUTO mode. PROGRAMChanges to PROGRAM mode. MANUALChanges to MANUAL mode. SYSTEMChanges to SYSTEM mode.

SAMPLE

Command: @AUTO[cr/lf] OK[cr/lf] Response:

2.2 AUTO mode operation

1. Program execution

Command format

@RESET[cr/lf]

@RUN[cr/lf]

@STEP[cr/lf]

@SKIP[cr/lf]

@NEXT[cr/lf]

@STOP[cr/lf]

Response format

OK[cr/lf]



 Programs can be executed only in AUTO mode.



Executes or stops the current program.

RESET.....Resets the program.

RUNExecutes the program.

STEP.....Executes one line of the program. (Enters the

subroutine.)

SKIPSkips one line of program. (Skips one line of the

subroutine.)

NEXT Executes to the next line. (Executes the subroutine as

one line.)

STOPStops the program.

SAMPLE

Command: @RUN[cr/lf]
Response: OK[cr/lf]

8

9

10

11

19

13

14



• Programs can be

mode.

executed only in AUTO

2. Setting a break point

Command format

@BREAK m,n[cr/lf]

Response format

OK[cr/lf]



Programs can be

executed only in AUTO

mode.

mBreak point number: 1 to 4

nLine number to set a break point: 1 to 9999

Meaning

Sets a break point used to temporarily stop execution of the program.

When setting a break point in the COMMON program, the line number should be ± 10000 .

Break point is cleared when 0 is specified as the line number.

SAMPLE

Command: @BREAK 1,28[cr/lf]

Response: OK[cr/lf]

3. Switching the execution task

Command format

@CHGTSK[cr/lf]

Response format

OK[cr/lf]

Meaning

Switches the selected task while program execution is stopped.

The ongoing task is switched to another task not being executed in order from task 1 \rightarrow 2 \rightarrow ... \rightarrow 8 \rightarrow 1.

SAMPLE

Command: @CHGTSK[cr/lf]

8

1. Changing the MANUAL mode speed

Command format

@MSPEED k[cr/lf]
@MSPEED2 k[cr/lf]

Response format

OK[cr/lf]



•The MANUAL mode speed can be changed only in MANUAL mode.



kManual movement speed: 1 to 100

Meaning

MSPEED: Changes manual movement speed for main robot. MSPEED2: Changes manual movement speed for sub robot.

Changes the MANUAL mode movement speed.

SAMPLE

Command: @MSPEED 50[cr/lf]

Response: OK[cr/lf]

2. Absolute reset

Command format

@ABSADJ k,f[cr/lf]
@ABSADJ2 k,f[cr/lf]
@ABSRESET k[cr/lf]

k[cr/lf]

Response format

@ABSRESET2

OK[cr/lf]



NOTE

 The MANUAL mode speed can be changed only in MANUAL mode.



k Designated axis: 1 to 6

fMovement direction / 0: + direction, 1: - direction

Meaning Performs absolute reset.

ABSADJ.......Moves the main robot axis to an absolute reset position.

ABSADJ2......Moves the sub robot axis to an absolute reset position.

ABSRESET.....Performs absolute reset on the main robot axis.

ABSRESET2....Performs absolute reset on the sub robot axis.

SAMPLE

Command: @ABSADJ 1,0[cr/lf]

Response: OK[cr/lf]

Ø MEMO

• ABSADJ and ABSADJ2 can be used at mark format axes.

Key operation

13-9

9

10

11

12

13

14



NOTE

 An axis can be specified from software version 8.45 onwards.

Command format

@ORGRTN k[cr/lf]
@ORGRTN2 k[cr/lf]

3. Return-to-origin operation

Response format

OK[cr/lf]

NOTE

 The MANUAL mode speed can be changed only in MANUAL mode.



kSpecified axis: 1 to 6

Meaning

Performs return-to-origin on the specified axis.

Performs return-to-origin on an incremental mode axis when return-to-origin is executed.

Performs absolute search on a semi-absolute mode axis when return-to-origin is executed.

ORGRTNPerforms return-to-origin on the specified main robot axis.

ORGRTN2Performs return-to-origin on the specified sub robot axis.

NOTE

 Response is transmitted after movement is complete.

SAMPLE

Command: @ORGRTN 1[cr/lf]

Response: OK[cr/lf]

4. Manual movement: inching

Command format

@INCH km[cr/lf] @INCH2 km[cr/lf]

Response format

OK[cr/lf]



NOTE

 The MANUAL mode speed can be changed only in MANUAL mode. Values

kSpecified axis: X, Y, Z, R, A, B mMovement direction / +, -

Meaning

Manually moves (inching motion) the specified axis. The robot performs the same motion as when moved manually in inching mode with the programming box jog keys (moves a fixed distance each time a jog key is pressed).

SAMPLE

Command: @INCH X+[cr/lf]

5. Manual movement: jog

Command format

@JOG km[cr/lf]
@JOG2 km[cr/lf]

Response format

OK[cr/lf]



NOTE

 Response is transmitted after movement is complete.



kSpecified axis: X, Y, Z, R, A, B mMovement direction / +, -

Meaning

Manually moves (jog motion) the specified axis. The robot performs the same motion as when holding down the programming box jog keys in manual mode.

After the robot has started moving, it will stop when any of the following occurs.

- When software limit was reached.
- When interlock signal was turned off.
- When STOP key on the programming box was pressed.
- \bullet When an online command (^C (=03H)) to interrupt execution was input.

JOGMoves the specified main robot axis in jog mode.

JOG2Moves the specified sub robot axis in jog mode.

SAMPLE

Command: @JOG X+[cr/lf]
Response: OK[cr/lf]

6. Point data teaching



NOTE

- At controllers with software version 8.28 or earlier, point numbers 0 to 4000 can be specified by point variables.
- The MANUAL mode speed can be changed only in MANUAL mode.

Command format

@TEACH mmmm[cr/lf]
@TEACH2 mmmm[cr/lf]

Response format

OK[cr/lf]

Values

mmmmPoint number for registering point data: 0 to 9999

(Meaning)

Registers the current robot position as point data for the specified point number. If point data is already registered in the specified point number, then that point data will be overwritten. Point data is registered in the same format as the currently selected unit system.

TEACH......Registers the current position of the main group as point data for the specified point number.

TEACH2......Registers the current position of the sub group as point data for the specified point number.

SAMPLE

Command: @TEACH 100[cr/lf]

3 Utility operation

3.1 Acquiring the program execution status

Command format

@PADDR[cr/lf]

Response format

cprogram name> Tn, m, k[cr/lf]



 The current program execution status can be acquired only when the program is stopped during AUTO mode. Values

mCurrent program line number: 1 to 9999 kCurrent task priority level:17 to 47

Meaning Acquires the current program execution status.

MEMO)

• If the COMMON program is used, the response format might become as follows. <COMMON>/<program name>, Tn,m,k[cr/lf]

SAMPLE

Command: @PADDR[cr/lf]

Response: <TEST>,T3,134,32[cr/lf]

3.2 Copy

Copying a program

Command format

COPY copy am name 1> TO copy am name 2> [cr/lf]

Response format

@COPY cprogram name 1> TO cprogram name 2> [cr/lf]

<program name 2>Program name in copy destination (8 characters or less consisting of alphanumeric characters and underscore)

Meaning Copies the contents of program name 1 under program name 2.

SAMPLE

Command: @COPY <TEST1> TO <TEST2>[cr/lf]

NOTE

• In controllers whose software version is earlier than 8.28, point numbers from 0 to 4000 can be specified as the point variables.



OK[cr/lf]



mmmmTop point number in copy source: 0 to 9999	
nnnnLast point number in copy source: 0 to 9999	
kkkkTop point number in copy destination: 0 to 999	9

Meaning Copies the point data between Pmmmm and Pnnnn to Pkkkk.

SAMPLE

Command: @COPY P101-P200 TO P1101[cr/lf]

Response: OK[cr/lf]

3. Copying point comments

Command format

@COPY PCmmmm-PCnnnn TO PCkkkk[cr/lf]



NOTE

• In controllers whose software version is earlier than 8.28, point numbers from 0 to 4000 can be specified as the point variables.

Response format

OK[cr/lf]



mmmm	Top point comment number in copy source: 0 to 9999
nnnn	Last point comment number in copy source: 0 to 9999
kkkk	Top point comment number in copy destination: 0 to
	9999

Meaning Copies the point comments between PCmmmm and PCnnnn to PCkkkk.

SAMPLE

Command: @COPY PC101-PC200 TO PC1101[cr/lf]

Response: OK[cr/lf]

8

9

10

11

12

13

14

Erase

9

9

10

11

12

13

14

15



NOTE

•In controllers whose software version is earlier than 8.28, point numbers from 0 to 4000 can be specified as the point variables.

1. Erasing a program

Command format

@ERA cr/lf]

Response format

OK[cr/lf]

Values

<program name>Program name to be erased (8 characters or less consisting of alphanumeric characters and underscore)

Meaning Erases the designated program.

SAMPLE

Command: @ERA <TEST1>[cr/lf]

Response: OK[cr/lf]

2. Erasing point data

Command format

@ERA Pmmmm-Pnnnn[cr/lf]

Response format

OK[cr/lf]

Values

mmmmTop point number to be erased: 0 to 9999 nnnnLast point number to be erased: 0 to 9999

Meaning Erases the point data between Pmmmm and Pnnnn.

SAMPLE

Command: @ERA P101-P200[cr/lf]

NOTE

• In controllers whose software version is earlier than 8.28, point numbers from 0 to 4000 can be specified as the point variables.

Response format

OK[cr/lf]

Values

Meaning Erases the point comments between PCmmmm and PCnnnn.

SAMPLE

Command: @ERA PC101-PC200[cr/lf]

Response: OK[cr/lf]

4. Erasing pallet data

Command format

@ERA PLm[cr/lf]

Response format

OK[cr/lf]

Values

mPallet number to be erased: 0 to 19

Meaning Erases the PLm pallet data.

SAMPLE

Command: @ERA PL1[cr/lf]

Response: OK[cr/lf]

9

0

11

19

13

14

3.4 Rename program name

Command format

@REN cprogram name 1> TO cprogram name 2> [cr/lf]

Response format

OK[cr/lf]

Meaning Changes the name of the specified program.

SAMPLE

Command: @REN <TEST1> TO <TEST2>[cr/lf]

Response: OK[cr/lf]

3.5 Changing the program attribute

Command format

@ATTR cprogram name> TO s[cr/lf]

Response format

OK[cr/lf]

Meaning Changes the attribute of the designated program.

SAMPLE

Command: @ATTR <TEST1> TO RO[cr/lf]

Response: OK[cr/lf]

3.6 Initialize

1. Initializing the memory

Command format

@INIT <memory area>[cr/lf]

Response format

OK[cr/lf]

Values

<memory area>One of the following memory areas is specified.

PRM......Initializes the parameter area.

ALLInitializes all areas (MEM+PRM).

Meaning Initializes the memory.

SAMPLE

Command: @INIT PGM[cr/lf]

Response: OK[cr/lf]

2. Initializing the communication port

Command format

@INIT CMU[cr/lf]

Response format

OK[cr/lf]

(Meaning)

Initializes the communication port parameters.

For information about the communication port initial settings, refer to the Controller user's manual.

SAMPLE

Command: @INIT CMU[cr/lf]

Response: OK[cr/lf]

8

9

0

11

12

13

14

3. Initializing the error log

Command format

@ INIT LOG[cr/lf]

Response format

OK[cr/lf]

Meaning Initializes the error log.

SAMPLE

Command: @INIT LOG[cr/lf]

Response: OK[cr/lf]

3.7 Setting the display language

Command format

@LANGUAGE k[cr/lf]

Response format

OK[cr/lf]

Meaning Sets the controller display language.

SAMPLE

Command: @ LANGUAGE 1[cr/lf]

Response: OK[cr/lf]

3.8 Setting the coordinates and units in MANUAL mode

Command format

@UNIT k[cr/lf]

Response format

OK[cr/lf]

Values

kUnit definition

0: pulses

1: mm or degrees

2 : mm or degrees in tool coordinate mode

NOTE

 k=2 (mm or degree units in tool coordinate mode) is available from software version 8.19 onwards. Meaning Select the display unit to indicate current position.

k=2 (tool coordinate mode) can be selected only when the hand attached to the R-axis of a Cartesian or SCARA robot is selected.

SAMPLE

Command: @UNIT 1[cr/lf]

Response: OK[cr/lf]

3.9 Clearing the programming box error message

Command format

@MSGCLR[cr/lf]

Response format

OK[cr/lf]

Meaning Clears the error messages displayed on the programming box.

SAMPLE

Command: @MSGCLR[cr/lf]

Response: OK[cr/lf]

8

9

10

П

2

13

14



 For details regarding the execution level, refer to the Controller user's manual.

• For details regarding the access level, refer to the

Controller user's manual.

3.10 Setting the UTILITY mode

1. Setting the access level

Command format

@ACCESS k[cr/lf]

Response format

OK[cr/lf]

Values kAccess level: 0 to 3

Meaning Sets the access level.

SAMPLE

Command: @ ACCESS 1[cr/lf]

Response: OK[cr/lf]

2. Setting the execution level

Command format

@EXELVL k[cr/lf]

Response format

OK[cr/lf]

Values kExecution level: 0 to 8

Meaning Sets the execution level.

SAMPLE

Command: @ EXELVL 1[cr/lf]

Response: OK[cr/lf]

Command format

@SEQUENCE k[cr/lf]

Response format

OK[cr/lf]

Values k Execution flag / 0: disable, 1: enable, 3: enable (DO reset)

Meaning Sets the sequence program execution flag.

SAMPLE

@ SEQUENCE 1[cr/lf] Command:

Response: OK[cr/lf]

4. Setting the SCARA robot hand system

Command format

@ARMTYP m, k[cr/lf] @ARMTYP2 m, k[cr/lf]

Response format

OK[cr/lf]

Values mCurrent hand system / 0: right-handed system, 1: left-handed system kHand system at program reset / 0: right-handed system, 1: left-handed system

Meaning Sets the SCARA robot hand system.

> ARMTYPChanges the main robot hand system. ARMTYP2Changes the sub robot hand system.

SAMPLE

Command: @ ARMTYP 0, 0 [cr/lf]

OK[cr/lf] Response:

5. Resetting the internal emergency stop flag

Command format

@EMGRST[cr/lf]

Response format

OK[cr/lf]

Meaning Resets the internal emergency stop flag.

SAMPLE

@ EMGRST[cr/lf] Command:

Response: OK[cr/lf]

3.11 Checking and setting the date

NOTE

• The date can be checked and set on the following software versions.

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

NOTE

omitted. Example:

To change only the year or month, the slash (/) following it can be

To set the year to 2007, enter 07(cr/lf).

enter /06(cr/lf).

To set the month to June,

Command format

@DATE[cr/lf]

Response format

current date: yy/mm/dd[cr/lf]
enter new date: (YY/MM/DD)[cr/lf]

Values

yy/mm/dd	Current date (year, month, day)
уу	Lower 2 digits of the year (00 to 99)
mm	Month (01 to 12)
dd	Day (01 to 31)

Meaning Acquires the current date in the controller and sets a new date.

Command format

aa/bb/cc[cr/lf]

Response format

OK[cr/lf] or "error message" [cr/lf]

Values

aa/bb/cc	Date to be set. (year/month/day)
aa	Lower 2 digits of the year (00 to 99) *This can be
	omitted.
bb	Month (01 to 12) *This can be omitted.
CC	Day (01 to 31) *This can be omitted.

- **MEMO**
- The currently set values are used for the omitted items.
- If only [cr/lf] is transmitted, then the date remains unchanged.
- If an improbable date is entered, then "5.2: Data error" occurs.

SAMPLE 1

To change only the day, //15[cr/lf] Day is set to 15th.

SAMPLE 2

Command: @DATE[cr/lf]

Response: current date: 07/05/10[cr/lf]

enter new date: (YY/MM/DD)[cr/lf]

Transmission: 07/05/11[cr/lf]

Response: OK[cr/lf]

3.12 Checking and setting the time



NOTE

 The time can be checked and set on the following software versions.

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

Command format

@TIME[cr/lf]

Response format

current time: hh:mm:ss[cr/lf]
enter new time: (HH:MM:SS)[cr/lf]

Values

 hh:mm:ss
 Current time

 hh
 hour (00 to 23)

 mm
 minute (00 to 59)

 ss
 second (00 to 59)

Meaning Acquires the current time in the controller and sets a new time.

Command format

aa:bb:cc[cr/lf]

Response format

OK[cr/lf] or "error message" [cr/lf]

Values



- The currently set values are used for the omitted items.
- If only [cr/lf] is transmitted, then the time remains unchanged.
- If an improbable time is entered, then "5.2: Data error" occurs.

SAMPLE 1

To change only the minute, :20:[cr/lf] Minute is set to 20 minutes.

SAMPLE 2

Command: @TIME[cr/lf]

Response: current time: 10:21:35[cr/lf]

enter new time:(HH/MM/SS)[cr/lf]

Transmission: 10:25:00[cr/lf]

Response: OK[cr/lf]

9

10

11

12

13

14

4 Data handling

4.1 Acquiring the display language

Command format

@?LANGUAGE[cr/lf]

Response format

m[cr/lf]

Values

m Display language / JAPANESE or ENGLISH

Meaning Acquires the language for displaying messages.

SAMPLE

Command @?LANGUAGE[cr/lf]
Response JAPANESE[cr/lf]

4.2 Acquiring the access level

Command format

@?ACCESS[cr/lf]

Response format

LEVELk[cr/lf]

Values

kAccess level: 0 to 3



 For a detailed description of the access level, refer to the Controller user's manual.

SAMPLE

Command @?ACCESS[cr/lf] Response LEVEL2[cr/lf]

Meaning Acquires the access level.

4.3 Acquiring the arm status

Command format

@?ARM[cr/lf]

Response format

m1/s1,m2/s2[cr/lf]

Values

Main robo	_ 1
wain ron	11

m1	Current arm setting status / RIGHTY: right-handed
	system, LEFTY: left-handed system
m2	Arm setting status at program reset / RIGHTY: right-
	handed system, LEFTY: left-handed system
Sub robot	
s1	Current arm setting status / RIGHTY: right-handed
	system, LEFTY: left-handed system
s2	Arm setting status at program reset / RIGHTY: right-

handed system, LEFTY: left-handed system

Meaning Acquires the arm setting status.



- Valid only on SCARA robots.
- "s1" and "s2" are not displayed when sub robot is not set.

SAMPLE

Command @?ARM[cr/lf]
Response RIGHTY,RIGHTY[cr/lf]

4.4 Acquiring the break point status

Command format

@?BREAK[cr/lf]

Response format

k1, k2, k3, k4 [cr/lf]

Values

knLine number on which break point "n" is set: 1 to 9999

(Meaning)

Acquires the break point status.

When kn is 0, this means no break point is set.

When a break point is set in the COMMON program, the line number shows +10000.

SAMPLE

Command @?BREAK[cr/lf]
Response 12,35,0,0[cr/lf]

8

9

10

11

12

13

14

4.5 Acquiring the controller configuration status

Command format

@?CONFIG[cr/lf]

Response format

mr/sr-ma/sa-r-o1-o2[cr/lf]

Values

mr	.Main robot name
sr	.Sub robot name
ma	.Main group axis setting (Auxiliary axes are shown
	separated by "+".)
sa	.Sub group axis setting (Auxiliary axes are shown
	separated by "+".)
r	.Standard interface unit
o1	.Option unit
o2	.Other setting

Meaning Acquires the controller configuration status.



• "sr" and "sa" are not displayed when sub robot is not set.

SAMPLE

Command @?CONFIG[cr/lf]
Response YK250X-XYZR-SRAM/196kB,DIO_N-DIO_N(1/2)[cr/lf]

4.6 Acquiring the execution level

Command format

@?EXELVL[cr/lf]

Response format

LEVELk[cr/lf]



kExecution level: 0 to 8



 For a detailed description of the execution level, refer to the Controller user's manual.

Meaning Acquires the execution level.

SAMPLE

Command @?EXELVL[cr/lf] Response LEVEL2[cr/lf]

4.7 Acquiring the mode status

Command format

@?MOD[cr/lf]

Response format

s[cr/lf]

Values

s.....Mode status

s		Mooning	
English	Japanese	Meaning	
AUTO	ジドウ	AUTO mode	
PROGRAM	プログラム	PROGRAM mode	
MANUAL	シュドウ	MANUAL mode	
SYSTEM	システム	SYSTEM mode	

Meaning Acquires the controller mode status.

SAMPLE

Command @?MOD[cr/lf]
Response AUTO[cr/lf]

8

9

10

11

12

13

14

Acquiring the message 4.8

Command format 1

@?MSG[c/r]

Response format 1

gg,bb: msg[c/r] or OK[c/r]

Command format 2

@?MSG m,n[cr/lf]

Response format 2

```
yy/mm/dd, hh:mm:ss gg.bb:msg[cr/lf]
yy/mm/dd, hh:mm:ss gg.bb:msg[cr/lf]
OK[cr/lf]
```

Values

gg	.Error group
bb	.Error category
msg	.Error message
m	.Top number to be acquired: 1 to 500
n	Last number to be acquired: 1 to 500
yy/mm/dd	.Date (year/month/day) when error occurred
hh:mm:ss	.Time (hour:minute:second) when error occurred

Meaning Command format 1 acquires information on the message line displayed on the programming box.

Command format 2 acquires error history message.

SAMPLE 1

```
Command @?MSG[cr/lf]
```

Response 5.30: Undefined identifier[cr/lf] or OK[cr/lf]

SAMPLE 2

```
Command @?MSG 1,5[cr/lf]
Response 01/10/28,14:20:20 5.30: Undefined identifier[cr/lf]
01/10/28,14:18:34 5.1: Syntax error[cr/lf]
01/10/28,14:10:54 5.30: Undefined identifier[cr/lf]
01/10/28,14:05:40 14.22: No start code(@)[cr/lf]
01/10/28,14:05:00 5.52: Command doesn't exist[cr/lf]
OK[cr/lf]
```

Command format

@?ORIGIN[cr/lf]

Response format

COMPLETE[cr/lf] or INCOMPLETE[cr/lf]

Meaning

Acquires return-to-origin status.

Response formatCOMPLETE: Return-to-origin is complete.

INCOMPLETE: Return-to-origin is incomplete.

SAMPLE

Command @?ORIGIN[cr/lf]
Response COMPLETE[cr/lf]

4.10 Acquiring the absolute reset status

Command format

@?ABSRST[cr/lf]

Response format

COMPLETE[cr/lf] or INCOMPLETE, xxxxxxxx[cr/lf]

Values

- 0: Incomplete
- 1: Complete
- 9: Not applicable

Meaning

Acquires the absolute reset status.

Response formatCOMPLETE: Return-to-origin is complete.

INCOMPLETE: Return-to-origin is incomplete.

SAMPLE

Command @?ABSRST[cr/lf]

Response INCOMPLETE, 99991011 [cr/lf]

8

9

10

11

12

13

14

4.11 Acquiring the servo status

Command format

@?SERVO[cr/lf]

Response format

OFF, xxxxxxxx [cr/lf] or ON, xxxxxxxx [cr/lf]

Values

- 0: Mechanical break ON + dynamic break ON
- 1: Servo ON
- 2: Mechanical break OFF + dynamic break OFF
- 9: Not applicable

Meaning

Acquires the servo status.

Response outputs are defined as follows:

ONMotor power is ON.

OFF.....Motor power is OFF.

SAMPLE

Command @?SERVO[cr/lf]
Response ON,99991011[cr/lf]

4.12 Acquiring the sequence program execution status

Command format

@?SEQUENCE[cr/lf]

Response format

- 1. ENABLE, s[cr/lf]
- ENABLE (RST.DO), s[cr/lf]
- 3. DISABLE[cr/lf]

Values

s......The sequence program's execution status is indicated as "RUNNING" or "STOP".

RUNNINGProgram execution is in progress.

STOPProgram execution is stopped.

Meaning

Acquires the sequence program execution status.

Response output means as follows:

ENABLE Enabled

ENABLE(RST.DO) Enabled and output is cleared at emergency stop

DISABLE Disabled

SAMPLE

Command @? SEQUENCE[cr/lf]
Response DISABLE[cr/lf]

@?SPEED[cr/lf]

Response format

ma/sa,mm/sm[cr/lf]

Values

Main group

maAutomatic movement speed setting status: 1 to 100 mmManual movement speed setting status: 1 to 100

sa......Automatic movement speed setting status: 1 to 100 sm.......Manual movement speed setting status: 1 to 100

Meaning Acquires the speed setting status.



• "sa" and "sm" are not displayed unless the sub robot is set.

SAMPLE

Command @?SPEED[cr/lf] Response 100,50[cr/lf]

Acquiring the point coordinates and units 4.14

Command format

@?UNIT[cr/lf]

Response format

s[cr/lf]

Values

s: Coordinates and unitsPULSE: joint coordinate in "pulse" units

MM: Cartesian coordinate in "mm" or "deg." units

Meaning Acquires the coordinates and units for point data.

SAMPLE

Command @?UNIT[cr/lf]

Response PULSE[cr/lf]

4.15 Acquiring the version information

Command format

@?VER[cr/lf]

Response format

 $cv, cr-mv-d1/d2/d3/d4/d5/d6/d7/d8{-ov}[cr/lf]$

ovOption unit version number (Vx.xx)

Values

Meaning Acquires the version information.

SAMPLE

Command @?VER[cr/lf]

Response V8.02,R1021-V5.10-V1.01/V1.01/V1.01/V1.01/----/-cr/lf]

4.16 Acquiring the current positions

1. Acquiring the current positions on pulse unit coordinates

Command format

@?WHERE[cr/lf]

@?WHERE2[cr/lf]

Response format

[POS]xxxxxx yyyyyy zzzzzz rrrrrr aaaaaa bbbbbb[cr/lf]

Values

Meaning Acquires the current positions.

WHERE: Acquires the current positions of main group axes.

WHERE2: Acquires the current positions of sub group axes.

• WHERE2 cannot be used unless the sub robot is set.

SAMPLE

Command @?WHERE[cr/lf]

Response [POS] 1000 2000 3000 -40000 0 0[cr/lf]

2. Acquiring the current positions on XY coordinates

Command format

@?WHRXY[cr/lf]
@?WHRXY2[cr/lf]

Response format

[POS]xxxxxx yyyyyy zzzzzz rrrrrr aaaaaa bbbbbb[cr/lf]

Values

bbbbbb Current position of axis 6 in "mm" or "deg" units

Meaning

Acquires the current positions.

WHRXY: Acquires the current positions of main group axes. WHRXY2: Acquires the current positions of sub group axes.



• WHRXY2 cannot be used unless the sub robot is set.

SAMPLE

Command @?WHRXY[cr/lf]
Response [POS] 100.00 200.00 300.00 -40.00 0.00 0.00[cr/lf]

3.XY coordinate system current position (including extended setting) acquisition



NOTE

 The "XY coordinate system current position (including extended setting) acquisition" function is only available in software version 10.66 onwards.

Command format

@?WHRXYEX[cr/lf]
@?WHRXYEX2[cr/lf]

Response format

[POS]xxxxxx yyyyyy zzzzzz rrrrrr aaaaaa bbbbbb n xr yr[cr/lf]

Values

- *1: The hand system flag is "0" on all robots other than the SCARA robot.
- *2: The arm rotation information is "0" on all robots other than the YK500TW robot.
- *3: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.

Meaning

The acquired current position data includes additional dedicated YK500TW information.

WHRXYEX: Acquires the current position of a main group axis.

WHRXYEX2: Acquires the current position of a sub group axis.

• WHRXYEX2 cannot be used unless the sub robot is set.



• The "XY coordinate system current position (including extended setting) acquisition" function is only available in software version 10.66 onwards.

MEMO

SAMPLE

Command @?WHRXYEX

Response [POS] 13.44 206.06 0.00 83.24 0.00 0.00 1 0 -1[cr/lf]

4.17 Acquiring the tasks in RUN or SUSPEND status

Command format

@?TASKS[cr/lf]

Response format

 $n{,n{,{...}}} [cr/lf]$

Values

n: Task number1 to 8 (Task currently run or suspended)

Meaning Acquires the tasks in RUN or SUSPEND status.

SAMPLE

Command @?TASKS[cr/lf] Response 1,3,4,6[cr/lf] @?TSKMON[cr/lf]

Response format

nfp, {nfp}, {nfp}, {nfp}, {nfp}, {nfp}, {nfp}, {nfp}, {nfp} [cr/lf]

Values

S: STOP

Meaning Acquires the status of each task in order from Task 1 to Task 8.

SAMPLE

Command @?TSKMON[cr/lf]
Response 11R32,,43U32,,,129R31,[cr/lf]

4.19 Acquiring the shift status

Command format

@?SHIFT[cr/lf]

Response format

m/s[cr/lf]



mShift number selected for main robot: 0 to 9 sShift number selected for sub robot: 0 to 9

Meaning Acquires the shift status.



• "s" is not displayed unless the sub robot is set.

SAMPLE

Command @?SHIFT[cr/lf]
Response 1[cr/lf]

8

9

10

11

2

13

14

4.20	Acquiring	the hand	status
			U.U.

Command format

@?HAND[cr/lf]

Response format

m/s[cr/lf]



mHand number selected for main robot: 0 to 3 sHand number selected for sub robot: 4 to 7

Meaning Acquires the hand status.



• "s" is not displayed unless the sub robot is set.

SAMPLE

Command @?HAND[cr/lf]
Response 1[cr/lf]

4.21 Acquiring the remaining memory capacity

Command format

@?MEM[cr/lf]

Response format

k/m[cr/lf]



Meaning Acquires the remaining memory capacity.

SAMPLE

Command @?MEM[cr/lf] Response 102543/1342[cr/lf] Command format

@?EMG[cr/lf]

Response format

k[cr/lf]

Values

kEmergency stop status / 0: normal operation, 1: emergency stop

Meaning Acquires the emergency stop status by checking the internal emergency stop flag.

SAMPLE

Command @?EMG[cr/lf]
Response 1[cr/lf]

4.23 Acquiring the error status by self-diagnosis

Command format

@?SELFCHK[cr/lf]

· When no error was found

Response format

OK[cr/lf]

• If an error occurred

Response format

```
m.n: "message" [cr/lf]
:
END [cr/lf]
```

Values

mError group
nError category
"message"Show error message.

Meaning Acquires the error status by self-diagnosis that checks for errors inside the controller.

SAMPLE

Command @?SELFCHK[cr/lf]
Response 12.1: Emg.stop on[cr/lf]
 END[cr/lf]

8

9

10

11

12

13

14

9

10

11

12

13

14

15

4.24 Acquiring the option slot status

Command format

@?OPSLOT[cr/lf]

Response format

```
OP.1 : <option board name> [cr/lf]
OP.2 : <option board name> [cr/lf]
OP.3 : <option board name> [cr/lf]
OP.4 : <option board name> [cr/lf]
```

Values

```
      <option board name>
      Name of option board installed in the controller.

      DIO_Nm
      DIO board with NPN specifications (m: board ID)

      DIO_Pm
      DIO board with PNP specifications (m: board ID)

      CCLnk
      CC-Link compatible board

      D_Net
      DeviceNet compatible board

      Profi
      Profibus compatible board

      E_Net
      Ethernet compatible board

      no board
      No option board is installed.

      illegal board
      Incompatible board is installed.
```

Meaning

Acquires the option slot status by checking the option boards.

SAMPLE

```
Command: @?OPSLOT[cr/lf]
```

Response: OP.1: DIO_N2[cr/lf]
OP.2: DIO_N1[cr/lf]
OP.3: no board[cr/lf]
OP.4: CCLnk [cr/lf]

4.25

Acquiring various values

1. Acquiring the value of a numerical expression

-

NOTE

 Numerical expression values can be acquired on the following software versions.

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

Command format

@? "numerical expression" [cr/lf]

Response format

"numerical value" [cr/lf]

Meaning Acquires the value of the specified numerical expression.

The numerical expression's value format is "decimal" or "real number".

SAMPLE 1

Command: @?SQR(100*5)[cr/lf]
Response: 2.23606E01[c/lf]

SAMPLE 2

Command: @?LOCX(WHERE)[cr/lf]

Response: 102054[cr/lf]

2. Acquiring the value of a character string expression



OTE

 Numerical expression values can be acquired on the following software versions.

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

Command format

@? "character string expression" [cr/lf]

Response format

"character string " [cr/lf]

Meaning Acquires the value (character string) of the specified character string expression.

SAMPLE

If A\$="ABC" and B\$="DEF"

Command: @?A\$+B\$+"123"[cr/lf] Response: ABCDEF123[cr/lf] 8

9

10

11

12

13

14

NOTE

versions.

 Numerical expression values can be acquired on the following software

RCX14x Ver. 8.64 onwards

RCX22x Ver. 9.11 onwards

 Numerical expression values can be acquired on the following software

RCX14x Ver. 8.64 onwards

RCX22x Ver. 9.11 onwards

versions.

3. Acquiring the value of a point expression

Command format

@? "point data expression" [cr/lf]

Response format

"point data" [cr/lf]

Meaning Acquires the value (point data) of the specified point expression.

SAMPLE

Command: @?P1+WHRXY[cr/lf]

Response: 10.41 -1.60 52.15 3.00 0.00 0.00 0[cr/lf]

4. Acquiring the value of a shift expression

Command format

@? "shift expression" [cr/lf]

Response format

"shift data" [cr/lf]

Meaning Acquires the value (shift data) of the specified shift expression.

SAMPLE

Command: @?s1[cr/lf]

Response: 25.00 12.60 10.00 0.00[cr/lf]

Response format

Response output depends on the designated readout file.



NOTE

 For more information about files, refer to the earlier Chapter 11 "Data file description".



NOTE

 The point comment separate format (PCn) is available on the following software versions.

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

Values

<readout file> Designate a readout file name.

Meaning

Reads out the data from the designated file.

Online commands that are input through the RS-232C port have the same meaning as the following command.

• SEND <readout file> TO CMU

Commands via Ethernet have the same meaning as the following command.

• SEND <readout file> TO ETH

Tuno	Readout file name	Definition format		
Туре	Readout file name	All	Separate file	
User memory	All files	ALL		
	Program	PGM	<pre><bdbbbbbbb></bdbbbbbbb></pre>	
	Point data	PNT	Pn	
	Point comment	PCM	PCn	
	Parameter	PRM	/ccccc/	
	Shift definition	SFT	Sn	
	Hand definition	HND	Hn	
	Pallet definition	PLT	PLn	
Variable, constant	Variable	VAR	abby	
	Array variable	ARY	abby(x)	
	Constant		"ccc"	
Status	Status Program directory Parameter directory		< <bbbbbbbb>></bbbbbbbb>	
	Machine reference	MRF		
	Error history (log) Memory size			
Device	DI port	DI()	Dln()	
	DO port	DO()	DOn()	
	MO port		MOn()	
	TO port		TOn()	
LO port		LO()	LOn()	
SI port		SI()	SIn()	
SO port		SO()	SOn()	
	SIW port	SIW()	SIWn()	
	SOW port		SOWn()	
Others	File end code	EOF		

a: Alphabetic character n: Number

b: Alphanumeric character or underscore (_) x: Expression (Array argument)

c: Alphanumeric character or symbol y: variable type

SAMPLE

Command: @READ PGM[cr/lf]

@READ P100[cr/lf]

Data handling 13-41

9

10

11

19

13

4

4.27

Data write processing

Command format

@WRITE <write file> [cr/lf]

Response format



• For more information about files, refer to the earlier Chapter 11 "Data file description".

Values

<write file> Designate a write file name.

Meaning

Writes the data in the designated file.

Online commands that are input through the RS-232C port have the same meaning as the following command.

• SEND CMU TO <write file>

Commands via Ethernet have the same meaning as the following command.

• SEND ETH TO <write file>



- At the DO, MO, TO, LO, SO, SOW ports, an entire port (DO(), MO(), etc.) cannot be designated as a WRITE file.
- Some separate files (DOn(), MOn(), etc.) cannot be designated as a WRITE file. For details, see Chapter 11 "Data File Details".

- N

NOTE

 The point comment separate format (PCn) is available on the following software versions

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

T. ma	Muito filo momo	Definition format	
Туре	Write file name	All	Separate file
User memory	All files	ALL	
	Program	PGM	<bbbbbbbb></bbbbbbbb>
	Point data	PNT	Pn
	Point comment	PCM	PCn
	Parameter	PRM	/ccccc/
	Shift definition	SFT	Sn
	Hand definition	HND	Hn
	Pallet definition		PLn
Variable, constant	Variable	VAR	abby
	Array variable	ARY	abby(x)
Device	DO port		DOn()
MO port			MOn()
	TO port		TOn()
	LO port		LOn()
	SO port		SOn()
	SOW port		SOWn()

- a: Alphabetic character n: Number
- b: Alphanumeric character or underscore (_) x: Expression (Array argument)
- c: Alphanumeric character or symbol y: variable type

SAMPLE 1

Command: @WRITE PRM[cr/lf]

@WRITE P100[cr/lf]

4.28 Current torque value acquisition

Command format

@?CHKTRQ k[cr/lf]
@?CHKTRQ2 k[cr/lf]

Values

 $k \dots Axis setting (k = 1 to 6).$

Response format

n[cr/lf]

Values

* The plus/minus sign indicates the direction.



NOTE

 The "@?CHKTRQ" and "@?CHKTRQ2" commands are available from the following software versions:

RCX240 Ver. 10.65 onwards, RCX22x Ver. 9.36 onwards

• If the specified axis has been set to "no axis" in the system generation, or if that axis uses the YC-Link or a power gripper, a "5.37: Specification mismatch" error message displays and command execution is stopped.

Meaning

• Acquires the current torque value of the specified axis.

CHKTRQ: Acquires the current torque value of a main group axis.

CHKTRQ2: Acquires the current torque value of a sub group axis.

SAMPLE

Command:

Response:

13

14

5 Executing the robot language independently

5.1 Switching the program

Command format

@SWI program name > [cr/lf]

Response format

OK[cr/lf] or LINEx, m, n: "message"

Values

Meaning

Switches the program.

- In AUTO mode, the program that is switched to will be compiled.
- In other modes, the program is only switched.

However, when "SEQUENCE" program is designated, a sequence object is created.

SAMPLE 1

```
In AUTO mode:
Command @SWI <TEST1>[cr/lf]
Response Line2,5.39:Illegal identifier[cr/lf]
```

SAMPLE 2

In other modes:
Command @SWI <TEST1>[cr/lf]
Response OK[cr/lf]

@"robot language"[cr/lf]

Response format

Command format

OK[cr/lf] or ***Aborted

Values OK......Command ended correctly.

***Aborted.....An error occurred.

Meaning Robot language commands can be executed.

- Independently executable commands can only be executed.
- Command format depends on each command to be executed.

SAMPLE 1

Command @SET DO(20) [cr/lf]
Response OK[cr/lf]

SAMPLE 2

Command @MOVE P,P100,S=20[cr/lf]
Response OK[cr/lf]

8

9

10

П

12

13

4

6

6.1

Interrupting the command execution

^C (=03H)

Command format

Response format

***Aborted

Meaning Interrupts execution of the current command.

SAMPLE

Command:

@MOVE P,P100,S=20[cr/lf]

Response: ***Aborted[cr/lf]

Chapter 14 IO commands

1	Overview14-1
2	IO command format14-1
3	Sending and receiving IO commands 14-3
4	IO command list14-5
5	IO command description14-6

Overview

Using bit information (DI/DO port) for general-purpose input/output allows issuing commands directly from the PLC. It is now possible to execute commands such as the MOVE command that were impossible to execute up until now without using the robot program or RS-232C port.



- In order to use the IO command, the "STD.DIO IO command (DI05)" (located in the SYSTEM mode's "Other parameters") must be enabled in advance.
 - RCX14x"IO cmd (DI05) on STD.DIO" of other parameters
 - RCX22x"IO cmd (DI05)" of option board parameters

For more details, refer to the Controller user's manual.

General-purpose outputs DO26 and DO27 (dedicated outputs DO16 and DO17 for RCX22x)
are used when executing an IO command. Pay attention to this point when you are using them
for other purposes.

IO command format



2

• IO commands are available from software version 8.18 onwards.

When using the IO command, the following functions are assigned to each IO.

■ Output: Controller → PLC

	Output port	Contents
RCX 14x/40	DO26	Execution check output
	DO27	Execution in-progress output
RCX 22x	DO16	Execution check output
	DO17	Execution in-progress output

Input: PLC ightarrow Controller

Input port	Contents	
DI05	IO command execution trigger input	
DI2 ()	Command code	
DI3 ()	0	
DI4 ()	Command data	

- IO commands can be executed by using part of the general-purpose input and output. When no connection is made to the option DIO, then DI4() is always recognized as being OFF.
- IO commands cannot be executed while program execution is in progress (DO13 is ON).
- IO commands cannot be executed simultaneously with online commands.
- IO commands assign command codes to be executed to DI2(), and command data to DI3() and DI4(). These are executed when the DI05 is changed from OFF to ON. The controller processes the IO commands when they are received and sends execution check results and execution inprogress information to the PLC via DO26 and DO27 (DO16 and DO17 for RCX22x).
- Command data added to the IO commands will differ according to the IO command.
 For details, refer to Chapter 14 "5 IO command description".
- Data is set in binary code. If the data size is greater than 8 bits, set the upper bit data into the higher address. (little endian)
 - For example, to set 0x0F9F [hexadecimal] (=3999) in the DI3 () and DI4 () ports, set 0x0F [hexadecimal] in DI4 () and set 0x9F [hexadecimal] in DI3 ().
- The IO command execution trigger input is not accepted when the execution in-progress output is ON.

O

9

10

1 1

19

13

14

8

9

10

11

12

13


14

- The execution in-progress output is ON in the following cases.
 - When an IO command is running after receiving an IO command execution trigger input.
 - When an IO command is terminated after receiving an IO command execution trigger input yet a maximum of 100ms state is maintained when IO command trigger input is ON.
- The IO command trigger input pulse must always be maintained for 100ms or more during input. Commands cannot be accepted unless this statement is maintained.
- Sometimes 20ms or more is needed for the execution in-progress output to turn ON after startup (rising edge) of the IO command trigger input pulse. The IO command trigger input might not be accepted during this period.
- After inputting the IO command trigger input pulse and the in-progress output turns OFF, at least a 100ms time period must always elapse before executing the next command. If this elapsed time period is too small, the IO command execution trigger input might not be accepted.
- The execution check output turns OFF when an IO command is received.
- The execution check output turns ON when an IO command ends normally, but it remains OFF if the IO command ends abnormally.

Sending and receiving IO commands

Sending and receiving is performed in the IO register as shown below.

Sending and receiving IO commands



^{*} For the RCX22x, the output ports are as follows: D027 D017, D026 D016.

33E01-R7-00

- (1) Set command code and command data (Time interval between (1) and (2): 30ms or more)
- (2) Set IO command execution trigger input (Pulse width: 100ms or more)
- (3) Transition to execute
- (4) Clear the IO command execution trigger input and command code and command data
- (5) Set termination of IO command and execution check output



• Output port for the execution check output is as follows: RCX14x: DO26

RCX22x: DO16

• Output port for the execution in-progress output is as follows: RCX14x: DO27

RCX22x: DO17

Example: Follow these steps when sending and receiving IO commands to execute the PTP movement command to point 19.

- (1) Set the following values in the register to execute the PTP movement command by designating a point.
 - DI2(): Command code (0x01)
 - DI3(): Lower point setting (0x13= point 19)
 - DI4(): Upper point setting (0x00=point 19)
- (2) Set DI05 from ON to OFF.
- (3) The controller receives the IO command and executes it if the command and command data are acceptable. The execution in-progress output turns ON and the execution check output turns OFF at this time. The robot moves to the position specified by point 19.
- (4) Clear DI2() through DI4() after checking that execution in-progress output is ON.
- (5) When the command ends, the output being executed turns OFF, and if execution ended normally, the execution judgment output turns ON. If execution ended in error, the execution judgment output remains OFF.




• If DI05 was not set to OFF in (4), the execution in-progress output remains ON for a maximum of 100ms from the timing in (5).

NOTE

 When a SCARA robot is used and a hand system flag is set for the point data you specify, that hand system has priority over the current arm type.

Sending and receiving IO commands (2)



^{*} For the RCX22x, the output ports are as follows: D027 \rightarrow D017, D026 \rightarrow D016.

33E02-R7-00

NOTE

• In the MOVE command, linear interpolation (0x83) for sub robot is only available on the following software versions.

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

•On controllers whose software version is earlier than 8.45, the returnto-origin command is executed on all axes (main robot + sub robot) and command code 0x32 can only be use.

IO commands are expressed with hexadecimal codes.

No.	Command conte	unto.	Command of	code (DI2())
INO.	Command Conte	ints	Main robot	Sub robot
1	MOVE command	PTP designation	0x01	0x81
		Linear interpolation	0x03	0x83
2	MOVEI command	PTP designation	0x09	0x89
3	Pallet movement command	PTP designation at pallet 0	0x18	0x98
4	Jog movement command		0x20	0xA0
5	Inching movement command		0x24	0xA4
6	Point teaching command		0x28	0x A 8
7	Absolute reset movement command		0x30	0xB0
8	Absolute reset command		0x31	0xB1
9	Return-to-origin command		0x32	0xB2
10	Servo command	On	0x34	0xB4
		Off	0x35	0xB5
		Free	0x36	0xB6
		Power-on	0x37	
11	Manual movement speed change command		0x38	0xB8
12	Auto movement speed change command		0x39	0xB9
13	Program speed change command		0x3A	0xBA
14	Shift designation change command		0x3B	0xBB
15	Hand designation change command		0x3C	0xBC
16	Arm designation change command		0x3D	0xBD
17	Point display unit designation command		0x3E	

Remarks

- *3 The pallet movement command is only valid for pallet 0.
- The movement methods for the JOG, INCHING, and POINT TEACHING commands differ according to the point units that were specified.
- The point teaching command uses different point units according to the point units that were *6 specified.
- If no axis is specified, the absolute reset command is executed on all axes (main robot + sub robot) in either case of command code 0x31 or 0xB1.
- The return-to-origin command applies to both main and sub robots in systems where 2 robots have been specified.
- *17 The point display unit designation command is for use on the controller.

IO command description

5.1 MOVE command

Moves the robot by the absolute position method

1. PTP designation

This command moves the robot to a target position in PTP motion by specifying the point number.

Command

DI port		Value	
DI2 ()	Command code For main robot		0x01
	For sub robot		0x81
DI3 ()	Point number		0хрррр
DI4 ()			

Values

MEMO

CAUTION

When performing linear

interpolation with a hand

system flag specified, be sure that the same hand system is used at the current position and

target position. If the same hand system is not used, an error will occur

and robot movement will

 When performing a linear interpolation, the current

position's X-arm and Y-arm rotation information must be the same as the movement destination's X-arm and Y-arm rotation information. If the two are different, an error will occur and movement will

be disabled.

be disabled.

• In controllers whose software version is earlier than 8.28, point numbers from 0 to 4000 can be specified.

.....

- The point number setting range is 0 to 255 when there is no DI4().
- When a SCARA robot is used and a hand system flag is set for the point data you specify, that hand system has priority over the current arm type.

2. Linear interpolation

This command moves the robot to a target position by linear interpolation by specifying the point number.

Command

DI port		Value	
DI2 ()	Command code For main robot		0x03
		For sub robot	
DI3 ()	Point number	0хрррр	
DI4 ()			

Values

-

NOTE

 In the MOVE command, linear interpolation (0x83) for sub robot is only available on the following software versions.

RCX14x Ver. 8.64 onwards RCX22x Ver. 9.11 onwards

 X-arm and Y-arm rotation information is only available in software Ver.10.66 onwards.

- In controllers whose software version is earlier than 8.28, point numbers from 0 to 4000 can be specified.
- The point number setting range is 0 to 255 when there is no DI4().
- When a SCARA robot is used and a hand system flag is set for the point data you specify, that hand system has priority over the current arm type.

MEMO

MOVEI command

Moves the robot by the relative position method

1. PTP designation

This command moves the robot a specified distance in PTP motion by specifying the point number.

Command

DI port		Contents		
DI2 ()	Command code	Command code For main robot		
	For sub robot		0x89	
DI3 ()	Point number	Point number		
DI4 ()				

Values

pppppSpecify the point number in 16 bits.

Specified range: 0 (=0x0000) to 9999 (=0x270F)





 This parameter is only available in the following software versions:

RCX14x Ver. 8.63 onwards RCX22x Ver. 9.08 onwards

 In versions prior to those shown above, a "RESET" must be performed at the controller. • When MOVEI motion to the original target position is interrupted and then restarted, the target position for the resumed movement can be selected as the "MOVEI/DRIVEI start position" in the controller's "other parameters". For details, refer to the controller user's manual.

.....

1) KEEP (default setting)Continues the previous (before interruption) movement. The original target position remains unchanged.

2) RESETRelative movement begins anew from the current position. The new target position is different from the original one (before interruption). (Backward compatibility)

- In controllers whose software version is earlier than 8.28, point numbers from 0 to 4000 can be specified.
- The point number setting range is 0 to 255 when there is no DI4().
- When a SCARA robot is used and a hand system flag is set for the point data you specify, that hand system has priority over the current arm type.

5.3 Pallet movement command

Moves the robot to a position relative to pallet 0

1.PTP designation

This command moves the robot to a target position in PTP motion by specifying the work position number.

(Command)

DI port		Value	
DI2 ()	Command code For main robot		0x18
	For sub robot		0x98
DI3 ()	Work position number	0xwwww	
DI4 ()			

Values

wwww......Specify the work position number in 16 bits.

Specified range: 1 (=0x0001) to 32767 (=0x7FFF)



• The work position number setting range is 0 to 255 when there is no DI4().

IO command description

14-7

9

10

11

19

13

14

14

5.4 Jog movement command

Performs robot JOG movement in the MANUAL mode.

This command is only valid in MANUAL mode.

This command is linked with the controller point display units. The robot axis moves in PTP motion when display units are in pulses, and moves by linear interpolation on Cartesian coordinates when units are in millimeters.

Jog speed is determined by the manual movement speed.

To stop the jog movement command, set the dedicated input interlock signal to OFF. After checking that jog movement has stopped, set the interlock signal back to ON.

Command

DI port	С	Contents		
DI2 ()	Command code	Command code		0x20
			For sub robot	0xA0
DI3 ()	Axis to move and direction	bit 0	Axis 1	tt
	bit	bit 1	Axis 2	
		bit 2	Axis 3	
		bit 3	Axis 4	
		bit 4	Axis 5	
		bit 5	Axis 6	
		bit 6	(0:Fixed)	0
		bit 7	Direction	d
DI4 ()	Not used			0x00

Values

- tt: Axis setting......Bits 0 to 3 select 1 axis
- d: Movement direction.......Bit 1 / 0: plus direction; 1: minus direction

5.5 Inching movement command

Performs robot INCHING movement in the MANUAL mode.

Inching movement distance is linked to the manual movement speed. The inching command can only be executed in MANUAL mode.

This command is linked with the controller's point display unit system. So when display units are in pulses, the axis moves a certain number of pulses at the manual speed setting. When display units are in millimeters, the axis moves on Cartesian coordinates by linear interpolation at the manual speed setting divided by 100.

(Command)

DI port	C	Contents		
DI2 ()	Command code	Command code		0x24
				0xA4
DI3 ()	Axis to move and direction	bit 0	Axis 1	tt
		bit 1	Axis 2	
		bit 2	Axis 3	
		bit 3	Axis 4	
		bit 4	Axis 5	
			Axis 6	
		bit 6	(0:Fixed)	0
		bit 7	Direction	d
DI4 ()	Not used			0x00

Values

- tt: Axis setting......Bits 0 to 3 select 1 axis
- d: Movement direction.......... Bit 1 / 0: plus direction; 1: minus direction

Teaches the robot's current position to a specified point No.

Point data units of this command are linked to the controller's point display unit system.

(Command)

DI port		Value	
DI2 ()	Command code For main robot		0x28
	For sub robot		0xA8
DI3 ()	Point number		0хрррр
DI4 ()	1		

pppp: Point numberSpecify in 16 bits. Specified range 0 (=0x0000) to 9999(=0x270F)



- In controllers whose software version is earlier than 8.28, point numbers from 0 to 4000 can be
- The point number setting range is 0 to 255 when there is no DI4().

5.7 Absolute reset movement command

Moves the nearest position where an absolute reset is possible

When absolute reset of the specified axis uses the mark method, this command moves the axis to the nearest position where absolute reset can be executed.

Positions capable of absolute reset are located at every 1/4 rotation of the motor.

Command

DI port	Contents			Value
DI2 ()	Command code		For main robot	0x30
			For sub robot	0xB0
DI3 ()	Axis to move and direction	bit 0	Axis 1	tt
		bit 1	Axis 2	
		bit 2	Axis 3	
		bit	bit 3	Axis 4
		bit 4	Axis 5	
		bit 5	Axis 6	
		bit 6	(0:Fixed)	0
			Direction	d
DI4 ()	Not used			0x00

Values

tt: Axis setting......Bits 0 to 3 select 1 axis

d: Movement direction..........Bit 1 / 0: plus direction; 1: minus direction

-

NOTE

 This parameter is only available in the following software versions:

RCX14x Ver. 8.63 onwards RCX22x Ver. 9.08 onwards

- In versions prior to those shown above, a "RESET" must be performed at the controller.
- An axis can be specified with the return-to-origin command from software version 8.45 onwards.
 On earlier version controllers, return-to-origin is performed on all axes and command code 0x32 can only be used.

5.8 Absolute reset command

Executes absolute reset of the specified axis.

If no axis is specified, the absolute reset command is executed on all axes (main robot + sub robot) in either case of command code 0x31 or 0xB1.

However, this command cannot be executed if return-to-origin is not yet complete on the axis using the mark method. In this case, perform absolute reset individually on each axis.

Command

DI port		Contents		
DI2 ()	Command code		For main robot	0x31
				0xB1
DI3 ()	Axis specification	Axis specification bit 0		tt
		bit 1	Axis 2	
		bit 2	Axis 3	
		bit 3	Axis 4	
		bit 4	Axis 5	
		bit 5	Axis 6	
		bit 7 - bit 6	(0:Fixed)	0
DI4 ()	Not used		<u>-</u>	0x00

Values

tt: Axis specification......Bits 0 to 3 select 1 axis (if not specified, the command applies to all the main group and sub group axes).

5.9 Return-to-origin command

Executes an incremental axis return-to-origin

When this command is executed on an incremental mode axis, that axis returns to its origin. When executed on a semi-absolute mode axis, an absolute search is performed on that axis.

If no axis is specified (DI3() is 0), this command is executed on all axes (main robot + sub robot) in either case of 0x32 or 0xB2.

Command

DI port		Contents		Value
DI2 ()	Command code		For main robot	0x32
			For sub robot	0xB2
DI3 ()	DI3 () Axis specification bit		Axis 1	tt
	bit 1 bit 2 bit 3	bit 1	Axis 2	
		bit 2	Axis 3	
		bit 3	Axis 4	
		bit 4	Axis 5	
		bit 5	Axis 6	
		bit 7 - bit 6	(0:Fixed)	0
DI4 ()	Not used	<u> </u>	<u> </u>	0x00

Values

tt: Axis specificationBits 0 to 3 select 1 axis (if not specified, the command applies to all the main group and sub group axes).

Operates the robot servo

These commands operate the robot servos, and switch the servos between their ON, OFF, and FREE settings in an axis-specific manner.

Operation	Contents
Servo ON	Execute this command to turn on the servo of a specified axis. The motor power must be turned on when specifying the axis. All controller servos are turned on if no axis is specified.
Servo OFF	Execute this command to turn off the servo of a specified axis. All controller servos are turned off if no axis is specified.
Servo Free	Execute this command to turn off the mechanical brake and dynamic brake after turning off the servo of a specified axis. Servo OFF and Free are repeated when this command is consecutively executed. All controller servos will be free if no axis is specified.
Power ON	Execute this command to turn on the motor power. No axis can be specified.

Command

DI port		Contents		Value
DI2 ()	Command code	Servo ON	For main robot	0x34
			For sub robot	0xB4
		Servo OFF	For main robot	0x35
			For sub robot	0xB5
		Servo Free	For main robot	0x36
			For sub robot	0xB6
		Power ON	All controller servos	0x37
DI3 ()	Axis specification	bit 0	Axis 1	tt
		bit 1	Axis 2	
		bit 2	Axis 3	
		bit 3	Axis 4	
		bit 4	Axis 5	
		bit 5	Axis 6	
		bit 7 - bit 6	(0:Fixed)	0
DI4 ()	Not used	•		0x00

Values

tt: Axis specification......Bits 0 to 3 select 1 axis (if not specified, the command applies to all controller processing).

No axis can be specified when executing Power ON.

5.11 Manual movement speed change command

Changes the MANUAL mode's manual movement speed

This command can only be executed in MANUAL mode.

Command

DI port	Contents		Value
DI2 ()	Command code For main robot		0x38
	For sub robot		0xB8
DI3 ()	Specified speed	0xss	
DI4 ()	Not used		0x00

Values

ss: Manual movement speed .. Specify in 8 bits.

Specified range1 (=0x01) to 100 (=0x64)

5.12 Auto movement speed change command

Changes the AUTO mode's automatic movement speed

This command can only be executed in AUTO mode.

Command

DI port	Contents		Value
DI2 ()	Command code For main robot		0x39
	For sub robot		0xB9
DI3 ()	Specified speed	0xss	
DI4 ()	Not used		0x00

Values

ss: Auto movement speed......Specify in 8 bits.

Specified range 1 (=0x01) to 100 (=0x64)

5.13 Program speed change command

Changes the AUTO mode's program movement speed

The program speed changed with this command is reset to 100% when the program is reset or changed.

Command

DI port		Contents	
DI2 ()	Command code	Command code For main robot	
		For sub robot	0xBA
DI3 ()	Specified speed	Specified speed	
DI4 ()	Not used	Not used	

Values

ss: Program speedSpecify in 8 bits.

Specified range1 (=0x01) to 100 (=0x64)

5.14 Shift designation change command

Changes a selected shift to the specified shift No.

Command

DI port	Contents		Value
DI2 ()	Command code For main robot		0x3B
	For sub robot		0xBB
DI3 ()	Specified shift number	0xss	
DI4 ()	Not used		0x00

Values

ss: Shift number.....Specify in 8 bits.

Specified range 0 (=0x00) to 9 (=0x09)

5.15 Hand designation change command

Changes a selected hand to the specified hand No.

Command

DI port		Contents	
DI2 ()	Command code	Command code For main robot	
-		For sub robot	0xBC
DI3 ()	Specified hand numb	Specified hand number	
DI4 ()	Not used	Not used	



ss: Hand number.....Specify in 8 bits.

Specified range For main robot: 0 (=0x00) to 3 (=0x03)

For sub robot: 4 (=0x04) to 7 (=0x07)

5.16 Arm designation change command

Changes the arm setting status

Command

DI port	Contents		Value
DI2 ()	Command code For main robot		0x3D
		For sub robot	0xBD
DI3 ()	Status of specified arm	0xss	
DI4 ()	Not used		0x00

Values

ss: Arm designation statusSpecify in 8 bits / 0x00: Right-handed system, 0x01: Left-handed system

5.17 Point display unit designation command

Changes the point display unit system

This command is for the controller.

Command

DI port	Contents		Value
DI2 ()	Command code For controller		0x3E
DI3 ()	Display units for specified point		0xss
DI4 ()	Not used		0x00

Values

ss: Point display unitSpecify in 8 bits / 0x00: Pulse units, 0x01: Millimeter units

Chapter 15 Appendix

1	Reserved word list15-1
2	Robot Language Lists: Command list in alphabetic order 15-3
3	Robot Language Lists: Function Specific 15-8
4	Functions: in alphabetic order 15-15
5	Functions: operation-specific15-18
6	Execution Level15-20

13

4

15

Α	CHKTRQ2	ETH	LET
ABSADJ	CHR	EXELVL	LOCA
ABSADJ2	CMU	EXIT	LOCB
ABSRESET	CMU1	EXITTASK	LOCF
ABSRESET2	CONFIG	F	LOCR
ABSRPOS	CONT	FDD	LOCX
ABSRPOS2	coo	FLIP	LOCY
ABSRST	COPY	FN	LOCZ
ABOVE	cos	FOR	LOG
ABS	CURTRQ	FREE	LOOP
ABSINIT	CURTRQ2	FUNCTION	LSHIFT
ABSINIT2	CUT	G	M
ACC	D	GASP	MANUAL
ACCEL	DATE	GEN	MCHREF
ACCEL2	DEC	GO	MCHREF2
ACCESS	DECEL	GOHOME	MEM
ALL	DECEL2	GOSUB	MID
ALL	DECLARE	GOTO	MIRROR
ARCH		H	
	DEF		MOD
ARCH2	DEFIO	HALT	MOVE
ARM	DEFPOS	HAND	MOVE2
ARM2	DEGRAD	HAND2	MOVEI
ARMTYPE	DELAY	HND	MOVEI2
ARMTYPE2	DI	HEX	MRF
ARY	DIM	HOME	MSG
ASPEED	DIR	HOLD	MSGCLR
ASPEED2	DIST		MSPEED
ATN	DO	IF	MSPEED2
ATN2	DPM	IN	N
ATTR	DRIVE	INCH	NAME
AUTO	DRIVE2	INCH2	NEXT
AXWGHT	DRIVEI	INIT	NONFLIP
AXWGHT2	DRIVEI2	INPUT	NOT
В	DS	INT	0
BELOW	DSPEED	INTEGER	OFF
BIN	Е	IRET	OFFLINE
BIT	ELSE	J	ON
BREAK	ELSEIF	JTOXY	ONLINE
BYTE	EMGRST	JTOXY2	OR
С	EMG	JOG	ORD
CALL	END	JOG2	ORGORD
CASE	ENDIF	L	ORGORD2
CHANGE	EOF	LANGUAGE	ORGRTN
CHANGE2	ERA	LEFT	ORGRTN2
CHGPRI	ERL	LEFTY	ORIGIN
CHGTSK	ERR	LEFTY2	OUT
CHKTRQ	ERROR	LEN	OUTPOS
OTHER TIME	LITTOIT	LLIN	001100

The words shown below are reserved for robot language and cannot be used as identifiers (variables, etc.).

OUTPOS2	RETURN	SQR	UNTIL
Р	RIGHT	START	V
P	RIGHTY	STEP	VAL
PASS	RIGHTY2	STOP	VAR
PADDR	RO	STOPON	VER
PATH	ROTATE	STR	VEL
PC	RSHIFT	SUB	W
PCM	RUN	SUSPEND	WAIT
PDEF	RW	SWI	WEIGHT
PLN	S	SYS	WEIGHT2
PLT	S	SYSTEM	WEND
PMOVE	SELECT	Т	WHERE
PMOVE2	SEND	TAN	WHERE2
PRINT	SEQUENCE	TASK	WHILE
PROGRAM	SERVO	TASKS	WHRXY
PGM	SERVO2	TCOUNTER	WHRXY2
PNT	SET	TEACH	WHRXYEX
POS	SFT	TEACH2	WHRXYEX2
PPNT	SGI	THEN	WORD
PRM	SGR	TIME	WRITE
PTP	SHARED	TIMER	Χ
PWR	SHIFT	TO	XOR
R	SHIFT2	TOLE	XY
RADDEG	SI	TOLE2	XYTOJ
READ	SID	TORQUE	XYTOJ2
REF	SIN	TORQUE2	Υ
REN	SIW	TRQSTS	YZ
RELESE	SKIP	TRQSTS2	Z
REM	SO	TRQTIME	ZX
REMOTE	SOD	TRQTIME2	SYMBOL
RESET	SOW	TSKMON	_SYSFLG
RESTART	SPEED	U	
RESUME	SPEED2	UNIT	

Because the following names are used as system variable names, they cannot be used at the beginning of other variable names (n: numeric value).

Dln	Hn	Pn	SOn
DOn	LOn	SIn	TOn
FN	MOn	Sn	

Variable name usage examples

• Although keywords which are reserved as robot language words cannot be used as they are, they can be used as variable names if alphanumeric characters are added to them.

Example: "ABS" cannot be used, but "ABS1" or "ABSX" can be used.

• Keywords reserved as system variables cannot be used at the beginning of other variable names, even if alphanumeric characters are added to them.

Example: "FN" cannot be used. "FNA" and "FN123" also cannot be used.

No.	Command	Function	Condition	Direct	Туре
Α					
1	ABS	Acquires the absolute value of a specified value.	-	-	Functions
2	ABSINIT	Resets the current position of a specified main group axis.	4	0	Command Statements
2	ABSINIT2	Resets the current position of a specified sub group axis.	4	0	Command Statements
3	ABSRPOS	Acquires the machine reference of the specified main group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)	-	-	Functions
3	ABSRPOS2	Acquires the machine reference of the specified sub group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)	-	-	Functions
4	ABSRST	Executes a return-to-origin at the robot absolute motor axes.	4	0	Command Statements
5	ACCEL	Specifies/acquires the acceleration coefficient parameter of the main group.	4/-	0	Command Statements Functions
5	ACCEL2	Specifies/acquires the acceleration coefficient parameter of the sub group.	4/-	0	Command Statements Functions
6	ARCH	Specifies/acquires the arch position parameter of the main group.	4/-	0	Command Statements Functions
6	ARCH2	Specifies/acquires the arch position parameter of the sub group.	4/-	0	Command Statements Functions
7	ARMCND	Acquires the current arm status of the main robot.	-	-	Functions
7	ARMCND2	Acquires the current arm status of the sub robot.	-	-	Functions
8	ARMTYPE	Acquires the current "hand system" setting of the main robot.	-	-	Functions
8	ARMTYPE2	Acquires the current "hand system" setting of the sub robot.	-	-	Functions
10	ASPEED	Changes the AUTO movement speed of the main group.	4	0	Command Statements
10	ASPEED2	Changes the AUTO movement speed of the sub group.	4	0	Command Statements
9	ATN	Acquires the arctangent of the specified value.	-	-	Functions
11	AXWGHT	Specifies/acquires the axis tip weight parameter of the main group.	4/-	0	Command Statements Functions
11	AXWGHT2	Specifies/acquires the axis tip weight parameter of the sub group.	4/-	0	Command Statements Functions
С					
12	CALL	Executes (calls) another program.	6	×	Command Statements
13	CHANGE	Switches the main robot hand.	4	0	Command Statements
13	CHANGE2	Switches the sub robot hand.	4	0	Command Statements
14	CHGPRI	Changes the priority ranking of a specified task.	6	X	Command Statements
15	CHR\$	Acquires a character with the specified character code.	-	-	Functions
16	COS	Acquires the cosine value of a specified value.	-	-	Functions
17	CURTRQ	Acquires the current torque value of the specified main group axis.	-	×	Functions
17	CURTRQ2	Acquires the current torque value of the specified sub group axis.	-	×	Functions
18	CUT	Terminates a task currently being executed or temporarily stopped.	6	×	Command Statements
D					
19	DATE\$	Acquires the date as a "yy/mm/dd" format character string.	-	-	Functions
L	·		.1	L	

No.	Command	Function	Condition	Direct	Туре
20	DECEL	Specifies/acquires the deceleration rate parameter of the main group.	4/-	0	Command Statements/ Functions
20	DECEL2	Specifies/acquires the deceleration rate parameter of the sub group.	4/-	0	Command Statements/ Functions
23	DEGRAD	Converts a specified value to radians (↔RADDEG).	-	-	Functions
24	DELAY	Waits for the specified period (units: ms).	6	X	Command Statements
27	DIM	Declares the array variable name and the number of elements.	6	×	Command Statements
26	DIST	Acquires the distance between 2 specified points.	-	-	Functions
28	DO	Outputs a specified value to the DO port.	1	0	Command Statements
29	DRIVE	Moves a specified main group axis to an absolute position.	4	0	Command Statements
29	DRIVE	(With T-option) Executes an absolute movement command for a specified axis.	4	0	Command Statements
29	DRIVE2	Moves a specified sub group axis to an absolute position.	4	0	Command Statements
30	DRIVEI	Moves a specified main group axis to a relative position.	4	0	Command Statements
30	DRIVEI2	Moves a specified sub group axis to a relative position.	4	0	Command Statements
E					
33	ERL	Gives the line No. where an error occurred.	-	-	Functions
33	ERR	Gives the error code number of an error which has occurred.	-	-	Functions
34	EXIT FOR	Terminates the FOR to NEXT statement loop.	6	X	Command Statements
36	EXIT TASK	Terminates its own task which is in progress.	6	X	Command Statements
F					
37	FOR to NEXT	Controls repetitive operations. Executes the FOR to NEXT statement repeatedly until a specified value is reached.	6	×	Command Statements
G					
38	GOSUB to RETURN	Jumps to a subroutine with the label specified by a GOSUB statement, and executes that subroutine.	6	×	Command Statements
39	GOTO	Unconditionally jumps to the line specified by a label.	6	×	Command Statements
Н					
40	HALT	Stops the program and performs a reset.	6	×	Command Statements
41	HAND	Defines the main robot hand.	4	0	Command Statements
41	HAND2	Defines the sub robot hand.	4	0	Command Statements
42	HOLD	Temporarily stops the program.	6	X	Command Statements
ı					
43	IF	Allows control flow to branch according to conditions.	6	X	Command Statements
44	INPUT	Assigns a value to a variable specified from the programming box.	1	0	Command Statements
45	INT	Acquires an integer for a specified value by truncating all decimal fractions.	-	-	Functions
J					
46	JTOXY	Converts joint coordinate data to main group Cartesian coordinate data. (↔XYTOJ)	-	-	Functions
46	JTOXY2	Converts joint coordinate data to sub group Cartesian coordinate data. (↔XYTOJ2)	-	-	Functions
L					
48	LEFT\$	Extracts a character string comprising a specified number of digits from the left end of a specified character string.	-	-	Functions
49	LEFTY	Sets the main robot hand system to "Left".	4	0	Command Statements

No.	Command	Function	Condition	Direct	Туре
49	LEFTY2	Sets the sub robot hand system to "Left".	4	0	Command Statements
50	LEN	Acquires the length (number of bytes) of a specified character string.	-	-	Functions
51	LET	Executes a specified assignment statement.	1	0	Command Statements
52	LO	Outputs a specified value to the LO port to enable/ disable axis movement.	1	0	Command Statements
53	LOCx	Specifies/acquires point data or shift data for a specified axis.	-	-	Command Statements/ Functions
54	LSHIFT	Shifts a value to the left by the specified number of bits. (↔RSHIFT)	-	-	Functions
M					
55	MCHREF	Acquires the return-to-origin or absolute-search machine reference for a specified main group axis.	-	-	Functions
55	MCHREF2	Acquires the return-to-origin or absolute-search machine reference for a specified sub group axis.	-	-	Functions
56	MID\$	Extracts a character string of a desired length from a specified character string.	-	-	Functions
57	MO	Outputs a specified value to the MO port.	1	0	Command Statements
58	MOVE	Performs absolute movement of all main robot axes.	5	0	Command Statements
58	MOVE2	Performs absolute movement of all sub robot axes.	5	0	Command Statements
59	MOVEI	Performs relative movement of all main robot axes.	4	0	Command Statements
59	MOVEI2	Performs relative movement of all sub robot axes.	4	0	Command Statements
0					
60	OFFLINE	Sets a specified communication port to the "offline" mode.	1	0	Command Statements
62	ON ERROR GOTO	If an error occurs during program execution, this command allows the program to jump to the error processing routine specified by the label without stopping the program, or it stops the program and displays the error message.	6	×	Command Statements
63	ON to GOSUB	Jumps to a subroutine with labels specified by a GOSUB statement in accordance with the conditions, and executes that subroutine.	6	×	Command Statements
64	ON to GOTO	Jumps to label-specified lines in accordance with the conditions.	6	×	Command Statements
65	ONLINE	Sets the specified communication port to the "online" mode.	1	0	Command Statements
61	ORD	Acquires the character code of the first character in a specified character string.	-	-	Functions
66	ORGORD	Specifies/acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the main group.	4/-	0	Command Statements/ Functions
66	ORGORD2	Specifies/acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the sub group.	4/-	0	Command Statements/ Functions
67	ORIGIN	Executes a return-to-origin for incremental specs. axes.	4	0	Command Statements
68	OUT	Turns ON the bits of the specified output ports and the command statement ends.	6	×	Command Statements
69	OUTPOS	Specifies/acquires the OUT enable position parameter of the main group.	4/-	0	Command Statements/ Functions
69	OUTPOS2	Specifies/acquires the OUT enable position parameter of the sub group.	4/-	0	Command Statements/ Functions
P					
70	PATH	Sets the movement path.	6	×	Command Statements
71	PATH END	Ends the movement path setting.	6	×	Command Statements
72	PATH SET	Starts the movement path setting.	6	X	Command Statements

No.	Command	Function	Condition	Direct	Туре
73	PATH START	Starts the PATH motion.	6	×	Command Statements
74	PDEF	Defines the pallet used to execute pallet movement commands.	1	0	Command Statements
75	PMOVE	Executes the main robot pallet movement command.	4	0	Command Statements
75	PMOVE2	Executes the sub robot pallet movement command.	4	0	Command Statements
76	Pn	Defines points within a program.	1	0	Command Statements
77	PPNT	Creates point data specified by a pallet definition number and pallet position number.	-	-	Functions
78	PRINT	Displays a character string at the programming box screen.	1	0	Command Statements
R					
79	RADDEG	Converts a specified value to degrees. (↔DEGRAD)	-	-	Functions
80	REM	Expresses a comment statement.	6	X	Command Statements
81	RESET	Turns the bit of a specified output port OFF.	1	0	Command Statements
82	RESTART	Restarts another task during a temporary stop.	6	X	Command Statements
83	RESUME	Resumes program execution after error recovery processing.	6	×	Command Statements
85	RIGHT\$	Extracts a character string comprising a specified number of digits from the right end of a specified character string.	-	-	Functions
86	RIGHTY	Sets the main robot hand system to "Right".	4	0	Command Statements
86	RIGHTY2	Sets the sub robot hand system to "Right".	4	0	Command Statements
87	RSHIFT	Shifts a value to the right by the specified number of bits. (↔LSHIFT)	-	-	Functions
S					<u>. </u>
88	Sn	Defines the shift coordinates within the program.	4	0	Command Statements
89	SELECT CASE to END SELECT	Allows control flow to branch according to conditions.	6	×	Command Statements
90	SEND	Sends a file.	1	0	Command Statements
91	SERVO	Controls the servo ON/OFF of specified main group axes or all main group axes.	4	0	Command Statements
91	SERVO2	Controls the servo ON/OFF of specified sub group axes or all sub group axes.	4	0	Command Statements
92	SET	Turns the bit at the specified output port ON.	3	In part	Command Statements
94	SHIFT	Sets the shift coordinates for the main robot by using the shift data specified by a shift variable.	4	0	Command Statements
94	SHIFT2	Sets the shift coordinates for the sub robot by using the shift data specified by a shift variable.	4	0	Command Statements
95	SIN	Acquires the sine value for a specified value.	-	-	Functions
96	SO	Outputs a specified value to the SO port.	1	0	Command Statements
97	SPEED	Changes the main group's program movement speed.	4	0	Command Statements
97	SPEED2	Changes the sub group's program movement speed.	4	0	Command Statements
98	START	Specifies the task number and priority ranking of a specified task, and starts that task.	6	×	Command Statements
99	STR\$	Converts a specified value to a character string (↔VAL)	-	-	Functions
100	SQR	Acquires the square root of a specified value.	-	-	Functions
	SUSPEND	Temporarily stops another task which is being executed.	6	×	Command Statements
102		Switches the program being executed, performs	2	0	Command Statements

No.	Command	Function	Condition	Direct	Туре
105	TCOUNTER	Outputs count-up values at 10ms intervals starting from the point when the TCOUNTER variable is reset.	-	-	Functions
106	TIME\$	Acquires the current time as an "hh:mm:ss" format character string.	-	-	Functions
107	TIMER	Acquires the current time in seconds, counting from 12:00 midnight.	-	-	Functions
108	ТО	Outputs a specified value to the TO port.	1	0	Command Statements
109	TOLE	Specifies/acquires the main group tolerance parameter.	4/-	0	Command Statements/ Functions
109	TOLE2	Specifies/acquires the sub group tolerance parameter.	4/-	0	Command Statements/ Functions
110	TORQUE	Specifies/acquires the maximum torque command value which can be set for a specified main group axis.	4/-	0	Command Statements/ Functions
110	TORQUE2	Specifies/acquires the maximum torque command value which can be set for a specified sub group axis.	4/-	0	Command Statements/ Functions
111	TRQSTS	Acquires the command end status for the DRIVE command with torque limit option executed at the main group.	-	-	Functions
111	TRQSTS2	Acquires the command end status for the DRIVE command with torque limit option executed at the sub group.	-	-	Functions
112	TRQTIME	Specifies/acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement.	1/-	0	Command Statements/ Functions
112	TRQTIME2	Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement.	1/-	0	Command Statements/ Functions
٧				•	
113	VAL	Converts the numeric value of a specified character string to an actual numeric value. (←STR\$)	-	-	Functions
W				•	
114	WAIT	Waits until the conditions of the DI/DO conditional expression are met (with time-out).	6	×	Command Statements
115	WAIT ARM	Waits until the main group robot axis operation is completed.	6	×	Command Statements
115	WAIT ARM2	Waits until the sub group robot axis operation is completed.	6	×	Command Statements
116	WEIGHT	Specifies/acquires the main robot tip weight parameter.	4/-	0	Command Statements/ Functions
116	WEIGHT2	Specifies/acquires the sub robot tip weight parameter.	4/-	0	Command Statements/ Functions
118	WHERE	Reads out the current position of the main group robot arm in joint coordinates (pulses).	-	-	Functions
118	WHERE2	Reads out the current position of the sub group robot arm in joint coordinates (pulses).	-	-	Functions
119	WHILE to WEND	Controls repeated operations.	6	×	Command Statements
120	WHRXY	Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees).	-	-	Functions
120	WHRXY2	Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees).	-	-	Functions
X			1	1	1
121	XYTOJ	Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (↔JTOXY).	-	-	Functions
121	XYTOJ2	Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (↔JTOXY2).	-	-	Functions
122	_SYSFLG	Axis status monitoring flag.	-	-	Functions

Robot Language Lists: Function Specific

Program commands

General commands

No.	Command	Function	Condition	Direct	Туре
27	DIM	Declares the array variable name and the number of elements.	6	×	Command Statements
51	LET	Executes a specified assignment statement.	1	0	Command Statements
80	REM	Expresses a comment statement.	6	×	Command Statements

Arithmetic commands

No.	Command	Function	Condition	Direct	Туре
1	ABS	Acquires the absolute value of a specified value.	-	-	Functions
2	ABSINIT	Resets the current position of a specified main group axis.	4	0	Command Statements
2	ABSINIT2	Resets the current position of a specified sub group axis.	4	0	Command Statements
9	ATN	Acquires the arctangent of the specified value.	-	-	Functions
16	cos	Acquires the cosine value of a specified value.	-	-	Functions
23	DEGRAD	Converts a specified value to radians (↔RADDEG).	-	-	Functions
26	DIST	Acquires the distance between 2 specified points.	-	-	Functions
45	INT	Acquires an integer for a specified value by truncating all decimal fractions.	-	-	Functions
54	LSHIFT	Shifts a value to the left by the specified number of bits. (↔RSHIFT)	-	-	Functions
79	RADDEG	Converts a specified value to degrees. (↔DEGRAD)	-	-	Functions
87	RSHIFT	Shifts a value to the right by the specified number of bits. (→LSHIFT)	-	-	Functions
95	SIN	Acquires the sine value for a specified value.	-	-	Functions
100	SQR	Acquires the square root of a specified value.	-	-	Functions
104	TAN	Acquires the tangent value for a specified value.	-	-	Functions

Date / time

No.	Command	Function	Condition	Direct	Туре
19	DATE\$	Acquires the date as a "yy/mm/dd" format character string.	-	-	Functions
105	TCOUNTER	Outputs count-up values at 10ms intervals starting from the point when the TCOUNTER variable is reset.	-	-	Functions
106	TIME \$	Acquires the current time as an "hh:mm:ss" format character string.	-	-	Functions
107	TIMER	Acquires the current time in seconds, counting from 12:00 midnight.	-	-	Functions

Character string operation

No.	Command	Function	Condition	Direct	Туре
15	CHR\$	Acquires a character with the specified character code.	-	-	Functions
48	LEFT\$	Extracts a character string comprising a specified number of digits from the left end of a specified character string.	-	-	Functions
50	LEN	Acquires the length (number of bytes) of a specified character string.	-	-	Functions
56	MID \$	Extracts a character string of a desired length from a specified character string.	-	-	Functions
61	ORD	Acquires the character code of the first character in a specified character string.	-	-	Functions
85	RIGHT \$	Extracts a character string comprising a specified number of digits from the right end of a specified character string.	-	-	Functions
99	STR\$	Converts a specified value to a character string (↔VAL)	-	-	Functions
113	VAL	Converts the numeric value of a specified character string to an actual numeric value. (←STR\$)	-	-	Functions

Point, coordinates, shift coordinates

No.	Command	Function	Condition	Direct	Туре
13	CHANGE	Switches the main robot hand.	4	0	Command Statements
13	CHANGE2	Switches the sub robot hand.	4	0	Command Statements
41	HAND	Defines the main robot hand.	4	0	Command Statements
41	HAND2	Defines the sub robot hand.	4	0	Command Statements
46	JTOXY	Converts joint coordinate data to main group Cartesian coordinate data. (↔XYTOJ)	-	-	Functions
46	JTOXY2	Converts joint coordinate data to sub group Cartesian coordinate data. (↔XYTOJ2)	-	-	Functions
49	LEFTY	Sets the main robot hand system to "Left".	4	0	Command Statements
49	LEFTY2	Sets the sub robot hand system to "Left".	4	0	Command Statements
76	Pn	Defines points within a program.	1	0	Command Statements
77	PPNT	Creates point data specified by a pallet definition number and pallet position number.	-	-	Functions
86	RIGHTY	Sets the main robot hand system to "Right".	4	0	Command Statements
86	RIGHTY2	Sets the sub robot hand system to "Right".	4	0	Command Statements
88	Sn	Defines the shift coordinates in the program.	4	0	Command Statements
94	SHIFT	Sets the shift coordinates for the main robot by using the shift data specified by a shift variable.	4	0	Command Statements
94	SHIFT2	Sets the shift coordinates for the sub robot by using the shift data specified by a shift variable.	4	0	Command Statements
121	XYTOJ	Converts the point variable Cartesian coordinate data to the main group's joint coordinate data $(\leftrightarrow JTOXY)$.	-	-	Functions
121	XYTOJ2	Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (↔JTOXY2).	-	-	Functions
53	LOCx	Specifies/acquires point data or shift data for a specified axis.	-	-	Command Statements/ Functions

Branching commands

No.	Command	Function	Condition	Direct	Туре
34	EXIT FOR	Terminates the FOR to NEXT statement loop.	6	×	Command Statements
37	FOR to NEXT	Controls repetitive operations. Executes the FOR to NEXT statement repeatedly until a specified value is reached.	6	×	Command Statements
38	GOSUB to RETURN	Jumps to a subroutine with the label specified by a GOSUB statement, and executes that subroutine.	6	×	Command Statements
39	GOTO	Unconditionally jumps to the line specified by a label.	6	X	Command Statements
43	IF	Allows control flow to branch according to conditions.	6	X	Command Statements
63	ON to GOSUB	Jumps to a subroutine with labels specified by a GOSUB statement in accordance with the conditions, and executes that subroutine.	6	×	Command Statements
64	ON to GOTO	Jumps to label-specified lines in accordance with the conditions.	6	X	Command Statements
89	SELECT CASE to END SELECT	Allows control flow to branch according to conditions.	6	X	Command Statements
119	WHILE to WEND	Controls repeated operations.	6	X	Command Statements

Error control

No.	Command	Function	Condition	Direct	Туре
62	ON ERROR GOTO	If an error occurs during program execution, this command allows the program to jump to the error processing routine specified by the label without stopping the program, or it stops the program and displays the error message.	6	×	Command Statements
83	RESUME	Resumes program execution after error recovery processing.	6	×	Command Statements
33	ERL	Gives the line No. where an error occurred.	-	-	Functions
33	ERR	Gives the error code number of an error which has occurred.	-	-	Functions

Program & task control

Program control

No.	Command	Function	Condition	Direct	Туре
12	CALL	Executes (calls) another program.	6	X	Command Statements
40	HALT	Stops the program and performs a reset.	6	×	Command Statements
42	HOLD	Temporarily stops the program.	6	×	Command Statements
103	SWI	Switches the program being executed, performs compiling, then begins execution from the first line.	2	0	Command Statements

Task control

No.	Command	Function	Condition	Direct	Туре
14	CHGPRI	Changes the priority ranking of a specified task.	6	×	Command Statements
18	CUT	Terminates a task currently being executed or temporarily stopped.	6	×	Command Statements
36	EXIT TASK	Terminates its own task which is in progress.	6	×	Command Statements
82	RESTART	Restarts another task during a temporary stop.	6	×	Command Statements
98	START	Specifies the task number and priority ranking of a specified task, and starts that task.	6	×	Command Statements
102	SUSPEND	Temporarily stops another task which is being executed.	6	×	Command Statements

Robot operations

No.	Command	Function	Condition	Direct	Туре
4	ABSRST	Executes a return-to-origin at the robot absolute motor axes.	4	0	Command Statements
13	CHANGE	Switches the main robot hand.	4	0	Command Statements
13	CHANGE2	Switches the sub robot hand.	4	0	Command Statements
29	DRIVE	Moves a specified main group axis to an absolute position.	4	0	Command Statements
29	DRIVE2	Moves a specified sub group axis to an absolute position.	4	0	Command Statements
30	DRIVEI	Moves a specified main group axis to a relative position.	4	0	Command Statements
30	DRIVEI2	Moves a specified sub group axis to a relative position.	4	0	Command Statements
41	HAND	Defines the main robot hand.	4	0	Command Statements
41	HAND2	Defines the sub robot hand.	4	0	Command Statements
49	LEFTY	Sets the main robot hand system to "Left".	4	0	Command Statements
49	LEFTY2	Sets the sub robot hand system to "Left".	4	0	Command Statements
58	MOVE	Performs absolute movement of all main robot axes.	5	0	Command Statements
58	MOVE2	Performs absolute movement of all sub robot axes.	5	0	Command Statements
59	MOVEI	Performs relative movement of all main robot axes.	4	0	Command Statements
59	MOVEI2	Performs relative movement of all sub robot axes.	4	0	Command Statements
67	ORIGIN	Executes a return-to-origin for incremental specs. axes.	4	0	Command Statements
75	PMOVE	Executes the main robot pallet movement command.	4	0	Command Statements
75	PMOVE2	Executes the sub robot pallet movement command.	4	0	Command Statements
86	RIGHTY	Sets the main robot hand system to "Right".	4	0	Command Statements
86	RIGHTY2	Sets the sub robot hand system to "Right".	4	0	Command Statements
91	SERVO	Controls the servo ON/OFF of specified main group axes or all main group axes.	4	0	Command Statements
91	SERVO2	Controls the servo ON/OFF of specified sub group axes or all sub group axes.	4	0	Command Statements

Status acquisition

•••••	Gialdo doquiolilori							
No.	Command	Function	Condition	Direct	Туре			
3	ABSRPOS	Acquires the machine reference of the specified main group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)	-	-	Functions			
3	ABSRPOS2	Acquires the machine reference of the specified sub group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)	-	-	Functions			
7	ARMCND	Acquires the current arm status of the main robot.	-	-	Functions			
7	ARMCND2	Acquires the current arm status of the sub robot.	-	-	Functions			
8	ARMTYPE	Acquires the current "hand system" setting of the main robot.	-	-	Functions			
8	ARMTYPE2	Acquires the current "hand system" setting of the sub robot.	-	-	Functions			
55	MCHREF	Acquires the return-to-origin or absolute-search machine reference for a specified main group axis.	-	-	Functions			
55	MCHREF2	Acquires the return-to-origin or absolute-search machine reference for a specified sub group axis.	-	-	Functions			
111	TRQSTS	Acquires the command end status for the DRIVE command with torque limit option executed at the main group.	-	-	Functions			

No.	Command	Function	Condition	Direct	Туре
111	TRQSTS2	Acquires the command end status for the DRIVE command with torque limit option executed at the sub group.	-	-	Functions
118	WHERE	Reads out the current position of the main group robot arm in joint coordinates (pulses).	-	-	Functions
118	WHERE2	Reads out the current position of the sub group robot arm in joint coordinates (pulses).	-	-	Functions
120	WHRXY	Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees).	-	-	Functions
120	WHRXY2	Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees).	-	-	Functions
115	WAIT ARM	Waits until the main group robot axis operation is completed.			
115	WAIT ARM2	Waits until the sub group robot axis operation is completed.	6	×	Command Statements

Status change

No.	Command	Function	Condition	Direct	Туре
5	ACCEL	Specifies/acquires the acceleration coefficient parameter of the main group.	4/-	0	Command Statements/ Functions
5	ACCEL2	Specifies/acquires the acceleration coefficient parameter of the sub group.	4/-	0	Command Statements/ Functions
6	ARCH	Specifies/acquires the arch position parameter of the main group.	4/-	0	Command Statements/ Functions
6	ARCH2	Specifies/acquires the arch position parameter of the sub group.	4/-	0	Command Statements/ Functions
10	ASPEED	Changes the AUTO movement speed of the main group.	4	0	Command Statements
10	ASPEED2	Changes the AUTO movement speed of the sub group.	4	0	Command Statements
11	AXWGHT	Specifies/acquires the axis tip weight parameter of the main group.	4/-	0	Command Statements/ Functions
11	AXWGHT2	Specifies/acquires the axis tip weight parameter of the sub group.	4/-	0	Command Statements/ Functions
20	DECEL	Specifies/acquires the deceleration rate parameter of the main group.	4/-	0	Command Statements/ Functions
20	DECEL2	Specifies/acquires the deceleration rate parameter of the sub group.	4/-	0	Command Statements/ Functions
66	ORGORD	Specifies/acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the main group.	4/-	Ο	Command Statements/ Functions
66	ORGORD2	Specifies/acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the sub group.	4/-	0	Command Statements/ Functions
69	OUTPOS	Specifies/acquires the OUT enable position parameter of the main group.	4/-	0	Command Statements/ Functions
69	OUTPOS2	Specifies/acquires the OUT enable position parameter of the sub group.	4/-	0	Command Statements/ Functions
74	PDEF	Defines the pallet used to execute pallet movement commands.	1	0	Command Statements
97	SPEED	Changes the main group's program movement speed.	4	0	Command Statements
97	SPEED2	Changes the sub group's program movement speed.	4	0	Command Statements

No.	Command	Function	Condition	Direct	Туре
109	TOLE	Specifies/acquires the main group tolerance parameter.	4/-	0	Command Statements/ Functions
109	TOLE2	Specifies/acquires the sub group tolerance parameter.	4/-	0	Command Statements/ Functions
116	WEIGHT	Specifies/acquires the main robot tip weight parameter.	4/-	0	Command Statements/ Functions
116	WEIGHT2	Specifies/acquires the sub robot tip weight parameter.	4/-	0	Command Statements/ Functions

Path control

No.	Command	Function	Condition	Direct	Туре
70	PATH	Sets the movement path.	6	×	Command Statements
71	PATH END	Ends the movement path setting.	6	×	Command Statements
72	PATH SET	Starts the movement path setting.	6	×	Command Statements
73	PATH START	Starts the PATH motion.	6	×	Command Statements

Torque control

No.	Command	Function	Condition	Direct	Туре
17	CURTRQ	Acquires the current torque value of the specified main group axis.	-	×	Functions
17	CURTRQ2	Acquires the current torque value of the specified sub group axis.	-	×	Functions
29	DRIVE	(With T-option) Executes an absolute movement command for a specified axis.	4	0	Command Statements
110	TORQUE	Specifies/acquires the maximum torque command value which can be set for a specified main group axis.	4/-	0	Command Statements/ Functions
110	TORQUE2	Specifies/acquires the maximum torque command value which can be set for a specified sub group axis.	4/-	0	Command Statements/ Functions
112	TRQTIME	Specifies/acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement.	1/-	0	Command Statements/ Functions
112	TRQTIME2	Specifies/acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement.	1/-	0	Command Statements/ Functions

Input/output & communication control

Input/output control

No.	Command	Function	Condition	Direct	Туре
24	DELAY	Waits for the specified period (units: ms).	6	×	Command Statements
28	DO	Outputs a specified value to the DO port.	1	0	Command Statements
52	LO	Outputs a specified value to the LO port to enable/ disable axis movement.	1	0	Command Statements
57	МО	Outputs a specified value to the MO port.	1	0	Command Statements
68	OUT	Turns ON the bits of the specified output ports and the command statement ends.	6	×	Command Statements
81	RESET	Turns the bit of a specified output port OFF.	1	0	Command Statements
92	SET	Turns the bit at the specified output port ON.	3	In part ×	Command Statements
96	SO	Outputs a specified value to the SO port.	1	0	Command Statements

П	
н	
L	

No.	Command	Function		Direct	Туре
108	то	Outputs a specified value to the TO port.	1	0	Command Statements
114	WAIT	Waits until the conditions of the DI/DO conditional	6	×	Command Statements
		expression are met (with time-out).			

Programming box

No.	Command	Function	Condition	Direct	Туре
44	INPUT	Assigns a value to a variable specified from the programming box.	1	0	Command Statements
78	PRINT	Displays a character string at the programming box screen.	1	0	Command Statements

Communication control

No.	Command	Function	Condition	Direct	Туре
65	ONLINE	Sets the specified communication port to the "online" mode.	1	0	Command Statements
60	OFFLINE	Sets a specified communication port to the "offline" mode.	1	0	Command Statements
90	SEND	Sends a file.	1	0	Command Statements

Other

Other

No.	Command	Function	Condition	Direct	Туре
122	SYSFLG	Axis status monitoring flag.	-	-	Functions

No.	Function	Туре	Function
Α			
1	ABS	Arithmetic function	Acquires the absolute value of a specified value.
3	ABSRPOS	Arithmetic function	Acquires the machine reference of the specified main group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)
3	ABSRPOS2	Arithmetic function	Acquires the machine reference of the specified sub group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)
5	ACCEL	Arithmetic function	Acquires the acceleration coefficient parameter of the main group.
5	ACCEL2	Arithmetic function	Acquires the acceleration coefficient parameter of the sub group.
6	ARCH	Arithmetic function	Acquires the arch position parameter of the main group.
6	ARCH2	Arithmetic function	Acquires the arch position parameter of the sub group.
7	ARMCND	Arithmetic function	Acquires the current arm status of the main robot.
7	ARMCND2	Arithmetic function	Acquires the current arm status of the sub robot.
8	ARMTYPE	Arithmetic function	Acquires the current "hand system" setting of the main robot.
8	ARMTYPE2	Arithmetic function	Acquires the current "hand system" setting of the sub robot.
9	ATN	Arithmetic function	Acquires the arctangent of the specified value.
11	AXWGHT	Arithmetic function	Acquires the axis tip weight parameter of the main group.
11	AXWGHT2	Arithmetic function	Acquires the axis tip weight parameter of the sub group.
С		·	
15	CHR\$	Character string function	Acquires a character with the specified character code.
16	cos	Arithmetic function	Acquires the cosine value of a specified value.
17	CURTRQ	Arithmetic function	Acquires the current torque value of the specified main group axis.
17	CURTRQ2	Arithmetic function	Acquires the current torque value of the specified sub group axis.
D			
19	DATE\$	Character string function	Acquires the date as a "yy/mm/dd" format character string.
20	DECEL	Arithmetic function	Acquires the deceleration rate parameter of the main group.
20	DECEL2	Arithmetic function	Acquires the deceleration rate parameter of the sub group.
23	DEGRAD	Arithmetic function	Converts a specified value to radians (↔RADDEG).
26	DIST	Arithmetic function	Acquires the distance between 2 specified points.
E			
33	ERL	Arithmetic function	Gives the line No. where an error occurred.
33	ERR	Arithmetic function	Gives the error code number of an error which has occurred.
ı			
45	INT	Arithmetic function	Acquires an integer for a specified value by truncating all decimal fractions.
J			
46	JTOXY	Point function	Converts joint coordinate data to main group Cartesian coordinate data. (↔XYTOJ)
46	JTOXY2	Point function	Converts joint coordinate data to sub group Cartesian coordinate data. (↔XYTOJ2)

No.	Function	Туре	Function
L			
48	LEFT\$	Character string function	Extracts a character string comprising a specified number of digits from the left end of a specified character string.
50	LEN	Arithmetic function	Acquires the length (number of bytes) of a specified character string.
53	LOCx	Point function	Acquires point data or shift data for a specified axis.
54	LSHIFT	Arithmetic function	Shifts a value to the left by the specified number of bits. (↔RSHIFT)
M			
55	MCHREF	Arithmetic function	Acquires the return-to-origin or absolute-search machine reference for a specified main group axis.
55	MCHREF2	Arithmetic function	Acquires the return-to-origin or absolute-search machine reference for a specified sub group axis.
56	MID\$	Character string function	Extracts a character string of a desired length from a specified character string.
0			
61	ORD	Arithmetic function	Acquires the character code of the first character in a specified character string.
66	ORGORD	Arithmetic function	Acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the main group.
66	ORGORD2	Arithmetic function	Acquires the axis sequence parameter for performing return-to- origin and absolute search operations in the sub group.
69	OUTPOS	Arithmetic function	Acquires the OUT enable position parameter of the main group.
69	OUTPOS2	Arithmetic function	Acquires the OUT enable position parameter of the sub group.
Р			
77	PPNT	Point function	Creates point data specified by a pallet definition number and pallet position number.
R			
79	RADDEG	Arithmetic function	Converts a specified value to degrees. (↔DEGRAD)
85	RIGHT\$	Character string function	Extracts a character string comprising a specified number of digits from the right end of a specified character string.
87	RSHIFT	Arithmetic function	Shifts a value to the right by the specified number of bits. $(\leftrightarrow \text{LSHIFT})$
S			
95	SIN	Arithmetic function	Acquires the sine value for a specified value.
100	SQR	Arithmetic function	Acquires the square root of a specified value.
99	STR\$	Character string function	Converts a specified value to a character string (↔VAL)
Т			
104	TAN	Arithmetic function	Acquires the tangent value for a specified value.
105	TCOUNTER	Arithmetic function	Outputs count-up values at 10ms intervals starting from the point when the TCOUNTER variable is reset.
106	TIME\$	Character string function	Acquires the current time as an "hh:mm:ss" format character string.
107	TIMER	Arithmetic function	Acquires the current time in seconds, counting from 12:00 midnight.
109	TOLE	Arithmetic function	Acquires the main group tolerance parameter.
109	TOLE2	Arithmetic function	Acquires the sub group tolerance parameter.

No.	Function	Туре	Function
110	TORQUE	Arithmetic function	Acquires the maximum torque command value which can be set for a specified main group axis.
110	TORQUE2	Arithmetic function	Acquires the maximum torque command value which can be set for a specified sub group axis.
111	TRQSTS	Arithmetic function	Acquires the command end status for the DRIVE command with torque limit option executed at the main group.
111	TRQSTS2	Arithmetic function	Acquires the command end status for the DRIVE command with torque limit option executed at the sub group.
112	TRQTIME	Arithmetic function	Acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement.
112	TRQTIME2	Arithmetic function	Acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement.
٧			
113	VAL	Arithmetic function	Converts the numeric value of a specified character string to an actual numeric value. (←STR\$)
W			
116	WEIGHT	Arithmetic function	Acquires the main robot tip weight parameter.
116	WEIGHT2	Arithmetic function	Acquires the sub robot tip weight parameter.
118	WHERE	Point function	Reads out the current position of the main group robot arm in joint coordinates (pulses).
118	WHERE2	Point function	Reads out the current position of the sub group robot arm in joint coordinates (pulses).
120	WHRXY	Point function	Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees).
120	WHRXY2	Point function	Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees).
Х			
121	XYTOJ	Point function	Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (←JTOXY).
121	XYTOJ2	Point function	Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (\leftrightarrow JTOXY2).
122	SYSFLG	Arithmetic function	Axis status monitoring flag.

Functions: operation-specific

Point related functions

No.	Function name	Function
46	JTOXY	Converts joint coordinate data to main group Cartesian coordinate data. (↔XYTOJ)
46	JTOXY2	Converts joint coordinate data to sub group Cartesian coordinate data. (↔XYTOJ2)
53	LOCx	Acquires point data or shift data for a specified axis.
77	PPNT	Creates point data specified by a pallet definition number and pallet position number.
118	WHERE	Reads out the current position of the main group robot arm in joint coordinates (pulses).
118	WHERE2	Reads out the current position of the sub group robot arm in joint coordinates (pulses).
120	WHRXY	Reads out the current position of the main group arm as Cartesian coordinates (mm, degrees).
120	WHRXY2	Reads out the current position of the sub group arm as Cartesian coordinates (mm, degrees).
121	XYTOJ	Converts the point variable Cartesian coordinate data to the main group's joint coordinate data (\leftrightarrow JTOXY).
121	XYTOJ2	Converts the point variable Cartesian coordinate data to the sub group's joint coordinate data (←JTOXY2).

Parameter related functions

No.	Function name	Function
3	ABSRPOS	Acquires the machine reference of the specified main group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)
3	ABSRPOS2	Acquires the machine reference of the specified sub group axis. (Valid only for axes where the return-to-origin method is set as "mark method".)
5	ACCEL	Acquires the acceleration coefficient parameter of the main group.
5	ACCEL2	Acquires the acceleration coefficient parameter of the sub group.
6	ARCH	Acquires the arch position parameter of the main group.
6	ARCH2	Acquires the arch position parameter of the sub group.
7	ARMCND	Acquires the current arm status of the main robot.
7	ARMCND2	Acquires the current arm status of the sub robot.
8	ARMTYPE	Acquires the current "hand system" setting of the main robot.
8	ARMTYPE2	Acquires the current "hand system" setting of the sub robot.
11	AXWGHT	Acquires the axis tip weight parameter of the main group.
11	AXWGHT2	Acquires the axis tip weight parameter of the sub group.
17	CURTRQ	Acquires the current torque value of the specified main group axis.
17	CURTRQ2	Acquires the current torque value of the specified sub group axis.
20	DECEL	Acquires the deceleration rate parameter of the main group.
20	DECEL2	Acquires the deceleration rate parameter of the sub group.
50	LEN	Acquires the length (number of bytes) of a specified character string.
55	MCHREF	Acquires the return-to-origin or absolute-search machine reference for a specified main group axis.
55	MCHREF2	Acquires the return-to-origin or absolute-search machine reference for a specified sub group axis.
61	ORD	Acquires the character code of the first character in a specified character string.
66	ORGORD	Acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the main group.
66	ORGORD2	Acquires the axis sequence parameter for performing return-to-origin and absolute search operations in the sub group.
69	OUTPOS	Acquires the OUT enable position parameter of the main group.
69	OUTPOS2	Acquires the OUT enable position parameter of the sub group.
109	TOLE	Acquires the main group tolerance parameter.
109	TOLE2	Acquires the sub group tolerance parameter.

No.	Function name	Function
110	TORQUE	Acquires the maximum torque command value which can be set for a specified main group axis.
110	TORQUE2	Acquires the maximum torque command value which can be set for a specified sub group axis.
111	TRQSTS	Acquires the command end status for the DRIVE command with torque limit option executed at the main group.
111	TRQSTS2	Acquires the command end status for the DRIVE command with torque limit option executed at the sub group.
112	TRQTIME	Acquires the current limit time-out period at the specified main group axis when using a torque limit option in the DRIVE statement.
112	TRQTIME2	Acquires the current limit time-out period at the specified sub group axis when using a torque limit setting option in the DRIVE statement.
116	WEIGHT	Acquires the main robot tip weight parameter.
116	WEIGHT2	Acquires the sub robot tip weight parameter.

Numeric calculation related functions

No.	Function name	Function
1	ABS	Acquires the absolute value of a specified value.
9	ATN	Acquires the arctangent of the specified value.
16	cos	Acquires the cosine value of a specified value.
23	DEGRAD	Converts a specified value to radians (↔RADDEG).
26	DIST	Acquires the distance between 2 specified points.
45	INT	Acquires an integer for a specified value by truncating all decimal fractions.
54	LSHIFT	Shifts a value to the left by the specified number of bits. (↔RSHIFT)
79	RADDEG	Converts a specified value to degrees. (↔DEGRAD)
87	RSHIFT	Shifts a value to the right by the specified number of bits. (\leftrightarrow LSHIFT)
95	SIN	Acquires the sine value for a specified value.
100	SQR	Acquires the square root of a specified value.
104	TAN	Acquires the tangent value for a specified value.
113	VAL	Converts the numeric value of a specified character string to an actual numeric value. (↔STR\$)

Character string calculation related functions

No.	Function name	Function
15	CHR\$	Acquires a character with the specified character code.
19	DATE \$	Acquires the date as a "yy/mm/dd" format character string.
48	LEFT\$	Extracts a character string comprising a specified number of digits from the left end of a specified character string.
56	MID \$	Extracts a character string of a desired length from a specified character string.
85	RIGHT \$	Extracts a character string comprising a specified number of digits from the right end of a specified character string.
99	STR\$	Converts a specified value to a character string (↔VAL)

Parameter related functions

No.	Function name	Function
122	_SYSFLG	Axis status monitoring flag.
33	ERL	Gives the line No. where an error occurred.
33	ERR	Gives the error code number of an error which has occurred.
105	TCOUNTER	Outputs count-up values at 10ms intervals starting from the point when the TCOUNTER variable is reset.
106	TIME \$	Acquires the current time as an "hh:mm:ss" format character string.
107	TIMER	Acquires the current time in seconds, counting from 12:00 midnight.

6 Execution Level

The level used to execute a program can be set as shown below.

However, the following commands can be executed only when in a "return-to-origin completion" condition.

Movement commands: MOVE, MOVE2, MOVE1, MOVE12, DRIVE, DRIVE2

DRIVEI, DRIVEI2, PMOVE, PMOVE2, PATH START

Position acquisition commands: WHERE, WHERE2, WHRXY, WHRXY2

Level	Content									
	Program execution at return-to-origin incompletion				Program reset at		Return-to-origin signal input in AUTO mode			
					m reset	program START		input in AOTO mode		
	Possible	Not possible	MANUAL	AUTO	Yes	No	Yes	No	Enabled	Disabled
0		0	0			0		0		0
1	0		0			0		0		0
2	0		0		0			0		0
3	0			0		0		0		0
4	0			0	0			0		0
5	0		0		0		0			0
6	0			0	0		0			0
7	0			0		0		0	O*1	
8	0			0	0		0		O*1	

^{*1:} When the AUTO mode absolute reset signal input (DI17) is enabled, the "robot program running" (DO13) signal switches ON during the processing operation executed by the AUTO mode absolute reset signal input.

REFERENCE For execution level details, refer the user's manuals for each controller.

9

10

11

12

13

14

15

Index

Index

	Auto movement speed change command . Axis tip weight	
Symbol	В	_
_SELECT 1-5	Bit Settings	3-19
A		
Absolute reset	C	
Absolute reset command	Cartesian coordinate format	4-1
Absolute reset movement command	CASE	
Acceleration coefficient	Changing the MANUAL mode speed	
Acceleration setting	Changing the mode	
Acquiring return-to-origin status	Changing the program attribute	
Acquiring the absolute reset status	Character constants	
Acquiring the access level	Character string	<i>L</i> .
Acquiring the arm status	Comparison	4-4
Acquiring the break point status	Connection	
Acquiring the controller configuration status	Link	
Acquiring the current positions	Operations	
Acquiring the current positions on pulse unit coordinates 13-32	Character string assignment statement	
Acquiring the current positions on XY coordinates 13-33	Circular interpolation	
Acquiring the display language	Clearing the error message	
Acquiring the emergency stop status	Command list for each group	
Acquiring the error status by self-diagnosis	Command Statement Format	
Acquiring the execution level	Comment	
Acquiring the message	COMMON	
Acquiring the mode status	Communication port	
Acquiring the option slot status	Compiling	
Acquiring the point coordinates and units	Constant file	
Acquiring the program execution status	Control codes	
Acquiring the remaining memory capacity	Control multiple robots	
Acquiring the servo status	CONT setting	
Acquiring the shift status	Coordinate plane setting	
Acquiring the speed setting status	Copying point comments	
Acquiring the tasks in RUN status	Copying point data	
Acquiring the tasks in SUSPEND status	Copyring point data	10 10
Acquiring the tasks operation status	D	_
Acquiring the version information	D	
All file	Data file	11
Arch motion setting	Data file types	
Arithmetic assignment statement	Data format conversion	
Arithmetic operations	Data handling	
Arm designation change command	Data readout processing	
Arm lock output8-91	Data write processing	
Arm lock output variable	Deceleration rate	
Arm lock output variables	Deceleration rate	
Array subscript	Declares array variable	
Array variable file	Define point	
Array variables	Defines functions which can be used by the	
11 ay vanabios 5-5	Domined functions without earl be used by the	uooi 0-40

DI/DO conditional expressions 4-6	Integer constants 2-1
DI file	Internal output8-97
DO file	Internal output variable3-12
Dummy argument 8-172	Interrupting the command execution
Dynamic variables	IO command
	Description14-6
E	Execution trigger input
_	Format14-1
EOF file	List
Erasing point comments	Sending and receiving14-3
Erasing point data	IO register
Error code number 8-121	Ç
Error message history file	J
Error processing 8-121, 8-153	0
Error recovery processing 8-153	Jog movement command14-8
Ethernet port communication file	Joint coordinate format 4-5
Executes absolute movement of specified axes 8-50	
Execution level	L
Execution Level	L
External program 8-42	Label 8-84
	LABEL Statement 8-84
-	Left-hand system
F	Linear interpolation
FUNCTION 1-2	Linear interpolation movement
Functions: in alphabetic order8-15, 15-15	Line number where error occurred
Functions: operation-specific	Local variable
Tunctions: operation specific 70, 10	Local variables
	LO file
G	Logic operations 4-2
Global variable	Logic operations4-2
Global variables	••
Global variables	M
	Machine reference file
Н	Machine reference file
Hand	Main group. 5-1
Hand	Main task
Acquiring the status	MANUAL mode operation
Define	Manual movement speed change command 14-12
Definition file	MO file
Designation change command	Motor power
Switche	MOVE command
Hand system flag3-9, 4-5, 8-105, 8-116, 8-145, 11-4, 11-18	MOVEI command 14-7
Hand system to "Right" 8-156	Movement direction setting
	Movement speed
- I	Moves the specified robot axes in a relative manner 8-58
	Multi-task 6-1
IF8-79	Multitask5-1
Block IF statement	
Simple IF statement 8-79	N
Inching movement command	
Incremental mode 8-126	Numeric constants 2-1
Initialize	
Communication port	
Memory 13-17	

0	Stop 8-72
	Switch between the programs 1-5
Online Command List 1	3-1 Switche 8-175
Online commands	Temporarily stop8-78
Acquiring the value of a character string expression 13	-39 Program directory file 11-24
Acquiring the value of a numerical expression 13	-39 Program execution wait
Acquiring the value of a point expression 13	-40 Program file 11-2
Acquiring the value of a shift expression	-40 Program level 8-164
Operation speed8	-31 Programming box 13-19
OUT enable position 8-	28 Program Names 1-2
·	Program speed change command 14-12
Р	PTP movement of specified axis
Pollot	_
Pallet	R
Define 8-	
Definition file	
Definition number	, ,
Erasing	
Movement 8-	-9 9,-
Movement command	·
Position number 8-	
Palletizing	
Parallel input variable	
Parallel output variable	
Parallel port 8-46, 8	· ·
Parameter directory file	•
Parameter file	5 5
PATH 8-130,	
Cautions when using this function	9-2 RS-232C 12-18, 12-19
Ends the movement setting 8-	36
Features	⁹⁻¹ S
How to use	9-1
Specifies the motion path 8-	30 Sealing 12-17
Starts the movement setting 8-	37 SEQUENCE 1-4
Starts the PATH motion 8-	39 Sequence function 7-1
Performs absolute movement8-98, 8-	114 Sequence program 7-1
Pick and place 12	-12 Acquiring the execution status
Point assignment statement 8	-89 Cannot be used 7-3
Point comment file	1-8 Compiling 7-2
Point data	Creating 7-5
For a specified axis8	-92 Executing 7-4
Format	4-5 Priority of logic operations
Point data variable	3-7 Program capacity 7-8
Point display unit designation command 14	-13 Programming method 7-1
Point element variable	-
Point file	
Point teaching command	
Port output setting 8-113, 8-	
Priority of arithmetic operation	
Program	Serial double word input
Copy 13	
Erase	·
Selected	·

Serial word input	Serial port	Start 8-169
Serial word output .3-18 Stopping .6-5	Serial port communication file	Starting 6-2
Service	Serial word input	Status and transition 6-2
FREE	Serial word output	Stopping6-7
OFF 8-162 Terminate 8-662 ON 8-162 Task status Servo command 14-11 NON EXISTENT 6-2 Setting a break point 1-3-8 READY 6-5 Setting the coordinates and units in MANUAL mode 13-18 SEUDY 6-6 Setting the display language 13-18 STOP 6-6 Setting the execution level 13-20 WAIT 6-6 Setting the schard system 13-21 Timer output variable 3-1 Setting the SCARA robot hand system 13-21 Timer output variable 3-1 Setting the sequence program execution flag 13-21 To file 11-4 Setting the UTILITY mode 13-20 To file 11-4 Shift assignment statement 8-90 To port 8-18 Shift coordinate 8-158, 8-165 8-165 Definition file 11-13 To group first value 8-53 Shift designation change command 14-13 To group effect value 8-53 Shift assitativariables 3-20	Servo	Suspending 6-5
ON 8-162 Task status Servo command 14-11 NON EXISTENT 6-2 Servo status 8-162 READY 6-3 Setting a break point 13-8 READY 6-4 Setting the coordinates and units in MANUAL mode 13-19 STOP 5-5 Setting the bread point 13-20 STOP 5-6 Setting the execution level 13-20 WAIT 6-6 Setting the sequence program execution flag 13-21 Timer output variable 3-12 Setting the sequence program execution flag 13-21 Timer output variable 3-18 Setting the sequence program execution flag 13-21 Timer output variable 3-19 Shift assignment statement 8-90 To port 8-186 Shift coordinate 8-158, 8-165 Torque command value 8-186 Shift coordinate variable 3-8 Torque of command value 8-186 Shift coordinate variable 3-8 Torque offset value 8-53 Shift coordinate variable 3-10 Torque offset value 8	FREE 8-162	Temporarily stop 8-174
Servo command	OFF 8-162	Terminate 8-68
Service status	ON 8-162	Task status
Setting a break point 13-8 Setting the coordinates and units in MANUAL mode 13-19 STOP Sctting the display language 13-18 SUSPEND Sctting the flashing language 13-18 SUSPEND Sctting the execution level 13-20 WAIT SUSPEND Sctting the SARA robot hand system 13-21 Tip weight 3-14 Setting the sequence program execution flag 13-21 To file 11-41 Setting the UTILITY mode 13-20 Tolerance 8-18 Softiff assignment statement 8-90 Top ord 8-18 Shift assignment statement 8-90 Top ord 8-18 Shift coordinate 8-158 8-165 Torque command value 8-18 Shift coordinate variable 3-10 Shift designation change command 14-13 Torque limit setting 8-53 8-15 Stifle	Servo command	NON EXISTENT 6-2
Setting the coordinates and units in MANUAL mode 13-19 Setting the display language 13-18 SUSPEND 6-2 Setting the display language 13-18 SUSPEND 6-2 Setting the display language 13-18 SUSPEND 6-2 Setting the hand system 13-21 Timer output variable 3-14 Timer output variable 3-15 Timer output variable 3-14 Timer output variable 3-15 Timer output variable 3-16 Timer output variab	Servo status	READY 6-2
Setting the display language	Setting a break point	RUN 6-2
Setting the execution level 13-20 Setting the hand system 13-21 Setting the hand system 13-21 Setting the SetAR robot hand system 13-21 Tip weight 9-11 inter output variable 3-12 Setting the Sequence program execution flag 13-21 Setting the UTILITY mode 13-20 Setting the UTILITY mode 13-20 Shift assignment statement 8-90 Shift coordinate 8-158, 8-165 Definition file 11-13 Torque firmit setting 8-168 Shift coordinate variable 3-8 Shift designation change command 14-13 Softile 3-10 Shift designation change command 14-13 Softile 11-45 Softile 11-45 SOW file 11-54 Static variables 3-20 STOPON condition setting 8-53, 8-62 Sub-procedure 8-33, 8-64, 8-72 Subroutine 8-122 Switching the execution task 13-8 System prior to shipment 5-15 System prior to shipment 5-15 System Variables 3-2 Task Condition wait 6-4 Definition 6-61 Deleting 6-6 Directly terminate 8-38 Number 8-169 Priority ranking 8-35, 8-169 Priority ranking 8-35, 8-169 Program example 6-8 Restart 8-8-152 Scheduling 6-65 Scheduling 6-66 Sc	Setting the coordinates and units in MANUAL mode 13-19	STOP 6-2
Setting the hand system	Setting the display language	SUSPEND6-2
Setting the SCARA robot hand system	Setting the execution level	WAIT 6-2
Setting the sequence program execution flag. 13-21 TO file. 11-45 Setting the UTILITY mode 13-20 Tolerance 8-186 Tolerance 8-186 Shift assignment statement 8-90 TO port 8-186 Shift coordinate. 8-158, 8-165 Torque command value 8-168 Shift coordinate variable 3-8 Torque filmit setting 8-53, 8-188 Shift designation change command 14-13 Torque filmit value 8-55 Shift element variable 3-10	Setting the hand system	Timer output variable
Setting the UTILITY mode	Setting the SCARA robot hand system	Tip weight 8-190
Shift assignment statement	Setting the sequence program execution flag 13-21	TO file
Shift coordinate	Setting the UTILITY mode	Tolerance 8-181
Definition file	Shift assignment statement	TO port 8-180
Shift coordinate variable 3-8 Torque limit value 8-50	Shift coordinate	Torque command value 8-182
Shift designation change command	Definition file	Torque limit setting8-53, 8-185
Shift element variable	Shift coordinate variable	Torque limit value 8-53
Simila	Shift designation change command	Torque offset value 8-53
SO file	Shift element variable	Type Conversions 3-6
SOW file	SI file	
SOW file. 11-54 Static variables 3-20 STOPON condition setting 8-144 STOPON conditions setting 8-53, 8-62 Basic operation 12-6 Sub-procedure 8-33, 8-164, 8-172 Sub-proutine 8-70 Subroutine 8-70 Subroutine 8-122 Switching the execution task 13-8 Utility operation 13-12 Switching the program 13-44 System Variables 3-2, 3-7 T Valid range of dynamic array variables 3-20 T Valid range of variables 3-20 Task Valid range of variables 3-20 Value Pass-Along & Reference Pass-Along 3-6 Variable Names 3-3 Variable Names 3-3 Variable Types 3-4 Variable Types 3-4 Variable Types 3-4 Variable Types 3-4 Witter file 8-160 Write file 8-160 Write file	SO file	U
STOPON condition setting	SOW file	
STOPON conditions setting	Static variables	User program examples
Sub-procedure 8-33, 8-164, 8-172 User Variables 3-2 Sub-routine 8-70 Using point numbers 12-2 Subroutine 8-122 Using shift coordinates 12-3 Switching the execution task 13-8 Utility operation 13-12 Switching the program 13-44 System prior to shipment 5-1 V System Variables 3-2, 3-7 Valid range of dynamic array variables 3-20 Valid range of variables 3-20 Value Pass-Along & Reference Pass-Along 3-6 Condition wait 6-4 Variable file 11-27 Variable Types 3-2 Variable Types 3-2 Deleting 6-6 Variable Types 3-4 Number 8-169 W Priority ranking 8-35, 8-169 Write file 8-160 Program example 6-8 Restart 8-152 X Restarting 6-5 Scheduling 6-3 XY setting 8-56	STOPON condition setting 8-144	Application12-8
Sub-routine 8-70 Using point numbers 12-2 Subroutine 8-122 Using shift coordinates 12-3 Switching the execution task 13-8 Utility operation 13-12 Switching the program 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-44 13-42 13-44 13-42 12-22 14-42 13-42 13-42 13-42 13-42 12-22 12-22 13-42 13-42 13-42 13-42 13-42 13-42 13-42 13-42 <td< td=""><td>STOPON conditions setting 8-53, 8-62</td><td>Basic operation12-1</td></td<>	STOPON conditions setting 8-53, 8-62	Basic operation12-1
Subroutine 8-122 Using shift coordinates 12-5 Switching the execution task 13-8 Utility operation 13-12 Switching the program 13-44 System prior to shipment 5-1 V System Variables 3-2, 3-7 Valid range of dynamic array variables 3-20 Valid range of variables 3-20 Value Pass-Along & Reference Pass-Along 3-6 Variable file 11-27 Variable Names 3-3 Definition 6-1 Variable Types 3-4 Deleting 6-6 Wariable Types 3-4 Number 8-169 Walt status 6-4 Priority order 6-1 Walt status 6-4 Program example 6-8 Write file 8-160 Restart 8-152 X Restarting 6-5 Xy setting 8-55	Sub-procedure8-33, 8-164, 8-172	User Variables 3-2
Switching the execution task 13-8 Utility operation 13-12 Switching the program 13-44 13-42	Sub-routine 8-70	Using point numbers12-2
Switching the program 13-44 System prior to shipment 5-1 System Variables 3-2, 3-7 Valid range of dynamic array variables 3-20 Valid range of variables 3-20 Value Pass-Along & Reference Pass-Along 3-6 Variable file 11-27 Variable Names 3-3 Variable Types 3-4 Deleting 6-6 Directly terminate 8-38 Number 8-169 Priority order 6-1 Mair status 6-4 Wair status 6-4 Write file 8-160 Program example 6-8 Restart 8-152 Restarting 6-5 Scheduling 6-3 XY setting 8-55	Subroutine	Using shift coordinates
V Valid range of dynamic array variables 3-20 T	Switching the execution task	Utility operation
System Variables 3-2, 3-7 Valid range of dynamic array variables 3-20	Switching the program	
System Variables 3-2, 3-7 Valid range of dynamic array variables 3-20	System prior to shipment 5-1	V
T Valid range of variables 3-20 Value Pass-Along & Reference Pass-Along 3-6 Variable file 11-27 Condition wait 6-4 Variable Names 3-3 Definition 6-1 Variable Types 3-4 Deleting 6-6 6-6 Directly terminate 8-38 W Number 8-169 WAIT status 6-4 Priority order 6-1 WalT status 6-4 Program example 6-8 Write file 8-160 Restart 8-152 X Restarting 6-5 XY setting 8-55 Scheduling 6-3 XY setting 8-55	System Variables	•
Task Value Pass-Along & Reference Pass-Along 3-6 Condition wait 6-4 Variable file 11-27 Definition 6-1 Variable Names 3-3 Deleting 6-6 Variable Types 3-4 Directly terminate 8-38 W Number 8-169 WAIT status 6-4 Priority order 6-1 WAIT status 6-4 Program example 6-8 Write file 8-160 Restart 8-152 X Restarting 6-5 Scheduling 8-55 Scheduling 6-3 XY setting 8-55		Valid range of dynamic array variables
Task Variable file 11-27 Condition wait 6-4 Variable Names 3-3 Definition 6-1 Variable Types 3-4 Deleting 6-6 6-6 Directly terminate 8-38 W Number 8-169 WAIT status 6-4 Priority order 6-1 WAIT status 6-4 Program example 6-8 Write file 8-160 Restart 8-152 X Restarting 6-5 Scheduling 8-55	Т	Valid range of variables
Condition wait 6-4 Variable Names 3-3 Definition 6-1 Variable Types 3-4 Deleting 6-6 6-6 Directly terminate 8-38 W Number 8-169 WAIT status 6-4 Priority order 6-1 WAIT status 6-4 Priority ranking 8-35, 8-169 Write file 8-160 Program example 6-8 X Restart 8-152 X Restarting 6-5 XY setting 8-55 Scheduling 6-3 XY setting 8-55	•	Value Pass-Along & Reference Pass-Along 3-6
Definition 6-1 Variable Types 3-4 Deleting 6-6 Directly terminate 8-38 W Number 8-169 Priority order 6-1 WAIT status 6-4 Priority ranking 8-35, 8-169 Write file 8-160 Program example 6-8 Restart 8-152 X Restarting 6-5 XY setting 8-55 Scheduling 6-3 XY setting 8-55	Task	Variable file
Deleting 6-6 Directly terminate 8-38 Number 8-169 Priority order 6-1 WAIT status 6-2 Priority ranking 8-35, 8-169 Write file 8-160 Program example 6-8 The start of the status 8-160 Restart 8-152 X Restarting 6-5 Scheduling 8-55	Condition wait 6-4	Variable Names 3-3
Directly terminate 8-38 Number 8-169 Priority order 6-1 WAIT status 6-4 Priority ranking 8-35, 8-169 Write file 8-160 Program example 6-8 Testart 8-152 X Restarting 6-5 Scheduling 8-55 Scheduling 6-3 XY setting 8-55	Definition 6-1	Variable Types 3-4
Number 8-169 Priority order 6-1 WAIT status 6-4 Priority ranking 8-35, 8-169 Write file 8-160 Program example 6-8 Restart 8-152 X Restarting 6-5 Scheduling 6-3 XY setting 8-55	Deleting 6-6	
Number 8-169 Priority order 6-1 WAIT status 6-4 Priority ranking 8-35, 8-169 Write file 8-160 Program example 6-8 Restart 8-152 X Restarting 6-5 Scheduling 6-3 XY setting 8-55	Directly terminate 8-38	W
Priority ranking 8-35, 8-169 Write file 8-160 Program example 6-8 Restart 8-152 X Restarting 6-5 Scheduling 6-3 XY setting 8-55	Number 8-169	
Priority ranking 8-35, 8-169 Write file 8-160 Program example 6-8 Restart 8-152 X Restarting 6-5 Scheduling 6-3 XY setting 8-55	Priority order 6-1	WAIT status 6-4
Program example 6-8 Restart 8-152 Restarting 6-5 Scheduling 6-3 XY setting 8-55	•	Write file 8-160
Restart 8-152 Restarting 6-5 Scheduling 6-3 XY setting 8-55		
Restarting 6-5 Scheduling 6-3 XY setting 8-55		X
Scheduling	Restarting 6-5	
	•	XY setting 8-55
	_	-

Revision record

Manual version	Issue date	Description
Ver. 4.00	Feb. 2013	Complete layout revision
Ver. 5.00	Mar. 2013	A "current torque" referencing command was added to the robot language. An "error message history details" file was added to the data file details. Errors in the text were corrected, etc.
Ver. 5.01	Apr. 2013	The ABSINIT and ATN2 commands were added to the robot language. Chapter 14 "Limitless motion" was added. Errors in the text were corrected, etc.
Ver. 5.02	Jul. 2013	The term name, "Acquisitions", was changed to "Functions" throughout the document. Cautions were added to Chapter 6. Chapter 14 "Limitless motion" was moved to Chapter 10. Errors in the text were corrected, etc.
Ver. 5.03	May 2014	The meaning of the torque limit designation in "29 DRIVE/DRIVE2" of Chapter 8 was changed. The supplemental description was added to the sample program in Chapter 10 "Limitless motion" and errors in the text were corrected, etc.
Ver. 5.04	Feb. 2017	IM Operations' contact information was changed.
Ver. 5.05	Jul. 2017	Clerical error corrections, etc.
Ver. 5.11	Nov. 2017	Cautions were added to Chapter 6 "2. Task definition" and "5. Sharing the robot language and data".

Programming Manual

RCX Series

Nov. 2017 Ver. 5.11

YAMAHA MOTOR CO., LTD. IM Operations

All rights reserved. No part of this publication may be reproduced in any form without the permission of YAMAHA MOTOR CO., LTD. The contents of this manual are subject to change without prior notice. Information furnished by YAMAHA in this manual is believed to be reliable. However, no responsibility is assumed for possible inaccuracies or omissions. If you find any part unclear in this manual, please contact your distributor.

IM Operations

127 Toyooka, Kitaku, Hamamatsu, Shizuoka, 433-8103, Japan Tel. 81-53-525-8250 Fax. 81-53-525-8378

Robot manuals can be downloaded from our company website. Please use the following for more detailed information.

https://global.yamaha-motor.com/business/robot/

