

MeshCom-Guru v0.5.2

User Manual

Structured manual for version 0.5.2

About this manual

This edition is updated for v0.5.2. The Favorites section is placed in the logical application flow. The manual also documents the 5-second refresh optimization and independent Echo/ACK status handling.

1. Quick Start

MeshCom-Guru connects to your MeshCom node and combines messages, rooms, private chats, monitor, stations, map, worldwide activity, weather and settings in one interface.

- Start the program and enter the hotspot IP.
- Choose Connect and wait for ONLINE.
- Enter your callsign and, if needed, GPS data.
- Create or select rooms and send messages.
- Use Settings → Language to choose a language.

2. Connection

The hotspot IP, local callsign and GPS settings are located in the upper area. The WebService is checked regularly. After a short interruption, MeshCom-Guru automatically attempts to reconnect.

3. Rooms and “All”

Rooms are managed on the left. “All” combines messages from saved rooms into one view. The room filter can include multiple saved rooms.

4. Private Chats

Private messages are kept separate from room chats. A callsign can be used to open a private chat and, where configured, QRZ.

5. Favorites and names

The Favorites manager stores a callsign together with an optional name. The name can be changed later.

Favorites can also be added directly from “All”. The selected message time is used as the activity reference.

- Enter the callsign.
- Optionally enter the person's or station's name.
- Save the favorite.
- Edit the name at any time.
- The online view and online popup show name and callsign together.

6. Sending Messages

The message field supports up to 149 characters. Quick texts and smileys are available next to the field. The paperclip can upload an image through Picrd.

7. Confirmations: Echo and ACK

A sent message may initially be pending. Echo and ACK are handled as independent status changes, so an existing message can change to ✓ or ✓✓ without waiting for another chat message.

Chat confirmation does not depend on an ACK row being visible in the monitor. Multiple pending sends in different rooms are kept separate.

8. Monitor - Live

The monitor shows received MSG, POS, TEL and ACK entries. Pause stops the live display; Clear removes the current display. Filters, search and auto-scroll help with monitoring.

9. Map and Stations

The map shows known stations and positions. Depending on received data, distance, RSSI and SNR may be shown. Marker information can include battery, node type, firmware and temperature.

The Stations/MH view lists recently heard stations with callsign, distance, RSSI, SNR, battery and last activity when available.

10. Worldwide, Weather and Settings

The Worldwide view shows MeshCom activity. Weather and telemetry are displayed when supplied by the node. Settings contain language, online favorites, sounds and other personal options.

11. Performance in v0.5.2

The Webservice is still checked every 5 seconds. When the data is unchanged, "All", rooms and visible chat bubbles are not rebuilt completely on every cycle. This reduces recurring GUI work, especially with many messages.

A new message triggers the required update. Echo and ACK are handled separately as status changes.

Important: The existing 120-second status window and the following hard freeze remain part of the status logic.