

MeshCom-Guru – User Guide v0.3.78

MeshCom-Guru v0.3.78 · English

New in v0.3.78 – Dashboard

Under Settings → Display you can choose Classic or Dashboard. The choice is saved and restored on the next start. Both views use the same MeshCom data and functions.

Dashboard layout

The Dashboard combines connection, rooms, chat, map, worldwide activity, monitor, stations/MH and statistics. Saved room chats and private chats are listed on the left; the active chat is in the center; map and worldwide activity are on the right; monitor, stations/MH and statistics are at the bottom.

Room Chats and “All”

Up to five saved rooms are shown on the left as clickable Room Chats. Clicking a room opens only that room. “All” is a separate view for messages from the saved rooms and can always be selected again. Saved rooms also remain available to the classic message filter.

Private Chats

Private conversations are listed separately. Clicking one opens that private conversation and does not jump back to “All”. New private messages are reflected in the private conversation and in “All”.

Sending messages

In the Dashboard, press Enter to send; a separate Send button is not required. This leaves more room for the message field. Messages are limited to 149 characters and the live counter shows the current length.

Connection and auto-reconnect

Enter the hotspot IP and press Connect. After a manual connection, automatic reconnection is enabled. Temporary network, hotspot or WebService failures trigger another connection attempt. Disconnect deliberately disables automatic reconnection. The program does not connect automatically at startup.

Monitor

Monitor displays live MeshCom UDP packets on port 1799 with time, type, callsign, target, RSSI, SNR and information. The information column remains readable and can be scrolled. Filtering, search, pause, auto-scroll and clear are available.

Stations / MH

Stations/MH shows recently heard stations with callsign, distance, RSSI and SNR. The columns are arranged without an unnecessary horizontal scrollbar. Existing LoRa/station data is used.

Statistics

Statistics shows live session counters for messages, nodes, positions, private messages, monitor entries and messages by room.

Map and Worldwide

The OSM/Leaflet map displays positions and stations. Worldwide opens the public MeshCom Activity page of ÖVSV and automatically selects ACTIVITY. The embedded website handles its own updates; MeshCom-Guru adds no 15-second refresh.

Weather and Node Info

WX can display temperature, humidity, QFE and QNH when supplied by the WebService. Weather can be refreshed and sent to the currently selected target. Node Info opens information from the connected MeshCom WebService.

Other features

Quick texts can be inserted and managed; emojis are inserted at the cursor position. Chat colors, clickable callsign/link color, sound, volume and light/dark theme are configurable. The interface supports German, English, Italian, Dutch and French.

Installation and settings

Linux: extract MeshCom and run `./run_linux.sh`. Windows: run `run_windows.bat`. Debian: install to `/usr/share/MeshCom`. Personal settings are stored in `~/.MeshCom/settings.ini`.

MeshCom-Guru v0.3.78