

MeshCom-Guru

User Manual

v0.4.9 · English

This manual explains the most important functions of version 0.4.8 in a simple, user-oriented way. activity, monitor, stations, weather and statistics in one interface.

Quick Start

1. Start the program and enter the hotspot IP.
2. Click Connect and wait until ONLINE is shown.
3. Enter your callsign and, if required, GPS coordinates, then save GPS.
4. Create or select the required rooms.
5. Enter messages in the field at the bottom and send them.
6. Use Settings → Language to switch between the eight supported languages.

1. Connection

Hotspot IP, callsign and GPS are located in the upper part of the application. Connect establishes the MeshCom WebService connection. After a short interruption, MeshCom-Guru automatically attempts to reconnect. Disconnect ends the connection deliberately.

2. Rooms and “All”

Your rooms are listed on the left. Add room lets you create rooms. All collects messages from your saved rooms in one view. The room filter can include up to six rooms.

3. Private Chats

Private messages are kept separate from room chats. A callsign can be clicked to open the appropriate private chat or QRZ.com. This keeps room traffic and direct conversations organized.

4. Sending Messages

Enter a message, check the target or room, and send it. The input field supports up to 149 characters. Quick texts and smileys are available next to the message field. The paperclip can upload an image through Picrd. If a received message contains a Picrd link and an image is detected at the link target, MeshCom-Guru shows a preview directly in the chat. The original link remains clickable. Normal web links without an image target are displayed as before. A preview already shown is not inserted again during later chat refreshes.

5. Monitor - Live

The monitor shows received MSG, POS, TEL and ACK entries. Pause stops the live display. Clear removes the current display. Filter, search and auto-scroll help monitor radio traffic. The counter shows displayed / saved.

6. Map

The map shows known stations and their positions. Use + and – to zoom. Depending on received data, distance, RSSI and SNR can be shown. The connection display can show actually received MeshCom paths as lines between known markers. Clicking a node can highlight detected connections. Lines are created only from actually received path information or direct local LoRa reception; position, distance or assumed radio range do not create a connection. RSSI and SNR are not assigned to individual hops.

Map markers and callsigns

Map markers use activity colors: blue = active (under 30 minutes), green = normal (30–120 minutes), orange = older (2–12 hours), gray = inactive (over 12 hours), red = own station.

The “Callsigns” button is directly below “Connections”. It lets you show or hide callsigns on the map.

Clicking a marker opens a compact information window with position, distance and last activity. Battery level, node type, firmware and temperature are shown when available. RSSI, SNR, humidity, air pressure, room and last message are not shown there.

7. Worldwide

The Worldwide tab shows the integrated MeshCom activity page. The page handles its own updates; MeshCom-Guru does not add a separate 15-second refresh. WebKitGTK is used on Linux/Raspberry Pi.

8. Stations / MH

Recently heard stations are shown here. The list can contain up to 250 entries. Typical information includes callsign, distance, RSSI and SNR.

9. Weather

The weather line shows temperature, humidity, QFE and QNH. Refresh weather reads the values again. Send weather transmits the current weather data.

10. Statistics

Statistics summarize messages, nodes, positions, telemetry, private messages and monitor entries. The number of messages per room is also shown.

11. Display and Settings

Settings → Display lets you switch between the classic view and the dashboard. Both views use the same MeshCom data and functions. Personal settings are saved and restored at the next start.

12. Language

MeshCom-Guru supports Deutsch, English, Italiano, Nederlands, Français, Español and Svenska. The language can be changed while the application is running. The integrated guide and controls are adapted as well.

13. Backup, Restore and Update Check

Personal MeshCom-Guru data can be backed up and restored. The update check informs you about a newer GitHub version. Updates are not downloaded or installed automatically.

14. Help and Tips

Help → Guide opens this documentation directly in the application. For connection problems, first check the hotspot IP, node reachability and the ONLINE/OFFLINE status. After a short interruption, wait briefly for the automatic reconnect. Good to know • The classic view remains available as a familiar alternative to the dashboard. • The Worldwide page is a real integrated HTML page and is not treated as a normal chat message. • The displayed / saved monitor counters are two different values and are not an error. • Personal settings are stored in the user area under ~/.MeshCom. • 73 – and enjoy MeshCom-Guru!

MeshCom-Guru