Dexter HMS Panel - Comprehensive User Guide

Table of contents

- STEP 4: Navigating to Device Configuration
  - STEP 1: Accessing Normal Zone Configuration
  - STEP 7:
  - STEP 1: Accessing Power Zone Configuration
  - STEP 2: Initiating Power Zone Configuration
  - STEP 5: Selecting Device Type for Power Zone
  - STEP 7: Completing Power Zone Configuration
  - STEP 3: Navigating Past Event & Log Management
  - STEP 2: Accessing Device Credential Settings
  - STEP 6: Exiting Device Credential Configuration
- STEP
- STEP
- STEP 3: Running Device Provisioning (PVSN)
- ✅

Introduction

This comprehensive guide provides detailed, step-by-step instructions for the installation and configuration of the Dexter HMS Panel. Designed for clarity and ease of use, this manual covers all essential procedures from initial login to advanced system settings, ensuring a smooth and efficient setup process. Each step is accompanied by visual aids to enhance understanding and facilitate accurate execution.

Initial Login & Navigation

To begin the configuration process, you must first access the panel's user interface. This section outlines the initial steps to log in and navigate to the main configuration menu.

STEP 1: Accessing the User Interface

Press the 🔘 **MENU** button located on the panel keypad. Upon pressing, the display will illuminate and show the prompt: User Interface >>.

STEP 2: Confirming Access

With User Interface >> displayed, press the 🔘 **ENTER** button on the keypad. This action confirms your intent to access the system's interface.

STEP 3: Entering Password

Following the confirmation, the display will prompt you to enter the system password. The screen will show Password, typically with a series of asterisks or dots indicating the input field. Use the panel's keypad to enter the correct password. (Default password is 123321)

STEP 4: Navigating to Device Configuration

Upon successful password entry, the system will grant access and the display will show: Device Configuration >. This indicates that you have successfully logged in and are now ready to proceed with device-specific configurations.

Device Configuration

This section details the configuration of various device-related settings, including normal zones, power zones, and output controls.

2.1 Normal Zone Configuration

This process is crucial for configuring the 16 normal zones on the Dexter HMS Panel, allowing you to define their status and device types.

STEP 1: Accessing Normal Zone Configuration
With the display showing Device Configuration >, press the **ENTER** button. The display will then transition to Normal Zone configuration.

STEP 2: Initiating Zone Configuration
Once Normal Zone configuration is displayed, press **ENTER** again to begin configuring individual zones. You will start with Zone 1.

STEP 3: Configuring Zone Status
The display will show Zone 1 [Active / De Active]. To change the zone's status, press **ENTER**. This action toggles the status between 'Active' and 'De Active'.

STEP 4: Configuring Buzzer
After setting the zone status, press the > button to navigate to the buzzer setting. The display will show Buzzer on/off. Press **ENTER** to toggle the buzzer for that specific zone between 'on' and 'off'.

STEP 5: Selecting Device Type
Next, press the > button again. The display will show Device Type. At this point, you will select the appropriate device type for the current zone using the number keys on the keypad:

- **1**: BAS (Buglar Alarm System)
- **2**: FAS (Fire Alarm System)
- **3**: Time Lock
- **4**: BACS (Biometric Access Control System)
- **5**: NVR & DVR (Network Video Recorder & Digital Video Recorder)
- **6**: IAS (Intruder Alarm System)

STEP 6: Proceeding to the Next Zone
After selecting the device type, press the > button to move to the next zone (e.g., Zone 2). Repeat Steps 3-5 for Zones 2 through 6, as they follow the same configuration options.

⚠ **Special Zone Configurations**:

- **Zones 7-8**: For these zones, the device type field is fixed to **CCTV**. You will still follow Steps 3-5, but the device type selection will be pre-determined.
- **Zones 9-14**: These zones follow the same configuration process as Zones 1-6.
- **Zones 15-16**: Similar to Zones 7-8, the device type for these zones is fixed to **CCTV**.

STEP 7: Completing Normal Zone Configuration
Once all 16 zones have been configured, press the > button again. The display will show EXIT [ENTER]. Press the **ENTER** button on the panel keypad to save your settings and exit this configuration section. The display will confirm the completion with NORMAL ZONE CONFIGURATION.

2.2 Power Zone Configuration

This process allows you to configure the 8 power zones on the panel, similar to the normal zones.

STEP 1: Accessing Power Zone Configuration
From the NORMAL ZONE CONFIGURATION screen, press the > button. The display will then show POWER ZONE CONFIGURATION.

STEP 2: Initiating Power Zone Configuration
Press **ENTER** to begin configuring each of the 8 power zones individually.

STEP 3: Configuring Power Zone Status
The display will show Power Zone 1 [Active / De-active]. Press **ENTER** to toggle the status of the power zone.

STEP 4: Configuring Buzzer for Power Zone
Press the > button. The display will show BUZZER ON /off. Press **ENTER** to configure the buzzer setting for the power zone.

STEP 5: Selecting Device Type for Power Zone
Press the > button again. You will use the number keys (1-6) to select the device type for the power zone:

1: BAS

2: FAS

3: Time Lock

- **4**: Access Control
- **5**: NVR & DVR
- **6**: IAS

STEP 6: Proceeding to the Next Power Zone

Press the > button to move to the next power zone and repeat Steps 3-5 until all 8 power zones are configured.

STEP 7: Completing Power Zone Configuration

After configuring Power Zone 8, press the > button. The display will show Exit [Enter]. Press **ENTER** to save your settings. The display will then show <POWER ZONE CONFIGURATION>.

2.3 Navigating to Network Settings

After completing the Power Zone configuration, you will navigate through several menus to reach the Network Settings. This section guides you through the necessary steps to access network-related configurations.

STEP 1: Skipping Output Management

From the <POWER ZONE CONFIGURATION> screen, press the > button. The display will show Output management. Press > again to skip this menu.

STEP 2: Exiting to Device Configuration

The display will now show Exit enter. Press **ENTER**. This action will return you to the Device Configuration > screen.

STEP 3: Navigating Past Event & Log Management

From Device Configuration >, press the > button to navigate past this menu. The display will then show EVENT & LOG MANAGEMENT. Press > again to skip this menu as well.

STEP 4: Accessing Network Settings

After skipping the Event & Log Management, the display will show Network Settings. Press **ENTER** to proceed and begin configuring the network settings.

Network Settings Configuration

This section provides a detailed, step-by-step procedure for configuring the Dexter HMS Panel's network settings. This guide assumes you have successfully navigated to the Network Settings menu and pressed **ENTER**.

3.1 Device Credential Configuration

Configuring device credentials is the first crucial step in enabling your Dexter HMS Panel to connect to the network. This involves setting up the Client ID, User Name, and Password.

STEP 1: Skipping Initial Network Options

Upon entering Network Settings, the display will first show eSIM SETTINGS. Press the > button to skip this option. Subsequently, the next screen will be GNSS SETTINGS. Press > again to bypass this setting.

STEP 2: Accessing Device Credential Settings

The display will now show DEVICE CREDENTIAL. Press **ENTER** to access the credential configuration options.

STEP 3: Setting the Client ID

1. The display will show SET CLIENT ID. Press **ENTER** to begin inputting the Client ID.
2. Press the > button to navigate to the put client id: section, which is the input field.
3. Use the panel's keypad (**0-9, A-F**) to enter the desired Client ID (e.g., RND-Cl4).
4. After entering the ID, press > to move to Update Client [UPDATE].
5. Press > again to confirm and update the Client ID. The display will show EXIT [enter].
6. Press **ENTER** to return to the SET CLIENT ID menu.

STEP 4: Setting the User Name

1. From the SET CLIENT ID screen, press the > button to navigate to set user name. Press **ENTER**.
2. Press > to go to the Put User Name: section.
3. Enter the desired username using the keypad.
4. Press > to reach Update User [UPDATE].
5. Press **ENTER** to confirm the new username.
6. Press > to navigate to Exit enter and then press **ENTER** to return to the set user name menu.

STEP 5: Setting the Password

1. From the set user name screen, press the > button to navigate to set password. Press **ENTER**.
2. The process for setting the password is identical to setting the username. Enter and update the password using the keypad.

3. After updating, exit back to the set password screen.

STEP 6: Exiting Device Credential Configuration

Press the > button to navigate to EXIT[ENTER]. Press **ENTER** on the keypad. The display will now show DEVICE CREDENTIAL, indicating that you have completed the credential setup.

3.2 LAN Setup Configuration

After configuring the device credentials, the next step is to set up the Local Area Network (LAN) settings. This involves configuring various network parameters such as IP address, port number, gateway, and subnet mask.

STEP 1: Accessing LAN Setup

From the DEVICE CREDENTIAL screen, press the > button to navigate to Lan Setup. Press **ENTER** to access the LAN configuration options.

STEP 2: Configuring LAN Parameters

Navigate through the following options by pressing the > button and configure them as needed. For input fields (like IP address, port number, gateway, subnet mask, DNS), the process is similar to setting the username or client ID:

- **LAN led status**: Press > to skip this and go to next.
- **Wireless lan interface**: Press > to skip this and go to next.
- **set Ip address**: Press **ENTER** and use the keypad to configure the IP Address.
- **set port Number**: Configure the port number in the same manner as the IP address.
- **gateway**: Configure the gateway address in the same manner.
- **IP Module**: Press > to skip IP Module and go to next.
- **Subnet Mask**: Configure the subnet mask in the same manner as the IP address.
- **DNS Setup status**: This will show automatic. Press > to continue.
- **APN Settings status**: This will show internet. Press > to continue.
- **Network Test**: Press > skip network test.
- **Interface status**: This will show [IPV4]. Press > to continue.
- **Enable /disable[static]**: Press > to continue.
- **preffered dns**: Set up the preferred DNS like the username.
- **Alternate DNS**: Set up the alternate DNS like the username.
- **DHCP**: This will show [Auto-enable]. Press > to continue.
- **Network Setting**: This will show [Configure]. Press **Enter** (* system will autoreboot) if u want to show ip address , gatway then they can nevigate to next .
- **ip address [N/A]**: This displays the current IP address. Press > to continue.
- **gateway [N/A]**: This displays the current gateway. Press > to continue.

STEP 3: Exiting LAN Setup

After configuring all the necessary LAN parameters, the display will show EXIT Enter. Press **ENTER**. The display will now show Lan setup, indicating that the LAN configuration is complete.

3.3 Navigation to Device Integration

After completing the network settings, you will proceed to the Device Integration section. This final navigation step within the network settings ensures you are ready for the next set of configurations.

STEP 1: Skipping GSM Settings

From Lan setup, press the > button to go to gsm setting. Press > again to skip the GSM settings.

STEP 2: Exiting Network Settings

The display will show exit enter. Press **ENTER**. The display will return to network setting.

STEP 3: Proceeding to Device Integration

Press the > button one last time. The display will now show Device integration, indicating that you are ready to begin configuring integrated devices.

Device Integration Configuration

This section guides you through the process of integrating various devices, such as NVRs and BACS systems, with your Dexter HMS Panel. This process begins from the Device integration menu item.

STEP 1: Accessing Integration Settings

With Device integration displayed on the panel, press **ENTER**. The display will then show Integration settings. Press **ENTER** again to proceed.

STEP 2: Activating Integration

Press the > button to navigate from Passive integer to Active Integer. Once Active Integer is highlighted, press **ENTER**. The display will now show Hikvision Nvr, indicating the first devic

STEP 3: Configuring Integrated Devices

This step involves configuring the IP address, credentials (device name and password), and port for each integrated device. The process is similar for all devices:

3.1 Configure Hikvision NVR

1. Press the > button to cycle through the settings: set ip address, then put nvr ip.
2. Use the keypad (0-9) to enter the IP address for the Hikvision NVR.
3. Press > to navigate to update ip address and press ENTER to confirm the update.
4. Continue pressing > to configure device name and device password in the same manner, pressing ENTER to update each one after inputting the values.
5. After setting the password, press > to navigate to set port number. Configure it using the keypad and then press >.
6. The display will show Exit Enter. Press ENTER to complete the configuration for Hikvision NVR.

3.2 Configure Other Devices

- The display will return to Hikvision Nvr. Press > to move to Hikvision Bacs. Configure it using the same steps as for the Hikvision NVR.
- Press > again to move to Dahua Nvr. Configure it in the same way.

STEP 4: Checking Connection Status

After configuring all integrated devices, press the > button to cycle through the status screens: Hik Nvr status, Dahua Nvr status, and hik bacs status. The status for each device will be displayed as (active / inactive).

STEP 5: Exiting Device Integration

1. Press the > button until the display shows exit enter. Press **ENTER**.
2. The display will return to Active integer. Press > again to get to exit enter and press **ENTER**.
3. The display will return to Integration settings. Press > to navigate past device managementand select exit enter. Press **ENTER**.
4. You are now back at the main device integrationscreen.

Output Management Configuration

This section details the configuration of the relay triggers, which allows you to define actions based on specific events. This section is accessed by navigating back from the Device integration screen.

STEP 1: Navigating to Output Management

1. From the device integrationscreen, press the < button to navigate backwards until the display shows Device Configuration. Press **ENTER**.
2. The display will show Normal zone configuration. Press > to navigate past POWER ZONE CONFIGURATION until you reach output management.
3. Press **ENTER** on output management.

STEP 2: Configuring Relay Triggers

The display shows Relay Confiuration. Press the > button to navigate through the following trigger options. For each option, press **ENTER** to toggle the setting between onand off:

- Action on trigger Press the > button to skip & go next
- clr buffer Press the > button to skip & go next
- Active Intgr on/off Press the > button to go next
- Act INT HV-nvr on/off(Hikvision NVR)
- INT HV-bio on/off (Hikvision Biometrics/BACS)
- act INT du-nvr on/off (Dahua NVR)

STEP 3: Completing Output Management Configuration

After configuring the last item, press the > button to navigate to exit enter. Press **ENTER**. The display will return to output management, and the configuration for this section is complete.

System Settings

This section covers general system-level configurations for your Dexter HMS Panel, including date/time, passwords, and site information.

STEP 1: Exiting Previous Menus

1. Starting from the output managementscreen, press the > button. The display will show exit enter.
2. Press **ENTER**. The display will return to Device configuration.

STEP 2: Accessing System Settings

From Device configuration, press the > button to navigate past power management until the display shows system setting. Press **ENTER** to access the system settings menu.

STEP 3: Configuring General Settings

1. The display shows General setting. Press **ENTER**.
2. Here you can configure the core settings of the panel. Navigate using the < > keys to select an option:

- **Date & Time**
- Press Enter. The display will show Day [1-31]. Enter the day (1-31).
- Press >to go next. The display will show Month [1-12]. Enter the month (1-12).
- Press >to go next. The display will show Year [0-99]. Enter the year (0-99).
- Press >to go next. The display will show Hour [0-23]. Enter the hour (0-23).
- Press >to go next. The display will show Minute [0-59]. Enter the minute (0-59).
- Press >to go next. The display will show Exit[Enter]. Press Enter.
- The display will show Date & Time. Press >to go next. The display will show Password Change. - **Password Change**
  - Press Enter. The display will show Set password user. Press >to go next.
  - The display will show old password. Enter the old password.
  - Press >to go next. The display will show Set Password Service. Press >to go next.
  - The display will show old password. Enter the old password.
  - Press >and the display will show Exit[Enter]. Press Enter.
  - The display will show Password Change. Press >to go next. The display will show Site Name. - **Site Name**
  - Press Enter. The display will show Add Site Name.
  - Press >and the pre-existing brand name will show. You can change it through the keypad on the panel.
  - Press >and the display will show Update Site[UPDATE]. Press Enter to update.
  - Press >and the display will show Exit[Enter]. Press Enter.
  - The display will show Site Name. Press >to go next. The display will show Brand Name. - **Brand Name**
  - This will also be configured as Site Name..

1. Press **ENTER** to select an option and then use the keypad to input the new values.
2. Press **EXIT/ENTER** to save your changes and exit back to the General setting menu.

STEP 4: Skipping Maintenance and Advanced Settings

From General setting, press the > button to navigate through the menus. You will see maintenanace and then Advance settings. Skip Advance settings by pressing >.

STEP 5: Exiting System Settings

The display will show exit enter. Press **ENTER** to return to the main system settings screen.

STEP 6: Optional System Test

Pressing > again will show system test. You can optionally press **ENTER** here to test the lamps, relays, and buzzer to ensure they are functioning correctly.

Device Provisioning

This is the final configuration step, used to provision the Dexter HMS Panel with the service, ensuring it is ready for operation.

STEP 1: Accessing Device Provisioning

From system test, press the > button to navigate past protocol configuration. The display will show device provisioning. Press **ENTER** to access this section.

STEP 2: Configuring SOL ID

1. The display shows sol id. Press **ENTER**.
2. The screen will now show Add sol id. Press the > button to navigate to the sol id: input field.
3. Use the keypad to enter the SOL ID.
4. Press > to move to update sol id [update].
5. Press **ENTER** to confirm the new ID.
6. Press > to navigate to exit enter, then press **ENTER**. The display will return to the sol id screen.

STEP 3: Running Device Provisioning (PVSN)

1. From the sol id screen, press the > button to navigate to Device provisioning. Press **ENTER**.
2. The display now shows Device PVSN. Press **ENTER**.
3. The display will show a please wait message, indicating the provisioning process is underway.
4. After the process completes, the screen will show device provisioning. Press > to find

exit enter, and press 🔘 **ENTER**. **(The device will go to auto reboot)**

STEP 4: Final Exit

1. You are now back in the main Device provisioning menu. Press the 🔘 > button to navigate past ota update.
2. The display will show exit[enter]. Press 🔘 **ENTER**.

✅ Configuration Complete

This completes the full configuration process for the Dexter HMS Panel according to the provided steps. Your panel is now fully installed and configured.