

Northstar Network Operations Manual

System: Atlas Gateway

The Atlas Gateway is the company's internal network gateway. Standard firmware version is 6.4.2. The management interface is available only from the internal administration network.

Restart Procedure

To restart the gateway safely, first confirm that no maintenance operation is active. Open the administration console, select System > Maintenance > Restart, and confirm the restart. A normal restart takes approximately 90 seconds.

Emergency Restart

If the administration console is unavailable, disconnect the gateway's power source for 20 seconds and reconnect it. Emergency restart should only be used when normal restart is unavailable.

Monitoring

A healthy gateway normally reports CPU utilization below 70 percent and memory utilization below 80 percent. Persistent values above these levels should be investigated by the Network Operations team.

Maintenance Window

Routine gateway maintenance is scheduled on Sundays between 02:00 and 04:00 UTC. Changes outside this window require approval from Network Operations.

Escalation

Network outages affecting more than 25 employees should be escalated immediately. The primary escalation team is Network Operations.