

1. Write Test cases on Pen.

TestCaseID	Test Scenario	Test Steps	Test Data	Expected Result	Actual Result	Status
PEN-001	Check pen writes smoothly	1. Open pen cap 2. Write on paper	Blue Ink Pen	Pen should write smoothly	Pen wrote smoothly	Pass
PEN-002	Verify ink flow	1. Write continuously for 2 minutes	Ball Pen	Ink flow should be continuous	Ink flow continuous	Pass
PEN-003	Check cap fitting	1. Close pen cap	Pen with cap	Cap should fit properly	Cap fitted properly	Pass
PEN-004	Check pen grip comfort	1. Hold pen 2. Write for 5 mins	Gel Pen	Grip should be comfortable	Grip comfortable	Pass
PEN-005	Verify refill replacement	1. Replace refill 2. Write	Refill Pen	Pen should work after refill replacement	Pen worked correctly	Pass
PEN-006	Check ink color	1. Write on paper	Black Ink Pen	Ink color should match specification	Ink color matched	Pass
PEN-007	Verify pocket clip strength	1. Attach pen to pocket	Pen with clip	Clip should hold properly	Clip worked correctly	Pass
PEN-008	Check pen without ink	1. Try writing with empty pen	Empty Pen	Pen should not write	Pen did not write	Fail
PEN-009	Check broken pen tip	1. Try writing with damaged tip	Damaged Pen	Writing should not work properly	Writing failed	Fail
PEN-010	Check leaking pen	1. Keep pen upside down 2. Open cap	Leaking Pen	Ink leakage should not occur	Ink leaked	Fail

2. Write Test cases on TV.

TestCaseID	Test Scenario	Test Steps	Test Data	Expected Result	Actual Result	Status
TV-001	Power on TV	1. Press power button	Smart TV	TV should turn on	TV turned on	Pass
TV-002	Check channel switching	1. Change channels using remote	Remote Control	Channels should switch properly	Channels switched properly	Pass
TV-003	Verify volume control	1. Increase/decrease volume	Remote Control	Volume should change correctly	Volume changed correctly	Pass
TV-004	Check HDMI connectivity	1. Connect HDMI cable	HDMI Device	TV should detect HDMI input	HDMI detected	Pass
TV-005	Verify WiFi connection	1. Connect TV to WiFi	WiFi Network	TV should connect to WiFi	Connected successfully	Pass
TV-006	Check display quality	1. Play HD video	HD Video	Display should be clear	Display clear	Pass
TV-007	Verify remote response	1. Press remote buttons	TV Remote	TV should respond properly	TV responded properly	Pass
TV-008	Check TV without power supply	1. Remove power cable 2. Press power button	No Power	TV should not turn on	TV did not turn on	Fail
TV-009	Check damaged screen	1. Turn on TV with cracked screen	Damaged Screen	Display should not function properly	Display distorted	Fail
TV-010	Check invalid remote battery	1. Insert dead batteries 2. Use remote	Dead Batteries	Remote should not work	Remote failed to work	Fail