

BOKARO STEEL PLANT — ILLUSTRATIVE SAMPLE

Standard Operating Procedure

SOP No: BSP-MM-006

Title: Safe Operation of EOT Cranes

Department: Mechanical Maintenance

Revision: 03

Date: 08-Oct-2024

1. PURPOSE

To ensure safe operation of Electric Overhead Travelling (EOT) cranes in all shops.

2. OPERATOR REQUIREMENTS

- Only authorised operators holding a valid crane operator licence (renewed every 3 years)
- Eyesight and medical fitness test every year

3. PRE-SHIFT CHECKS

- Test hoist, cross-travel and long-travel limit switches
- Test brakes of all motions with no load
- Check wire rope for broken wires, kinks or crushing; discard if 10 or more broken wires in one lay length
- Check hook safety latch and horn/siren
- Record checks in the Crane Log Book

4. OPERATING RULES

- Never exceed the Safe Working Load (SWL) marked on the crane
- Lift the load 150 mm first and check the brakes before full lift
- Sound the horn before every movement
- Never carry loads over people
- Follow signals from only one designated signal person, except the STOP signal which must be obeyed from anyone

5. WHEN TO STOP OPERATION

- Wind speed above 50 km/h for outdoor cranes
- Any abnormal noise, brake slip or limit-switch failure

6. EMERGENCY

On power failure with a suspended load, stay in the cabin, warn people below with the horn, and inform the Shift In-charge. Do not attempt to lower the load manually unless trained.