

```

#include <DHT.h>

// Constants
#define DHTPIN 7           // Pin where the DHT sensor is connected
#define DHTTYPE DHT22     // DHT 22 (AM2302)

// Initialize DHT sensor
DHT dht(DHTPIN, DHTTYPE);

// Variables
float hum; // Stores humidity value
float temp; // Stores temperature value

void setup() {
  Serial.begin(9600); // Start the serial communication
  dht.begin();        // Initialize the DHT sensor
}

void loop() {
  delay(2000); // Wait a few seconds between measurements

  // Read humidity and temperature values
  hum = dht.readHumidity();
  temp = dht.readTemperature();

  // Check if any readings failed and exit early (to try again)
  if (isnan(hum) || isnan(temp)) {
    Serial.println("Failed to read from DHT sensor!");
    return;
  }

  // Print temperature and humidity values to the serial monitor
  Serial.print("Humidity: ");
  Serial.print(hum);
  Serial.print(" %, Temp: ");
  Serial.print(temp);
  Serial.println(" °C");

  delay(10000); // Delay 10 seconds before the next reading
}

```