

```

#include <Servo.h>

Servo myServo;          // Create a Servo object
const int servoPin = 9; // Pin connected to the servo signal pin

void setup() {
  Serial.begin(9600);      // Start Serial communication
  myServo.attach(servoPin); // Attach the servo to the specified pin
  Serial.println("Servo motor control via Serial Monitor:");
  Serial.println("Enter an angle between 0 and 180.");
}

void loop() {
  if (Serial.available() > 0) {
    int angle = Serial.parseInt(); // Read angle input from Serial
    Monitor

    // Check if the angle is within the valid range
    if (angle >= 0 && angle <= 180) {
      myServo.write(angle); // Set servo to the specified angle
      Serial.print("Servo moved to: ");
      Serial.print(angle);
      Serial.println(" degrees.");
    } else {
      Serial.println("Invalid input. Please enter an angle between 0 and
180.");
    }
  }
}

```