

Diagram showing the connection between a control system (STYRSYSTEM) and a field (FÄLT).

STYRSYSTEM (Control System):

- SR207-201 KS201-351 DIST. I/O
- EC015
- FABRIKAT: GE POWER
- TYP: SIR 4.35/68
- INSIGNAL: -
- UTSIGNAL: -
- MÄTNMR.: -
- ÖVR. DATA: -
- R4
- FABRIKAT: PHOENIX
- TYP: PSR-PS20-1NO-1NC-24DC-SC
- INSIGNAL: -
- UTSIGNAL: -
- MÄTNMR.: -
- ÖVR. DATA: -

FÄLT (Field):

- ER228-228 -02.G22 STV.-GRUPP
- 400VAC
- L1, L2, L3
- EXT. STOPP
- X1
- 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100
- SK
- FOAR-PG 2x10
- 345EC015
- AXQJ 3x50/15
- W1, W2, W3, W4, W5, W6, W7, W8, W9, W10, W11, W12, W13, W14, W15, W16, W17, W18, W19, W20, W21, W22, W23, W24, W25, W26, W27, W28, W29, W30, W31, W32, W33, W34, W35, W36, W37, W38, W39, W40, W41, W42, W43, W44, W45, W46, W47, W48, W49, W50, W51, W52, W53, W54, W55, W56, W57, W58, W59, W60, W61, W62, W63, W64, W65, W66, W67, W68, W69, W70, W71, W72, W73, W74, W75, W76, W77, W78, W79, W80, W81, W82, W83, W84, W85, W86, W87, W88, W89, W90, W91, W92, W93, W94, W95, W96, W97, W98, W99, W100
- PE
- ETHERNET CAT6
- 345EC015-A1 BL 4 KOMMUNIKATIONSSKÅP