ClickShare REST API

Reference manual

BARCO

Table of contents

1 ClickShare REST API 5
1.1 Documentation for the ClickShare REST API 6

2 Resources 7
2.1 configuration/audio 8
2.2 configuration/buttons 8
2.3 configuration/buttons/connection-method 10
2.4 configuration/buttons/connection-method/network-integration/scep/enrollments 17
2.5 configuration/buttons/identification-method 17
2.6 configuration/buttons/{index} 18
2.7 configuration/configurator 20
2.8 configuration/features/airplay 21
2.9 configuration/features/blackboard 21
2.10 configuration/features/clickshare-app 22
2.11 configuration/features/digital-signage 22
2.12 configuration/features/flexible-room-systems 23
2.13 configuration/features/google-cast 24
2.14 configuration/features/local-view 25
2.15 configuration/features/miracast 25
2.16 configuration/features/remote-pairing 26
2.17 configuration/features/smart-focus 27
2.18 configuration/features/snmp 27
2.19 configuration/features/ultrasound 29
2.20 configuration/features/wired-roomdock 29
2.21 configuration/https 30
2.22 configuration/https/custom-certificates 31
2.23 configuration/https/custom-certificates/last-upload/status 32
2.24 configuration/https/custom-signing-requests 32
2.25 configuration/https/custom-signing-requests/last-upload/status 33
2.26 configuration/input-cards 33
2.27 configuration/input-cards/{index} 34
2.28 configuration/peripherals 35
2.29 configuration/peripherals/{index} 36
2.30 configuration/peripherals/{index}/updates 37
2.31 configuration/personalization 37
2.32 configuration/security 40

2.33 configuration/system/device-identity 41
2.34 configuration/system/logging 42
2.35 configuration/system/network 42
2.36 configuration/system/network/wired/{index} 45
2.37 configuration/system/network/wired/{index}/802dot1xAuthentication/scep/enrollments 52
2.38 configuration/system/network/wireless/{index} 53
2.39 configuration/system/network/wireless/{index}/wireless-client/authentication/scep/enrollments 63
2.40 configuration/system/power-management 63
2.41 configuration/system/software/available/latest 65
2.42 configuration/system/status 65
2.43 configuration/system/time 66
2.44 configuration/system/update-settings 67
2.45 configuration/system/updates 68
2.46 configuration/system/updates/current 69
2.47 configuration/system/updates/next 69
2.48 configuration/troubleshooting/erase-settings 70
2.49 configuration/troubleshooting/factory-reset 70
2.50 configuration/troubleshooting/logs 70
2.51 configuration/users/{username} 70
2.52 configuration/uvc/audio 71
2.53 configuration/uvc/camera 71
2.54 configuration/uvc/video 72
2.55 configuration/video 74
2.56 configuration/video-outputs 75
2.57 configuration/video-outputs/{index} 76
2.58 configuration/wallpapers 78
2.59 configuration/wallpapers/last-upload/status 79
2.60 configuration/wallpapers/selected 80
2.61 configuration/wallpapers/{index} 81
2.62 configuration/warranty 82
2.63 configuration/xml 83
2.64 configuration/xml/full 83
2.65 configuration/xml/portable 83
2.66 configuration/xms 83
2.67 operations/reboot 84
2.68 operations/standby 85
2.69 operations/supported 85
2.70 operations/wakeup 85

ClickShare REST API

1

1.1 Documentation for the ClickShare REST API

Versions

Documentation for each supported version can be accessed at {baseUnitAddress}:4003/api-docs. To get a list of all supported versions of the API for this Base Unit, call {baseUnitAddress}:4003/supportedVersions. To get the latest version, call {baseUnitAddress}:4003/currentVersion. Note that only the major version is required when calling the API endpoints (for example "v2"). The minor version is for informational purposes only. It can be used to identify when a feature was introduced, if your units are not all using the same firmware version.

Authentication

The API endpoints are configured with basic authentication. When executing the example curl commands, an extra parameter `--user` is required. See *the curl man page* for more info on the format of the credentials. Note that curl uses basic authentication by default, so the `--basic` parameter is optional.

Self signed certificate

Before executing the example curl commands, it is recommended to replace the default self-signed certificate with a trusted one to ensure secure HTTPS connections. The API is accessible only over HTTPS, and without replacing the certificate, most tools will raise certificate warnings. While it is possible to bypass these warnings in curl and other tools, using proper certificates is the preferred approach to avoid the need for such configurations.

Subscribing to endpoints (Server-Sent Events)

Instead of continuously polling a resource, one can subscribe to it, in order to lower the bandwidth used. A request can set the request header "accept" to "text/event-stream". This accept type will trigger the unit to keep the connection open. The unit will then send updates whenever the resource gets updated, or every 90 seconds to keep the connection alive. The sent data will be the application/json data, prepended with "data: " and appended with 2 newlines "\n\n". Complete package: "data: {Json data} \n\n"

Resources 2

2.1 configuration/audio

GET

Get the audio settings.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Indicates if the audio is enabled. After this setting is changed, the buttons must be re-paired before the setting becomes active.
`output`	string	The output to be used to play audio. Check supportedOutputs to see which outputs are actually available on the Base Unit.
`supportedOutputs`	array	Example: ['DisplayPort', 'Jack', 'HDMI', 'SPDIF'] read-only

PATCH

Change the audio settings.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Indicates if the audio is enabled. After this setting is changed, the buttons must be re-paired before the setting becomes active.
`output`	string	The output to be used to play audio. Check supportedOutputs to see which outputs are actually available on the Base Unit.
`supportedOutputs`	array	Example: ['DisplayPort', 'Jack', 'HDMI', 'SPDIF'] read-only

Responses	
200	PATCH successful.

2.2 configuration/buttons

GET

Get a list of all paired buttons.

Responses	
200	GET successful.

Response (application/json): object array		
Member	**Type**	**Description**
`connected`	boolean	Indicates if the button is currently connected to this Base Unit.
`connectionCount`	integer (int32)	The number of times this button has been connected to this Base Unit.
`firmwareVersion`	string	The firmware version of the button. Example: 04.05.00
`id`	number	The ID for this button. Example: 1 read-only
`ipAddress`	string (ipv4)	The IP address of the button. Example: 192.168.2.10
`lastConnected`	string (date-time)	The date and time that this button was last connected to this Base Unit. Example: 2019-04-11 19:37:53
`lastPaired`	string (date-time)	The date and time that this button was last paired by this Base Unit. Buttons that have been paired using the Button Manager will give the date and time of the first connection with the Base Unit after pairing. Example: 2019-05-14 16:55:38
`macAddress`	string (mac-address)	The MAC address of the button. Example: 00:11:22:33:44:55
`modelInfo`	string	The model info of the button. Example: GEN4.0 Since version: 2.12 read-only
`productId`	string	The product ID of the button. Example: 0x0114 Since version: 2.17 read-only
`serialNumber`	string	The serial number of the button. Example: 1860000001
`status`	string	The firmware and software status of the button. A value of 'Ok' means that the button firmware and software are up to date. A value of 'Error' means that the button firmware version is probably incompatible with the Base Unit firmware version and needs updating. A value of 'Warning' means that the firmware and software on the button is not the same as the one on the Base Unit, but they should be compatible and updating is not strictly required.
`supportedUsbIdentifierModes`	array	The supported identification modes for the button's serial number.

Response (application/json): object array		
Member	**Type**	**Description**
		Example: ['Default', 'Room'] Since version: 2.16 read-only
usbIdentifierMode	string	The identification mode in use for button's serial number Since version: 2.16 read-only
vendorId	string	The vendor ID of the button. Example: 0x0600 Since version: 2.17 read-only

2.3 configuration/buttons/connection-method

GET

Since version 2.2

Get the buttons connection configuration for network integration feature.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
externalAccessPoint	object	Buttons setting for Network Integration. Since version: 2.2
authentication	object	Settings for 802.1X authentication.
anonymousIdentity	string	Used to select the correct authentication server to process the credentials.
authenticationErrorCode	string	Wired Authentication error code. read-only
authenticationMode	string	The 802.1X mode that is used.
authenticationState	string	Wired Authentication State. read-only
caCertificate	string	
certificates	object	Since version: 2.8 read-only
ca	object	Retrieve information about the ca certificate. Since version: 2.8
commonName	string	Common name of the active certificate.

Response (application/json): object		
Member	**Type**	**Description**
		Example: ClickShare-1862300136 Since version: 2.8
`country`	string	Country of the active certificate. Example: BE Since version: 2.8
`locality`	string	Locality of the active certificate. Since version: 2.8
`notAfter`	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
`notBefore`	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
`organization`	string	Organization of the active certificate. Since version: 2.8
`organizationalUnit`	string	OrganizationalUnit of the active certificate. Since version: 2.8
`serialNumber`	string	SerialNumber of the active certificate. Since version: 2.8
`state`	string	State of the active certificate. Since version: 2.8
`client`	object	Retrieve information about the client certificate. Since version: 2.8
`commonName`	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
`country`	string	Country of the active certificate. Example: BE Since version: 2.8
`locality`	string	Locality of the active certificate. Since version: 2.8
`notAfter`	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
`notBefore`	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
`organization`	string	Organization of the active certificate. Since version: 2.8

Response (application/json): object		
Member	**Type**	**Description**
organizationalUnit	string	OrganizationalUnit of the active certificate. Since version: 2.8
serialNumber	string	SerialNumber of the active certificate. Since version: 2.8
state	string	State of the active certificate. Since version: 2.8
clientCertificate	string	
clientCertificatePassword	string (pass-word)	The password for the client certificate. Since version: 2.2 write-only
domain	string	The domain used for connections in PEAP and EAP-TTLS mode. Example: barco.com
eapIdentity	string	The identity used for connections in PEAP and EAP-TTLS mode.
eapPassword	string (pass-word)	The password used for connections in PEAP and EAP-TTLS mode. write-only
enabled	boolean	Indicates if the 802.1X Authentication is enabled.
passPhrase	string	Pass Phrase for WPA2-PSK authentication Example: passphrase Since version: 2.2 write-only
scep	object	The SCEP settings that are used for EAP_TLS mode with automatic enrollment.
challenge	string	Challenge token to prevent revocation by user without token. This token is only used when type is SCEP. Since version: 2.8 write-only
city	string	Additional information about the city. This parameter is optional. Since version: 2.8
commonName	string	Optional custom common name for the client certificate. By default the BaseUnit's hostname will be used. Example: ClickShare-3083543628.barco.com Since version: 2.8
country	string	Additional information about the country. This parameter is optional. Since version: 2.8
department	string	Additional information about the department. This parameter is optional.

Response (application/json): object		
Member	**Type**	**Description**
		Since version: 2.8
`enabled`	boolean	
`organisation`	string	Additional information about the organisation. This parameter is optional. Since version: 2.8
`password`	string	Password parameter is needed for NDES. write-only
`serverType`	string	SCEP RFC is an open source Linux certificate protocol. NDES is a certificate protocol developed by Microsoft. Before REST API v2.8 NDES was referred to as SCEP enrollment Since version: 2.8
`serverUrl`	string	The SCEP server to contact. Only http is currently supported. For NDES, you can omit the default /CertSrv/mscep/ path. Example: http://barco.com/scep
`state`	string	Additional information about the state. This parameter is optional. Since version: 2.8
`supportedServerTypes`	array	Since version: 2.8 read-only
`username`	string	Username parameter is needed for NDES.
`supportedAuthenticationModes`	array	The different supported authentication modes. Example: ['None', 'PEAP', 'WPA2-PSK'] read-only
`ssid`	string	The public name (SSID) for the wireless network of the Base Unit. Example: Clickshare-0123456789 Since version: 2.2
`operationMode`	string	Button connection mode to Base unit. Since version: 2.2
`supportedOperationModes`	array	Example: ['InternalAccessPoint', 'ExternalAccessPoint'] Since version: 2.2 read-only

PATCH

Since version 2.2

Change the buttons connection configuration for network integration feature.

Request body (application/json): object		
Member	**Type**	**Description**
externalAccessPoint	object	Buttons setting for Network Integration. Since version: 2.2
authentication	object	Settings for 802.1X authentication.
anonymousIdentity	string	Used to select the correct authentication server to process the credentials.
authenticationErrorCode	string	Wired Authentication error code. read-only
authenticationMode	string	The 802.1X mode that is used.
authenticationState	string	Wired Authentication State. read-only
caCertificate	string	
certificates	object	Since version: 2.8 read-only
ca	object	Retrieve information about the ca certificate. Since version: 2.8
commonName	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
country	string	Country of the active certificate. Example: BE Since version: 2.8
locality	string	Locality of the active certificate. Since version: 2.8
notAfter	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
notBefore	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
organization	string	Organization of the active certificate. Since version: 2.8
organizationalUnit	string	OrganizationalUnit of the active certificate. Since version: 2.8
serialNumber	string	SerialNumber of the active certificate. Since version: 2.8
state	string	State of the active certificate. Since version: 2.8
client	object	Retrieve information about the client certificate.

Request body (application/json): object		
Member	**Type**	**Description**
		Since version: 2.8
commonName	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
country	string	Country of the active certificate. Example: BE Since version: 2.8
locality	string	Locality of the active certificate. Since version: 2.8
notAfter	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
notBefore	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
organization	string	Organization of the active certificate. Since version: 2.8
organizationalUnit	string	OrganizationalUnit of the active certificate. Since version: 2.8
serialNumber	string	SerialNumber of the active certificate. Since version: 2.8
state	string	State of the active certificate. Since version: 2.8
clientCertificate	string	
clientCertificatePassword	string (pass-word)	The password for the client certificate. Since version: 2.2 write-only
domain	string	The domain used for connections in PEAP and EAP-TTLS mode. Example: barco.com
eapIdentity	string	The identity used for connections in PEAP and EAP-TTLS mode.
eapPassword	string (pass-word)	The password used for connections in PEAP and EAP-TTLS mode. write-only
enabled	boolean	Indicates if the 802.1X Authentication is enabled.
passPhrase	string	Pass Phrase for WPA2-PSK authentication Example: passphrase Since version: 2.2 write-only

Request body (application/json): object		
Member	**Type**	**Description**
`scep`	object	The SCEP settings that are used for EAP_TLS mode with automatic enrollment.
`challenge`	string	Challenge token to prevent revocation by user without token. This token is only used when type is SCEP. Since version: 2.8 write-only
`city`	string	Additional information about the city. This parameter is optional. Since version: 2.8
`commonName`	string	Optional custom common name for the client certificate. By default the BaseUnit's hostname will be used. Example: ClickShare-3083543628.barco.com Since version: 2.8
`country`	string	Additional information about the country. This parameter is optional. Since version: 2.8
`department`	string	Additional information about the department. This parameter is optional. Since version: 2.8
`enabled`	boolean	
`organisation`	string	Additional information about the organisation. This parameter is optional. Since version: 2.8
`password`	string	Password parameter is needed for NDES. write-only
`serverType`	string	SCEP RFC is an open source Linux certificate protocol. NDES is a certificate protocol developed by Microsoft. Before REST API v2.8 NDES was referred to as SCEP enrollment Since version: 2.8
`serverUrl`	string	The SCEP server to contact. Only http is currently supported. For NDES, you can omit the default /CertSrv/mscep/ path. Example: http://barco.com/scep
`state`	string	Additional information about the state. This parameter is optional. Since version: 2.8
`supportedServerTypes`	array	Since version: 2.8 read-only
`username`	string	Username parameter is needed for NDES.
`supportedAuthenticationModes`	array	The different supported authentication modes. Example: ['None', 'PEAP', 'WPA2-PSK']

Request body (application/json): object		
Member	**Type**	**Description**
		read-only
`ssid`	string	The public name (SSID) for the wireless network of the Base Unit. Example: Clickshare-0123456789 Since version: 2.2
`operationMode`	string	Button connection mode to Base unit. Since version: 2.2
`supportedOperationModes`	array	Example: ['InternalAccessPoint', 'ExternalAccessPoint'] Since version: 2.2 read-only

Responses	
200	PATCH successful.

2.4 configuration/buttons/connection-method/network-integration/scep/enrollments

POST

Since version 2.2

Starting the SCEP enrollment.

Responses	
202	SCEP enrollment started.

2.5 configuration/buttons/identification-method

GET

Since version 2.16

Get the button identification configuration for the serial number.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`identificationMode`	string	USB identification mode of the ClickShare Button. Since version: 2.16
`supportedIdentificationModes`	array	Example: ['ClickShareDefault', 'UniquePerMeetingRoom'] Since version: 2.16 read-only

PATCH

Since version 2.16

Change the button identification configuration for the serial number.

Request body (application/json): object		
Member	**Type**	**Description**
`identificationMode`	string	USB identification mode of the ClickShare Button. Since version: 2.16
`supportedIdentificationModes`	array	Example: ['ClickShareDefault', 'UniquePerMeetingRoom'] Since version: 2.16 read-only

Responses	
200	PATCH successful.

2.6 configuration/buttons/{index}

GET

Get information about a paired button.

Responses	
200	GET successful.
404	Resource does not exist.

Response (application/json): object		
Member	**Type**	**Description**
`connected`	boolean	Indicates if the button is currently connected to this Base Unit.
`connectionCount`	integer (int32)	The number of times this button has been connected to this Base Unit.
`firmwareVersion`	string	The firmware version of the button. Example: 04.05.00

Response (application/json): object		
Member	**Type**	**Description**
`id`	number	The ID for this button. Example: 1 read-only
`ipAddress`	string (ipv4)	The IP address of the button. Example: 192.168.2.10
`lastConnected`	string (date-time)	The date and time that this button was last connected to this Base Unit. Example: 2019-04-11 19:37:53
`lastPaired`	string (date-time)	The date and time that this button was last paired by this Base Unit. Buttons that have been paired using the Button Manager will give the date and time of the first connection with the Base Unit after pairing. Example: 2019-05-14 16:55:38
`macAddress`	string (mac-address)	The MAC address of the button. Example: 00:11:22:33:44:55
`modelInfo`	string	The model info of the button. Example: GEN4.0 Since version: 2.12 read-only
`productId`	string	The product ID of the button. Example: 0x0114 Since version: 2.17 read-only
`serialNumber`	string	The serial number of the button. Example: 1860000001
`status`	string	The firmware and software status of the button. A value of 'Ok' means that the button firmware and software are up to date. A value of 'Error' means that the button firmware version is probably incompatible with the Base Unit firmware version and needs updating. A value of 'Warning' means that the firmware and software on the button is not the same as the one on the Base Unit, but they should be compatible and updating is not strictly required.
`supportedUsbIdentifierModes`	array	The supported identification modes for the button's serial number. Example: ['Default', 'Room'] Since version: 2.16 read-only

Response (application/json): object		
Member	**Type**	**Description**
`usbIdentifierMode`	string	The identification mode in use for button's serial number Since version: 2.16 read-only
`vendorId`	string	The vendor ID of the button. Example: 0x0600 Since version: 2.17 read-only

DELETE

Remove a paired button from the collection.

Responses	
204	DELETE successful.
404	Resource does not exist.

2.7 configuration/configurator

GET

Get the Configurator (web UI) settings.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabledOverWiFi`	boolean	Indicates if the Configurator (the web interface) can be accessed via the wireless interface.

PATCH

Change the Configurator (web UI) settings.

Request body (application/json): object		
Member	**Type**	**Description**
`enabledOverWiFi`	boolean	Indicates if the Configurator (the web interface) can be accessed via the wireless interface.

Responses	
200	PATCH successful.

2.8 configuration/features/airplay

GET

Get the settings for the AirPlay functionality.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of AirPlay.

PATCH

Change the AirPlay settings.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of AirPlay.

Responses	
200	PATCH successful.

2.9 configuration/features/blackboard

GET

Get the settings for the blackboarding and annotation functionalities.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Allow the clients to enable blackboarding and annotations. Since version: 2.8
`savingEnabled`	boolean	Allow the clients and plugged in drives to save annotations.

PATCH

Change the blackboard settings.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Allow the clients to enable blackboarding and annotations. Since version: 2.8
`savingEnabled`	boolean	Allow the clients and plugged in drives to save annotations.

Responses	
200	PATCH successful.

2.10 configuration/features/clickshare-app

GET

Get the settings for the ClickShare App functionality.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	read-only

2.11 configuration/features/digital-signage

GET

Since version 2.16

Get the settings for Digital Signage.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Use digital signage instead of the wallpaper. Since version: 2.16
`url`	string (uri)	URL of the Digital Signage content provider (only https is supported). Example: https://digitalsignage.barco.com Since version: 2.16

PATCH

Since version 2.16

Change the settings for Digital Signage.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Use digital signage instead of the wallpaper. Since version: 2.16
`url`	string (uri)	URL of the Digital Signage content provider (only https is supported). Example: https://digitalsignage.barco.com Since version: 2.16

Responses	
200	PATCH successful.

2.12 configuration/features/flexible-room-systems

GET

Since version 2.13

Get the settings for the Flexible Room Systems functionality.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of Flexible Room Systems. Since version: 2.13
`peripheralsInUse`	boolean	If 'true' peripherals are used by the Room System. If 'false' peripherals are used by ClickShare. Since version: 2.13 read-only
`roomSystemType`	string	The type of flexible meeting room system to be used if the feature is 'enabled'. Since version: 2.13
`supported`	boolean	Indicates whether Flexible Meeting Room is supported for this device. Since version: 2.16 read-only
`supportedRoomSystemTypes`	array	Example: ['CollaborationBar', 'ModularSetup'] Since version: 2.13 read-only

PATCH

Since version 2.13

Change the Flexible Room Systems settings.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of Flexible Room Systems. Since version: 2.13
`peripheralsInUse`	boolean	If 'true' peripherals are used by the Room System. If 'false' peripherals are used by ClickShare. Since version: 2.13 read-only
`roomSystemType`	string	The type of flexible meeting room system to be used if the feature is 'enabled'. Since version: 2.13
`supported`	boolean	Indicates whether Flexible Meeting Room is supported for this device. Since version: 2.16 read-only
`supportedRoomSystemTypes`	array	Example: ['CollaborationBar', 'ModularSetup'] Since version: 2.13 read-only

Responses	
200	PATCH successful.

2.13 configuration/features/google-cast

GET

Get the settings for the GoogleCast functionality.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of GoogleCast.

PATCH

Change the GoogleCast settings.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of GoogleCast.

Responses	
200	PATCH successful.

2.14 configuration/features/local-view

GET

Since version 2.16

Get the current state for Local View.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Indicates if Local View is enabled or not. Since version: 2.16
`supported`	boolean	Shows whether or not Local View is supported for this device. Since version: 2.16 read-only

PATCH

Since version 2.16

Enable or disable Local View.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Indicates if Local View is enabled or not. Since version: 2.16
`supported`	boolean	Shows whether or not Local View is supported for this device. Since version: 2.16 read-only

Responses	
200	PATCH successful.

2.15 configuration/features/miracast

GET

Get the settings for the Miracast functionality.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of Miracast.

PATCH

Change the Miracast settings.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of Miracast.

Responses	
200	PATCH successful.

2.16 configuration/features/remote-pairing

GET

Get the settings for the remote pairing service.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Enable the remote button pairing service.
`password`	string (pass-word)	Remote button pairing password. write-only

PATCH

Change the settings for the remote pairing service.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Enable the remote button pairing service.
`password`	string (pass-word)	Remote button pairing password. write-only

Responses	
200	PATCH successful.

2.17 configuration/features/smart-focus

GET

Since version 2.18

Get the current state for SmartFocus.

Responses	
410	Resource is gone.

PATCH

Since version 2.18

Enable or disable SmartFocus.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Indicates if SmartFocus is enabled or not. Since version: 2.18

Responses	
410	Resource is gone.

2.18 configuration/features/snmp

GET

Since version 2.8

Get the SNMP settings.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Indicates whether the SNMP functionality is enabled or disabled. This parameter can be changed in order to enable or disable the SNMP functionality. Since version: 2.8
`engineId`	string	Unique SNMP identification for the baseunit. Since version: 2.8
`managerAddress`	string	Determines the TCP/IP (IPv4) address or hostname of the host where the SNMP network manager is initialized. The Traps will be sent to this address. Example: snpm.barco.com Since version: 2.8

Response (application/json): object		
Member	**Type**	**Description**
`password`	string (pass-word)	The password used for SNMP authentication and encrypted requests. Since version: 2.8 write-only
`useDefaultEngineId`	boolean	Since version: 2.9
`username`	string	The username used for SNMP authentication and encrypted requests. Since version: 2.8 write-only

PATCH

Since version 2.8

Change the SNMP settings.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Indicates whether the SNMP functionality is enabled or disabled. This parameter can be changed in order to enable or disable the SNMP functionality. Since version: 2.8
`engineId`	string	Unique SNMP identification for the baseunit. Since version: 2.8
`managerAddress`	string	Determines the TCP/IP (IPv4) address or hostname of the host where the SNMP network manager is initialized. The Traps will be sent to this address. Example: snpm.barco.com Since version: 2.8
`password`	string (pass-word)	The password used for SNMP authentication and encrypted requests. Since version: 2.8 write-only
`useDefaultEngineId`	boolean	Since version: 2.9
`username`	string	The username used for SNMP authentication and encrypted requests. Since version: 2.8 write-only

Responses	
200	PATCH successful.

2.19 configuration/features/ultrasound

GET

Since version 2.4

Get the settings for the Ultrasound functionality.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of Ultrasound. Since version: 2.4
`signalStrength`	string	Ultrasound Signal Strength. Since version: 2.4

PATCH

Since version 2.4

Change the Ultrasound settings.

Request body (application/json): object		
Member	**Type**	**Description**
`enabled`	boolean	Status of Ultrasound. Since version: 2.4
`signalStrength`	string	Ultrasound Signal Strength. Since version: 2.4

Responses	
200	PATCH successful.

2.20 configuration/features/wired-roomdock

GET

Since version 2.10

Get the current state for Wired RoomDock.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`connected`	boolean	Displays the current Wired RoomDock status. Since version: 2.10 read-only
`enabled`	boolean	Indicates if Wired RoomDock is enabled or not. Since version: 2.10
`supported`	boolean	Shows whether or not Wired RoomDock is supported for this device. Since version: 2.10 read-only

PATCH

Since version 2.10

Enable or disable Wired RoomDock.

Request body (application/json): object		
Member	**Type**	**Description**
`connected`	boolean	Displays the current Wired RoomDock status. Since version: 2.10 read-only
`enabled`	boolean	Indicates if Wired RoomDock is enabled or not. Since version: 2.10
`supported`	boolean	Shows whether or not Wired RoomDock is supported for this device. Since version: 2.10 read-only

Responses	
200	PATCH successful.

2.21 configuration/https

GET

Since version 2.8

Get the HTTPS configuration information.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`certificateChain`	object	Information about the active certificate. read-only
`serverCertificateInfo`	array	Information about the active certificate. Since version: 2.8
`certificateType`	string	Shows the certificate type Since version: 2.8
`supportedCertificateTypes`	string	Since version: 2.8 read-only

PATCH

Since version 2.8

Change the HTTPS encryption settings.

Request body (application/json): object		
Member	**Type**	**Description**
`certificateChain`	object	Information about the active certificate. read-only
`serverCertificateInfo`	array	Information about the active certificate. Since version: 2.8
`certificateType`	string	Shows the certificate type Since version: 2.8
`supportedCertificateTypes`	string	Since version: 2.8 read-only

Responses	
200	PATCH successful.
400	The 'certificateType' parameter should be self-signed.

2.22 configuration/https/custom-certificates

POST

Since version 2.8

Upload a custom certificate.

Request body (application/json): object		
Member	**Type**	**Description**
`passphrase`	string (pass-word)	
`url`	string	

Responses	
202	Uploading of Custom Certificate started.
400	The 'url' parameter is not valid. The passphrase is incorrect.

2.23 configuration/https/custom-certificates/last-upload/status

GET

Since version 2.8

Get the custom-certificates information.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`status`	string	Status of the uploaded custom certificate. Since version: 2.8

2.24 configuration/https/custom-signing-requests

POST

Since version 2.8

Generate CSR.

Request body (application/json): object		
Member	**Type**	**Description**
`city`	string	
`country`	string	
`department`	string	
`domainName`	string	

Request body (application/json): object		
Member	**Type**	**Description**
`organization`	string	
`state`	string	

Responses	
303	Redirect.

2.25 configuration/https/custom-signing-requests/last-upload/status

GET

Since version 2.8

Get the custom-signing-requests information.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`message`	string	Message from CSR generation. Since version: 2.8
`status`	string	Status from the Certificate Signing Request generation. Since version: 2.8

2.26 configuration/input-cards

GET

Get the input card (HDMI or DisplayPort) settings if available on the platform.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`inputs`	array	read-only

2.27 configuration/input-cards/{index}

GET

Get the input card with a specified ID.

Responses	
200	GET successful.
404	Resource does not exist.

Response (application/json): object

Member	Type	Description
`enabled`	boolean	Indicates if the input is enabled.
`hasInvalidSignal`	boolean	Indicates if the input has an invalid signal (e.g. no DisplayPort signal in case of a usb-c input). Since version: 2.11 read-only
`hasSignal`	boolean	Indicates if the input has signal. read-only
`id`	number	The ID for this input. read-only
`sourceName`	string	The name of the source displayed when sharing. Example: HDMI-0

PATCH

Change the input card with a specified ID.

Request body (application/json): object

Member	Type	Description
`enabled`	boolean	Indicates if the input is enabled.
`hasInvalidSignal`	boolean	Indicates if the input has an invalid signal (e.g. no DisplayPort signal in case of a usb-c input). Since version: 2.11 read-only
`hasSignal`	boolean	Indicates if the input has signal. read-only
`id`	number	The ID for this input. read-only
`sourceName`	string	The name of the source displayed when sharing. Example: HDMI-0

Responses	
200	PATCH successful.

2.28 configuration/peripherals

GET

Get the list of (USB) peripherals.

Responses	
200	GET successful.

Response (application/json): object array		
Member	**Type**	**Description**
`cameras`	array	read-only
`combinedRevision`	number (float)	Sum of the binary-coded decimal revisions of the individual peripherals. For example, if the revision for camera, microphone and speaker are 2.1, 2.2 and 2.3, then the combinedRevision will be 6.6. Since version: 2.15 read-only
`id`	integer	read-only
`microphones`	array	read-only
`name`	string	read-only
`pluggedIn`	boolean	read-only
`serialNumber`	string	See the serial number of the individual camera, microphone or speaker instead read-only
`speakers`	array	read-only
`touchscreens`	array	Since version: 2.6 read-only
`usbSignature`	string	Unique peripheral identifier constructed by VID followed by all PIDs in sorted order Example: 1234:0001-0002-0003 Since version: 2.15 read-only
`vendor`	string	read-only
`vendorId`	string	Since version: 2.11 read-only
`version`	string	Firmware version of the peripheral. Since version: 2.7 read-only

2.29 configuration/peripherals/{index}

GET

Get the peripheral with a specified ID.

Responses	
200	GET successful.
404	Resource does not exist.

Response (application/json): object

Member	Type	Description
`cameras`	array	read-only
`combinedRevision`	number (float)	Sum of the binary-coded decimal revisions of the individual peripherals. For example, if the revision for camera, microphone and speaker are 2.1, 2.2 and 2.3, then the combinedRevision will be 6.6. Since version: 2.15 read-only
`id`	integer	read-only
`microphones`	array	read-only
`name`	string	read-only
`pluggedIn`	boolean	read-only
`serialNumber`	string	See the serial number of the individual camera, microphone or speaker instead read-only
`speakers`	array	read-only
`touchscreens`	array	Since version: 2.6 read-only
`usbSignature`	string	Unique peripheral identifier constructed by VID followed by all PIDs in sorted order Example: 1234:0001-0002-0003 Since version: 2.15 read-only
`vendor`	string	read-only
`vendorId`	string	Since version: 2.11 read-only
`version`	string	Firmware version of the peripheral. Since version: 2.7 read-only

2.30 configuration/peripherals/{index}/updates

POST

Since version 2.8

Start a new peripheral firmware update.

Responses	
202	Firmware update started.
400	Peripheral does not support updating.
404	1. Peripheral is not attached. 2. ID is invalid.

2.31 configuration/personalization

GET

Get the personalization settings.

Responses	
200	GET successful.

Response (application/json): object

Member	Type	Description
`language`	string	The language that will be used for all on-screen messages and the ClickShare Instructions wallpaper. The possible values can be retrieved using the supportedLanguages parameter. Example: English
`location`	string	The meeting room location that may be displayed. Example: South
`meetingRoomName`	string	The meeting room name that may be displayed. Example: MR Antarctica
`screenIdOverlay`	string	Choose how to display the status information: Standard (in the Floating Box) or Small (in the bottom Status Bar). Since version: 2.15
`screensaver`	object	The settings related to the screensaver.
`mode`	string	Example: HDMI Since version: 2.10
`state`	boolean	Indicates if the screensaver is currently active or not. Since version: 2.10 read-only

Response (application/json): object		
Member	**Type**	**Description**
`supportedModes`	array	The supported screensaver modes. Example: ['Default', 'DisplayPort', 'HDMI'] Since version: 2.10 read-only
`supportedTimeouts`	array	The supported values for the timeout. Example: ['Infinite', '10', '60'] read-only
`timeout`	string	The period of inactivity in minutes after which the screen saver starts. If this parameter is set to 'Infinite', the screen saver is disabled. Otherwise, the value should be smaller than the value specified in 'standbyTimeout'. The supported values are in the supportedTimeouts field. Example: Infinite
`showNetworkInfo`	boolean	Shows network information on display. Since version: 2.1
`showWallpaper`	boolean	Shows wallpaper information on display. Since version: 2.8
`supportedLanguages`	array	The list of possible values that can be used for the 'language' parameter. Example: ['English', 'Dutch'] read-only
`supportedScreenIdOverlays`	array	Supported overlays for status information. Example: ['Standard', 'Small'] Since version: 2.15 read-only
`theaterMode`	object	
`enabled`	boolean	Enable the TheaterMode, hiding the statusbar when sharing. Since version: 2.4
`welcomeMessage`	string	The welcome message that may be displayed. Example: Welcome to Antarctica

PATCH

Change the personalization settings.

Request body (application/json): object		
Member	**Type**	**Description**
`language`	string	The language that will be used for all on-screen messages and the ClickShare Instructions wallpaper. The possible values can be retrieved using the supportedLanguages parameter. Example: English
`location`	string	The meeting room location that may be displayed. Example: South
`meetingRoomName`	string	The meeting room name that may be displayed. Example: MR Antarctica
`screenIdOverlay`	string	Choose how to display the status information: Standard (in the Floating Box) or Small (in the bottom Status Bar). Since version: 2.15
`screensaver`	object	The settings related to the screensaver.
`mode`	string	Example: HDMI Since version: 2.10
`state`	boolean	Indicates if the screensaver is currently active or not. Since version: 2.10 read-only
`supportedModes`	array	The supported screensaver modes. Example: ['Default', 'DisplayPort', 'HDMI'] Since version: 2.10 read-only
`supportedTimeouts`	array	The supported values for the timeout. Example: ['Infinite', '10', '60'] read-only
`timeout`	string	The period of inactivity in minutes after which the screen saver starts. If this parameter is set to 'Infinite', the screen saver is disabled. Otherwise, the value should be smaller than the value specified in 'standbyTimeout'. The supported values are in the supportedTimeouts field. Example: Infinite
`showNetworkInfo`	boolean	Shows network information on display. Since version: 2.1
`showWallpaper`	boolean	Shows wallpaper information on display. Since version: 2.8
`supportedLanguages`	array	The list of possible values that can be used for the 'language' parameter. Example: ['English', 'Dutch'] read-only

Request body (application/json): object		
Member	**Type**	**Description**
`supportedScreenIdOverlays`	array	Supported overlays for status information. Example: ['Standard', 'Small'] Since version: 2.15 read-only
`theaterMode`	object	
`enabled`	boolean	Enable the TheaterMode, hiding the statusbar when sharing. Since version: 2.4
`welcomeMessage`	string	The welcome message that may be displayed. Example: Welcome to Antarctica

Responses	
200	PATCH successful.

2.32 configuration/security

GET

Get the security settings.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`eepromIntegrityCheck`	boolean	Integrity check status of the EEPROM Since version: 2.7 read-only
`level`	integer	The security level. 1 is the lowest, 3 is the highest. Example: 1
`passcodeType`	string	The type of passcode.
`supportedPasscodeTypes`	array	The supported passcode types. Example: ['NoPasscode', 'NumericPasscode'] read-only

PATCH

Change the security settings.

Request body (application/json): object		
Member	**Type**	**Description**
`eepromIntegrityCheck`	boolean	Integrity check status of the EEPROM Since version: 2.7 read-only
`level`	integer	The security level. 1 is the lowest, 3 is the highest. Example: 1
`passcodeType`	string	The type of passcode.
`supportedPasscodeTypes`	array	The supported passcode types. Example: ['NoPasscode', 'NumericPasscode'] read-only

Responses	
200	PATCH successful.

2.33 configuration/system/device-identity

GET

Get information about the Base Unit.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`articleNumber`	string	The Barco article number of this Base Unit. Example: R9861511EU
`hardwareVersion`	string	The hardware version of this Base Unit. It will be empty for first generation cx devices and "2.0" for next gen devices. Note that this is shown as Gen2 in the ClickShare Configurator. Example: 2.0 Since version: 2.5
`modelName`	string	The model (now called platform) name of this Base Unit. Cfr 'platform' in the ClickShare Configurator. Example: C3010S
`productName`	string	The product (now called model) name of this Base Unit. Cfr 'model' in the ClickShare Configurator. Example: CX-30
`serialNumber`	string	The serial number of this Base Unit. Example: 1234567890

2.34 configuration/system/logging

GET

Get the logging settings.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`level`	string	Indicates the level of logging.
`supportedLevels`	array	Example: ['Debug', 'Info', 'Warning', 'Error', 'Critical'] read-only

PATCH

Change the logging settings.

Request body (application/json): object		
Member	**Type**	**Description**
`level`	string	Indicates the level of logging.
`supportedLevels`	array	Example: ['Debug', 'Info', 'Warning', 'Error', 'Critical'] read-only

Responses	
200	PATCH successful.

2.35 configuration/system/network

GET

Get the network settings.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`hostname`	string	The hostname of the Base Unit. Hostnames are human-readable nicknames that correspond to the address of a device connected to a network. Example: ClickShare-1234567890
`services`	object	

Response (application/json): object		
Member	**Type**	**Description**
`dhcpServer`	object	
`domainName`	string	Indicates the domain name given to the DHCP leases. Example: clickshare read-only
`leases`	array	The DHCP leases. read-only
`leaseTime`	integer	Number of seconds the leases are valid. read-only
`maxAddress`	string (ipv4)	Highest IP address of the range used by the DHCP server. Example: 192.168.2.254 read-only
`minAddress`	string (ipv4)	Lowest IP address of the range used by the DHCP server. Example: 192.168.2.2 read-only
`subnetMask`	string (ipv4)	The subnet mask for IP leases. Example: 255.255.255.0
`proxy`	object	
`enabled`	boolean	Indicates if the proxy server is enabled or disabled.
`password`	string (pass-word)	The password for the proxy server. write-only
`serverAddress`	string (ipv4)	IP address of the proxy server. Example: 10.11.0.15
`serverPort`	integer	Port number of the proxy number. Example: 80
`username`	string	The username for the proxy server.
`wired`	array	read-only
`wireless`	array	read-only

PATCH

Change the network settings.

Request body (application/json): object		
Member	**Type**	**Description**
`hostname`	string	The hostname of the Base Unit. Hostnames are human-readable nicknames that correspond to the address of a device connected to a network. Example: ClickShare-1234567890
`services`	object	
`dhcpServer`	object	
`domainName`	string	Indicates the domain name given to the DHCP leases. Example: clickshare read-only
`leases`	array	The DHCP leases. read-only
`leaseTime`	integer	Number of seconds the leases are valid. read-only
`maxAddress`	string (ipv4)	Highest IP address of the range used by the DHCP server. Example: 192.168.2.254 read-only
`minAddress`	string (ipv4)	Lowest IP address of the range used by the DHCP server. Example: 192.168.2.2 read-only
`subnetMask`	string (ipv4)	The subnet mask for IP leases. Example: 255.255.255.0
`proxy`	object	
`enabled`	boolean	Indicates if the proxy server is enabled or disabled.
`password`	string (pass-word)	The password for the proxy server. write-only
`serverAddress`	string (ipv4)	IP address of the proxy server. Example: 10.11.0.15
`serverPort`	integer	Port number of the proxy number. Example: 80
`username`	string	The username for the proxy server.
`wired`	array	read-only
`wireless`	array	read-only

Responses	
200	PATCH successful.

2.36 configuration/system/network/wired/{index}

GET

Get settings for the LAN with the specified ID.

Responses	
200	GET successful.
404	Resource does not exist.

Response (application/json): object		
Member	**Type**	**Description**
`802dot1xAuthentication`	object	Settings for 802.1X authentication.
`anonymousIdentity`	string	Used to select the correct authentication server to process the credentials.
`authenticationErrorCode`	string	Wired Authentication error code. read-only
`authenticationMode`	string	The 802.1X mode that is used.
`authenticationState`	string	Wired Authentication State. read-only
`caCertificate`	string	
`certificates`	object	Since version: 2.8 read-only
`ca`	object	Retrieve information about the ca certificate. Since version: 2.8
`commonName`	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
`country`	string	Country of the active certificate. Example: BE Since version: 2.8
`locality`	string	Locality of the active certificate. Since version: 2.8
`notAfter`	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
`notBefore`	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24

Response (application/json): object		
Member	**Type**	**Description**
		Since version: 2.8
organization	string	Organization of the active certificate. Since version: 2.8
organizationalUnit	string	OrganizationalUnit of the active certificate. Since version: 2.8
serialNumber	string	SerialNumber of the active certificate. Since version: 2.8
state	string	State of the active certificate. Since version: 2.8
client	object	Retrieve information about the client certificate. Since version: 2.8
commonName	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
country	string	Country of the active certificate. Example: BE Since version: 2.8
locality	string	Locality of the active certificate. Since version: 2.8
notAfter	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
notBefore	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
organization	string	Organization of the active certificate. Since version: 2.8
organizationalUnit	string	OrganizationalUnit of the active certificate. Since version: 2.8
serialNumber	string	SerialNumber of the active certificate. Since version: 2.8
state	string	State of the active certificate. Since version: 2.8
clientCertificate	string	
clientCertificatePassword	string (pass-word)	The password for the client certificate. Since version: 2.2 write-only
domain	string	The domain used for connections in PEAP and EAP-TTLS mode.

Response (application/json): object		
Member	**Type**	**Description**
		Example: barco.com
`eapIdentity`	string	The identity used for connections in PEAP and EAP-TTLS mode.
`eapPassword`	string (pass-word)	The password used for connections in PEAP and EAP-TTLS mode. write-only
`enabled`	boolean	Indicates if the 802.1X Authentication is enabled.
`passPhrase`	string	Pass Phrase for WPA2-PSK authentication Example: passphrase Since version: 2.2 write-only
`scep`	object	The SCEP settings that are used for EAP_TLS mode with automatic enrollment.
`challenge`	string	Challenge token to prevent revocation by user without token. This token is only used when type is SCEP. Since version: 2.8 write-only
`city`	string	Additional information about the city. This parameter is optional. Since version: 2.8
`commonName`	string	Optional custom common name for the client certificate. By default the BaseUnit's hostname will be used. Example: ClickShare-3083543628.barco.com Since version: 2.8
`country`	string	Additional information about the country. This parameter is optional. Since version: 2.8
`department`	string	Additional information about the department. This parameter is optional. Since version: 2.8
`enabled`	boolean	
`organisation`	string	Additional information about the organisation. This parameter is optional. Since version: 2.8
`password`	string	Password parameter is needed for NDES. write-only
`serverType`	string	SCEP RFC is an open source Linux certificate protocol. NDES is a certificate protocol developed by Microsoft. Before REST API v2.8 NDES was referred to as SCEP enrollment Since version: 2.8

Response (application/json): object		
Member	**Type**	**Description**
`serverUrl`	string	The SCEP server to contact. Only http is currently supported. For NDES, you can omit the default /CertSrv/mscep/ path. Example: http://barco.com/scep
`state`	string	Additional information about the state. This parameter is optional. Since version: 2.8
`supportedServerTypes`	array	Since version: 2.8 read-only
`username`	string	Username parameter is needed for NDES.
`supportedAuthenticationModes`	array	The different supported authentication modes. Example: ['None', 'PEAP', 'WPA2-PSK'] read-only
`addressing`	string	If this parameter is set to 'DHCP', the network connection is configured automatically through DHCP. If it is set to 'Static', a fixed IP address should be specified using the 'ipAddress' parameter.
`defaultGateway`	string (ipv4)	The default gateway. This parameter should only be changed if `addressing` is set to `Static`. Example: 10.0.18.1
`dnsServers`	array	The DNS servers used for resolving domain names. The children of this node should only be set if `addressing` is set to `Static`. Example: ['195.130.130.5', '195.130.131.5']
`domain`	string	Example: barco.com
`id`	integer	The ID for this LAN. read-only
`ipAddress`	string (ipv4)	The IP address of the Base Unit. This parameter should only be changed if `addressing` is set to `Static`. Example: 10.0.18.25
`macAddress`	string (mac-address)	MAC address of the wired ethernet adapter of the Base Unit. Example: 99:88:77:66:55:44 read-only
`status`	string	Indicates the status of the ethernet port. read-only
`subnetMask`	string (ipv4)	The subnet mask appropriate for the local subnet. This parameter should only be changed if `addressing` is set to `Static`. Example: 255.255.255.0

PATCH

Change individual LAN settings.

Request body (application/json): object		
Member	**Type**	**Description**
`802dot1xAuthentication`	object	Settings for 802.1X authentication.
`anonymousIdentity`	string	Used to select the correct authentication server to process the credentials.
`authenticationErrorCode`	string	Wired Authentication error code. read-only
`authenticationMode`	string	The 802.1X mode that is used.
`authenticationState`	string	Wired Authentication State. read-only
`caCertificate`	string	
`certificates`	object	Since version: 2.8 read-only
`ca`	object	Retrieve information about the ca certificate. Since version: 2.8
`commonName`	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
`country`	string	Country of the active certificate. Example: BE Since version: 2.8
`locality`	string	Locality of the active certificate. Since version: 2.8
`notAfter`	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
`notBefore`	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
`organization`	string	Organization of the active certificate. Since version: 2.8
`organizationalUnit`	string	OrganizationalUnit of the active certificate. Since version: 2.8
`serialNumber`	string	SerialNumber of the active certificate. Since version: 2.8
`state`	string	State of the active certificate. Since version: 2.8
`client`	object	Retrieve information about the client certificate.

Request body (application/json): object		
Member	**Type**	**Description**
		Since version: 2.8
commonName	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
country	string	Country of the active certificate. Example: BE Since version: 2.8
locality	string	Locality of the active certificate. Since version: 2.8
notAfter	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
notBefore	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
organization	string	Organization of the active certificate. Since version: 2.8
organizationalUnit	string	OrganizationalUnit of the active certificate. Since version: 2.8
serialNumber	string	SerialNumber of the active certificate. Since version: 2.8
state	string	State of the active certificate. Since version: 2.8
clientCertificate	string	
clientCertificatePassword	string (pass-word)	The password for the client certificate. Since version: 2.2 write-only
domain	string	The domain used for connections in PEAP and EAP-TTLS mode. Example: barco.com
eapIdentity	string	The identity used for connections in PEAP and EAP-TTLS mode.
eapPassword	string (pass-word)	The password used for connections in PEAP and EAP-TTLS mode. write-only
enabled	boolean	Indicates if the 802.1X Authentication is enabled.
passPhrase	string	Pass Phrase for WPA2-PSK authentication Example: passphrase Since version: 2.2 write-only

Request body (application/json): object		
Member	**Type**	**Description**
`scep`	object	The SCEP settings that are used for EAP_TLS mode with automatic enrollment.
`challenge`	string	Challenge token to prevent revocation by user without token. This token is only used when type is SCEP. Since version: 2.8 write-only
`city`	string	Additional information about the city. This parameter is optional. Since version: 2.8
`commonName`	string	Optional custom common name for the client certificate. By default the BaseUnit's hostname will be used. Example: ClickShare-3083543628.barco.com Since version: 2.8
`country`	string	Additional information about the country. This parameter is optional. Since version: 2.8
`department`	string	Additional information about the department. This parameter is optional. Since version: 2.8
`enabled`	boolean	
`organisation`	string	Additional information about the organisation. This parameter is optional. Since version: 2.8
`password`	string	Password parameter is needed for NDES. write-only
`serverType`	string	SCEP RFC is an open source Linux certificate protocol. NDES is a certificate protocol developed by Microsoft. Before REST API v2.8 NDES was referred to as SCEP enrollment Since version: 2.8
`serverUrl`	string	The SCEP server to contact. Only http is currently supported. For NDES, you can omit the default /CertSrv/mscep/ path. Example: http://barco.com/scep
`state`	string	Additional information about the state. This parameter is optional. Since version: 2.8
`supportedServerTypes`	array	Since version: 2.8 read-only
`username`	string	Username parameter is needed for NDES.
`supportedAuthenticationModes`	array	The different supported authentication modes. Example: ['None', 'PEAP', 'WPA2-PSK']

Request body (application/json): object		
Member	**Type**	**Description**
		read-only
`addressing`	string	If this parameter is set to 'DHCP', the network connection is configured automatically through DHCP. If it is set to 'Static', a fixed IP address should be specified using the 'ipAddress' parameter.
`defaultGateway`	string (ipv4)	The default gateway. This parameter should only be changed if `addressing` is set to `Static`. Example: 10.0.18.1
`dnsServers`	array	The DNS servers used for resolving domain names. The children of this node should only be set if `addressing` is set to `Static`. Example: ['195.130.130.5', '195.130.131.5']
`domain`	string	Example: barco.com
`id`	integer	The ID for this LAN. read-only
`ipAddress`	string (ipv4)	The IP address of the Base Unit. This parameter should only be changed if `addressing` is set to `Static`. Example: 10.0.18.25
`macAddress`	string (mac-address)	MAC address of the wired ethernet adapter of the Base Unit. Example: 99:88:77:66:55:44 read-only
`status`	string	Indicates the status of the ethernet port. read-only
`subnetMask`	string (ipv4)	The subnet mask appropriate for the local subnet. This parameter should only be changed if `addressing` is set to `Static`. Example: 255.255.255.0

Responses	
200	PATCH successful.
404	Resource does not exist.

2.37 configuration/system/network/wired/{index}/802dot1xAuthentication/scep/enrollments

POST

Starting the SCEP enrollment.

Responses	
202	SCEP enrollment started.
404	Resource does not exist.

2.38 configuration/system/network/wireless/{index}

GET

Get settings for the WLAN with the specified ID.

Responses	
200	GET successful.
404	Resource does not exist.

Response (application/json): object		
Member	**Type**	**Description**
`accessPoint`	object	
`broadcastSsid`	boolean	Indicates if the SSID will be broadcasted.
`channel`	integer (int32)	The wireless connection channel that is currently in use. Re-pairing the Buttons is not required when changing the frequency band or wireless connection channel. The channel must be in the range of accepted channels for the current frequency. Example: 12
`frequencyBand`	string	The wireless network frequency band that is currently in use. It can be set to either '2.4 GHz' or '5 GHz'. Re-pairing the Buttons is not required when changing the frequency band or wireless connection channel.
`password`	string (pass-word)	The password for the wireless network of the Base Unit. write-only
`signalStrengthPercentage`	integer	Set the signal strength of the wireless device. Example: 50 Since version: 2.10
`ssid`	string	The public name (SSID) for the wireless network of the Base Unit. Example: clickshare-1234
`supportedChannels2400MHz`	array	List of the available channels in the 2.4 GHz band. The channels available in the list vary depending on the country code of the Base Unit. Example: [10, 11, 12] read-only

Response (application/json): object		
Member	**Type**	**Description**
`supportedChannels5000MHz`	array	List of the available channels in the 5 GHz band. The channels available in the list vary depending on the country code of the Base Unit. Example: [36, 40] read-only
`supportedFrequencyBands`	array	Example: ['2.4 GHz', '5 GHz'] read-only
`addressing`	string	If this parameter is set to 'DHCP', the network connection is configured automatically through DHCP. If it is set to 'Static', a fixed IP address should be specified using the 'ipAddress' parameter.
`defaultGateway`	string (ipv4)	The default gateway. This parameter should only be changed if `addressing` is set to `Static`. Example: 192.168.2.1
`dnsServers`	array	The DNS servers used for resolving domain names. The children of this node should only be set if `addressing` is set to `Static`. While getting the values of DNSServer , it will always return the values of all 5 servers even if the number of active servers is less than 5. Also, user is allowed to have individual PUT value for each server. Example: ['192.168.2.10', '192.168.2.11']
`id`	integer	The ID for this WLAN. read-only
`ipAddress`	string (ipv4)	The IP address of the Base Unit. This parameter should only be changed if `addressing` is set to `Static`. Example: 192.168.2.3
`macAddress`	string (mac-address)	MAC address of the wireless adapter of the Base Unit. Example: 12:23:34:45:56 read-only
`operationMode`	string	
`subnetMask`	string	The subnet mask appropriate for the local subnet. This parameter should only be changed if `addressing` is set to `Static`. Example: 255.255.255.0
`supportedOperationModes`	array	Example: ['AccessPoint', 'WirelessClient', 'Off'] read-only
`wirelessClient`	object	Client mode settings for baseunit. Since version: 2.2
`authentication`	object	Settings for 802.1X authentication.

Response (application/json): object		
Member	**Type**	**Description**
anonymousIdentity	string	Used to select the correct authentication server to process the credentials.
authenticationErrorCode	string	Wired Authentication error code. read-only
authenticationMode	string	The 802.1X mode that is used.
authenticationState	string	Wired Authentication State. read-only
caCertificate	string	
certificates	object	Since version: 2.8 read-only
ca	object	Retrieve information about the ca certificate. Since version: 2.8
commonName	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
country	string	Country of the active certificate. Example: BE Since version: 2.8
locality	string	Locality of the active certificate. Since version: 2.8
notAfter	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
notBefore	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
organization	string	Organization of the active certificate. Since version: 2.8
organizationalUnit	string	OrganizationalUnit of the active certificate. Since version: 2.8
serialNumber	string	SerialNumber of the active certificate. Since version: 2.8
state	string	State of the active certificate. Since version: 2.8
client	object	Retrieve information about the client certificate. Since version: 2.8
commonName	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8

Response (application/json): object		
Member	**Type**	**Description**
country	string	Country of the active certificate. Example: BE Since version: 2.8
locality	string	Locality of the active certificate. Since version: 2.8
notAfter	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
notBefore	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
organization	string	Organization of the active certificate. Since version: 2.8
organizationalUnit	string	OrganizationalUnit of the active certificate. Since version: 2.8
serialNumber	string	SerialNumber of the active certificate. Since version: 2.8
state	string	State of the active certificate. Since version: 2.8
clientCertificate	string	
clientCertificatePassword	string (pass-word)	The password for the client certificate. Since version: 2.2 write-only
domain	string	The domain used for connections in PEAP and EAP-TTLS mode. Example: barco.com
eapIdentity	string	The identity used for connections in PEAP and EAP-TTLS mode.
eapPassword	string (pass-word)	The password used for connections in PEAP and EAP-TTLS mode. write-only
enabled	boolean	Indicates if the 802.1X Authentication is enabled.
passPhrase	string	Pass Phrase for WPA2-PSK authentication Example: passphrase Since version: 2.2 write-only
scep	object	The SCEP settings that are used for EAP_TLS mode with automatic enrollment.

Response (application/json): object		
Member	**Type**	**Description**
`challenge`	string	Challenge token to prevent revocation by user without token. This token is only used when type is SCEP. Since version: 2.8 write-only
`city`	string	Additional information about the city. This parameter is optional. Since version: 2.8
`commonName`	string	Optional custom common name for the client certificate. By default the BaseUnit's hostname will be used. Example: ClickShare-3083543628.barco.com Since version: 2.8
`country`	string	Additional information about the country. This parameter is optional. Since version: 2.8
`department`	string	Additional information about the department. This parameter is optional. Since version: 2.8
`enabled`	boolean	
`organisation`	string	Additional information about the organisation. This parameter is optional. Since version: 2.8
`password`	string	Password parameter is needed for NDES. write-only
`serverType`	string	SCEP RFC is an open source Linux certificate protocol. NDES is a certificate protocol developed by Microsoft. Before REST API v2.8 NDES was referred to as SCEP enrollment Since version: 2.8
`serverUrl`	string	The SCEP server to contact. Only http is currently supported. For NDES, you can omit the default /CertSrv/mscep/ path. Example: http://barco.com/scep
`state`	string	Additional information about the state. This parameter is optional. Since version: 2.8
`supportedServerTypes`	array	Since version: 2.8 read-only
`username`	string	Username parameter is needed for NDES.

Response (application/json): object		
Member	**Type**	**Description**
`supportedAuthenticationModes`	array	The different supported authentication modes. Example: ['None', 'PEAP', 'WPA2-PSK'] read-only
`ssid`	string	The public name (SSID) for the wireless network of the Base Unit. Example: clickshare-0123456789 Since version: 2.2

PATCH

Change individual WLAN settings.

Request body (application/json): object		
Member	**Type**	**Description**
`accessPoint`	object	
`broadcastSsid`	boolean	Indicates if the SSID will be broadcasted.
`channel`	integer (int32)	The wireless connection channel that is currently in use. Re-pairing the Buttons is not required when changing the frequency band or wireless connection channel. The channel must be in the range of accepted channels for the current frequency. Example: 12
`frequencyBand`	string	The wireless network frequency band that is currently in use. It can be set to either '2.4 GHz' or '5 GHz'. Re-pairing the Buttons is not required when changing the frequency band or wireless connection channel.
`password`	string (pass-word)	The password for the wireless network of the Base Unit. write-only
`signalStrengthPercentage`	integer	Set the signal strength of the wireless device. Example: 50 Since version: 2.10
`ssid`	string	The public name (SSID) for the wireless network of the Base Unit. Example: clickshare-1234
`supportedChannels2400MHz`	array	List of the available channels in the 2.4 GHz band. The channels available in the list vary depending on the country code of the Base Unit. Example: [10, 11, 12] read-only
`supportedChannels5000MHz`	array	List of the available channels in the 5 GHz band. The channels available in the list vary depending on the country code of the Base Unit.

Request body (application/json): object		
Member	**Type**	**Description**
		Example: [36, 40] read-only
`supportedFrequencyBands`	array	Example: ['2.4 GHz', '5 GHz'] read-only
`addressing`	string	If this parameter is set to 'DHCP', the network connection is configured automatically through DHCP. If it is set to 'Static', a fixed IP address should be specified using the 'ipAddress' parameter.
`defaultGateway`	string (ipv4)	The default gateway. This parameter should only be changed if `addressing` is set to `Static`. Example: 192.168.2.1
`dnsServers`	array	The DNS servers used for resolving domain names. The children of this node should only be set if `addressing` is set to `Static`. While getting the values of DNSServer , it will always return the values of all 5 servers even if the number of active servers is less than 5. Also, user is allowed to have individual PUT value for each server. Example: ['192.168.2.10', '192.168.2.11']
`id`	integer	The ID for this WLAN. read-only
`ipAddress`	string (ipv4)	The IP address of the Base Unit. This parameter should only be changed if `addressing` is set to `Static`. Example: 192.168.2.3
`macAddress`	string (mac-address)	MAC address of the wireless adapter of the Base Unit. Example: 12:23:34:45:56 read-only
`operationMode`	string	
`subnetMask`	string	The subnet mask appropriate for the local subnet. This parameter should only be changed if `addressing` is set to `Static`. Example: 255.255.255.0
`supportedOperationModes`	array	Example: ['AccessPoint', 'WirelessClient', 'Off'] read-only
`wirelessClient`	object	Client mode settings for baseunit. Since version: 2.2
`authentication`	object	Settings for 802.1X authentication.
`anonymousIdentity`	string	Used to select the correct authentication server to process the credentials.

Request body (application/json): object		
Member	**Type**	**Description**
`authenticationErrorCode`	string	Wired Authentication error code. read-only
`authenticationMode`	string	The 802.1X mode that is used.
`authenticationState`	string	Wired Authentication State. read-only
`caCertificate`	string	
`certificates`	object	Since version: 2.8 read-only
`ca`	object	Retrieve information about the ca certificate. Since version: 2.8
`commonName`	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
`country`	string	Country of the active certificate. Example: BE Since version: 2.8
`locality`	string	Locality of the active certificate. Since version: 2.8
`notAfter`	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
`notBefore`	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
`organization`	string	Organization of the active certificate. Since version: 2.8
`organizationalUnit`	string	OrganizationalUnit of the active certificate. Since version: 2.8
`serialNumber`	string	SerialNumber of the active certificate. Since version: 2.8
`state`	string	State of the active certificate. Since version: 2.8
`client`	object	Retrieve information about the client certificate. Since version: 2.8
`commonName`	string	Common name of the active certificate. Example: ClickShare-1862300136 Since version: 2.8
`country`	string	Country of the active certificate.

Request body (application/json): object		
Member	**Type**	**Description**
		Example: BE Since version: 2.8
`locality`	string	Locality of the active certificate. Since version: 2.8
`notAfter`	string (date-time)	Indicate the end of the validity period of the certificate. Example: 2021-04-29 10:00:24 Since version: 2.8
`notBefore`	string (date-time)	Indicate the start of the validity period of the certificate. Example: 2020-04-29 10:00:24 Since version: 2.8
`organization`	string	Organization of the active certificate. Since version: 2.8
`organizationalUnit`	string	OrganizationalUnit of the active certificate. Since version: 2.8
`serialNumber`	string	SerialNumber of the active certificate. Since version: 2.8
`state`	string	State of the active certificate. Since version: 2.8
`clientCertificate`	string	
`clientCertificatePassword`	string (pass-word)	The password for the client certificate. Since version: 2.2 write-only
`domain`	string	The domain used for connections in PEAP and EAP-TTLS mode. Example: barco.com
`eapIdentity`	string	The identity used for connections in PEAP and EAP-TTLS mode.
`eapPassword`	string (pass-word)	The password used for connections in PEAP and EAP-TTLS mode. write-only
`enabled`	boolean	Indicates if the 802.1X Authentication is enabled.
`passPhrase`	string	Pass Phrase for WPA2-PSK authentication Example: passphrase Since version: 2.2 write-only
`scep`	object	The SCEP settings that are used for EAP_TLS mode with automatic enrollment.
`challenge`	string	Challenge token to prevent revocation by user without token. This token is only used when type is SCEP.

Request body (application/json): object		
Member	**Type**	**Description**
		Since version: 2.8 write-only
`city`	string	Additional information about the city. This parameter is optional. Since version: 2.8
`commonName`	string	Optional custom common name for the client certificate. By default the BaseUnit's hostname will be used. Example: ClickShare-3083543628.barco.com Since version: 2.8
`country`	string	Additional information about the country. This parameter is optional. Since version: 2.8
`department`	string	Additional information about the department. This parameter is optional. Since version: 2.8
`enabled`	boolean	
`organisation`	string	Additional information about the organisation. This parameter is optional. Since version: 2.8
`password`	string	Password parameter is needed for NDES. write-only
`serverType`	string	SCEP RFC is an open source Linux certificate protocol. NDES is a certificate protocol developed by Microsoft. Before REST API v2.8 NDES was referred to as SCEP enrollment Since version: 2.8
`serverUrl`	string	The SCEP server to contact. Only http is currently supported. For NDES, you can omit the default /CertSrv/mscep/ path. Example: http://barco.com/scep
`state`	string	Additional information about the state. This parameter is optional. Since version: 2.8
`supportedServerTypes`	array	Since version: 2.8 read-only
`username`	string	Username parameter is needed for NDES.

Request body (application/json): object		
Member	**Type**	**Description**
`supportedAuthenticationModes`	array	The different supported authentication modes. Example: ['None', 'PEAP', 'WPA2-PSK'] read-only
`ssid`	string	The public name (SSID) for the wireless network of the Base Unit. Example: clickshare-0123456789 Since version: 2.2

Responses	
200	PATCH successful.
404	Resource does not exist.

2.39 configuration/system/network/wireless/{index}/wireless-client/authentication/scep/enrollments

POST

Since version 2.2

Starting the SCEP enrollment.

Responses	
202	SCEP enrollment started.
404	Resource does not exist.

2.40 configuration/system/power-management

GET

Get the current power management settings.

Responses	
200	GET successful

Response (application/json): object		
Member	**Type**	**Description**
`powerMode`	string	The energy mode of the Base Unit, which defines the standby type.
`standbyTimeout`	string	The period of inactivity in minutes after which the display output is disabled (standby mode). If this parameter is set to 'Infinite', the output is never disabled automatically. The supported values are in the supportedStandbyTimeouts field.

Response (application/json): object		
Member	**Type**	**Description**
		Example: 30
status	string	The current system state of the Base Unit. read-only
supportedPowerModes	array	Example: ['EcoStandby', 'NetworkedStandby', 'DeepStandby'] read-only
supportedStandbyTimeouts	array	Example: ['Infinite', '1', '5', '10', '15', '30', '45', '60'] read-only
supportedStatuses	array	Example: ['On', 'Standby'] read-only

PATCH

Change the power management settings.

Request body (application/json): object		
Member	**Type**	**Description**
powerMode	string	The energy mode of the Base Unit, which defines the standby type.
standbyTimeout	string	The period of inactivity in minutes after which the display output is disabled (standby mode). If this parameter is set to 'Infinite', the output is never disabled automatically. The supported values are in the supportedStandbyTimeouts field. Example: 30
status	string	The current system state of the Base Unit. read-only
supportedPowerModes	array	Example: ['EcoStandby', 'NetworkedStandby', 'DeepStandby'] read-only
supportedStandbyTimeouts	array	Example: ['Infinite', '1', '5', '10', '15', '30', '45', '60'] read-only
supportedStatuses	array	Example: ['On', 'Standby'] read-only

Responses	
200	PATCH successful.

2.41 configuration/system/software/available/latest

GET

Since version 2.8

Get information if a new firmware version is available on barco.com

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`url`	string	Link to the new available update. Since version: 2.8 read-only
`version`	string	The new firmware version available to update. Since version: 2.8 read-only

2.42 configuration/system/status

GET

Get information about the Base Unit.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`currentUptime`	integer	The number of seconds since this Base Unit was last booted.
`errorCode`	string	The health state of this Base Unit. If the status is not 'Ok', more detailed information can be found in the 'errorMessage' parameter.
`errorMessage`	string	The health message of this Base Unit.
`firstUsed`	string (date-time)	The date and time when this Base Unit was booted for the first time. Example: 2019-09-27 03:24:36
`inUse`	boolean	Indicates if at least one source (Button, App…) is currently connected.
`sharing`	boolean	Indicates if at least one of the connected sources (Button, App…) is currently sharing content on the display.
`totalUptime`	integer	The total number of seconds that this Base Unit has been running.

2.43 configuration/system/time

GET

Get the time settings.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`dateTime`	string (date-time)	The current date. Example: 2020-04-29 10:00:24
`ntpEnabled`	boolean	Indicates if NTP is enabled.
`ntpServers`	array	Addresses of the NTP servers. Example: ['ntp.mycompany.com', 'ntp.othercompany.com']
`ntpStatus`	string	NTP status. read-only
`supportedTimeFormats`	array	The supported values for the timeFormat property. Example: ['12-hr', '24-hr'] Since version: 2.4 read-only
`supportedTimeZones`	array	The supported timeZones. Example: ['UTC', 'Europe/Brussels', 'Europe/Athens'] read-only
`timeFormat`	string	For selecting 12 hour or 24 hour clock. Must be in the `supportedTimeFormats` list. Example: 24-hr Since version: 2.4
`timeZone`	string	The selected timeZone. Must be in the `supportedTimeZones` list. Example: Europe/Brussels

PATCH

Change the time settings.

Request body (application/json): object		
Member	**Type**	**Description**
`dateTime`	string (date-time)	The current date. Example: 2020-04-29 10:00:24
`ntpEnabled`	boolean	Indicates if NTP is enabled.

Request body (application/json): object		
Member	**Type**	**Description**
`ntpServers`	array	Addresses of the NTP servers. Example: ['ntp.mycompany.com', 'ntp.othercompany.com']
`ntpStatus`	string	NTP status. read-only
`supportedTimeFormats`	array	The supported values for the timeFormat property. Example: ['12-hr', '24-hr'] Since version: 2.4 read-only
`supportedTimeZones`	array	The supported timeZones. Example: ['UTC', 'Europe/Brussels', 'Europe/Athens'] read-only
`timeFormat`	string	For selecting 12 hour or 24 hour clock. Must be in the `supportedTimeFormats` list. Example: 24-hr Since version: 2.4
`timeZone`	string	The selected timeZone. Must be in the `supportedTimeZones` list. Example: Europe/Brussels

Responses	
200	PATCH successful.

2.44 configuration/system/update-settings

GET

Get the software update settings.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`allowBaseUnitUpdateOverUSB`	boolean	Enable/disable base update over USB.
`allowFirmwareDowngrade`	boolean	Set this value to 'true' to allow a firmware downgrade.

Response (application/json): object		
Member	**Type**	**Description**
`autoUpdateType`	string	Defines how the Base Unit will behave with regards to automatic updates. Use `Automatic` for unattended updates, `Notify` for update checks, but no unattended updates, and `Off` for no update checks.
`supportedAutoUpdateTypes`	array	Defines the supported auto update types. Example: ['Automatic', 'Notify', 'Off'] read-only

PATCH

Change the software update settings.

Request body (application/json): object		
Member	**Type**	**Description**
`allowBaseUnitUpdateOverUSB`	boolean	Enable/disable base update over USB.
`allowFirmwareDowngrade`	boolean	Set this value to 'true' to allow a firmware downgrade.
`autoUpdateType`	string	Defines how the Base Unit will behave with regards to automatic updates. Use `Automatic` for unattended updates, `Notify` for update checks, but no unattended updates, and `Off` for no update checks.
`supportedAutoUpdateTypes`	array	Defines the supported auto update types. Example: ['Automatic', 'Notify', 'Off'] read-only

Responses	
200	PATCH successful.

2.45 configuration/system/updates

POST

Create a new firmware update.

Request body (application/json): object		
Member	**Type**	**Description**
`url`	string	

Request body (multipart/form-data)

Responses	
202	Firmware update started.
400	The 'url' parameter is not valid. The upload of the file failed. A url or a file must be provided.

2.46 configuration/system/updates/current

GET

Get the info about the current software.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`date`	string (date-time)	Date and time of the last firmware update of the Base Unit. Example: 2020-04-29 08:21:39 read-only
`version`	string	The Base Unit software version. Example: 02.04.00 read-only

2.47 configuration/system/updates/next

GET

Get the info about the new software.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`status`	object	Informations about the Base Unit firmware update. read-only
`inProgress`	boolean	Indicates if a software update is currently in progress.
`isSuccessful`	boolean	Indicates if the software update process finished successfully.
`message`	string	Current update message shown on Base Unit display.
`progress`	string	Current state of the ongoing update process.

2.48 configuration/troubleshooting/erase-settings

POST

Since version 2.1

Erase all settings.

Responses	
202	Erase succeeded.

2.49 configuration/troubleshooting/factory-reset

POST

Reset to factory settings.

Responses	
202	Reset succeeded.

2.50 configuration/troubleshooting/logs

GET

Get a link to the downloadable baseunit logs.

Responses	
307	Redirect.

DELETE

Clear the ClickShare logs.

Responses	
202	Logs removed.

2.51 configuration/users/{username}

PATCH

Change the password for the specified user.

Request body (application/json): object

Member	Type	Description
`password`	string	Password write-only

Responses	
200	PATCH successful.

2.52 configuration/uvc/audio

GET

Since version 2.14

Get the UVC presets Values for Audio.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`productId`	string	Since version: 2.14 read-only
`vendorId`	string	Since version: 2.14 read-only

2.53 configuration/uvc/camera

GET

Since version 2.14

Get the UVC presets Values for the Camera.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`pan`	integer (int32)	Absolute Pan value of Camera Since version: 2.14
`supportedViewAngles`	array	Supported view angles for camera presets. Example: ['FixedPosition', 'GroupFraming', 'SpeakerFraming', 'CompositionFraming'] Since version: 2.14 read-only
`tilt`	integer (int32)	Absolute Tilt value of Camera Since version: 2.14
`viewAngle`	string	View Angle Position of Camera Since version: 2.14
`zoom`	integer (int32)	Absolute Zoom value of Camera Since version: 2.14

PATCH

Since version 2.14

Change the UVC presets Values for the Camera.

Request body (application/json): object		
Member	**Type**	**Description**
`pan`	integer (int32)	Absolute Pan value of Camera Since version: 2.14
`supportedViewAngles`	array	Supported view angles for camera presets. Example: ['FixedPosition', 'GroupFraming', 'SpeakerFraming', 'CompositionFraming'] Since version: 2.14 read-only
`tilt`	integer (int32)	Absolute Tilt value of Camera Since version: 2.14
`viewAngle`	string	View Angle Position of Camera Since version: 2.14
`zoom`	integer (int32)	Absolute Zoom value of Camera Since version: 2.14

Responses	
200	PATCH successful.
400	The parameter viewAngle is mandatory.

2.54 configuration/uvc/video

GET

Since version 2.14

Get the UVC presets Values for Video.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`autoWhiteBalance`	integer (int32)	Feature about auto adjust the Whitebalance value of Camera Since version: 2.14
`brightness`	integer (int32)	Brightness value of Camera Since version: 2.14
`contrast`	integer (int32)	Contrast value of Camera Since version: 2.14
`exposure`	integer (int32)	Absolute Exposure value of Camera Since version: 2.14
`exposureAuto`	integer (int32)	ExposureAuto value of Camera Since version: 2.14
`gamma`	integer (int32)	Gamma value of Camera Since version: 2.14

Response (application/json): object		
Member	**Type**	**Description**
`powerLineFrequency`	string	Power line frequency of Camera. Since version: 2.17
`productId`	string	Since version: 2.14 read-only
`saturation`	integer (int32)	Saturation value of Camera Since version: 2.14
`supportedPowerLineFrequencies`	array	Supported power line frequency for camera. Example: ['50 Hz', '60 Hz'] Since version: 2.17 read-only
`vendorId`	string	Since version: 2.14 read-only
`whiteBalanceTemperature`	integer (int32)	WhiteBalanceTemperature value of Camera Since version: 2.14

PATCH

Since version 2.14

Change the UVC presets Values for Video.

Request body (application/json): object		
Member	**Type**	**Description**
`autoWhiteBalance`	integer (int32)	Feature about auto adjust the Whitebalance value of Camera Since version: 2.14
`brightness`	integer (int32)	Brightness value of Camera Since version: 2.14
`contrast`	integer (int32)	Contrast value of Camera Since version: 2.14
`exposure`	integer (int32)	Absolute Exposure value of Camera Since version: 2.14
`exposureAuto`	integer (int32)	ExposureAuto value of Camera Since version: 2.14
`gamma`	integer (int32)	Gamma value of Camera Since version: 2.14
`powerLineFrequency`	string	Power line frequency of Camera. Since version: 2.17
`productId`	string	Since version: 2.14 read-only
`saturation`	integer (int32)	Saturation value of Camera Since version: 2.14
`supportedPowerLineFrequencies`	array	Supported power line frequency for camera.

Request body (application/json): object		
Member	**Type**	**Description**
		Example: ['50 Hz', '60 Hz'] Since version: 2.17 read-only
`vendorId`	string	Since version: 2.14 read-only
`whiteBalanceTemperature`	integer (int32)	WhiteBalanceTemperature value of Camera Since version: 2.14

Responses	
200	PATCH successful.

2.55 configuration/video

GET

Get the video settings.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`autoDetect`	boolean	Indicates if the Base Unit should automatically detect display changes. If disabled, the Base Unit should be restarted when a display is plugged or unplugged.
`cecConfigurable`	boolean	Indicates whether the CEC option can be configured. Since version: 2.19 read-only
`cecEnabled`	boolean	Indicates if the Base Unit should react to CEC signals from connected devices.
`mode`	string	If two screens are connected to the Base Unit, this parameter defines the composition of the shared sources.
`supportedModes`	array	Supported modes to use the displays. Example: ['Extended', 'Clone'] read-only

PATCH

Change the video settings.

Request body (application/json): object		
Member	**Type**	**Description**
`autoDetect`	boolean	Indicates if the Base Unit should automatically detect display changes. If disabled, the Base Unit should be restarted when a display is plugged or unplugged.
`cecConfigurable`	boolean	Indicates whether the CEC option can be configured. Since version: 2.19 read-only
`cecEnabled`	boolean	Indicates if the Base Unit should react to CEC signals from connected devices.
`mode`	string	If two screens are connected to the Base Unit, this parameter defines the composition of the shared sources.
`supportedModes`	array	Supported modes to use the displays. Example: ['Extended', 'Clone'] read-only

Responses	
200	PATCH successful.

2.56 configuration/video-outputs

GET

Get a list of the available video outputs.

Responses	
200	GET successful.

Response (application/json): object array		
Member	**Type**	**Description**
`connected`	boolean	Indicates if a screen is currently connected to this output. read-only
`enabled`	boolean	Indicates if this output is enabled. Since version: 2.7
`id`	integer	read-only
`modelName`	string	Model name of the screen connected to this output. Since version: 2.9 read-only
`position`	integer	Determines the position for this output. This value switches the monitors in 'Extended video mode'. Only the CX-50 Gen2 devices

Response (application/json): object array		
Member	**Type**	**Description**
		support a value different than one. All other device types have a single display output. C-5/C-10/CX-20 and CX-30 Gen2 do support two outputs, but only one can be active at the same time. Example: 1 Since version: 2.10
`preferredResolution`	string	The preferred resolution of the screen connected to this output. Example: 1920x1080 read-only
`resolution`	string	The requested resolution for this output. If this parameter is set to 'Auto', the native resolution (see nativeHorizontalResolution and nativeVerticalResolution) of the display will be used. A manual resolution that is listed under SupportedResolutions can be set in the format [hor]x[ver]. Example: Auto
`supportedResolutions`	array	Supported resolutions for the screen currently connected to this output. Example: ['Auto', '1280x720', '1920x1080'] read-only
`vendorName`	string	Vendor name of the screen connected to this output. Since version: 2.9 read-only

2.57 configuration/video-outputs/{index}

GET

Get the video output with a specified ID.

Responses	
200	GET successful.
404	Resource does not exist.

Response (application/json): object		
Member	**Type**	**Description**
`connected`	boolean	Indicates if a screen is currently connected to this output. read-only
`enabled`	boolean	Indicates if this output is enabled. Since version: 2.7
`id`	integer	read-only

Response (application/json): object		
Member	**Type**	**Description**
`modelName`	string	Model name of the screen connected to this output. Since version: 2.9 read-only
`position`	integer	Determines the position for this output. This value switches the monitors in 'Extended video mode'. Only the CX-50 Gen2 devices support a value different than one. All other device types have a single display output. C-5/C-10/CX-20 and CX-30 Gen2 do support two outputs, but only one can be active at the same time. Example: 1 Since version: 2.10
`preferredResolution`	string	The preferred resolution of the screen connected to this output. Example: 1920x1080 read-only
`resolution`	string	The requested resolution for this output. If this parameter is set to 'Auto', the native resolution (see nativeHorizontalResolution and nativeVerticalResolution) of the display will be used. A manual resolution that is listed under SupportedResolutions can be set in the format [hor]x[ver]. Example: Auto
`supportedResolutions`	array	Supported resolutions for the screen currently connected to this output. Example: ['Auto', '1280x720', '1920x1080'] read-only
`vendorName`	string	Vendor name of the screen connected to this output. Since version: 2.9 read-only

PATCH

Change the output.

Request body (application/json): object		
Member	**Type**	**Description**
`connected`	boolean	Indicates if a screen is currently connected to this output. read-only
`enabled`	boolean	Indicates if this output is enabled. Since version: 2.7
`id`	integer	read-only

Request body (application/json): object		
Member	**Type**	**Description**
`modelName`	string	Model name of the screen connected to this output. Since version: 2.9 read-only
`position`	integer	Determines the position for this output. This value switches the monitors in 'Extended video mode'. Only the CX-50 Gen2 devices support a value different than one. All other device types have a single display output. C-5/C-10/CX-20 and CX-30 Gen2 do support two outputs, but only one can be active at the same time. Example: 1 Since version: 2.10
`preferredResolution`	string	The preferred resolution of the screen connected to this output. Example: 1920x1080 read-only
`resolution`	string	The requested resolution for this output. If this parameter is set to 'Auto', the native resolution (see nativeHorizontalResolution and nativeVerticalResolution) of the display will be used. A manual resolution that is listed under SupportedResolutions can be set in the format [hor]x[ver]. Example: Auto
`supportedResolutions`	array	Supported resolutions for the screen currently connected to this output. Example: ['Auto', '1280x720', '1920x1080'] read-only
`vendorName`	string	Vendor name of the screen connected to this output. Since version: 2.9 read-only

Responses	
200	PATCH successful.

2.58 configuration/wallpapers

GET

Get the list of all available wallpapers.

Responses	
200	GET successful.

Response (application/json): object array		
Member	**Type**	**Description**
`id`	number	The ID for this wallpaper. read-only
`md5`	string	The MD5 hash of the wallpaper file. Can be `null` in case of a problem. Example: 6f34fedd3c91a130fde57b7c76ab44f5 read-only
`name`	string	The file name of the wallpaper. Example: barco.jpg read-only

POST

Add a new wallpaper.

Request body (application/json): object		
Member	**Type**	**Description**
`url`	string	

Request body (multipart/form-data)

Responses	
202	Wallpaper upload started.
400	The 'url' parameter is not valid. The upload of the file failed. A url or a file must be provided.
405	The maximum number of five user wallpapers has already been reached. You need to delete one before you can upload a new wallpaper.

2.59 configuration/wallpapers/last-upload/status

GET

Status of the current wallpaper upload.

Responses	
200	OK

Response (application/json): object		
Member	**Type**	**Description**
`message`	string	More details on the status of the last wallpaper upload. If it is empty, the upload succeeded. Otherwise, it will contain a message indicating that the upload is still in progress, or the reason why it failed. Example: Uploading wallpaper to the Base Unit... read-only
`status`	string	Indicates the status of the last wallpaper upload. If the status is not Ok, you can find more details in the message. Example: Uploading

2.60 configuration/wallpapers/selected

GET

Get the wallpaper that is currently selected.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`id`	number	The ID for this wallpaper. read-only
`md5`	string	The MD5 hash of the wallpaper file. Can be `null` in case of a problem. Example: 6f34fedd3c91a130fde57b7c76ab44f5 read-only
`name`	string	The file name of the wallpaper. Example: barco.jpg read-only

PATCH

Change the selected wallpaper.

Request body (application/json): object		
Member	**Type**	**Description**
`id`	number	The ID of the wallpaper to select. Example: 1
`md5`	string	The MD5 hash of the wallpaper to select. Example: 3d8644944f358d3ef2d466c683255328
`name`	string	The name of the wallpaper to select. Example: barco.jpg

Responses	
200	Wallpaper changed.
400	The given wallpaper does not exist.

2.61 configuration/wallpapers/{index}

GET

Get information about a specific wallpaper.

Responses	
200	OK
404	The wallpaper with the requested index does not exist.

Response (application/json): object		
Member	**Type**	**Description**
`id`	number	The ID for this wallpaper. read-only
`md5`	string	The MD5 hash of the wallpaper file. Can be `null` in case of a problem. Example: 6f34fedd3c91a130fde57b7c76ab44f5 read-only
`name`	string	The file name of the wallpaper. Example: barco.jpg read-only

DELETE

Delete a wallpaper.

Responses	
200	DELETE successful.
404	The wallpaper with the requested index does not exist.
405	The wallpaper with the requested index is a built in wallpaper and cannot be deleted.

2.62 configuration/warranty

GET

Since version 2.3

Get warranty info.

Responses	
200	GET successful.

Response (application/json): object

Member	Type	Description
`contract`	object	Info about an additional warranty contract. Since version: 2.3
`endDate`	string (date-time)	Date on which the additional warranty contract ends. Example: 2026-01-26T00:00:00Z Since version: 2.3
`maxActivationDate`	string (date-time)	Date before which the unit must be added in XMS to activate an additional warranty contract. Example: 2021-07-26T00:00:00Z Since version: 2.3
`startDate`	string (date-time)	Date on which the additional warranty contract started. Example: 2021-02-15T00:00:00Z Since version: 2.3
`type`	string	Type of the additional warranty contract. Example: ESSENTIAL CARE Since version: 2.3
`endDate`	string (date-time)	Date on which the warranty ends (not taking any additional contract into account). Example: 2023-01-26T00:00:00Z Since version: 2.3
`startDate`	string (date-time)	Date on which the warranty started. Example: 2021-01-26T00:00:00Z Since version: 2.3

2.63 configuration/xml

PUT

Upload config file.

Request body (application/json): object		
Member	**Type**	**Description**
`url`	string	

Request body (text/xml)

Responses	
202	PUT successful.

2.64 configuration/xml/full

GET

Get the full config file.

Responses	
200	GET successful.

Response (text/xml)

2.65 configuration/xml/portable

GET

Get the minimalized config file.

Responses	
200	GET successful.

Response (text/xml)

2.66 configuration/xms

GET

Since version 2.1

Get XMS cloud info.

Responses	
200	GET successful.

Response (application/json): object		
Member	**Type**	**Description**
`claimUrl`	string	URL to use for adding the device to XMS cloud. Only relevant if not yet managed. Example: https://xms.cloud.barco.com/add Since version: 2.1
`cloudConnectivity`	boolean	Status of IoT Connectivity to cloud. Since version: 2.8
`deviceToken`	string	Token to use when adding the device to XMS cloud. Only relevant if not yet managed. Example: ABCD0123 Since version: 2.1
`managed`	boolean	Whether this device is managed by XMS cloud or not. Since version: 2.1
`tenant`	object	The organization with which this device is associated with in XMS cloud. Since version: 2.2 read-only
`name`	string	Name of the organization. Example: Barco N.V. Since version: 2.2

DELETE

Since version 2.1

Remove device from organization.

Responses	
202	Device will be removed.

2.67 operations/reboot

POST

Reboot the system.

Responses	
202	System will restart.

2.68 operations/standby

POST

Put the system in standby.

Responses	
202	System will go to standby.

2.69 operations/supported

GET

Get a list of supported operations.

Responses	
200	GET successful.

2.70 operations/wakeup

POST

Since version 2.9

Wake up the system from standby.

Responses	
202	System will wake up from standby.

R5915531 /12 | 2025-10-29