1. Safety and Setup

Read all instructions before using the Aurora X200. Keep the machine out of reach of children under eight years of age. Place the machine on a flat, heat-resistant surface and leave at least 15 cm of free space above and 10 cm on each side so that steam can escape safely. Never operate the machine without water in the tank, and never immerse the base, power cord or plug in water.

The Aurora X200 runs on 230 V at 50 Hz and draws 1450 W when the boiler is heating. The power cord is 1.2 m long. Do not use an extension cord. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent.

The removable water tank holds 1.8 litres when filled to the MAX line. Use fresh, cold drinking water only. Do not fill the tank with milk, coffee or any other liquid. Empty and refill the tank every day for the best flavour; water that has been sitting for more than 24 hours should be discarded.

Before the first brew, unpack all accessories: the portafilter, one single-shot basket, one double-shot basket, a stainless-steel tamper, a 450 ml milk jug and a measuring scoop.

2. First Use and Brewing

Before making your first coffee, run a rinse cycle: fill the tank, place a large cup under the group head, and press and hold the Brew button for three seconds. Hot water will flow for about 40 seconds. Repeat the rinse cycle once more if the machine has not been used for more than a week.

The Aurora X200 heats up in 40 seconds from cold. The Ready light turns solid green when the machine reaches brewing temperature. The pump delivers 15 bar of pressure during extraction, and the thermostat holds water temperature at 93 degrees Celsius.

The factory presets are 30 ml for a single shot and 60 ml for a double shot. To change the volume, hold the Single or Double button during a brew until you reach the volume you want, then release it; the new volume is stored automatically. For best results, use a medium-fine grind and dose 9 g of coffee for the single basket and 18 g for the double basket. Tamp firmly and evenly with about 15 kg of pressure.

A good espresso takes between 25 and 30 seconds to extract. If the shot runs faster than 20 seconds, use a finer grind; if it takes longer than 35 seconds, use a coarser grind.

3. Milk Frothing

The steam wand lets you texture milk for cappuccinos and lattes. Press the Steam button and wait for the Steam light to turn solid blue. The boiler needs about 25 seconds to switch from brewing to steaming temperature. Do not turn the steam dial until the light is solid, otherwise the wand may spit hot water.

Before steaming, point the wand at the drip tray and open the steam dial for 3 seconds to purge any condensed water. Submerge the wand tip just below the milk surface, tilt the jug slightly, and open the dial fully. Lower the jug as the milk expands to create foam.

Stop steaming when the milk reaches between 60 and 65 degrees Celsius, which is when the side of the jug becomes too hot to hold comfortably for more than a couple of seconds. Overheating milk above 70 degrees Celsius makes it taste flat and burnt. Always use cold, fresh milk straight from the refrigerator; whole milk gives the creamiest foam, but oat and soy drinks marketed for baristas also work.

After every use, wipe the wand with a damp cloth and purge it for 2 seconds again. Dried milk inside the wand tip is the most common cause of weak steam.

4. Cleaning and Maintenance

Empty and rinse the drip tray and the used-coffee basket after each day of use. The drip tray has a red float that pops up when the tray is full; empty it at that point. Wash the tray, portafilter and baskets in warm soapy water; they are not dishwasher safe.

Backflush the group head once a week using the supplied blind basket and one Aurora CT-10 cleaning tablet. Run five cycles of 10 seconds each with the tablet, then rinse with five more cycles of clear water.

Descale the machine every 3 months, or after every 200 shots, whichever comes first. Mix 100 ml of Aurora DS-5 descaling solution with 1 litre of fresh water, pour it into the tank and run the Descale program by holding the Steam and Brew buttons together for five seconds. The program takes about 20 minutes. Afterwards flush the tank with two full tanks of fresh water. Never use vinegar, which can damage the seals.

Replace the water filter cartridge every 60 days. Soak the new cartridge in cold water for 5 minutes before inserting it. If you live in an area with very hard water, replace it every 30 days.

5. Troubleshooting

Error E1 flashes when the water tank is empty or not seated properly. Refill the tank, push it firmly down onto its base, and press Brew to resume. Error E2 means the boiler has overheated. Switch the machine off at the wall and wait 20 minutes before turning it on again. If E2 reappears, descale the machine. Error E3 indicates a pump fault. Do not keep pressing buttons; switch off, unplug the machine and contact customer support.

If the espresso has little or thin crema, the coffee is probably stale or ground too coarse. Use beans roasted within the last four weeks and adjust the grind finer. If no coffee comes out, the group head screen may be blocked; run a backflush with a cleaning tablet. If the portafilter leaks around the edge, check that the basket is correctly seated and remove any grounds from the rim.

If there is no steam, make sure the Steam light is solid blue, purge the wand, and use a pin to clear the tip holes. If the machine makes a loud buzzing noise, the tank is probably empty or an air lock has formed; refill the tank and run a rinse cycle.

The machine switches itself into standby after 30 minutes of inactivity to save energy. Press any button to wake it.

6. Warranty and Support

The Aurora X200 is covered by a 24-month limited warranty from the date of purchase. The warranty covers defects in materials and workmanship under normal household use. Accessories such as the milk jug, tamper and water filter are covered for 90 days.

Register your machine at the Aurora Coffee website within 30 days of purchase to extend the warranty to 36 months at no cost. Keep your receipt; proof of purchase is required for any claim.

The warranty does not cover damage caused by scale build-up where the machine has not been descaled as described in this manual, damage from using unapproved cleaning products, commercial use, or accidental drops. Cosmetic wear on the exterior is also excluded.

To make a claim, call customer support on 1-800-555-0142, Monday to Friday, 9 am to 6 pm Eastern Time, or write to support@aurora-coffee.example. Please have your serial number ready; it is printed on a label under the water tank. Repaired or replaced units carry only the remainder of the original warranty period. Do not return the machine to the store; support will arrange a prepaid courier collection.