


ENPEP-BALANCE File Structure

ENPEP-BALANCE Training CourseSingapore December 5-9, 2011



Guenter CONZELMANN

Center for Energy, Environmental, and Economic Systems Analysis Decision and Information Sciences Division (DIS)

ARGONNE NATIONAL LABORATORY

9700 South Cass Avenue


Argonne, IL 60439

guenter@anl.gov; ++1-630-252-7173




The Default Installation Folder is C:\Program Files\ENPEPWIN


- In general, the software can be installed anywhere
- Windows VISTA and WINDOWS 7 users need to install under C:\ENPEPWIN



The BALANCE Folder Contains the ENPEP-BALANCE Executable, Databases, Output Reports, and the Run Folder



The DATABASE Folder Typically Contains all your Databases (But, in General, Databases Can be Located Anywhere)




The Model Always Works with Just One Database: ENPEPWIN.db

- Open (double-click) your database, e.g., DEMO.DB
- The software will make a copy of DEMO.DB and rename it to ENPEPWIN.DB
- When you create cases, modify input data, run your simulation, and view result, all of this is done within ENPEPWIN.DB
- When you exit the database, the software will make a copy of ENPEPWIN.DB and rename it to DEMO.DB (and overwrite the previous one)




The REPORTS Folder Contains all Text-File Reports Created by the Model - Organized by Database






Available Report Files



Within the DEMO DATABASE, there may be 3 cases (10, 12, 95); this is why each file is shown three times; All files are accessible through the interface as well





The RUN Folder Contains the Actual Simulation Engine (C-Code) and Input & Output Files of Most Recent Model Run

