

SMECO Viewer

user guide

introduction

SMECO Viewer is an interactive 3D platform designed for visualization, inspection, and navigation of ship machinery systems and components. The application allows users to explore equipment assemblies, isolate components, view technical information, and access related documentation.

access authorization

Access to SMECO Viewer is restricted to authorized personnel only.

Users may access the platform only after receiving valid credentials and approval from the responsible organization. Unauthorized access, credential sharing, or misuse of the platform is strictly prohibited.

login procedure

1. Open the SMECO Viewer application.
2. Enter your assigned username.
3. Enter your assigned password.
4. Click **Login** to access the platform.

documentation

The Documentation section provides access to user manuals, technical instructions, and supporting documents related to the platform and available systems.

support

If you have received authorization to use SMECO Viewer but are unable to access the platform, please contact technical support.

Phone: +385 99 222 222

Please provide your name, organization, and a brief description of the issue when requesting assistance.

about

The About section contains general information regarding the SMECO Viewer platform, its purpose, and system overview.

disclaimer

This platform contains technical information intended for authorized users only. Users are responsible for maintaining the confidentiality of their login credentials and complying with all applicable company policies and procedures.