

Technics SX-WSA1R

System Exclusive Reference

Acoustic Modeling Synthesizer Module

Applies equally to the SX-WSA1 keyboard

Operating system version 2.0

Unofficial

This document is not published, endorsed or checked by Technics or Panasonic. It was written by inspecting a disassembly of the program

ROMs — the same ROMs ship in the SX-WSA1 keyboard and the SX-WSA1R rack — operating system version 2, and checking the result against a bulk dump captured from a real instrument.

Contents

1	Overview	4
1.1	Applicability	4
1.2	Ports	4
1.3	Relationship to the published documentation	4
1.4	Verification	5
1.5	Conventions	6
2	At a glance	7
2.1	Frame	7
2.2	Messages	7
2.3	Rules	7
2.4	Bulk dump	8
2.5	Errors	8
3	Message framing	9
3.1	Identifiers	9
3.2	Termination	9
3.3	Length limit	9
4	The Technics message set	10
4.1	Fields	10
4.2	Commands	10
4.3	Which fields each message carries	11
4.4	Tempo	12
4.5	Parameter commands	12
5	Bulk dump	13
5.1	Categories and what each transmits	13
5.2	Data message — BTR	14
5.3	Payload encoding	15
5.4	Checksum	15
5.5	Requesting a dump — DRQ	15
5.6	Opening a transfer	15
5.7	Acknowledgement and retry	16
5.8	Continuation — CDD	16
5.9	Closing	16
5.10	Receiving	16

6	What a block contains	17
6.1	Signatures	17
6.2	Names	18
6.3	Inside the SOUND block	18
6.4	Inside the COMBINATION block	18
6.5	Inside the SEQUENCER block	20
6.5.1	Inside a song record	20
6.5.2	PERFORMANCE	21
7	Parameter messages	22
7.1	The address	22
7.2	Parts	22
7.3	What the instrument actually accepts	23
7.4	Parameters and the bulk dump are the same bytes	23
7.5	What a parameter accepts	24
7.6	Names	27
7.7	Whole-category request	28
7.8	The sound areas	28
8	The sound areas	29
8.1	How a normal sound is laid out	29
8.2	How a drum sound is laid out	30
8.3	What is transcribed here, and how far it is checked	30
8.4	Normal Sound parameters	31
8.5	Drum Sound parameters	35
9	Effects	39
9.1	What the type byte selects	39
9.2	What the value bytes mean	39
9.3	From a byte to a quantity	43
10	Enumerations	46
10.1	Control functions	46
10.2	Filter values	47
10.3	Interaction connect	47
11	Universal System Exclusive	48
11.1	Recognised messages	48
11.2	Messages not recognised	48
11.3	Practical consequences	48
11.4	The identifier is checked once	49
12	Settings that affect System Exclusive	50
12.1	The EXCLUSIVE filter	50
12.2	Which sockets carry what	51
12.3	Memory protect	51
13	Errors	52
13.1	The messages	52
13.2	ERROR 40 — wrong identification	52
13.3	ERROR 41 — reception	52
13.4	ERROR 42 — transmission	53

13.5 Interference from other traffic	53
14 SX-WSA1 and SX-WSA1R	54
15 Relationship to other Technics instruments	56
15.1 What is shared	56
15.2 What distinguishes the products	56
15.3 Dump regions differ	57
16 Worked examples	58
16.1 A parameter, written and read back	58
16.2 A frame from a real instrument	58
17 Scope of this edition	59
17.1 Deliberately outside it	59
17.2 Open, and what would close it	59

Chapter 1

Overview

This is unofficial documentation

Nothing here comes from Technics or Panasonic, and nothing here has been checked by them. This document was written by inspecting a disassembly of the program ROMs, operating system version 2, and by confronting what that showed with a bulk dump captured from a real instrument. The same ROMs ship in both machines, so it describes the SX-WSA1 keyboard as fully as the SX-WSA1R rack; chapter 14 gives the two behavioural differences between them.

Technics did publish a specification of its own, and where that specification covers the same ground this document follows it and uses its terms — section 1.3 says what it is and where it differs. Everything beyond it is inference from a disassembly, and inference can be wrong. Treat a statement here as a report of what one machine was observed to do, not as a guarantee about yours.

The Technics SX-WSA1R exchanges data over MIDI System Exclusive. This reference describes the messages it sends and accepts: their byte layout, the bulk-dump transfer protocol, the universal messages it honours, and what it reports when a transfer fails.

1.1 Applicability

This reference describes operating system version **2.0**. An earlier version 1 exists; its behaviour may differ and is not covered.

1.2 Ports

The instrument has two sets of MIDI sockets, MIDI 1 and MIDI 2. Ordinary performance data is handled on both. **Bulk dump transfers use MIDI 1 only** — a dump offered on MIDI 2 is not received, and the instrument sends dumps only from MIDI 1.

1.3 Relationship to the published documentation

Technics documented this instrument's System Exclusive implementation, in the *Reference Guide* that shipped alongside the two user manuals. Its pages 34–35 carry a MIDI implementation chart headed *Synthesizer* [SX-WSA1] *Synthesizer module* [SX-WSA1R], and pages 41–56 give the message format, the address map and the parameter tables. Where that guide and this reference describe the same thing, the guide's terms are used here and its statements are followed.

This reference exists because the published specification describes the *format* and not the *behaviour*. It does not say what raises each error number, that a dump can be requested only while one screen is displayed, that the EXCLUSIVE filter governs a single message, that the rack refuses two functions silently, or that the instrument stops announcing its own General MIDI changes once a controller has sent one. Those are the subject of the chapters that follow, and they were established by decoding the program and by checking a dump from a real machine.

An earlier edition of this reference said no chart was published

It said the instrument shipped without a MIDI implementation chart. That was wrong: the chart and the full message format are in the *Reference Guide*, which is a separate volume from the user manual the claim had been checked against. The document now takes the published specification as its starting point.

One statement of the published documentation is contradicted here: the meaning of ERROR 42, set out in chapter 13.

1.4 Verification

The message layouts, the payload encoding and the checksum rule in this reference have been checked against a bulk dump captured from a real instrument: 2 883 messages. Despite its name the capture is a three-category session — SYSTEM, PART & MIDI, SOUND and COMBINATION — which matters, because the first of those is the category chapter 7 maps, so the parameter tables can be read against it directly. Of these, 2 876 carry a checksum, and all 2 876 verify under the rule given in chapter 5. Every transfer in the capture delivered exactly the byte count its header declared.

The parameter placement in chapter 7 has been checked against the same capture. The SYSTEM, PART & MIDI category was reassembled from it and each parameter’s own field read out of the result, for all 32 parts: 1 833 fields, of which 1 832 hold a value inside the range the instrument accepts for that parameter. Run against a plausible but wrong placement — one uniform stride for all 32 parts, instead of the two runs chapter 7 describes — the same check puts 69 fields out of range, so it is capable of rejecting a wrong map.

What the capture covers, and what covers the rest

Three of the four bulk-dump categories appear in it. SEQUENCER does not, and cannot: the capture came from a rack, which refuses that category (chapter 14).

That category is confirmed a different way. The eight address-and-length pairs the instrument accepts were decoded from the program, and Technics printed the same lengths in its *Reference Guide*. The two sets are identical, area by area, including all three SEQUENCER blocks and the guide’s own word *Variable* for the last of them. The guide also prints SEQUENCER : WSA1 ONLY beside its request table — the same restriction the program gives the rack.

What a capture would still add for that one category is frame-level behaviour — its checksums, continuation and acknowledgements have been watched on the other three, and the program runs all four through one path — and the part of a song record that section 6.5 does not reach, which is now the 672 bytes outside its record stream and the PERFORMANCE block.

Two fields in that capture label themselves. Every part’s MIDI channel holds its own

part number, so the 32 parts spell out an unbroken ramp from 0 to 31 — which the wrong placement interrupts at part 8, the first part past the gap. Every part's pan holds 64, the value the instrument's own scale displays as CTR. Those two names in chapter 7 therefore rest on a real dump as well as on the instrument's screen.

1.5 Conventions

Byte values are hexadecimal. A field written *nn* takes one of the values listed for it. Ellipses inside a message stand for a body whose length depends on the message.

Every message begins with F0 and ends with F7, as required by MIDI.

Real-time messages are safe inside a transfer

System Real Time bytes (F8–FF) may be interleaved anywhere inside a System Exclusive message without disturbing it. Conversely, while the instrument is receiving a System Exclusive message it ignores F8 TIMING CLOCK, FA START, FB CONTINUE and FC STOP for transport purposes.

Chapter 2

At a glance

Everything in this chapter is stated again, with its conditions, in the chapters that follow. This page is for someone who already knows the protocol and wants the bytes.

2.1 Frame

F0 50 CMD 04 *md* 11 [ADR×3 SIZ×3 DT... *cn sm*] F7

04 is PC, the product; *md* is 00 for the SX-WSA1 and 01 for the SX-WSA1R, and both are accepted by both; 11 is VER, the exclusive specification's version. ADR and SIZ are 21-bit values in three seven-bit bytes, most significant first. There is no device or unit number anywhere.

2.2 Messages

F0 50 21 04 <i>md</i> 11 F7	HRQ	hand shake request
F0 50 22 04 <i>md</i> 11 F7	HRT	hand shake routine
F0 50 23 7E F7	ACK	acknowledge
F0 50 24 7E F7	NAK	not acknowledged
F0 50 25 <i>lo hi</i> F7	TMP	tempo, <i>lo</i> + 16 <i>hi</i> ; no checksum
F0 50 27 7E F7	EOK	end of category
F0 50 28 7E F7	END	end of dump
F0 50 29 7E F7	ERR	abort
F0 50 2A 7E F7	FUL	destination full
F0 50 2B ...	DRQ	request: ADR, SIZ, no DT
F0 50 2C ...	ITR	write one parameter
F0 50 2D ...	BTR	bulk data, first frame
F0 50 7E ...	CDD	bulk data, every frame after
F0 7E 7F 09 01 F7	General MIDI System On	
F0 7E 7F 09 02 F7	General MIDI System Off	

2.3 Rules

Payload. Each source byte goes out as two bytes, **high nibble first**: F1 becomes 0F 01. A payload is always an even number of bytes.

Checksum. $sm = (0 - S) \& 7F$, where S sums every byte from 50 through cn . Equivalently everything after F0, checksum included, sums to zero modulo 128. Verified on reception for 7E, 2B, 2C and 2D only.

Continue. cn is 01 while more frames follow, 00 on the last.

Size. At most 256 bytes per message including F0 and F7: 120 source bytes in a BTR frame, 125 in a CDD frame.

2.4 Bulk dump

ADR	area	menu name
40 00 00	PANEL	SYSTEM, PART & MIDI
20 00 00	SOUND MEMORY	SOUND
50 00 00	COMBINATION	COMBINATION
60 00 00	SEQUENCER	SEQUENCER (keyboard only)

Send DRQ with one of those to ask for a category. The instrument must be showing the SYSEX BULK DUMP screen to receive a dump, and bulk traffic works on the MIDI 1 sockets only.

2.5 Errors

ERROR 40 wrong product, model or version. ERROR 41 anything wrong with reception, including a missing acknowledgement. ERROR 42 an internal deadline, not a fault at the far end. ERROR 21 the destination is full.

Chapter 3

Message framing

3.1 Identifiers

The instrument accepts exactly two System Exclusive identifiers:

identifier	meaning
50	Matsushita (Technics)
7E	Universal Non-Real Time

A message carrying any other identifier is tracked to its F7 and discarded. No error is reported for it.

There is no device or unit number after the identifier

Many instruments place a device id immediately after the manufacturer identifier. The SX-WSA1R does not. The byte following 50 is already CMD, the command, described in chapter 4. A model byte does appear two positions later in most commands, but it names the model, not the device, and it is not where the convention would put a device id.

3.2 Termination

A message ends at F7. If any other status byte in the range 80–F6 arrives while a message is open, the message is abandoned and its contents discarded.

3.3 Length limit

A complete message may not exceed 256 bytes counting F0 and F7, that is 254 bytes between them. A longer message is abandoned and, inside a bulk-dump session, reported as a reception error. Dumps sent by the instrument use the full 256 bytes for all but the last message of each transfer.

Chapter 4

The Technics message set

4.1 Fields

Technics' published specification names the fields of a Technics System Exclusive message. This reference uses those names.

field	value	meaning
SOX	F0	exclusive status
IDC	50	Technics identifier
CMD		command, see below
PC	04	product category, WSA
	7E	DMY, the dummy used where no product is named
MD	00	model, SX-WSA1
	01	model, SX-WSA1R
VER	11	exclusive version 2.1
<i>then, for the messages that carry data:</i>		
ADR	3 bytes	a 21-bit address, seven bits each, most significant first
SIZ	3 bytes	length in source bytes, encoded the same way
DT		the data
CN	00/01	continue identifier
SM		checksum
EOX	F7	end of exclusive

VER is a version, not part of a model identifier

11 is the version of the *exclusive specification*, 2.1. It is not an operating system version — this instrument's operating system 2.0 sends VER = 11 — and it is not part of a model code. The model is MD, the byte before it.

4.2 Commands

After F0 50, CMD selects the message.

CMD		
21	HRQ	hand shake request
22	HRT	hand shake routine
23	ACK	acknowledge
24	NAK	negative acknowledge
25	TMP	tempo data
27	EOK	end of block
28	END	end
29	ERR	error
2A	FUL	memory full
2B	DRQ	data request
2C	ITR	individual data
2D	BTR	data block
7E	CDD	continuing data

The instrument accepts one further value that the published table does not list, 7F, and does not accept 26.

4.3 Which fields each message carries

ACK, NAK, EOK, END, ERR and FUL name no product: they carry PC = 7E DMY and stop there, with no MD and no VER. That is why they are five bytes long.

message	
F0 50 23 7E F7	ACK
F0 50 24 7E F7	NAK
F0 50 27 7E F7	EOK, end of block
F0 50 28 7E F7	END, end of dump
F0 50 29 7E F7	ERR
F0 50 2A 7E F7	FUL, memory full
F0 50 21 04 <i>md</i> 11 F7	HRQ, hand shake request
F0 50 22 04 <i>md</i> 11 F7	HRT, hand shake routine

DRQ, ITR and BTR carry PC, MD and VER, then ADR and SIZ, then CN and SM. ITR and BTR carry DT between them; DRQ, which asks rather than tells, carries none. CDD carries DT, CN and SM with no address at all.

MD is rewritten on transmission

The keyboard transmits MD = 00, the rack 01. The rack substitutes the byte as the message leaves, on every 21, 22, 2C and 2D message it sends, and recomputes the checksum afterwards, so the substitution is invisible to a receiver that validates it. A bulk dump captured from a real rack carries 04 01 11 throughout.

Reception is model-blind. Both values are accepted by both models, on every command that carries MD, and reach the same handler; a message is never refused, ignored or treated differently because of it. A receiver must therefore accept both, and a file dumped from one model loads into the other.

A message whose PC, MD or VER the instrument does not recognise is rejected with ERROR 40.

4.4 Tempo

TMP carries a tempo and nothing else:

F0 50 25 *lo hi* F7

Six bytes. Unlike every other Technics command it carries **no PC, no MD, no VER and no checksum**, and any bytes sent beyond the fifth are ignored. The tempo is nine bits sent low nibble first: $value = lo + 16 hi$. The accepted range is 40 to 300 beats per minute and a value outside it is treated as 120.

This message is the one thing the EXCLUSIVE filter governs; see chapter 12. It is also one of the two things the rack does not support; see chapter 14.

4.5 Parameter commands

DRQ requests and ITR writes an individual parameter. Both address the space chapter 7 sets out; chapter 16 works one through byte by byte.

Chapter 5

Bulk dump

Bulk dump transfers the instrument’s internal data as System Exclusive. The instrument is silent for the duration, and the transfer uses the MIDI 1 sockets only.

5.1 Categories and what each transmits

The SYSEX BULK DUMP screen offers five categories. Each sends one or more BTR messages at fixed addresses. The menu’s names and the published address map’s names for the same data differ; both are given.

category	area	ADR	SIZ	length	blocks
SYSTEM, PART & MIDI	PANEL	40 00 00	00 00 20	32	
		40 00 20	00 12 60	2 400	
SOUND	SOUND MEMORY	20 00 00	10 00 00	262 144	32
COMBINATION	COMBINATION	50 00 00	00 06 00	768	
		50 06 00	05 40 00	90 112	16
SEQUENCER	SEQUENCER	60 00 00	00 18 00	3 072	
		60 18 00	01 70 00	30 720	
		62 08 00	set at send time		
TOTAL KEYBOARD	the four categories in the order above				

Lengths are in source bytes; on the wire each occupies twice as many, because of the payload encoding described below.

These lengths are confirmed by the manufacturer

Every length in the table was decoded from the program, and Technics prints the same set in its *Reference Guide*. The two agree area by area, including SEQUENCER, whose last block the guide also calls variable rather than giving it a size.

The *blocks* column is internal structure, not extra messages: SOUND sends one header covering all 262 144 bytes, which is 32 repeats of an 8 192-byte layout, and COMBINATION’s second block one header covering 90 112 bytes as 16 repeats of 5 632. Those are the instrument’s 32 sounds and 16 combinations.

TOTAL KEYBOARD runs the four categories one after another in the order listed, each closed by its own end-of-category message, with a single end-of-dump message after the last.

The transmit order is not the menu order

The table above is in transmit order, which a capture from a real instrument confirms: SYSTEM, PART & MIDI goes first. The SYSEX BULK DUMP menu lists the same categories in a different order, with SOUND at the top. A receiver should take each transfer's ADR as the statement of what is arriving, and not infer the category from its position in the session.

The SEQUENCER category is the only one whose final message has no fixed length — it carries as much recorded material as the instrument holds.

The address is an exclusive address, not a memory address

ADR is a position in the published MIDI exclusive address map, which chapter 7 gives in full. It is not an address inside the instrument: SOUND and COMBINATION are held side by side in the machine, yet their exclusive addresses are 786 432 apart. For a bulk dump it is best treated as a fixed name. On reception the instrument compares ADR and SIZ against a fixed list and performs no arithmetic on them, so seven of the eight blocks are pinned on all six bytes; see below.

5.2 Data message — BTR

F0 50 2D 04 *nn* 11 *a2 a1 a0 l2 l1 l0 data... c sum* F7

nn MD, the model: 00 or 01.

a2 a1 a0 ADR, the destination, three bytes, most significant first, seven bits each: the value is $a_2 \times 128^2 + a_1 \times 128 + a_0$.

l2 l1 l0 SIZ, the length in *source* bytes, encoded the same way.

data DT, the payload, encoded as described below.

c CN, the continue identifier: 01 if further messages follow, 00 on the last.

sum SM, the checksum.

How much each frame carries

A complete message may not exceed 256 bytes including F0 and F7 (chapter 3), and the two frame shapes reach that limit differently, because a BTR header is eleven bytes where a CDD continuation header is two:

frame	total	payload bytes	source bytes
BTR, the first of a transfer	255	240	120
CDD, every one after it	256	250	125

Longer transfers are split across as many CDD frames as needed. Those figures are the observed maxima in a dump from a real instrument, not a stated limit; a sender may use less.

5.3 Payload encoding

Each source byte is sent as two message bytes, **high nibble first**:

$$b \longrightarrow (b \gg 4), \quad (b \& 0F)$$

So source byte **F1** appears on the wire as **0F 01**, and the payload occupies twice as many bytes as the length field states. A receiver rejoins them as $((\text{first} \& 0F) \ll 4) | (\text{second} \& 0F)$.

An odd number of payload bytes is invalid.

5.4 Checksum

Let S be the eight-bit sum of every byte from the identifier **50** through the continuation flag inclusive. Then

$$\text{sum} = (0 - S) \& 7F$$

The leading **F0**, the checksum byte itself and the trailing **F7** take no part in the sum. Equivalently, the sum of every byte after **F0** including the checksum is zero modulo 128.

The checksum is not verified for every family

On reception the checksum is checked only for families **7E**, **2B**, **2C** and **2D**. For the other accepted families a wrong checksum passes unremarked.

5.5 Requesting a dump — DRQ

A dump can be asked for over MIDI; the front-panel **SEND** button is not the only way to start one. The request names a category by the top byte of **ADR**:

F0 50 2B 04 nn 11 area 00 00 x x x F7

ADR	category requested
40	SYSTEM, PART & MIDI
20	SOUND
50	COMBINATION
60	SEQUENCER

The three bytes of **siz** are ignored; any values are accepted. The instrument then runs exactly the transfer the corresponding menu row would have run.

There is no request for **TOTAL KEYBOARD**: the four categories must be asked for one at a time.

5.6 Opening a transfer

A dump begins with a two-step exchange. Each step is attempted up to three times.

1. The sender transmits **F0 50 21 04 00 11 F7** and expects **F0 50 22 04 nn 11 F7**.
2. The sender transmits **F0 50 22 04 00 11 F7** and expects **F0 50 23 7E F7**.

If the exchange succeeds, every subsequent data message must be acknowledged. If all three attempts of the first step fail, **the dump proceeds anyway, without acknowledgements**, at a fixed pace of roughly 51 ms between messages.

5.7 Acknowledgement and retry

With acknowledgements in force, each data message must be answered with F0 50 23 7E F7. Any other reply causes the same message to be retransmitted, up to three attempts, after which the transfer is abandoned.

A reply is awaited for about 5.1 seconds; during the opening exchange the wait is about 2.05 seconds.

5.8 Continuation — CDD

Data messages after the first open with F0 50 7E, CDD, followed by DT, CN, SM and F7. A continuation carries no address.

5.9 Closing

At the end of each category the sender transmits F0 50 27 7E F7 and waits for an acknowledgement. At the end of the whole transfer it transmits F0 50 28 7E F7. If the transfer was abandoned after three failed retries it transmits F0 50 29 7E F7.

5.10 Receiving

When the SX-WSA1R is the receiver it answers each data message with F0 50 23 7E F7 to accept, F0 50 24 7E F7 to reject, and F0 50 2A 7E F7 when the incoming data is larger than the destination.

While a bulk-dump session is open the instrument accepts only the 50 identifier; universal messages are not honoured until the session ends.

The instrument must be on the SYSEX BULK DUMP screen to receive

A dump cannot be pushed to an idle instrument. Reception happens only while that screen is displayed; a dump sent at any other time is parsed, discarded, and not reported.

A dump offered on the MIDI 2 input is never received either, at any time. This is what lies behind the published instruction to use MIDI 1 for bulk transfers.

Seven of the eight patterns are pinned on all six bytes, address and length together. Sending a correct address with a shortened length is not a short transfer — it is an unrecognised message, refused with ERROR 41. Only SEQUENCER block 3 has its length read as a number, because that block's size varies. An arbitrary destination cannot be written.

The one length the message itself controls is SEQUENCER part 3, which is capped at 330 752 bytes; beyond that, and whenever the destination fills mid-message, the instrument answers F0 50 2A 7E F7 and reports ERROR 21.

Memory-full is treated as end-of-dump

When the SX-WSA1R is *sending* and the receiver answers F0 50 2A 7E F7 to report that its memory is full, the instrument treats that exactly as it treats F0 50 28 7E F7, end of dump. It stops, and it reports success. A sender that needs to know whether the data arrived cannot rely on the instrument to notice.

Chapter 6

What a block contains

Every block opens with a fixed signature, and two of them carry readable names, which let a program check a stored dump and list what is in it. Beyond that, all three of the SOUND, COMBINATION and SEQUENCER blocks are laid out below, each to a different depth.

6.1 Signatures

The bytes below are the first bytes of the reassembled block — after the payload has been rejoined from its nibbles, not as they appear on the wire. They were read out of a dump from a real instrument, and the two rows of each entry are the same sixteen bytes shown twice, as hexadecimal and as text.

block	ADR	first sixteen bytes	as text
SYSTEM, PART & MIDI 1	40 00 00	5A 5A 01 00 57 41 30 00 00 00 A0 00 00 00 00 00	ZZ..WA0.
SYSTEM, PART & MIDI 2	40 00 20	78 10 20 20 20 20 20 20 20 20 20 20 20 20 20 20	x. x.
SOUND	20 00 00	57 53 41 20 53 4F 55 4E 44 20 52 41 4D 20 53 30	WSA SOUN D RAM SO
COMBINATION 1	50 00 00	5A 5A 5A 5A 00 00 57 53 41 31 20 20 01 00 00 02	ZZZZ..WS A1
COMBINATION 2	50 06 00	78 10 20 53 70 61 63 65 20 49 6E 66 69 6E 69 74	x. Space Infinite

A file whose first bytes do not match the block it claims to be is not a dump of that category.

The first SYSTEM, PART & MIDI block is a signature in the fullest sense: all 32 of its bytes are a constant the instrument copies out of its own program when it initialises, with one byte filled in afterwards. It carries no settings.

The instrument writes its signature but does not check it

Two routines copy that constant into memory and both are plain copy loops. No comparison against it was found anywhere in either program image, and none against its leading 5A 5A either. **Do not expect a block with a wrong signature to be refused.** Checking it is something a librarian should do; the instrument does not.

The coverage of that negative: every three-byte pointer to the constant, which is two sites, and every immediate comparison against 5A 5A across both images. Code reaching the constant from a different base, or comparing through a pointer built elsewhere, would not have been seen.

6.2 Names

The SOUND block continues, immediately after its sixteen-byte signature, with sixteen-byte names in the instrument’s own character set, padded with spaces. The second COMBINATION block and the second SYSTEM, PART & MIDI block use a different framing: a two-byte prefix, then a sixteen-byte name, then two further bytes.

A librarian can therefore show the user what a stored file holds — “SWEEP PAD”, “Space Infinity” — without decoding anything else.

6.3 Inside the SOUND block

The SOUND block is sound *memory*, and it is laid out in four banks of 10000 bytes. Within a bank the stored sounds are packed back to back, and a stored sound **is the same 713-byte layout chapter 8 gives for the sound being edited** — so its name is its first sixteen bytes, and every parameter in that chapter is at its stated offset from the start of the record.

	at	
bank b	$10000 \times b$	four banks
stored sounds	359 in bank 0, 090 in the others	713 bytes each
a drum kit’s 128 notes	B468	150 bytes each

A stored drum kit is likewise the layout of chapter 8: its 128 note records sit at a 150-byte stride, each beginning with its thirteen-character name.

6.4 Inside the COMBINATION block

The larger COMBINATION block is **128 stored combinations of 704 bytes**, arranged as sixteen banks of eight. The banks’ names are the last 256 bytes of the smaller COMBINATION block, one name per bank; each combination carries its own sixteen-character name two bytes into its record.

A combination is a stream of parameter records

The 704 bytes are not a fixed layout but a **tagged stream**. Each record is a tag byte, a length byte, then that many bytes of payload; the stream ends with FF FF and fills the 704 exactly. Every one of the 128 combinations has the same 23 records in the same order.

at	tag	length	
000	78	16	the combination's name
012	60	12	effect common
020	61	30	EFFECT1
040	62	30	EFFECT2
060	63	30	REVERB
080	00, 20	30 each	part 1, two records
...	...		parts 2 to 8, the same pair
280	92	14	key scaling and scale tuning
290	79	44	part common
2BE	FF FF		end of stream

The tags are the instrument's own record numbers

This is what makes the format legible. A tag is not arbitrary: all 23 are record numbers in the parameter area of chapter 7, and a record's payload is that record's bytes. So 20 is part 1's own block — the same 20 that addresses part 1 in an ITR message — and the parameter tables name its fields directly.

The record numbers also run in address order with exactly two bytes between consecutive records, which are the tag and length. The stream is a copy of a region of the instrument's memory with its record headers intact.

One byte the parameter tables do not reach

A part's first record carries, at +15, six flags that no parameter addresses. Each says whether the part uses its own value for one of the MIDI MULTIPLE MESSAGES OUTPUT settings or the instrument's internal one:

bit	parameter
0	PROGRAM CHANGE
1	VOLUME
2	PANPOT
3	CHORUS DEPTH
4	REVERB DEPTH
5	BANK SELECT

Six sibling routines each test one of those bits and then choose between the part's internal field and its override field; the six parameters are exactly the six the published tables give an override at all. Bits 6 and 7 are not accounted for.

That also explains the second SYSTEM, PART & MIDI block, whose first bytes chapter 6 lists as 78 10: those are not a signature but the first record's tag and length — the same stream, beginning with the same name record.

How this was established, and why it is not a coincidence

A dump from a real instrument was walked at a 713-byte stride from the first stored sound. Sixty-four consecutive records began with a printable sixteen-character name, in every bank, and the drum runs gave 128 consecutive thirteen-character names in every bank. A stride one byte either side of 713 breaks the run at the first record. The combination stream is checked differently: its records must tile the 704 bytes and land on FF FF. All 128 do, with the same 23 records in the same order, and all 23 tags are live record numbers in the parameter area.

6.5 Inside the SEQUENCER block

No capture available for this reference contains a SEQUENCER transfer — the one to hand came from a rack, which refuses that category. The top-level arrangement is settled all the same, because the program gives it away, and the record’s own contents are read below from a native sequencer file off a disk, which carries the HEADER block byte for byte.

block	size	
LOCATION	3 072	one song record: the song being edited
HEADER	30 720	ten song records of 3 072
PERFORMANCE	variable	the recorded material

A song’s name is **six characters at offset CA** of its record. One routine establishes all of it at once: it blanks that name in three places, and its destinations are literal — the LOCATION block at CA, and the HEADER block at $\text{song} \times 3072 + \text{CA}$, the multiply written as a shift by eleven plus a shift by ten. Ten records of 3 072 fill the block exactly, and the published manual says the sequencer holds ten songs.

That LOCATION carries the name at the *same* offset is what shows it to be a song record as well, rather than a directory: it is the working copy, in the shape of a stored one.

6.5.1 Inside a song record

A native sequencer file from a disk, 01220497.SQF, is 30 720 bytes — the HEADER block exactly — and it decodes on the arrangement above without adjustment: ten records of 3 072, each opening 5A 5A 5A 5A, each with six printable characters at +CA. Nine of the ten are byte-identical, which is what ten song slots with one song recorded into them should look like, and the recorded one differs from the empty template in 727 bytes.

Most of a song record is material this reference already names. From +220 it is a tagged stream in the same form as a combination, {tag, length, payload} runs closed by FF FF, and it falls into three:

at	records	
+220–+4DF	23	a complete combination , 704 bytes
+4E0–+AFF	49	parts 8–31, then record 7A
+B00–+B7F	5	records 98, 99, 80, 91, 93

The first stream is a combination in the strict sense: the same 23 records in the same order and the same 704 bytes as section 6.4 gives, compared field for field rather than by eye. So a song carries its own combination inside it.

The part records then run 00–1F for block A and 20–3F for block B, complete and without gaps: **a song has thirty-two parts**, the same thirty-two the parameter grammar addresses at block 20 plus the part number. Eight arrive inside the embedded combination and the other twenty-four follow it. Every one of their fields is named by chapter 7, because they are the same records — which puts 2 400 of a song record’s 3 072 bytes under names this reference already carries.

The 544 bytes ahead of the stream and the 128 after it are not covered.

6.5.2 PERFORMANCE

The same disk set carries a companion file of 179 200 bytes, which is everything the fixed-size song records are not — so it is the recorded material, the PERFORMANCE block. That correspondence comes from how the disk splits the sequencer and not from anything in the program, and it is the one claim here that rests on an inference rather than a decode.

What can be said about it is deliberately little. It is not an array of fixed-size records: no power-of-two chunking of the file leaves a single chunk empty, and its last byte is not padding. Its commonest bytes are 00 at 16.1 %, 81 at 14.6 % and 90 at 9.9 %, and 90 is MIDI note-on, so the stream is events rather than a table. The event framing is *not* decoded here. The opening bytes look like six-byte records and that does not survive contact with the rest of the file — across 179 200 bytes the longest run of 90 bytes six apart is one. Anyone continuing this should start from the playback routine rather than from the pattern the first few events appear to make.

Reassembly is self-checking

A block reassembled correctly comes out at exactly the length its own header declared. A wrong nibble order, or a payload taken with its trailing flag and checksum still attached, does not. Checking the length is a cheap way to confirm a receiver is unpacking correctly before trusting anything it produces.

Chapter 7

Parameter messages

Two commands address individual parameters rather than transferring blocks. ITR (2C) writes one; DRQ (2B) requests one.

F0 50 2B 04 *md* 11 *a2 a1 a0 s2 s1 s0 cn sm* F7

7.1 The address

ADR is a single 21-bit address, sent as three seven-bit bytes, most significant first. It is the same address space the bulk dump uses — a dump and a parameter write are two ways of reaching one map. The published map divides it as follows.

ADR	address	area	subarea	
00 00 00	000000	SYSTEM		real time
00 08 00	000400	SYSTEM		non-real time
00 10 00	000800	PART	COMMON	real time
00 18 00	000C00	PART	COMMON	non-real time
00 20 00	001000	PART	INDIVIDUAL	part 1, real time
00 20 40	001040	PART	INDIVIDUAL	part 1, non-real time
00 3F 40	001FC0	PART	INDIVIDUAL	part 32, non-real time
00 60 00	003000	PART	SPECIAL	real time
00 68 00	003400	PART	SPECIAL	non-real time
10 00 00	040000	NORMAL SOUND	INDIVIDUAL	real time
18 00 00	060000	DRUM SOUND	INDIVIDUAL	real time
20 00 00	080000	SOUND MEMORY	TOTAL	
40 00 00	100000	PANEL	HEADER	
40 00 20	100020	PANEL	PANEL DATA	
50 00 00	140000	COMBINATION	HEADER	
60 00 00	180000	SEQUENCER	LOCATION	

The last five are the bulk-dump categories of chapter 5. The ones above them are what an individual parameter message reaches.

7.2 Parts

A part occupies 80 bytes of the map, split in half: the first 40 are its real-time parameters and the second 40 its non-real-time ones. So for part *n*, counting from 1, the middle byte of

ADR is $20 + n - 1$, and the last byte is the parameter, below 40 for a real-time parameter and 40 or above for a non-real-time one.

All 32 parts take the same 57 parameters.

7.3 What the instrument actually accepts

Not every address in the map is a parameter. In the 00 area the instrument accepts 108 distinct addresses, which the tables below enumerate in full.

ADR middle	area	subarea	parameters
00, 01	SYSTEM		22
08	SYSTEM	non-real time	4
10, 11	PART	COMMON	24
20–3F	PART	INDIVIDUAL	57 each
60	PART	SPECIAL	1

Under 11, values of the last byte from 03 upward are admitted in three runs, one per effect processor:

run	processor	
20–36	EFFECT1	type, twenty values, send, dynamic control
40–56	EFFECT2	type, twenty values, send, dynamic control
60–75	REVERB	type, twenty values, dynamic control

Within a run the first address is the effect type and the next twenty are its parameters, whose meaning depends on the type selected. Any value of the last byte outside the three runs is accepted by the parser and then discarded, producing no error and no effect.

7.4 Parameters and the bulk dump are the same bytes

The PART and SYSTEM parameters and the PANEL bulk dump — the category the menu calls SYSTEM, PART & MIDI — are two views of one object. That dump carries 100000 to 100980, and every parameter of the 00 area is one byte, or a field of one byte, inside it.

This matters in both directions. An editor that writes parameters and a librarian that restores dumps are competing for the same storage, so a dump restored after a parameter write discards that write. It also gives a way to confirm any row of the tables below without opening the instrument: dump the category, change the one parameter, dump again, and the two dumps differ at the stated address and nowhere else.

Where a part’s record sits

Each part occupies a 40-byte record in that dump, and the offsets in table 7.1 are relative to the start of it. The records are in two runs:

part	record begins at
1 to 8	$1000A2 + 40 \times (\text{part} - 1)$
9 to 32	$1002E2 + 40 \times (\text{part} - 9)$

The part records are not one array

The obvious formula, $1000A2 + 40 \times (\text{part} - 1)$, is correct for the first eight parts and wrong for the other twenty-four. A 40-byte gap after part 8 holds common-block storage, and the parts resume above it. Code that assumes a single stride will read and write the wrong part for parts 9 upward, and will corrupt two common blocks on the way past.

7.5 What a parameter accepts

Each parameter has a fixed data length and a range of accepted values. A value outside the range is rejected without an error message. The *bits* column gives which bits of the dump byte belong to the parameter; where that is not all of them, other parameters share the byte, and a dump editor changing one must preserve the rest.

Three parameters accept an enumerated set rather than a range; sending any other value has no effect.

Two parameters where the published range and the range check disagree

The *values* column below is the range the instrument's own check enforces. For all but two parameters that is also the published range. The exceptions:

00 00 08 **MASTER TUNING**. Published as C0–00–3F, a signed value with 00 at concert pitch, spanning 427.3 to 453.0 Hz. The range check admits 48 to 192. A dump from a real machine holds 00 there — the published centre, and not a member of the checked range.

00 *nn* 05 **EFFECT2 ON/OFF**. Published as 00–01. The range check admits 0 to 127, and the instrument passes the value through a substitution before storing it, so reading it back does not return what was written.

Send what the published specification gives.

The accepted values are what a write is checked against

They are what the instrument takes from an ITR, not a guarantee about what a stored byte contains. A librarian should not validate a dump by checking it against these ranges.

Table 7.1: The 57 parameters of a part block. *p* is the third address byte; the offset is the byte's position inside that part's record in a SYSTEM, PART & MIDI bulk dump.

<i>p</i>	data	offset	bits	values	name
00	3	00	all	0–127	PROGRAM CHANGE & BANK
03	1	03	7F	0–127	VOLUME
04	1	05	7F	0–127	EFFECT1 SEND
05	1	06	7F	0–127	EFFECT2 ON/OFF
06	1	07	7F	0–127	REVERB SEND
07	1	08	7F	0–127	PANPOT
08	1	09	7F	28–100	KEY SHIFT

<i>p</i>	data	offset	bits	values	name
09	1	0A	all	0–255	FINE TUNE
0A	1	0B	7F	0–12	PITCH BEND RANGE
10	1	26	0F	0–1	ASSIGN MODE
14	1	0C	08	0–1	KEY SCALING
20	1	25	all	0–48	VELOCITY OFFSET
28	1	27	7F	0–127	KEY LAYER LOW
29	1	28	7F	0–127	KEY LAYER HIGH
2A	1	29	7F	0–127	VELOCITY LAYER LOW
2B	1	2A	7F	0–127	VELOCITY LAYER HIGH
30	1	23	all	0–1	MAIN OUT
31	1	24	all	enumerated, 4 values	SUB OUT
40	1	0D	20	0–1	LOCAL CONTROL
41	1	0D	1F	0–31	BASIC CHANNEL
42	1	0D	40	0–1	MIDI OUT SETTING
43	1	0D	80	0–1	MIDI IN SETTING
48	1	2F	10	0–1	MIDI INPUT FILTER: PROGRAM CHANGE
49	1	30	80	0–1	MIDI INPUT FILTER: BANK SELECT
4A	1	30	04	0–1	MIDI INPUT FILTER: VOLUME
50	1	33	10	0–1	MIDI OUTPUT FILTER: PROGRAM CHANGE
51	1	34	80	0–1	MIDI OUTPUT FILTER: BANK SELECT
52	1	34	04	0–1	MIDI OUTPUT FILTER: VOLUME
53	1	34	10	0–1	MIDI OUTPUT FILTER: PANPOT
54	1	34	20	0–1	MIDI OUTPUT FILTER: EFFECT DEPTH
55	1	33	40	0–1	MIDI OUTPUT FILTER: PITCH BEND
56	1	34	02	0–1	MIDI OUTPUT FILTER: MODULATION1
57	1	36	10	0–1	MIDI OUTPUT FILTER: MODULATION2
58	1	36	01	0–1	MIDI OUTPUT FILTER: REAL-TIME CREATOR-X
59	1	36	02	0–1	MIDI OUTPUT FILTER: REAL-TIME CREATOR-Y
5A	1	36	04	0–1	MIDI OUTPUT FILTER: REAL-TIME CONTROLLER-X
5B	1	36	08	0–1	MIDI OUTPUT FILTER: REAL-TIME CONTROLLER-Y
5C	1	34	01	0–1	MIDI OUTPUT FILTER: HOLD1
5D	1	36	20	0–1	MIDI OUTPUT FILTER: CONTROL PEDAL
5E	1	33	20	0–1	MIDI OUTPUT FILTER: AFTER TOUCH
60	1	0E	all	0–129	MIDI MULTIPLE MESSAGES OUTPUT: PROGRAM CHANGE
61	2	—	all	0–129	MIDI MULTIPLE MESSAGES OUTPUT: BANK SELECT
63	1	11	all	0–129	MIDI MULTIPLE MESSAGES OUTPUT: VOLUME
64	1	12	all	0–129	MIDI MULTIPLE MESSAGES OUTPUT: PANPOT
65	1	14	all	0–129	MIDI MULTIPLE MESSAGES OUTPUT: REVERB DEPTH
66	1	13	all	0–129	MIDI MULTIPLE MESSAGES OUTPUT: CHORUS DEPTH
68	1	37	all	28–100	MIDI OUT KEY TRANSPOSE
70	1	2B	40	0–1	CONTROLLER INTERNAL FILTER: PITCH BEND

<i>p</i>	data	offset	bits	values	name
71	1	2C	02	0–1	CONTROLLER INTERNAL FILTER: MODULATION1
72	1	2E	10	0–1	CONTROLLER INTERNAL FILTER: MODULATION2
73	1	2E	01	0–1	CONTROLLER INTERNAL FILTER: REAL-TIME CREATOR-X
74	1	2E	02	0–1	CONTROLLER INTERNAL FILTER: REAL-TIME CREATOR-Y
75	1	2E	04	0–1	CONTROLLER INTERNAL FILTER: REAL-TIME CONTROLLER-X
76	1	2E	08	0–1	CONTROLLER INTERNAL FILTER: REAL-TIME CONTROLLER-Y
77	1	2C	01	0–1	CONTROLLER INTERNAL FILTER: HOLD1
78	1	2E	20	0–1	CONTROLLER INTERNAL FILTER: CONTROL PEDAL
79	1	2B	20	0–1	CONTROLLER INTERNAL FILTER: AFTER TOUCH

Table 7.2: The parameters of the common blocks. The address is the one a SYSTEM, PART & MIDI bulk dump carries for the same byte.

<i>s</i>	<i>p</i>	data	address	bits	values	name
00	00	1	outside	01	0–1	SOUND MEMORY PROTECT
00	01	1	outside	02	0–1	COMBINATION MEMORY PROTECT
00	08	1	10094A	all	48–192	MASTER TUNING
00	10	1	10095A	0F	0–9	VELOCITY CURVE
00	11	1	10095C	7F	0–127	VELOCITY OFFSET
00	12	1	10095F	all	0–10	AFTER TOUCH CURVE
00	13	1	100960	7F	0–127	AFTER TOUCH THRESHOLD
00	20	1	10094E	all	enumerated, 4 values	DRUMS MAP SELECT
00	30	1	1008E4	0F	0–2	DATA LOAD FILTER: EFFECT & OUTPUT
00	31	1	1008E4	F0	0–2	DATA LOAD FILTER: REAL-TIME CREATOR 1-6
00	32	1	100907	04	0–1	DATA LOAD FILTER: COMBINATION OCTAVE
00	33	1	100907	02	0–1	DATA LOAD FILTER: MIDI SETTING
00	34	1	100907	01	0–1	DATA LOAD FILTER: KEY & VELOCITY LAYER
00	35	1	100907	08	0–1	DATA LOAD FILTER: MAIN OUT EQUALIZER
00	36	1	100907	10	0–1	DATA LOAD FILTER: KEY SCALING
00	40	2	—	7F	0–127	COMBINATION NUMBER and BANK
01	00	1	100935	0F	0–2	MIDI INPUT MODE
01	01	1	100935	F0	0–1	MIDI OUTPUT MODE
01	02	1	100936	1F	0–15	SINGLE CHANNEL
01	03	1	100936	20	0–1	LOCAL TOTAL

<i>s</i>	<i>p</i>	data	address	bits	values	name
01	04	1	100932	03	0–1	PROGRAM CHANGE MODE
01	05	1	100932	08	0–1	SINGLE CHANNEL PROGRAM CHANGE
08	00	1	—	—	0–6	INITIAL
08	08	1	—	F0	0–1	PLAY MODE REQUEST
08	10	1	—	—	0–127	COMBINATION WRITE REQUEST
08	11	3	—	—	0–1	SOUND WRITE REQUEST
10	00	1	1002B2	7F	28–100	KEY TRANSPOSE
10	10	1	1002A3	80	0–1	KEY SCALING MODE
10	11	1	1002A2	all	enumerated, 15 values	TOTAL KEY SCALING
10	12	1	1002A3	0F	0–11	KEY SCALING SHIFT
10	13	1	1002A4	all	0–255	Ckey DETUNE SETTING
10	14	1	1002A5	all	0–255	Dbkey DETUNE SETTING
10	15	1	1002A6	all	0–255	Dkey DETUNE SETTING
10	16	1	1002A7	all	0–255	Ebkey DETUNE SETTING
10	17	1	1002A8	all	0–255	Ekey DETUNE SETTING
10	18	1	1002A9	all	0–255	Fkey DETUNE SETTING
10	19	1	1002AA	all	0–255	Gbkey DETUNE SETTING
10	1A	1	1002AB	all	0–255	Gkey DETUNE SETTING
10	1B	1	1002AC	all	0–255	Abkey DETUNE SETTING
10	1C	1	1002AD	all	0–255	Akey DETUNE SETTING
10	1D	1	1002AE	all	0–255	Bbkey DETUNE SETTING
10	1E	1	1002AF	all	0–255	Bkey DETUNE SETTING
10	20	1	—	1F	0–17	MAIN OUT EQUALIZER LOW-FREQ
10	21	1	1002B3	3F	0–48	MAIN OUT EQUALIZER LOW-GAIN
10	22	1	—	1F	17–26	MAIN OUT EQUALIZER HIGH-FREQ
10	23	1	1002B5	3F	0–48	MAIN OUT EQUALIZER HIGH-GAIN
11	00	1	100034	01	0–1	EFFECT COMMON ALGORITHM
11	01	1	1002B7	0F	1–4	EFFECT1 OUTPUT SELECT
11	02	1	1002B7	F0	1–4	EFFECT2 OUTPUT SELECT
11	20	1	—	—	0–0	EFFECT1 TYPE
60	00	1	100905	7F	0–127	METRONOME VOLUME

parameter	accepted values	count
00 00 20	00 40 41 42	4
00 10 11	00 40 41 42 03 04 06 10 11 12 13 14 15 16 80	15
00 20 31	00 02 03 04	4

7.6 Names

Every name in the tables is the one Technics’ own parameter tables print for that address. None is inferred. Two of them are corroborated a second way, from a dump taken off a real machine: every part’s PANPOT reads 64, the value the instrument displays as CTR, and the 32 parts’ BASIC CHANNEL bytes read an unbroken ramp from 0 to 31.

The 08 block is marked receivable but not requestable: the instrument accepts a write to

it and will not report its contents. Its four addresses are commands rather than settings — they initialise a section, switch play mode, or ask for a store.

7.7 Whole-category request

DRQ also requests an entire bulk-dump category, as described in chapter 5. There ADR names one of the lower five rows of the map above.

7.8 The sound areas

ADR values beginning 10 and 18 reach NORMAL SOUND and DRUM SOUND, the individual sound being edited rather than any stored one. This edition does not enumerate their parameters.

Chapter 8

The sound areas

NORMAL SOUND and DRUM SOUND are the two areas of the address map that hold an instrument sound rather than a setting. They are reached the same way as any other parameter, with ITR to write and DRQ to request.

ADR	address	area
10 00 00	040000	NORMAL SOUND, individual
18 00 00	060000	DRUM SOUND, individual

This is the sound being edited, not a stored one

These addresses reach the instrument's working copy — the sound currently loaded for editing. They are not a way to read or write one of the 32 stored sounds. For those, use the SOUND bulk-dump category, which carries the whole sound memory at 20 00 00.

8.1 How a normal sound is laid out

The NORMAL SOUND area is **713 bytes**. It is one GENERAL DATA block, then four identical TONE DATA blocks, then four identical MODELING DATA blocks — the instrument's four tones and the four driver and resonator models that go with them.

block	size	repeats	parameter numbers
GENERAL DATA	217	1	000–0D8
TONE DATA	81	4	0D9, 12A, 17B, 1CC
MODELING DATA	43	4	21D, 248, 273, 29E
total	713		000–2C8

A parameter number is an offset from the start of the area, so the address of parameter p of tone n (counting tones from 1) is

$$040000 + 0D9 + 81 \times (n - 1) + p$$

expressed as ADR in the usual three seven-bit bytes, and the same with 21D and 43 for a modeling block. The tables below give one instance of each repeating block; the other three are identical at the offsets above.

Two independent sources agree on the size

The block sizes and repeat counts here come from Technics' published parameter tables. The figure of 713 bytes for the whole area comes from the program, decoded separately, and the guide never states it. The transcribed blocks tile 000 to 2C8 with no gap and no overlap and come to exactly that total, which is what makes the layout above trustworthy rather than merely plausible.

8.2 How a drum sound is laid out

The DRUM SOUND area is **19 608 bytes** and is arranged quite differently: a kit, then a table choosing a sound for each of the 128 note numbers, then 128 note records — one per key.

block	size	repeats	parameter numbers
KIT DATA	152	1	000–097
SOUND SELECT	256	1	098–197, two bytes per note
NOTE DATA	150	128	198 + 150 × note
total	19 608		000–4C97

Each note record is itself three kinds of block, and a drum note has *two* tones and two modeling blocks where a normal sound has four:

block	size	repeats	offset within the note
NOTE GENERAL DATA	18	1	000
NOTE TONE DATA	23	2	012, 029
NOTE MODELING DATA	43	2	040, 06B
total	150		

The modeling block is the same 43-byte layout a normal sound uses. The tone block is not: a drum tone has no pitch or filter envelope of its own and no layer ranges, which is what takes it from 81 bytes down to 23.

The note positions are checked against the guide's own table

The guide prints the starting number of every one of the 128 notes. The layout above implies them instead — 198 plus 150 per note — and the two agree wherever they were compared, including at the last row, NOTE:7F, which both put at 4C02. With the area also totalling the 19 608 bytes the program gives, that is three independent routes to the same arithmetic.

8.3 What is transcribed here, and how far it is checked

The tables give each parameter's number, its bit field within that byte, its name and its range. They were read from scans of the published tables, and the numbering is checked by the tiling described above. **The names, bit fields and ranges are not checked by anything;** a misreading of one would survive.

The enumerations these tables point at — the control functions a controller can be assigned to, the filter VALUE bytes for each filter mode, and the INTERACTION CONNECT table — are in chapter 10.

8.4 Normal Sound parameters

GENERAL DATA

no.	bits	parameter	values
000-00F	6-0	NAME (16 characters)	20-7F — space to }
010	7-6	ATTRIBUTE FLAG: PARAMETER MODE	00-00 — 0: NORMAL MODE, fixed
011	7-0	TONE ON/OFF	two bits per tone, 4th 3rd 2nd 1st
012	7-0	KEY ON MODE	per tone: 0 KEY ON, 1 KEY OFF, 2 LEGATO, 3 NON LEGATO
013	7-0	KEY SCALING	00-42 — 0 OFF, 1-22 octave, 64-66 all key on/off and phase, function select, depth same three bytes
014-016		CONTROLLERS: PITCH BEND	
017-019		MODULATION WHEEL 1 SELECT1	
01A-01C		MODULATION WHEEL 1 SELECT2	
01D-01F		MODULATION WHEEL 2 SELECT1	
020-022		MODULATION WHEEL 2 SELECT2	
023	6-0	REALTIME CREATOR BOX SELECT	bit per box, BOX1-BOX6
024	6-0	REALTIME CONTROLLER BOX SELECT	bit per box, BOX1-BOX6
025-027		CONTROL PEDAL SELECT1	
028-02A		CONTROL PEDAL SELECT2	
02B-02D		AFTER TOUCH SELECT1	
02E-030		AFTER TOUCH SELECT2	
031-054		BOX SELECT: CONTROLLER BOX1 X through BOX6 Y	twelve controllers, three bytes each, X then Y
055	3-0	PITCH OCTAVE SHIFT	06-0A — 6 is -2 oct, 8 is 0, A is +2 oct
056		(RESERVE)	
057-066		PITCH LFO BOX1-BOX4	four bytes per box: depth, speed, key sync and touch depth, wave and delay
067-076		LEVEL LFO BOX1-BOX4	same four bytes per box
077-086		FILTER LFO BOX1-BOX4	same four bytes per box
087	3-0, 7-4	MIXER OUTPUT SELECT: MAIN, SUB	00-05 — 0 no output, 1 MAIN, 2-4 SUB1-3, 5 EFFECT2
088	6-0	EFFECT SEND VOLUME: EFFECT1	00-7F
089	6-0	EFFECT SEND VOLUME: REVERB	00-7F

no.	bits	parameter	values
08A	3–0, 7–4	EFFECT OUTPUT SELECT: EFFECT1, EFFECT2	01-04 — 1 MAIN, 2-4 SUB1-3
08B	0	DSP EFFECT COMMON ALGORITHM	00-01 — 0 SERIAL, 1 PARALLEL
08C		EFFECT1 TYPE	see the guide's DSP EFFECT pages
08D-0A0		EFFECT1 PARAMETER VALUE1-VALUE20	meaning depends on the type
0A1		EFFECT1 ANOTHER EFF SEND	
0A2		EFFECT1 DYNAMIC CONTROL	
0A3		EFFECT2 TYPE	
0A4-0B7		EFFECT2 PARAMETER VALUE1-VALUE20	
0B8		EFFECT2 ANOTHER EFF SEND	
0B9		EFFECT2 DYNAMIC CONTROL	
0BA		REVERB TYPE	
0BB-0CE		REVERB PARAMETER VALUE1-VALUE20	
0CF		REVERB DYNAMIC CONTROL	reverb has no ANOTHER EFF SEND
0D0	7, 6, 3–0	DIGITAL EFFECT MODE: ON/OFF, PAN, EFFECT TYPE	00-0B — 0-1 CELESTE, 2-3 CHORUS, 4-5 ENSEMBLE, 6-7 TREMOLO, 8-9 DELAY, 10-11 SOLO EFFECT
0D1-0D8		DIGITAL EFFECT VALUE1-VALUE8	

TONE DATA

no.	bits	parameter	values
0D9	5–0	ATTRIBUTE DELAY	00-32 — 0 delay off
0DA	7–0	ATTRIBUTE PANNING	00-80 — 0-127 fixed pan, 128 random pan
0DB	6–0	TONE SELECT: TTN SELECT	00-7F
0DC	7–6, 5–4, 3–0	TONE KIND, TONE LOCATION, BANK SELECT	kind 0 NORMAL 1 DRUM 2 ATTACK; location 0 internal ROM 1 internal RAM 2 external ROM
0DD	7–0	PITCH KEY SHIFT	E8-18 — -24 to +24
0DE	7–0	PITCH DETUNE	80-7F — -128 to +127
0DF	7–6, 5, 4, 2–0	BOX CONTROL LFO-FM1: BOX SELECT, ON/OFF, PHASE, SCALE SELECT	scale 0 1/1 through 6 1/64, 7 FIX
0E0-0E9		PITCH ENVELOPE SHAPE: total depth, start pitch, attack time, peak level, decay1 time, sustain1 level, decay2 time, sustain2 level, release time, stop pitch	one byte each, in that order

no.	bits	parameter	values
0EA	7-0	PITCH ENV TOUCH FOLLOW ADR TIME	CE-32 — -50 to +50
0EB	7-0	PITCH ENV TOUCH FOLLOW DEPTH	CE-32
0EC	6-0	PITCH ENV KEY FOLLOW CENTER KEY	00-7F
0ED	7-0	PITCH ENV KEY FOLLOW ATTACK SLOPE	CE-32
0EE	7-0	PITCH ENV KEY FOLLOW DECAY SLOPE	CE-32
0EF	7-0	PITCH ENV KEY FOLLOW RELEASE SLOPE	CE-32
0F0	6-0	LEVEL VOLUME	00-7F — one step is 0.375 dB
0F1	7-0	LEVEL TOUCH DEPTH	CE-32
0F2	7-5	LEVEL TOUCH CURVE	00-06 — 0 is -3 curve through 6 is +3 curve
0F3	6-0	LEVEL KEY FOLLOW CENTER KEY	00-7F
0F4	6-0	LEVEL KEY FOLLOW LOW KEY LIMIT	00-7F
0F5	6-0	LEVEL KEY FOLLOW HIGH KEY LIMIT	00-7F
0F6	7-0	LEVEL KEY FOLLOW SLOPE	CE-32
0F7-0FA	6-0	LAYER KEY RANGE: low key select, low fade, high key select, high fade	00-7F
0FB-0FE	6-0	LAYER VELOCITY RANGE: low vel select, low fade, high vel select, high fade	00-7F
0FF	7-6, 5, 4	BOX CONTROL LFO-AM: BOX SELECT, ON/OFF, PHASE	
100-106		LEVEL ENVELOPE SHAPE: attack time, peak level, decay1 time, sustain1 level, decay2 time, sustain2 level, release time	
107	7-0	LEVEL ENV TOUCH FOLLOW ATTACK	CE-32
108	7-0	LEVEL ENV TOUCH FOLLOW DECAY	CE-32
109-10B	6-0	LEVEL ENV KEY FOLLOW: center key, low key limit, high key limit	00-7F
10C-10E	7-0	LEVEL ENV KEY FOLLOW: attack slope, decay slope, release slope	CE-32
10F	2-0, 7-5	FILTER MODE, TOUCH CURVE	00-06 — 0 THROUGH, 1 LPF12+EQ, 2 HPF12+EQ, 3 LPF24, 4 HPF24, 5 BPF
110	5-0	FILTER TOUCH DEPTH	00-32
111	7-6, 5, 4	FILTER LFO-FCM: BOX SELECT, ON/OFF, PHASE	
112-114	6-0	FILTER KEY FOLLOW: center key, low key limit, high key limit	00-7F
115	7-0	FILTER KEY FOLLOW SLOPE	CE-32

no.	bits	parameter	values
116-11F		FILTER ENVELOPE SHAPE: cutoff adjust, start point, attack time, peak level, decay1 time, sustain1 level, decay2 time, sustain2 level, release time, stop point	
120	7-0	FILTER ENV TOUCH FOLLOW ADR TIME	CE-32
121	7-0	FILTER ENV TOUCH FOLLOW DEPTH	CE-32
122	6-0	FILTER ENV KEY FOLLOW CENTER KEY	00-7F
123-125	7-0	FILTER ENV KEY FOLLOW: attack slope, decay slope, release slope	CE-32
126-129		FILTER PARAMETER VALUE1-VALUE4	meaning depends on the filter mode

MODELING DATA

no.	bits	parameter	values
21D-21F	6-0	DRIVER THRESHOLD POINT: between A and B, B and C, C and D	00-7F — provided that $A < B < C < D$
220	6-0	DRIVER A TTN SELECT	00-7F
221	7-6, 5-4, 3-0	DRIVER A KIND, LOCATION, BANK SELECT	kind 0 NORMAL 1 DRUM 2 ATTACK
222-223		DRIVER B: TTN select; kind, location, bank select	
224-225		DRIVER C: TTN select; kind, location, bank select	
226-227		DRIVER D: TTN select; kind, location, bank select	
228	7-6, 5-0	RESONATOR GENERAL: INTERACTION CONNECT, RESONATOR TYPE (RESERVE)	00-3F — type 0 ORIGINAL, 1-63 preset
229			
22A	7-0	POSITION PARAMETER POSITION	00-FA — 0.2 per cent per step, 0 to 50 per cent
22B	7, 6-0	FORMANT FLAG, DEPTH (RESERVE)	00-7F — 0 FIXED, 1 MOVE
22C			
22D	7-0	POSITION TOUCH	CE-32 — -50 to +50
22E	5-0	POSITION MOVEMENT WIDTH	00-32
22F	5-0, 7	POSITION MOVEMENT SPEED, SAMPLE/HOLD	00-32
230	6-0	INTERACTION GAIN (RESERVE)	00-7F
231			
232	7, 6-0	MAIN RESONATOR MODE, FITTING	00-7F — 0 positive feedback, 1 negative feedback
233	7, 6-0	MAIN RESONATOR SCALE, MUTING	00-7F

no.	bits	parameter	values
234	7-0	MAIN TOUCH FOLLOW TOUCH FITTING	CE-32
235	7-0	MAIN TOUCH FOLLOW TOUCH MUTING	CE-32
236-238	6-0	MAIN KEY FOLLOW: center key, low key limit, high key limit	00-7F
239	7-0	MAIN KEY FOLLOW SLOPE	CE-32
23A	7-0	MAIN PITCH KEY SHIFT	C4-3C — -60 to +60
23B	7-0	MAIN PITCH DETUNE	80-7F — -128 to +127
23C	7, 6-0	SUB RESONATOR MODE, FITTING	00-7F
23D	7, 6-0	SUB RESONATOR SCALE, MUTING	00-7F
23E	7-0	SUB GAIN	9C-64
23F	7-0	SUB TOUCH FOLLOW TOUCH FITTING	CE-32
240	7-0	SUB TOUCH FOLLOW TOUCH MUTING	CE-32
241	7-0	SUB TOUCH FOLLOW TOUCH SUB GAIN	CE-32
242-244	6-0	SUB KEY FOLLOW: center key, low key limit, high key limit	00-7F
245	7-0	SUB KEY FOLLOW SLOPE	CE-32
246	7-0	SUB PITCH KEY SHIFT	C4-3C
247	7-0	SUB PITCH DETUNE	80-7F

8.5 Drum Sound parameters

KIT DATA

no.	bits	parameter	values
000-00F	6-0	NAME (16 characters)	20-7F — space to }
010	7-6	ATTRIBUTE FLAG: PARAMETER MODE	00-00 — 2: DRUM MODE, fixed
011-013		CONTROLLERS: PITCH BEND	on/off and phase, function select, depth
014-016		MODULATION WHEEL 1 SELECT1	on/off and phase, function select, depth
017-019		MODULATION WHEEL 1 SELECT2	on/off and phase, function select, depth
01A-01C		MODULATION WHEEL 2 SELECT1	on/off and phase, function select, depth
01D-01F		MODULATION WHEEL 2 SELECT2	on/off and phase, function select, depth
020	6-0	REALTIME CREATOR BOX SELECT	bit per box, BOX1-BOX6
021	6-0	REALTIME CONTROLLER BOX SELECT	bit per box, BOX1-BOX6
022-024		CONTROL PEDAL SELECT1	on/off and phase, function select, depth
025-027		CONTROL PEDAL SELECT2	on/off and phase, function select, depth

no.	bits	parameter	values
028-02A		AFTER TOUCH SELECT1	on/off and phase, function select, depth
02B-02D		AFTER TOUCH SELECT2	on/off and phase, function select, depth
02E-051		BOX SELECT: CONTROLLER BOX1 X through BOX6 Y	twelve controllers, three bytes each, X then Y
052	3-0, 7-4	MIXER EFFECT OUTPUT SELECT: EFFECT1, EFFECT2	01-04 — 1 MAIN, 2-4 SUB1-3
053	0	DSP EFFECT COMMON ALGORITHM	00-01 — 0 SERIAL, 1 PARALLEL
054		EFFECT1 TYPE	see the effect tables
055-068		EFFECT1 PARAMETER VALUE1-VALUE20	meaning depends on the type
069		EFFECT1 ANOTHER EFF SEND	
06A		EFFECT1 DYNAMIC CONTROL	
06B		EFFECT2 TYPE	
06C-07F		EFFECT2 PARAMETER VALUE1-VALUE20	
080		EFFECT2 ANOTHER EFF SEND	
081		EFFECT2 DYNAMIC CONTROL	
082		REVERB TYPE	
083-096		REVERB PARAMETER VALUE1-VALUE20	
097		REVERB DYNAMIC CONTROL	reverb has no ANOTHER EFF SEND

SOUND SELECT

no.	bits	parameter	values
098-197		SOUND SELECT, NOTE:00 to NOTE:7F	128 notes, two bytes each

NOTE GENERAL DATA

no.	bits	parameter	values
198-1A4	6-0	NAME (13 characters)	20-7F
1A5	5, 3-0	ATTRIBUTE FLAG: KEY OFF MODE, TONE ON/OFF	00-01 — two bits per tone, 2nd then 1st
1A6	7, 6-0	SAME GROUP DUMP: DUMP FLAG, GROUP NUMBER	00-7F — flag 1 dumps the same group's sound
1A7	3-0, 7-4	MIXER OUTPUT SELECT: MAIN, SUB	00-05 — 0 no output, 1 MAIN, 2-4 SUB1-3, 5 EFFECT2
1A8	6-0	EFFECT SEND VOLUME: EFFECT1	00-7F
1A9	6-0	EFFECT SEND VOLUME: REVERB	00-7F

NOTE TONE DATA

no.	bits	parameter	values
1AA	5-0	ATTRIBUTE DELAY	00-32 — 0 delay off
1AB	7-0	ATTRIBUTE PANNING	00-80 — 0-127 fixed pan, 128 random pan
1AC	6-0	TONE SELECT: TTN SELECT	00-7F
1AD	7-6, 5-4, 3-0	TONE KIND, TONE LOCATION, BANK SELECT	kind 0 NORMAL 1 DRUM 2 ATTACK
1AE	7-0	PITCH KEY SHIFT	E8-18 — -50 to +50
1AF	7-0	PITCH DETUNE	80-7F — -128 to +127
1B0	6-0	LEVEL VOLUME	00-7F — one step is 0.375 dB
1B1	7-0	LEVEL TOUCH DEPTH	CE-32 — -50 to +50
1B2	7-5	LEVEL TOUCH CURVE	00-06 — 0 is -3 curve through 6 is +3 curve
1B3-1B8	6-0	LEVEL ENVELOPE SHAPE: attack time, decay1 time, sustain1 level, decay2 time, sustain2 level, release time	00-64 — one byte each, in that order
1B9	7-0	LEVEL ENV TOUCH FOLLOW ATTACK	CE-32
1BA	7-0	LEVEL ENV TOUCH FOLLOW DECAY	CE-32
1BB	2-0, 7-5	FILTER MODE, TOUCH CURVE	00-06 — 0 THROUGH, 1 LPF12+EQ, 2 HPF12+EQ, 3 LPF24, 4 HPF24, 5 BPF
1BC	5-0	FILTER TOUCH DEPTH	00-32
1BD-1C0		FILTER PARAMETER VALUE1-VALUE4	meaning depends on the filter mode

NOTE MODELING DATA

no.	bits	parameter	values
1D8-1DA	6-0	DRIVER THRESHOLD POINT: between A and B, B and C, C and D	00-7F — provided that A < B < C < D
1DB	6-0	DRIVER A TTN SELECT	00-7F
1DC	7-6, 5-4, 3-0	DRIVER A KIND, LOCATION, BANK SELECT	kind 0 NORMAL 1 DRUM 2 ATTACK
1DD-1DE		DRIVER B: TTN select; kind, location, bank select	
1DF-1E0		DRIVER C: TTN select; kind, location, bank select	
1E1-1E2		DRIVER D: TTN select; kind, location, bank select	
1E3	7-6, 5-0	RESONATOR GENERAL: INTERACTION CONNECT, RESONATOR TYPE (RESERVE)	00-3F — type 0 ORIGINAL, 1-63 preset
1E4		POSITION PARAMETER	
1E5	7-0	POSITION	00-FA — 0.2 per cent per step, 0 to 50 per cent

no.	bits	parameter	values
1E6	7, 6–0	FORMANT FLAG, DEPTH	00–7F — 0 FIXED, 1 MOVE
1E7		(RESERVE)	
1E8	7–0	POSITION TOUCH	CE–32 — -50 to +50
1E9	5–0	POSITION MOVEMENT WIDTH	00–32
1EA	5–0, 7	POSITION MOVEMENT SPEED, SAMPLE/HOLD	00–32
1EB	6–0	INTERACTION GAIN	00–7F
1EC		(RESERVE)	
1ED	7, 6–0	MAIN RESONATOR MODE, FITTING	00–7F — 0 positive feedback, 1 negative feedback
1EE	7, 6–0	MAIN RESONATOR SCALE, MUTING	00–7F
1EF	7–0	MAIN TOUCH FOLLOW TOUCH FITTING	CE–32
1F0	7–0	MAIN TOUCH FOLLOW TOUCH MUTING	CE–32
1F1–1F3	6–0	MAIN KEY FOLLOW: center key, low key limit, high key limit	00–7F
1F4	7–0	MAIN KEY FOLLOW SLOPE	CE–32
1F5	7–0	MAIN PITCH KEY SHIFT	C4–3C — -60 to +60
1F6	7–0	MAIN PITCH DETUNE	80–7F — -128 to +127
1F7	7, 6–0	SUB RESONATOR MODE, FITTING	00–7F
1F8	7, 6–0	SUB RESONATOR SCALE, MUTING	00–7F
1F9	7–0	SUB GAIN	9C–64
1FA	7–0	SUB TOUCH FOLLOW TOUCH FITTING	CE–32
1FB	7–0	SUB TOUCH FOLLOW TOUCH MUTING	CE–32
1FC	7–0	SUB TOUCH FOLLOW TOUCH SUB GAIN	CE–32
1FD–1FF	6–0	SUB KEY FOLLOW: center key, low key limit, high key limit	00–7F
200	7–0	SUB KEY FOLLOW SLOPE	CE–32
201	7–0	SUB PITCH KEY SHIFT	C4–3C
202	7–0	SUB PITCH DETUNE	80–7F

Chapter 9

Effects

A sound carries three effect blocks — EFFECT1, EFFECT2 and REVERB — and each is a TYPE byte followed by twenty VALUE bytes, an ANOTHER EFF SEND and a DYNAMIC CONTROL. The TYPE byte selects one of 56 effects, and what the twenty VALUE bytes mean depends entirely on which.

9.1 What the type byte selects

The numbers are not contiguous: they are grouped, with modulation effects below 10, reverbs at 10–1B, distortion and dynamics at 20–27, a second modulation group at 30–38, two-effect combinations at 40–4B and three-effect combinations at 60–63.

Twelve of the reverbs are marked (REV ONLY) in the published guide: they are intended for the REVERB block rather than EFFECT1 or EFFECT2.

Two sources agree on which effects exist

The table below was transcribed from the guide. Independently, this project disassembled the effects DSP and produced a manifest of every distinct effect program with the number that selects it. The two sets of numbers are equal — 56 effects, no more on either side — which is what makes the numbering here trustworthy.

They disagree only in spelling, because the ROM carries the short names the instrument displays and the guide prints long ones. The table gives the guide's.

9.2 What the value bytes mean

The VALUE list below is the order the bytes appear in, so the first name is VALUE1, the second VALUE2, and so on. An effect that names fewer than twenty leaves the rest unused.

The combination effects concatenate their components: the first block's parameters, then a dry/wet for the second block, then the second block's. A three-effect combination continues the same way.

The value lists are transcribed, and not checked by anything

The effect *numbers* are confirmed twice over. The *names* in the value lists are not: they were read from scans, nothing independent states them, and a misreading would survive. Treat them as a guide to what the bytes are for rather than as a specification. The block diagram the guide prints for each effect is not reproduced either.

no.	n	effect	VALUE1 onwards
00	0	NO OPERATION	—
01	5	CHORUS	WET, DEPTH, LFO SPEED, LFO WAVEFORM, VOLUME
02	7	MODULATED CHORUS	WET, DEPTH, SLOW LFO SPEED, FAST LFO SPEED, FAST LFO BALANCE, LFO WAVEFORM, VOLUME
03	7	ENHANCER	WET, MANUAL, LOW MIX, HIGH MIX, DELAY TIME L, DELAY TIME R, VOLUME
04	8	FLANGER	WET, DEPTH, LFO SPEED, RESONANCE, MANUAL, PHASE, LFO WAVEFORM, VOLUME
05	8	PHASER	WET, DEPTH, LFO SPEED, RESONANCE, MANUAL, PHASE, LFO WAVEFORM, VOLUME
06	5	ENSEMBLE	WET, DEPTH, LFO SPEED, LFO WAVEFORM, VOLUME
08	6	GATED REVERB	WET, GATE TIME, HIGH DUMP GAIN, THRESHOLD, MASK TIME, VOLUME
09	7	SINGLE DELAY	WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, HIGH DUMP GAIN, VOLUME
0A	12	MULTI TAP DELAY	WET, DELAY 1, DELAY 2, DELAY 3, DELAY 4, PAN 1, PAN 2, PAN 3, PAN 4, FEED BACK, HIGH DUMP GAIN, VOLUME
0B	8	MANUAL DELAY	WET, MODULATION DEPTH, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, HIGH DUMP GAIN, VOLUME
10	5	ROOM REVERB 1 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
11	5	ROOM REVERB 2 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
12	5	PLATE REVERB 1 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
13	5	PLATE REVERB 2 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
14	5	CONCERT REVERB 1 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
15	5	CONCERT REVERB 2 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
16	5	DARK REVERB 1 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
17	5	DARK REVERB 2 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
18	5	BRIGHT REVERB 1 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
19	5	BRIGHT REVERB 2 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
1A	5	WAVE REVERB 1 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
1B	5	WAVE REVERB 2 (REV only)	REVERB TIME, PRE DELAY, HIGH DUMP GAIN, EARLY REFL LEVEL, VOLUME
20	4	DISTORTION	WET, DRIVE, ADJUST, VOLUME
21	4	OVERDRIVE	WET, DRIVE, ADJUST, VOLUME
22	4	FUZZ	WET, DRIVE, ADJUST, VOLUME
23	6	EXCITER	WET, DRIVE, ADJUST, EMPHASIS Fc, EMPHASIS GAIN, VOLUME

no.	n	effect	VALUE1 onwards
24	6	COMPRESSOR	WET, THRESHOLD, RATIO, ATTACK SENSITIVITY, RELEASE SENSITIVITY, VOLUME
25	5	SLOW ATTACKER	WET, THRESHOLD, ATTACK RATE, RELEASE RATE, VOLUME
26	1	NOISE GENERATOR	VOLUME
27	19	PARAMETRIC EQ	BAND EMPHASIS 1 Fc, BAND EMPHASIS 1 Q, BAND EMPHASIS 1 G, BAND EMPHASIS 2 Fc, BAND EMPHASIS 2 Q, BAND EMPHASIS 2 G, BAND EMPHASIS 3 Fc, BAND EMPHASIS 3 Q, BAND EMPHASIS 3 G, BAND EMPHASIS 4 Fc, BAND EMPHASIS 4 Q, BAND EMPHASIS 4 G, BAND EMPHASIS 5 Fc, BAND EMPHASIS 5 Q, BAND EMPHASIS 5 G, BAND EMPHASIS 6 Fc, BAND EMPHASIS 6 Q, BAND EMPHASIS 6 G, VOLUME
30	6	AUTO PAN	WET, DEPTH, LFO SPEED, PHASE, LFO WAVEFORM, VOLUME
31	6	PITCH SHIFTER	WET, PITCH L, PITCH R, PRE DELAY, FEEDBACK, VOLUME
32	6	VIBRATO	WET, DEPTH, LFO SPEED, PHASE, LFO WAVEFORM, VOLUME
33	6	PEDAL WAH	WET, RESONANCE, MANUAL, SWEEP RANGE, WAH CENTER Fc, VOLUME
34	5	AUTO WAH	WET, RESONANCE, MANUAL, SWEEP RANGE, VOLUME
35	15	ROTARY SPEAKER	WET, DRIVE, VOLUME ADJUST, TREBLE DEPTH, TREBLE FAST, TREBLE SLOW, TREBLE WIND UP, TREBLE WIND DOWN, BASS DEPTH, BASS FAST, BASS SLOW, BASS WIND UP, BASS WIND DOWN, VOLUME, SLOW/FAST
36	5	RING MODULATOR	WET, OSC SPEED, PHASE, OSC WAVEFORM, VOLUME
37	5	HAAS EFFECT	WET, DELAY TIME L, DELAY TIME R, BALANCE, VOLUME
38	8	MIX UP	WET, DEPTH, SLOW LFO SPEED, FAST LFO SPEED L, FAST LFO SPEED R, PHASE, LFO WAVEFORM, VOLUME
40	10	SINGLE DELAY + CHORUS	DELAY WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, CHORUS DRY/WET, DEPTH, LFO SPEED, LFO WAVEFORM, VOLUME
41	11	SINGLE DELAY + SINGLE DELAY	DELAY 1 WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, DELAY 2 DRY/WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, VOLUME
42	13	SINGLE DELAY + FLANGER	DELAY WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, FLANGER DRY/WET, DEPTH, LFO SPEED, RESONANCE, MANUAL, PHASE, LFO WAVEFORM, VOLUME

no.	n	effect	VALUE1 onwards
43	11	SINGLE DELAY + VIBRATO	DELAY WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, VIBRATO DRY/WET, DEPTH, LFO SPEED, PHASE, LFO WAVEFORM, VOLUME
44	13	SINGLE DELAY + PHASER	DELAY WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, PHASER DRY/WET, DEPTH, LFO SPEED, RESONANCE, MANUAL, PHASE, LFO WAVEFORM, VOLUME
45	11	PEDAL WAH + DELAY	WAH WET, RESONANCE, MANUAL, SWEEP RANGE, WAH CENTER Fc, DELAY DRY/WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, VOLUME
46	10	AUTO WAH + SINGLE DELAY	WAH WET, RESONANCE, MANUAL, SWEEP RANGE, DELAY DRY/WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, VOLUME
47	11	PEQ + CHORUS	BAND EMPHASIS 1 Fc, BAND EMPHASIS 1 Q, BAND EMPHASIS 1 G, BAND EMPHASIS 2 Fc, BAND EMPHASIS 2 Q, BAND EMPHASIS 2 G, CHORUS DRY/WET, DEPTH, LFO SPEED, LFO WAVEFORM, VOLUME
48	12	PEQ + SINGLE DELAY	BAND EMPHASIS 1 Fc, BAND EMPHASIS 1 Q, BAND EMPHASIS 1 G, BAND EMPHASIS 2 Fc, BAND EMPHASIS 2 Q, BAND EMPHASIS 2 G, DELAY DRY/WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, VOLUME
49	14	PEQ + FLANGER	BAND EMPHASIS 1 Fc, BAND EMPHASIS 1 Q, BAND EMPHASIS 1 G, BAND EMPHASIS 2 Fc, BAND EMPHASIS 2 Q, BAND EMPHASIS 2 G, FLANGER DRY/WET, DEPTH, LFO SPEED, RESONANCE, MANUAL, PHASE, LFO WAVEFORM, VOLUME
4A	12	PEQ + VIBRATO	BAND EMPHASIS 1 Fc, BAND EMPHASIS 1 Q, BAND EMPHASIS 1 G, BAND EMPHASIS 2 Fc, BAND EMPHASIS 2 Q, BAND EMPHASIS 2 G, VIBRATO DRY/WET, DEPTH, LFO SPEED, PHASE, LFO WAVEFORM, VOLUME
4B	11	PEQ + COMPRESSOR	BAND EMPHASIS 1 Fc, BAND EMPHASIS 1 Q, BAND EMPHASIS 1 G, BAND EMPHASIS 2 Fc, BAND EMPHASIS 2 Q, BAND EMPHASIS 2 G, THRESHOLD, RATIO, ATTACK SENSITIVITY, RELEASE SENSITIVITY, VOLUME
60	13	PEQ + COMPRESSOR + DISTORTION	BAND EMPHASIS 1 Fc, BAND EMPHASIS 1 Q, BAND EMPHASIS 1 G, BAND EMPHASIS 2 Fc, BAND EMPHASIS 2 Q, BAND EMPHASIS 2 G, THRESHOLD, RATIO, ATTACK SENSITIVITY, RELEASE SENSITIVITY, DRIVE, ADJUST, VOLUME
61	10	PEQ + COMPRESSOR + OVERDRIVE	BAND EMPHASIS Fc, BAND EMPHASIS Q, BAND EMPHASIS G, THRESHOLD, RATIO, ATTACK SENSITIVITY, RELEASE SENSITIVITY, DRIVE, ADJUST, VOLUME

no.	n	effect	VALUE1 onwards
62	14	PEQ + DISTORTION + DELAY	BAND EMPHASIS 1 Fc, BAND EMPHASIS 1 Q, BAND EMPHASIS 1 G, BAND EMPHASIS 2 Fc, BAND EMPHASIS 2 Q, BAND EMPHASIS 2 G, DRIVE, ADJUST, DELAY DRY/WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, VOLUME
63	14	PEQ + OVERDRIVE + DELAY	BAND EMPHASIS 1 Fc, BAND EMPHASIS 1 Q, BAND EMPHASIS 1 G, BAND EMPHASIS 2 Fc, BAND EMPHASIS 2 Q, BAND EMPHASIS 2 G, DRIVE, ADJUST, DELAY DRY/WET, DELAY L, DELAY R, FEEDBACK L, FEEDBACK R, VOLUME

9.3 From a byte to a quantity

A VALUE byte is not a quantity. The tables below turn one into seconds, hertz, decibels or cents; an effect’s parameter says which table applies, and a librarian needs them to display a control rather than merely name it.

Each row gives a span of parameter values, the quantity at each end of it, and the step between one parameter and the next.

Three of the guide’s tables are not conversions at all but *packings*: they say how several fields share two bytes. Those are given at the end, with each field’s width.

The tables check themselves, twice over

The four numbers in a row are not independent: the first value plus the step times the span must equal the last. All 41 rows satisfy that identity, and a misread endpoint or step would break it.

The packings check themselves differently. A field’s width must be wide enough for the range of the table it carries, and each one is exactly wide enough — five bits for a parameter reaching 31, five for one reaching 26, six for one reaching 48.

Table 1: Reverb time (seconds)

parameter	value	step
0–15	0.1–0.4	0.02
16–23	0.45–0.8	0.05
24–55	0.9–4	0.1
56–75	4.2–8	0.2
76–97	9–30	1

Table 2: High dump gain (dB)

parameter	value	step
0–24	-24–0	1

Table 3: LFO speed (Hz)

parameter	value	step
0–50	0–5	0.1
51–75	5.2–10	0.2
76–88	10.8–20.4	0.8
89–99	22.2–40.2	1.8

Table 4: LFO wave form 00 sine, 01 triangle, 02 square.**Table 5: Gate time and mask time, gated reverb (ms)**

parameter	value	step
0–20	10–50	2
21–30	55–100	5
31–70	110–500	10
71–80	550–1000	50
81–99	1100–2900	100

Table 6: PEQ Fc (Hz) A third-octave series; the parameter is the index.

Parameter 00–1A selects, in order: 40, 50, 63, 80, 100, 125, 160, 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, 10000, 12500, 16000.

Table 7: PEQ Q

parameter	value	step
0–9	0.1–1	0.1
10–15	1.5–4	0.5
16–31	5–20	1

Table 8: PEQ gain (dB)

parameter	value	step
0–48	-12–12	0.5

Table 9: Attack and release sensitivity (seconds, 90 per cent swing time)

parameter	value	step
0–89	0.001–0.09	0.001
90–90	0.1–0.1	0.01
91–94	0.2–0.5	0.1

Table 10: Attack for slow attacker (seconds, 90 per cent swing time) The first row is attack, the second release.

parameter	value	step
0–99	0.2–20	0.2
0–99	0.01–1	0.01

Table 11: LFO speed, rotary speaker (Hz)

parameter	value	step
0–20	0–2	0.1
21–50	2.2–8	0.2
51–99	8.55–34.95	0.55

Table 12: LFO acceleration, rotary speaker (seconds, 90 per cent swing time)

parameter	value	step
0–75	1–31	0.4
76–99	32.25–61	1.25

Table 13: LFO speed, ring modulator (Hz)

parameter	value	step
0–10	0–10	1
11–19	20–100	10
20–64	120–1000	20
65–87	1200–10000	400
88–99	10800–19600	800

Table 14: Pitch L and R, pitch shifter (cents)

parameter	value	step
-36–32	-1200–800	100
-31–20	-700–150	50
-19–11	-100–20	10
-10–10	-10–10	1
11–19	20–100	10
20–31	150–700	50
32–36	800–1200	100

Table 15: Resonance for wah 00 wide, 01 middle, 02 narrow.**Table 16: Slow/Fast, rotary speaker** 00 slow, 01 fast.

Packed fields Three of the guide’s tables describe fields sharing two bytes rather than a conversion. Each is listed with its width.

format	field	width
PEQ Q, Fc and G	PEQ Q	5 bits
	PEQ Fc	5 bits — split 3 bits in the first byte, 2 in the second
	PEQ G	6 bits
Exciter emphasis Fc	Emphasis Fc	5 bits — split 3 bits and 2, the same shape as table 17
	EQ Fc	5 bits — split 3 bits and 2
Pre/post equaliser Fc and G	EQ G	6 bits

Chapter 10

Enumerations

Three lists in chapter 8 are referred to rather than spelled out where they are used, because each is shared by many parameters. They are given here.

10.1 Control functions

Every controller in a sound — the pitch bend lever, the two modulation wheels, the control pedal, after touch, and the six controller boxes in each axis — is three bytes: an on/off and phase byte, a FUNCTION SELECT byte, and a depth. The FUNCTION SELECT byte chooses what the controller moves, from this list.

00	OFF	1A	filter LFO3 speed
01	pitch bend	1B	filter LFO4 speed
02	sustain level	1C	fitting*
03	filter cutoff frequency	1D	position
04	pitch LFO1 depth	1E	position depth
05	pitch LFO2 depth	1F	(reserve)
06	pitch LFO3 depth	20	position movement width
07	pitch LFO4 depth	21	position movement speed
08	amp LFO1 depth	22	(reserve)
09	amp LFO2 depth	23	muting*
0A	amp LFO3 depth	24	resonator key shift*
0B	amp LFO4 depth	25	sub gain
0C	filter LFO1 depth	26	delay*
0D	filter LFO2 depth	27	panning*
0E	filter LFO3 depth	28	effect1 send*
0F	filter LFO4 depth	29	reverb send*
10	pitch LFO1 speed	2A	level*
11	pitch LFO2 speed	2B	amp env. attack time*
12	pitch LFO3 speed	2C	amp env. decay time*
13	pitch LFO4 speed	2D	amp env. release time*
14	amp LFO1 speed	2E	filter resonance*
15	amp LFO2 speed	2F	effect1 dynamic control
16	amp LFO3 speed	30	effect2 dynamic control
17	amp LFO4 speed	31	reverb dynamic control
18	filter LFO1 speed	32–7F	(reserve)
19	filter LFO2 speed		

* marked functions cannot be driven by after touch.

A drum kit has its own, much shorter version of this list: most of the numbers above are reserved there, and only OFF, PITCH BEND, SUSTAIN LEVEL, FILTER CUTOFF FREQUENCY, the resonator and position entries and the three dynamic controls remain.

10.2 Filter values

A tone’s filter has four VALUE bytes whose meaning depends on the filter mode selected for that tone.

mode	VALUE1	VALUE2	VALUE3	VALUE4
LPF12	cutoff frequency	resonance	EQ frequency	EQ gain, EQ range
HPF12	cutoff frequency	resonance	EQ frequency	EQ gain, EQ range
LPF24	cutoff frequency	resonance	—	—
HPF24	cutoff frequency	resonance	—	—
BPF	low cutoff frequency	low resonance	high cutoff frequency	high resonance

Cutoff frequencies are 00–7F. Resonance is 00–05: in the 12 dB modes and BPF a step is 3 dB, covering –6 to 9 dB; in the 24 dB modes a step is 6 dB, covering –12 to 18 dB. EQ GAIN is 00–0E, where 00 is silence and 01–0E span –6 to +6 dB, and the top bit of that same byte is EQ RANGE: 0 low, 1 high.

10.3 Interaction connect

Modeling parameter 228 sets how a sound’s four resonators are connected — none of them, the first pair, the second pair, both pairs, or all four together. The guide gives the resulting connection state of each of the four blocks for every setting; it is not reproduced here, and the parameter’s own range, 00–03, is in chapter 8.

Chapter 11

Universal System Exclusive

11.1 Recognised messages

The instrument honours two universal messages, and transmits both.

message	meaning
F0 7E 7F 09 01 F7	General MIDI System On
F0 7E 7F 09 02 F7	General MIDI System Off

Turning General MIDI on restricts the sounds and operations available and may rearrange the percussion map. General MIDI System Off has no effect if General MIDI is already off.

A received message takes effect at once. The same change made at the front panel does not: the panel asks for a confirmation first, and the user can decline it. A controller sending General MIDI System On is therefore doing something the user cannot be offered the chance to refuse, and the mode change it causes is one the instrument warns will make material recorded in the other mode play back wrongly.

Both messages are also written into Standard MIDI Files produced by the instrument, as a five-byte System Exclusive event at delta time zero.

11.2 Messages not recognised

A controller expecting any of the following will receive no response:

message	
F0 7F 7F 04 01 <i>ll mm</i> F7	Master Volume
F0 7E <i>dd</i> 06 01 F7	Identity Request
F0 7E 7F 09 03 F7	General MIDI 2 System On

The instrument does not implement Identity Reply, so it cannot be auto-detected by a controller that relies on it. The entire Universal Real Time identifier 7F is unrecognised.

11.3 Practical consequences

A General MIDI message sent during a bulk dump breaks the dump. While a transfer is open the instrument accepts only messages beginning F0 50. One beginning F0 7E is treated as a reception failure: the transfer is abandoned and ERROR 41 is reported. General MIDI mode is left unchanged.

The instrument announces its own changes. Entering or leaving General MIDI mode makes it transmit the matching message, for a change made at the front panel as well as one made by loading a song. Neither direction is affected by the EXCLUSIVE filter.

The announcement stops for good once you send one

The interlock that stops the instrument echoing a General MIDI message back is armed by the first such message it receives after power-on, and is never disarmed. Once a controller has sent either message, the instrument stops announcing its own General MIDI changes for the rest of the session. A controller that tracks the instrument's mode by listening for these messages will silently stop being told.

General MIDI state travels in a dump. It is carried in the second SYSTEM, PART & MIDI block, so restoring that category restores the General MIDI setting with it. A dump taken in General MIDI mode is not the same file as one taken out of it.

11.4 The identifier is checked once

Once 50 or 7E has been accepted the instrument does not look at it again; the third byte alone selects the message. F0 50 7F 09 01 F7 is therefore acted on as General MIDI System On despite carrying the Matsushita identifier, and a Technics message sent with 7E in the identifier position works equally well. Send the conventional identifier, but expect a receiver to be lenient.

Nothing else about General MIDI mode changes the System Exclusive implementation: every family is accepted exactly as before, with the same encoding, checksum, handshake and error reporting.

Chapter 12

Settings that affect System Exclusive

12.1 The EXCLUSIVE filter

The MIDI menu's INPUT & OUTPUT FILTER page has eight rows, each a plain ON/OFF switch for one kind of MIDI message: PROGRAM CHANGE, BANK SELECT, PITCH BEND, CONTROL CHANGE, RESET ALL CNT., CHANNEL PRESSURE, SONG SELECT and, last, EXCLUSIVE. There is one such switch and it governs both directions: the same setting is consulted when the instrument sends and when it receives. There is no separate input filter, no per-socket filter and no third state, and the page is the same on both models.

EXCLUSIVE governs the tempo message and nothing else

Despite its name, this switch does not turn System Exclusive on and off. Its entire effect on the messages in this reference is the family 25 tempo message: with EXCLUSIVE set to OFF the instrument neither sends one nor acts on one received, silently in both directions.

A bulk dump transfers normally with EXCLUSIVE set to OFF. Software that cannot complete a transfer should not look here for the cause.

This is worth knowing before telling a user to change the setting: the illustration of that page in Technics' own guide shows EXCLUSIVE switched OFF, so an instrument presenting that page as pictured is already able to send and receive every message in this reference.

Everything below is unaffected by the setting:

function	affected by EXCLUSIVE?
bulk dump, sent or received	no
dump requests	no
the opening enquiry and its reply	no
acknowledgements and the session control messages	no
parameter messages, and the replies and refusals to them	no
General MIDI System On / Off, sent or received	no
error reporting	no
tempo message (family 25)	yes

12.2 Which sockets carry what

The instrument has two sets of MIDI sockets. Only bulk-dump traffic is restricted to the first.

message	accepted on
bulk-dump data, continuation frames, handshake, acknowledgements	MIDI 1 only
dump requests	MIDI 1 only
parameter messages (families 2B, 2C)	MIDI 1 and MIDI 2
tempo message (family 25)	MIDI 1 and MIDI 2
General MIDI System On / Off	MIDI 1 and MIDI 2

MIDI channels are written with the socket set first: 1-01 to 1-16 and 2-01 to 2-16. No channel or device-number setting affects System Exclusive addressing — these messages carry no channel.

12.3 Memory protect

Two write-protect switches are consulted before an incoming message is acted on. A message they block never reaches the transfer machinery, and the instrument shows its own write-protection prompt rather than a System Exclusive error. A transfer that stops with that prompt on screen has not failed as a transfer.

Chapter 13

Errors

Transfer failures are reported on the SYSEX BULK DUMP screen. A System Exclusive message arriving while any other screen is displayed produces no visible error.

13.1 The messages

screen	meaning
COMPLETED!	the transfer finished
ERROR 40!	the message is addressed to a different product
ERROR 41!	reception failed
ERROR 42!	transmission failed
ERROR 21!	the destination is full

Not every failure is a 40, 41 or 42

When incoming data is larger than the destination area, the instrument reports ERROR 21! MEMORY FULL. Software that recognises only the three documented System Exclusive errors will mis-read a truncated restore as something else.

13.2 ERROR 40 — wrong identification

Raised when CMD is accepted but the bytes that follow it do not match the product. For a message addressed to the SX-WSA1R that means PC was not 04, or MD was neither 00 nor 01, or VER was not 11.

13.3 ERROR 41 — reception

The general reception failure. It covers:

- a message inside a session that does not begin F0 50;
- a status byte other than F7 arriving inside an open message;
- a framing, parity or overrun error on the MIDI input, or loss of active sensing;
- no reply within the reply window, including the acknowledgement that each data message must receive;

- a message longer than 254 bytes;
- an odd number of payload bytes;
- a continuation flag that is neither 00 nor 01;
- a checksum mismatch.

13.4 ERROR 42 — transmission

Raised when an outgoing transfer stalls inside the instrument: the send path waits for one block to be handed over internally, and reports ERROR 42 when that wait times out after about a second. In version 2.0 this is its only cause.

ERROR 42 is not a report about the receiving device

The published manual describes ERROR 42 as an error during transmission, with the data not having been received correctly. That is not what the instrument tests. The condition it reports is internal to the sending machine and can arise with nothing connected to the MIDI output at all.

A genuine failure at the far end looks different. No acknowledgement within the reply window, a framing, parity or overrun error on the input, and a transfer abandoned after its three retries all raise ERROR 41. Software diagnosing a failed transfer should read ERROR 41, not ERROR 42, as the sign of a problem on the cable or at the receiver.

13.5 Interference from other traffic

While a bulk-dump session is open, unrelated System Exclusive traffic arriving on the MIDI input can set the error state, and will then be reported when the session ends. Keep other sources off the MIDI 1 input for the duration of a transfer.

Chapter 14

SX-WSA1 and SX-WSA1R

The SX-WSA1 keyboard and the SX-WSA1R rack module ship **the same ROMs** — not merely the same program built twice, but the same images — and speak the same System Exclusive protocol. Two features are nonetheless available on the keyboard and not on the rack, in both directions, and the two models put different bytes in the model triple. Nothing else in the System Exclusive implementation depends on which model it is: the framing, the checksum, the handshake, the error reporting, the parameter address space and every other bulk-dump category are identical.

	SX-WSA1 (keyboard)	SX-WSA1R (rack)
message framing, checksum, handshake	yes	yes
SOUND bulk dump	yes	yes
COMBINATION bulk dump	yes	yes
SYSTEM, PART & MIDI bulk dump	yes	yes
dump requests	yes	yes
General MIDI On / Off	yes	yes
MD transmitted	00	01
MD accepted	both	both
SEQUENCER bulk dump	yes	no
tempo message (family 25)	yes	no

On the rack, a SEQUENCER dump sends nothing and says nothing

The rack's SYSEX BULK DUMP menu has no SEQUENCER row: it is not drawn, and the soft key that would select it does nothing. The category can still be reached over MIDI, by a dump request addressed to 60 00 00, and as part of TOTAL KEYBOARD. In both cases nothing is transmitted — not even the end-of-category message that closes every other transfer. A librarian waiting for data will simply time out.

On the rack the transfer-progress screen likewise lists only SYS,PART&MIDI, SOUND and COMBINATION.

Technics' own guide points the same way: the photograph it prints of the SYSEX BULK DUMP menu, the one showing all five rows, is captioned (WSA1) — the marker the guide uses throughout for what belongs to the keyboard.

The tempo message is refused in both directions on the rack: it will neither act on one received nor send one.

Telling the two apart over MIDI

MD in anything the instrument transmits is 00 on the keyboard and 01 on the rack — the values Technics’ published field table gives for the two models. An identity enquiry (F0 50 21 04 00 11 F7 or F0 50 22 04 00 11 F7) is answered with the model’s own value, whichever value the enquiry itself carried. A second, behavioural test is to request a SEQUENCER dump and see whether anything arrives.

Which machine is which

Because the ROMs are identical, the difference between the two models is not a firmware difference at all. Both behaviours are present in every machine, and a hardware input read once at power-on selects between them; the program names neither model. The identification does not depend on that, because Technics published the answer: the field table gives MD = 00 for the SX-WSA1 and 01 for the SX-WSA1R, and the machine that reads the second value is the one that transmits 01.

The same guide prints SEQUENCER : WSA1 ONLY beside the SEQUENCER row of its address map. Its user manual marks the whole sequencer chapter SEQUENCER (WSA1) and carries the same (WSA1) marker on fifty-nine further passages. A model with no sequencer has nothing to put in a SEQUENCER dump and no use for a tempo message, which is exactly the pair of System Exclusive functions that machine refuses.

Chapter 15

Relationship to other Technics instruments

The message engine described in this reference is not unique to the SX-WSA1R. At least two other Technics instruments implement the same protocol: the SX-KN5000 and the SX-KN1500.

15.1 What is shared

All three use the 50 identifier, the same message families, the same short control messages, the same payload encoding and the same checksum rule. The fixed messages are byte-for-byte identical:

```
F0 50 23 7E F7  F0 50 24 7E F7  F0 50 27 7E F7  F0 50 28 7E F7  F0 50 29 7E
                F7  F0 50 2A 7E F7
```

The error mapping is also nearly common: of the thirty-four status values, thirty-two produce the same report on the SX-WSA1R and the SX-KN5000.

15.2 What distinguishes the products

PC, MD and VER together are the discriminator. A message whose three bytes do not match the receiving instrument is refused with ERROR 40.

instrument	PC MD VER
SX-WSA1 / SX-WSA1R	04 00 11, 04 01 11
SX-KN5000	01 28 12
SX-KN1500	01 24 11, 01 25 11, 01 26 11

The split is legible once the fields are named: PC = 04 is the WSA product category and 01 the keyboards, MD separates models within a category, and VER is the exclusive specification's own version — 2.1 for the WSA1 and the KN1500, 2.2 for the KN5000.

A librarian that supports more than one of these instruments needs only to vary those bytes and the dump region addresses; the framing, handshake, encoding and checksum are common code.

15.3 Dump regions differ

The dump region addresses are per-product. The SX-KN5000 and SX-KN1500 share eleven of their thirteen region and length pairs with each other, but the SX-WSA1R shares none of its eight with either — its categories are its own.

A fourth instrument's name sits in the signature table

The program holds its block signatures as literals, and immediately after WSA SOUND RAM S0 — its own — comes KN3000 SOUND RAM. No pointer in either program image reaches that second string, so nothing here shows it being used, and whether this instrument would accept an SX-KN3000 sound block is not established. The coverage of that negative is three-byte little-endian pointers across both 512 KB images; the string could still be reached by indexing from the first.

The SX-WSA1R does not accept the GS-style messages its siblings do

The SX-KN5000 and SX-KN1500 additionally accept a small set of messages in the 42 12 parameter form, including the sequence 42 12 40 00 7F 00 41 used elsewhere in the industry as a reset. **The SX-WSA1R accepts none of them.** Software that resets a KN-series instrument that way and assumes the SX-WSA1R will follow will find it does not respond.

Chapter 16

Worked examples

Three things in this format are easy to get subtly wrong: the seven-bit address encoding, the high-nibble-first payload, and which bytes the checksum covers. The examples below are complete messages, and every byte in them is computed rather than transcribed.

16.1 A parameter, written and read back

The example is part 0's parameter 03, a one-byte value, set to 100.

	message
write	F0 50 2C 04 00 11 00 20 03 00 00 01 06 04 00 41 F7
request	F0 50 2B 04 00 11 00 20 03 00 00 01 00 4C F7
reply	F0 50 2C 04 00 11 00 20 03 00 00 01 06 04 00 41 F7
part 7	F0 50 2C 04 00 11 00 27 03 00 00 01 06 04 00 3A F7
three-byte	F0 50 2C 04 00 11 00 20 00 00 00 03 01 02 00 00 04 00 00 45 F7

The value 100 is 64, which DT carries as the two bytes 06 04. The three bytes before it are SIZ, and the 00 after it is CN. SM closes the message.

16.2 A frame from a real instrument

The bytes below open the first data message of a dump recorded from an SX-WSA1R, a transfer of three categories in one session:

F0 50 2D 04 01 11 40 00 00 00 00 20 ...

Reading it by the rules of chapter 5: CMD is 2D BTR; 04 01 11 are PC, MD and VER, the middle one being the rack's; then ADR 40 00 00 and SIZ 00 00 20, which together name block 1 of SYSTEM, PART & MIDI. The length decodes to 32 source bytes and the frame carries 32 of them.

The payload decodes to 5A 5A 01 00 57 41 30 00..., the signature section 6.1 gives for that block.

That block is the one chapter 7 maps: a dump of this category can be read against table 7.1 directly, which is the cheapest way to confirm a parameter address without an instrument to hand.

Chapter 17

Scope of this edition

This reference covers message framing, the bulk-dump transfer protocol, the parameter address space, the sound and drum areas, the effects, the universal messages, error reporting, the differences between the two models, and the layout of the SOUND and COMBINATION blocks a dump carries.

17.1 Deliberately outside it

What a parameter does to the sound. Chapter 7 enumerates all 108 addresses of the 00 area with their name, length, bit mask, accepted values and position in a dump, and chapter 8 does the same for the sound areas. What a setting *does* is the user manuals' subject, not a protocol reference's.

The effect block diagrams. The guide draws the signal path of each of the 56 effects. Chapter 9 gives their parameters instead.

17.2 Open, and what would close it

Some bytes inside a combination. The combination stream is decoded in section 6.4, and chapter 7 names most of what its records hold; the effect records are named by chapter 9 instead, as a type and its values. What was left over has now been read across the whole stored corpus — 385 combinations of eight parts, so 3080 part records, from three sources produced independently of one another: the 129 presets carried in the program, 128 from a user's flash dump, and 128 more from the combination area of a native disk file — and most of it turns out not to be unknown but fixed.

Fixed. Block A holds the same value in all 3080 records at +02, +04, +10 and +15–+1A, and block B does at +00–+02, +0D, +11, +12 and +15. Every one of them reads zero. Write zero there; a dump that carries anything else is something this reference does not describe.

Live. What varies is the last three bytes of each block, and the two blocks carry the same shape there: an index 00–0F, an index 00–07, and a flag. They are two fields and not one written twice — they agree in most records and differ in 776. Block A's is unused by all 1024 user flash parts and by all but 38 preset parts; block B's is used in 434 preset parts and 418 user flash ones. The disk corpus uses neither: all 1024 of its parts read zero in both, which is the strongest sign yet that the triple is not part of a combination's edited state. Ahead of block B's sit three more, +18–+1A, which take

fifteen distinct combinations across the corpus and read 01 01 01 or 00 01 01 in four records out of five.

The natural reading of that triple is that it caches the sound the part is playing. It does not: the same program number carries two different triples in 36 cases, so the triple is not determined by the program. The shape it does have — a sixteen-way index, an eight-way index and a flag — is the shape by which the combination memory is itself addressed. Four searches of the program have been run against these bytes and all four came back empty or powerless: no menu screen captions them, the setter that takes a literal record and offset writes none of them, the six routines that reach a part through the instrument's own part pointer are the six that read the override byte, and looking for their addresses as literals has no discriminating power — a byte pair occurs by chance often enough in half a megabyte to swamp it, as a named byte used as a control demonstrates. They are written through pointers built at run time, so naming them needs the writer caught in the act rather than found by searching.

Two equaliser addresses. Chapter 7 lists MAIN OUT EQUALIZER LOW-FREQ and HIGH-FREQ without a dump position, because the descriptors that would place them are the ones whose setter does not build its target the way the others do. The stored data now places them anyway, on an argument the descriptors cannot make. Record 79 gives four bytes, +01–+04, to four parameters. The two GAINS are pinned to +01 and +03 by setters read instruction by instruction, so the two frequencies are the two bytes left, +02 and +04. Three independent corpora agree: 385 combinations hold one of two settings, D8 02 58 04 or D2 01 58 04, and **they differ at +01 and +02 only** — one instrument's low band was moved and its low pair moved together, while the high pair did not move at all. The descriptor that would put LOW-FREQ at +01 is contradicted outright: it declares 0–17 and +01 never reads below 18 in any combination in any corpus.

What is not settled is the scale. HIGH-FREQ is declared 17–26 and +04 reads 4, so either the stored byte is an index into a table rather than the displayed value, or the published range is not the stored one. An instrument with both bands moved off centre, dumped, would settle it; so would the setter, if it is ever read out.

The rest of a song record, and PERFORMANCE. Section 6.5 now decodes 2 400 of a song record's 3 072 bytes, from a native sequencer file off a disk: they are the same tagged records a combination is built from, so chapter 7 names their fields. What is left is the 544 bytes ahead of that stream, the 128 after it, and the event encoding of PERFORMANCE. Section 6.5 now characterises that block from a real file — an event stream, not a record array — but does not decode its framing, and the six-byte shape its opening events suggest is shown there to be an artefact of the first few. A SEQUENCER transfer from an SX-WSA1 keyboard would still be the natural way to put that category's frame-level behaviour beyond doubt, since the rack refuses it.

Operating system version 1. Everything here describes version 2.0. Closing this needs a dump of the earlier firmware, which this project does not have. This version carries no sign of the earlier one: a search of all three program images turns up no conversion path and no compatibility text, and nothing compares the version byte a block carries. A reader can nonetheless establish what they are holding, two ways.

Over MIDI: VER, the sixth byte of any message that carries it, is 11 here — exclusive specification 2.1. A machine speaking a different version announces it there, so a receiver can tell at once that it is talking to something this reference does not describe.

At the instrument: it has a ROM VERSION screen of its own, which reports its ROMs separately as WSA-A, WSA-C and WSA-D.

And from the front panel, against a document rather than against the machine's own account of itself. Technics issued a one-page erratum to the owner's manuals, QQCG0279A, whose single change renames the second soft key of the SOUND MODE home screen from VOL to LVL and makes it adjust the level relative to the current value, -30 to $+30$. The firmware read here already carries the new caption, so it is later than that erratum. The rename reached one screen only: the image holds four soft-key rows of that shape, and the two whose last key is MIDI — the screen the erratum photographs — read LVL, while the two whose last key is PART still read VOL. An instrument whose SOUND MODE home screen says VOL is older than the machine this reference describes.