STICKER ON THE BOX

>2 secs. OUT

>2 secs. CONDITIONS

>2 secs. SETTINGS
>10 secs. ADV. SETTINGS

+ ↑

SET/INTRO

- ↓