

Addendum: Installing Nexus eFinder firmware

The latest firmware is aligned with the commercial delivery version. This has some key behaviours. These are designed for buyers who won't (initially at least) have an infrastructure WIFI set.

They are also aimed at preventing a 'bricked' device during install. The intention is that it the Pi will always broadcast a WIFI Hotspot, regardless of any fault conditions or bad configuration.

When you now start an eFinder (as it will always try to do after firmware install thru autostart), it can result in ...

1. If plugged into a Nexus DSC Pro which has been set up previously, a successful start in Nexus Mode. It will then start WIFI according to eFinder.config, which from the repo is Hotspot. You can then use the Electronic Finder/Settings screen to change to Infrastructure if one has been set. If you are a DIY builder you will of course have an infrastructure set up.
2. If a fault is found eg no camera. Then it will always boot to Hotspot.
3. If booting to Live Mode, either manually by button press or the new auto boot (ie no nexus found), then the WIFI again comes up according to eFinder.config. This time you can flip WIFI mode with a short press of the side button.
4. As the eFinder code starts, specific faults are written to a logfile. This should be visible at `efinder.local/log.php`
5. If connected to a Nexus DSC Pro and the firmware establishes a connection, then the version number shown on the Electronic Finder/ Info screen will include any fault codes found, eg 10.4(3)

Fault codes ...

- | | |
|---|---|
| 1 | Bad or absent eFinder.config file |
| 2 | No accelerometer found (10.3 only) |
| 3 | Camera not found or working |
| 4 | Failed to set WIFI mode as configured |
| 5 | Failed to connect to Nexus DSC Pro |
| 6 | Nexus DSC Pro message error, usually recoverable. |

Iss1

July 2026