| Preset Patch (Hold MODE Button) | | Command (Hold MODE Button) | | Toggle *Setting* (Hold MODE Button) Single blink **OFF**, Double blink **ON** | | | **LE STRUM QUICK REF V1.1** | | | | |

	C	C#	D	D#	E	F	F#	G	G#	A	A#	B
MAJ	Basic Strum Mode		Guitar Strum Mode		Guitar Sustain Mode	Organ Buttons Mode		Organ Buttons with Adds		Organ Buttons with Adds/Retrig		Load User Patch From EEPROM
MIN	Play Note On Contact Make	Play Note On Contact Break	Guitar Open Chord Voicing	Added Notes (Sus4/6/9)	Sustain Chord Until Next Chord	Chromatic Scale On Pads				Enable Organ Buttons On MIDI Ch 2	Sustain O/B Until Next Chord	Save User Patch To EEPROM
DOM7	Damp Note On Contact Make	Damp Note On Contact Break	Repeat Guitar Chord At +1 Octave	Map Guitar Chord Bass Notes	Common Notes Sustain On Change	Diatonic Scale On Pads	Pentatonic Scale On Pads			Common Notes Sustain On O/B		MIDI Panic (All Notes Off)
	C	C#	D	D#	E	F	F#	G	G#	A	A#	B

Special Chord Button Combinations
MAJ + DOM7 = Major Seventh Chord
MIN + DOM7 = Minor Seventh Chord
MAJ + MIN = Diminished Triad
MAJ + MIN + DOM7 = Augmented Triad

Added Notes (When enabled by Mode)
Hold chord and press top row button to right = Sus 4
Hold chord and press middle row button to right = Add 6
Hold chord and press bottom row button to right = Add 2/9

Use of the MODE button
Hold MODE and touch a pad with the stylus to set MIDI velocity
Hold MODE at startup to view firmware version