



Procedure #11

Prepared by:

Andy Gomes

Approved by:

Clive Baek

Revised Date: March 2026**Original Date:** January 2017

CLAYTON BOILER FEEDWATER PUMP DISCHARGE HEAD FLUSH

This is a monthly maintenance routine on the Clayton Boiler feedwater pump. Be sure to wear safety glasses for this procedure. This procedure can be done when the boiler is in service or in standby. There are four drain cocks on this feedwater pump.

Clayton Boiler Feedwater Pump Discharge Head Flush			
Step	Operation	Initial when Complete	Date and Time when Complete
1	Place the Clayton Boiler feedwater pump into manual operation at a fill rate of 20 percent. If the boiler is in operation, proceed to step 2.		
2	Place a container under the drain cock at the bottom of the feedwater pump.		
3	Partially open the drain cock. Water will drain under pressure. Exercise caution.		
4	Close the drain cock once water runs clear.		
5	Repeat the procedure for the remaining three drain cocks.		
6	Return the feedwater pump to the condition it was originally found.		
7	Make an appropriate log book entry.		
End of Procedure			