



UBC Centre of Comparative Medicine (CCM) Levelmaster Semi-Auto Blowdown Procedure

Procedure #12

Prepared by:
Andy Gomes

Approved by:
Clive Baek

Revised Date: March 2026

Original Date: January 2017

LEVELMASTER WATER COLUMN SEMI-AUTOMATIC BLOWDOWN

This procedure details the steps required for a successful blow down of the Level Master water column without tripping the C.B. Boiler. **This procedure must be carried out daily to ensure the water column remains clean. This procedure must be completed daily to prevent the boiler from shutting down.**

Step	Operation	Initial when Complete	Date and Time when Complete
NOTE: The Level Master Controller will prompt for a blow down as indicated on the LCD screen.			
1	Press the Menu-Reset button. The controller will display the message "Perform Blowdown?"		
2	Press the Menu-Reset button again. The controller will display the message "Perform Blowdown Now?"		
3	Press the Menu-Reset button again to begin a 90-second timer. This is the grace period to perform a blow down of the Level Master water column without tripping the boiler.		
4	Open the Level Master water column blow down valve, within 90 seconds, and allow the column to drain completely. Verify this with the gauge glass on the water column. Only keep column blowdown open for 5 seconds after red light comes on, or boiler will trip in LWCO consequently shutting down the boiler.		
5	Make an appropriate log book entry.		

NOTES:

- When the low water level is reached, the RED low water light (LED) on the right side of the Level Master controller will illuminate.
- For blow down to succeed, the Level Master internal float ball must reach the bottom of the sensor stem. To allow the float ball to drop completely, it may be necessary to leave the blow down valve open for a short time (about 5 seconds) after the low water LED comes on. The amount of time required will vary depending on boiler pressure.
- The "Blowdown Successful" message will appear if the procedure was a success. This will then be logged into the controller's history.
- The "Blowdown Unsuccessful" message will appear if the procedure failed. It will remain on for five minutes before returning to the "Req. Col. Blowdown" message.
- The time between blow downs cannot be less than 1 minute. If the water level remains below the low water cut-off point for more than 30 seconds the Level Master will open the low water cut off contacts and shut down the boiler.