

Braillix print day - current plan

Authority: PRINT_RELEASE_2026-08-19.md

Do not use the old print_batch folder, old 3-wall G-code, or any enclosure/mechanism G-code outside the current checked folder.

Before printing

- 1 Dry NuMaker PETG HS at 60-65 C for 4-6 hours.
- 2 Clean the bed and nozzle.
- 3 Confirm the printer is the stock Anycubic Kobra Neo with a 0.4 mm nozzle.
- 4 Copy only the eight files currently inside printing/gcode_kobra_neo_checked.
- 5 Keep the motor unpowered during all shaft-coupon fitting.

Print order

- 1 motor_cam_socket_coupon.gcode
- 2 base_interface_coupon.gcode
- 3 pigtail_slot_coupon.gcode
- 4 pogo_receiver_coupon.gcode
- 5 top_interface_coupon.gcode
- 6 hardware_fit_coupon.gcode
- 7 cam_linkage_test_fixture.gcode if the resin test set and real spring are available
- 8 mid_plate.gcode after the first coupon proves the PETG/profile is behaving normally

The full top plate is on HOLD until the real M2.5 screw and real resin dot insert pass the top-interface coupon. The production cam, base, box, pod, linkage set, dot insert, nav caps, and TPU end cap are also on HOLD for the reasons in the release document.

Stop immediately if

- the first layer lifts or separates;
- walls split or warp;
- a required hole/slot prints closed;
- the nozzle hits the part;
- the printer emits unsupported G2/G3 errors;
- the material pops/crackles from moisture;
- any shaft coupon needs force, hammering, heat, or power.

A failed coupon is a successful warning. Do not continue to the larger dependent part.

Record after printing

Photograph and write down:

- selected motor double-flat size;
- motor-seat roof flat/rock-free result;
- selected M4 pilot and M2.5 standoff bore;
- selected pigtail cable-slot size;
- selected M2.5 shank, head diameter, and head depth;
- selected resin-insert clearance;
- selected heat-insert bore;
- selected magnet pocket;
- selected Hall depth;
- measured pogo receiver opening.

For the real cam/linkage/spring test, follow MECHANISM_BENCH_TEST.md and record travel, 50-cycle return behavior, damage, and peak pull force. Do not release the full mechanism from a visual fit alone.