Program Radio

The Program Radio dialog is accessed by one of these methods:

- In the Network View or Topology View area, select the radio(s) to be programmed, then select **Actions > Program Radio**.
- In the Network View or Topology View area, select the radio(s) to be programmed, then select **Program** from the context menu.

After the **Program Radios** dialog displays, confirm that the stations to be included in the output file are displayed in the left-hand side of the dialog.

On the Programming Parameters portion, make the required settings as discussed below:

- **File Name** - Type the desired file name, which must be alphanumeric and can be up to 32 characters in length.

Select either the **Radio/File System** or **Ethernet** radio buttons as required.

- **Radio/File System** - If a radio is connected as storage device, this menu can be used to transfer the output file to the selected radio by using the Transfer Location drop-down box. The output file can also be sent to the designated file location by using the Browse feature.
- **Ethernet** - If a radio is connected as a RNDIS device, the output file can be sent to a designated IP Address by entering the required address.

> **NOTE -** Refer to the radio's operation manual for instructions on configuring the Ethernet interface. Use <**ipconfig**> from the PC command line to view the IP address.

Under **Programming Options**, the following properties are set to True in the Options folder and cannot be modified:

- **Program Radio Plan** - The plan configuration data will be loaded into the radio during programming.
- **Program Keys** -The traffic encryption keys will be loaded into the radio during programming. This field is only available if all the keys used by the radio include key values and the radio net has a key assigned.
- **Program Training File** - The training file for use with text prediction in SMS (when SMS is enabled) will be loaded.
- **Program CAM** - CAM will be loaded into the radio during programming. This field is accessible only if a CAM is part of the CPA Plan.

When configuration settings are set as required, select **Start Programming**.