

Woodshop Access Control – System Documentation

Oct 6, 2026 · @bruce

Contents

- 1. Overview
- 2. Network interfaces and message formats
- 3. Server: master_server.py
- 4. Server data stores
- 5. Server: web app (app.py)
- 6. Server: daily jobs and log files
- 7. Server operations
- 8. Client: hardware and firmware structure
- 9. Client: cards, sessions, server veto, relays
- 10. Client: LEDs, sensing, overrides, updates, diagnostics
- 11. Test and support tools
- 12. Building the system
- 13. Installing the system
- 14. Open items and assumptions
- 15. Index

1. Overview

A member can run a woodshop machine only if they are signed in at the door kiosk and their permissions include that machine. Three kinds of device cooperate to enforce this.

Part	What it is	Role
Machine client ("client", "node")	One ESP32 per machine, Arduino firmware	Reads the RFID card, switches the machine and blast-gate relays, measures current, reports to the server


Part	What it is	Role
Server	Raspberry Pi 2B running DietPi, address 192.168.0.5	<code>master_server.py</code> (machine and kiosk TCP listeners, SQLite, LEDs) and <code>app.py</code> (web pages on port 80)
Kiosk ("Login")	Lee Robertshaw's Raspberry Pi at the door	Sends a LOGIN or LOGOUT message to the server when a member signs in or out

Typical sequence

1. The member signs in at the kiosk. The server adds a row to its active-members table.
2. The member taps their NTAG215 card on a machine. The client reads the card and switches the machine on straight away, using the permissions stored on the card.
3. The client sends an INSERT message (machine number, member ID) to the server.
4. The server checks that the member is signed in, then looks up their permission for that machine in the member file. It replies with status 0 (grant) or a non-zero status (deny).
5. On a deny the client clears its authorization flag, the relay drops, and the machine-on time for that session is reported as 0.
6. When the card is removed the client sends a REMOVE message with machine-on time, average current and start/stop counts. The server records the session and appends a row to the access log.
7. The member signs out at the kiosk; the server deletes their active-members row.

The web app shows who is signed in, the access log, member and machine administration, and daily log files for download.

One Pi decides access for every machine and serves the web pages



system overview · 3 device types, 1 server

Machines send INSERT and REMOVE messages and get an allow-or-deny reply. The kiosk sends sign-in and sign-out messages. Browsers, and the clients' firmware and diagnostics traffic, use the web app on port 80.

2. Network interfaces and message formats

The server listens on three TCP ports; the Pi is wired (eth0) and the machine clients join the shop WiFi network, both on one subnet (SSID set in the client's `config.h`). The client finds the server at the same subnet with last octet 5, so 192.168.0.5.

Port	Protocol	Used by	Handler
35487	Binary TCP, 16-byte request, 8-byte reply, one connection per message	Machine clients	WoodshopServer in master_server.py
45432	Binary TCP, 45-byte message, no reply, one connection per message	Kiosk (Login)	LoginListener in master_server.py
80	HTTP (Flask)	Browsers; clients for firmware and diagnostics	app.py

Machine to server: 16 bytes, big-endian (port 35487)

Offset	Size	Field	Notes
0	1	Machine number	1 to 128; stored on the client in flash, set by config card
1	4	Member ID	From the card
5	2	Machine-on time (s)	Time current was flowing; 0 on INSERT
7	2	Average current	Units of 0.01 A
9	4	Connect time (s)	How long the card was in; 0 on INSERT
13	1	Override flags	0x01 main override, 0x02 blast override, 0x40 watchdog fault
14	1	Starts	Machine start count
15	1	Stops	Machine stop count

There is no event-type field. The server infers it: all of duration, connect time, starts and stops equal to 0 is an INSERT (card in); any of them above 0 is a REMOVE (card out); override bit 0x40 is a FAULT. A card held for under one second therefore looks like an INSERT.

Server to machine: 8 bytes, big-endian

Offset	Size	Field
0	1	Machine number (echo)
1	4	Member ID (echo)
5	2	Status code
7	1	Update available (1 = firmware update ready)

Status	Name	Meaning
0x0000	OK	Access granted / message recorded
0x0001	ERROR	Generic server error

Status	Name	Meaning
0x0002	MEMBER_NOT_FOUND	Reserved
0x0003	MACHINE_DISABLED	Reserved
0x0004	MEMBER_NOT_AUTHORIZED	Not signed in, blocked by the admin, or no permission for this machine
0x0005	INVALID_MESSAGE	Short or malformed message

The client treats any non-zero status on an INSERT as a denial.

Kiosk to server: 45 bytes, big-endian (port 45432)

Offset	Size	Field	Notes
0	1	Message type	0 = login, 1 = logout
1	8	Timestamp	Unix epoch seconds, UTC
9	4	Member ID	Integer
13	16	First name	ASCII, null-padded
29	16	Last name	ASCII, null-padded

This format was confirmed with Lee Robertshaw on August 19, 2026.

`BruceTestSender.py` is the reference sender. An earlier 52-byte ASCII draft (`esp32_client.py`) is obsolete.

HTTP endpoints used by the clients

Endpoint	Purpose
<code>GET /firmware/version</code> , <code>GET /firmware/manifest.json</code>	Firmware version check
<code>GET /firmware/<file></code>	Download <code>firmware.bin</code> (white LED on the server lights during a download)
<code>POST /diag/report</code>	Reboot diagnostics posted by a client after a reset

3. Server: master_server.py

`master_server.py` is the access-control engine. It runs as one process with several threads and writes everything to `master.log` and the console.

Thread	Job
<code>WoodshopServer</code> (port 35487)	Receives machine INSERT, REMOVE and FAULT messages, decides access, replies
<code>LoginListener</code> (port 45432)	Receives kiosk LOGIN and LOGOUT messages, maintains the signed-in list
<code>daily-tasks</code>	2:00 AM log backup and 4:00 AM NTP sync (section 6)
Main thread	Sets the status LEDs and logs a <code>[HEARTBEAT]</code> <code>alive threads=N</code> line every 60 s

How access is decided

When a machine sends an INSERT, the server replies `0x0004` (not authorized) unless **all** of these are true:

1. The member has a row in `active_members` (signed in at the kiosk).
2. The member exists in `data/users.json` and is not blocked. Eligibility (dues paid, membership current) is decided by the kiosk (Login), which sends no message for an ineligible member, so the server does not test expiry dates or a grace period. The only local block is the `active` flag: a member whose record is set to inactive on the Users page gets no permissions.
3. The permission string for the member has a `1` in the character at index machine number minus 1. Bit 0, the first character, is machine 1.

The permission string is re-read from `users.json` on every request, so edits take effect immediately. A message with the override bit (`0x01`) set skips these checks. If authorized, the server records a session unless one is already open for that member and machine, which makes a repeated INSERT harmless.

On a REMOVE the server closes the session in the database and appends a row to `access_log.csv`. A REMOVE with no matching INSERT, which is what a denied card produces, still creates a row; its start time is blank.

Kiosk messages

A LOGIN looks the member up in `users.json` and inserts or replaces the `active_members` row (name from the message, login time from the message timestamp converted to server local time). A LOGOUT deletes the row. Both also append a `LOGIN` or `LOGOUT` row to `access_log.csv` so they appear on the web Logs page.

Every kiosk message is trusted. Login sends a message only for a member it has approved, so the server treats each one as a valid member. On a LOGIN for an ID not yet in `users.json`, `ensure_member()` appends a record (names from the message, active, blank expiry, permission string of 128 1 characters) and logs `[ENROLL]`. The write is atomic, and a `users.json` that exists but cannot be parsed is left untouched with an error logged. There is no authentication on port 45432; the shop's cameras and club rules are the control against a forged message.

Debug trace

`LOGIN_DEBUG = True` (above the `LoginListener` class) logs `[LOGIN-DBG]` lines for each kiosk message: the connection, raw bytes in hex, any extra bytes, the parsed fields, and the resulting `active_members` row. Set it to `False` to quiet the log.

Status LEDs on the Pi

GPIO	Colour	Meaning
25	Red	Server inoperable (a listener thread stopped or an exception escaped)
20	Green	Server running normally
5	Blue	Flashes 1 s on each kiosk message (port 45432)
26	Yellow	Flashes 1 s on each machine message (port 35487)
27	White	A client is downloading firmware (driven by <code>app.py</code>)

If `gpiozero` or its pin backend is missing, the server logs a warning and runs without LEDs.

Other points

- `UPDATE_AVAILABLE` at the top of the file is sent to every client in byte 7 of each reply (section 10 covers how clients react).
- The `MACHINES` table that gives machine numbers their names in logs is 0-based (0 = Table Saw). Permission bits are 1-based. See section 14.
- The header comment at the top of `master_server.py` still describes an older message layout (event-type and auth-status bytes). The parser itself uses the layout in section 2.

4. Server data stores

Everything lives under the server's install folder (`~/woodshop`). Back up the whole folder, or at minimum `data/` and `woodshop.db` .

Path	Written by	What it holds
<code>woodshop.db</code>	<code>master_server.py</code>	SQLite database (tables below). Recreated empty if deleted
<code>data/users.json</code>	<code>app.py</code> (admin pages, CSV import)	Member file: id, first and last name, email, phone, rfid, active flag, joined and expiry dates, 128-character permission string (members are added automatically at their first kiosk login)
<code>data/machines.json</code>	<code>app.py</code>	Machine list: id, name, location, enabled
<code>data/admin_creds.json</code>	<code>app.py</code>	Web login: username and SHA-256 password hash. Created as <code>admin / woodshop</code> if missing, so change it
<code>data/access_log.csv</code>	<code>master_server.py</code>	The log the web Logs page reads (formats below)

Path	Written by	What it holds
<code>data/logs/log<yyyy><MMM><dd>.csv</code>	<code>master_server.py</code> daily job	One backup file per day, for example <code>log2026OCT05.csv</code>
<code>firmware/firmware.bin</code> , <code>firmware/version.txt</code>	You	Firmware image and its version string served to the clients
<code>master.log</code>	Both programs	Text log. Keep one process per log file in mind: a running program keeps writing to a deleted log until restarted
<code>data/active_sessions.json</code>	none	Legacy, unused since August 2026

If `users.json` or `machines.json` is missing when the web app starts, it creates demo data (Alice Smith, Bob Jones, Charlie Brown and eight sample machines) and a sample `access_log.csv`. Import your real members before relying on the log.

SQLite tables (woodshop . db)

Table	Purpose
active_members	Who is signed in at the kiosk: member_id (key), first and last name, login_time, permissions snapshot. This is what the Active page shows and what the access check consults first
sessions	One row per machine session: member, machine, insert and remove times, machine-on seconds, average amps, connect seconds, override flags
machines	Current state per machine number: who is using it, session start, last seen, status
raw_messages	Every machine message received, with its hex dump, for troubleshooting
members	Created but not used by the current code

access_log.csv row formats

Row kind	Columns
Machine session (11)	timestamp (stop time), member_id, member_name, machine_number, machine_name, start_time, stop_time, connect_time_s, machine_on_s, avg_current_A, starts
Kiosk event (6)	timestamp, member_id, member_name, machine_number (blank), machine_name ("Kiosk"), event (LOGIN or LOGOUT)

The daily backup files use one 12-column layout: the 11 session columns plus an event column, with kiosk rows widened to fit. A session row with a blank start time is a REMOVE that had no matching INSERT, which is what a denied card produces.

5. Server: web app (app.py)

`app.py` is a Flask app on port 80, used from a phone, tablet or laptop on the shop WiFi at `http://192.168.0.5`. Every page except the client endpoints needs the admin login. The top menu on every page reads **Refresh, Logs, Log Files, Active, Users, Machines, Diagnostics, Logout**.

Menu item	Route	What it does
Refresh	none (browser reload)	Reloads the page you are on with current data; never changes page. Pages are sent with no-cache headers so a reload always fetches fresh data
Logs	<code>/logs</code>	The access log, newest first, with filters for machine, user, date range and last N rows. Shows machine sessions and kiosk LOGIN and LOGOUT rows. Event badges: SESSION, LOGIN, LOGOUT
Log Files	<code>/logfiles</code>	Lists the daily CSV backups, newest first, with date and size; click a name to download
Active	<code>/active</code>	Members currently signed in at the kiosk, with sign-in time and the machines they may use. Reloads itself every 30 s
Users	<code>/admin/users</code>	Member list, search, add, edit, delete, CSV import and export
Machines	<code>/admin/machines</code>	Machine list and editing, CSV import and export
Renew	<code>/admin/renew</code>	Hidden from the menu (the page still works if you type the address). Bulk membership renewal: tick the members who paid, choose the year, and their expiry becomes Dec 31 of that year. Informational only; the server no longer checks it
Diagnostics	<code>/admin/diag</code>	Reboot reports posted by the clients
Logout	<code>/logout</code>	Ends the session

Other routes: `/admin/password` (change the admin password), JSON at `/api/logs` and `/api/active`, CSV export at `/api/users/export.csv`, `/api/machines/export.csv` and `/api/log/export.csv`, CSV import at `/api/users/import.csv` and

`/api/machines/import.csv`.

Members and permissions

A member's `permissions` value is a 128-character string of `0` and `1`; character 1 is machine 1. In the CSV import the columns are `member_id`, `first_name`, `last_name`, `email`, `phone`, `rfid`, `joined`, `expiry`, `active`, `permissions`. Import merges: rows replace members with the same ID and everyone else is kept. A blank `permissions` value becomes all zeros (no access).

Members are normally created automatically: the first time the kiosk sends a login for an unknown member ID, the server adds a record with the names from the message, the active flag on, blank expiry, and full access to all 128 machines. An existing record is never changed by a kiosk message, so permissions limited on the Users page stay limited. Use the Users page to restrict a member to certain machines, or to set the active flag off to block someone. The Users list shows only ID, name, how many machines the member may use, and a (blocked) tag when the active flag is off. Email, phone, RFID and expiry are not shown on the list or the edit form; they stay in `users.json` as hidden form fields, so saving a member never erases them, and they are still in the CSV export and import. The Renew page is hidden from the menu, and expiry does not affect machine access.

Client endpoints (no login)

`/firmware/version`, `/firmware/manifest.json`, `/firmware/<file>` and `POST /diag/report` are called by the machine clients, so they do not require the admin login. Keep the network private.

6. Server: daily jobs and log files

A background thread in `master_server.py` runs two jobs once per day at local time. The times, NTP host and folder are constants in the block headed "Daily maintenance" (`LOG_BACKUP_TIME`, `NTP_SYNC_TIME`, `NTP_SERVER`, `LOG_BACKUP_DIR`).

Time	Job	Result
2:00 AM	Log backup	Writes the previous day's rows from <code>access_log.csv</code> to <code>data/logs/log<yyyy><MMM><dd>.csv</code> . The original log is left untouched. Days with no activity still get a header-only file

Time	Job	Result
4:00 AM	NTP sync	Reads the time from <code>pool.ntp.org</code> . If the clock is off by more than 1 second it sets the system clock; otherwise it only logs the offset

File names. `log2026OCT05.csv` holds October 5, 2026. The month is a three-letter upper-case code. Files are written to a temporary name and renamed, so a partial file never appears.

Start-up back-fill. When the server starts it creates yesterday's file if it is missing, for example after a power cut at 2:00 AM.

Setting the clock needs permission. The server runs as the `woodshop` user. To let it set the time, add this line with `sudo visudo -f /etc/sudoers.d/woodshop-date`:

```
woodshop ALL=(root) NOPASSWD: /bin/date
```

Without it the job still checks the offset and logs a warning, but cannot change the clock. If DietPi's own time sync is active, offsets are normally tiny. The Pi 2B has no battery clock, so the time is wrong after a power-up until a sync happens.

Log lines to look for in `master.log`: `[BACKUP] wrote N row(s) for <date> -> <path>`, `[NTP] clock OK (offset ...)`, and `[NTP] clock was ... off -- set from ...`.

Downloading. The web app's Log Files page lists the files in `data/logs` newest first. Only names of the exact form `log<yyyy><MMM><dd>.csv` can be downloaded.

7. Server operations

Programs. Two separate programs run on the Pi: `app.py` (web, port 80) and `master_server.py` (ports 35487 and 45432). The code comments name them as the systemd services `woodshop` and `woodshop-tcp`. Both use the Python in `~/woodshop/venv`.

Restart after copying a new file.

```
sudo systemctl restart woodshop      # app.py
sudo systemctl restart woodshop-tcp   # master_server.py
```

If you start them by hand instead, stop the old process first (`kill -f master_server.py`) and run `./venv/bin/python master_server.py` or `app.py` from `~/woodshop`. Run `ps aux | grep -E "master_server|app.py" | grep -v grep` to confirm exactly one of each is running; an old process left behind keeps serving the old code.

Watching activity.

```
tail -f ~/woodshop/master.log | grep --line-buffered "LOGIN"    # kiosk
messages
grep -E "NOT AUTHORIZED|INSERT:|Response:" ~/woodshop/master.log | tail -20
# machine decisions
```

Reading a machine decision. The `Response:` line shows `Status=0x0000` for a grant and `Status=0x0004` for a denial. The `Auth=AUTHORIZED` text on the `From ...: INSERT` line is a fixed default from the parser and does not reflect the decision.

Resetting the data. Stop both programs first. Then remove the files you want cleared: `master.log`, `woodshop.db`, and `data/access_log.csv` (replace the last with an empty file, `> data/access_log.csv`, so the web app does not re-create demo rows). Keep `data/users.json`, `data/machines.json` and `data/admin_creds.json` unless you mean to lose members, machines and the admin password.

Stale sign-ins. A kiosk LOGIN with no matching LOGOUT leaves the member signed in. Inspect with `sqlite3 ~/woodshop/woodshop.db "SELECT * FROM active_members;"` and clear one with `DELETE FROM active_members WHERE member_id=N;`.

Troubleshooting.

Symptom	Check
Kiosk message light flashes but nothing happens	<code>tail master.log</code> ; confirm the running copy has the 45-byte parser (startup line says "expecting 45-byte binary messages")
Member signed in but machine denies	Permission string in <code>users.json</code> has no <code>1</code> at machine number minus 1, member is blocked (active flag off), or the machine number does not match

Symptom	Check
Machine runs although denied	The server replied 0x0004 but the client firmware is older than the version that acts on it; update the client
Log page looks old	Press Refresh; the Active page reloads itself, Logs does not
Logs missing after a clean-up	A running program kept the deleted file open; restart it
Clock wrong after power-up	Section 6: NTP sync runs once a day at 4:00 AM only

8. Client: hardware and firmware structure

Each machine has one ESP32 board running the sketch `Client.ino` (Arduino IDE 2.3.10, board "ESP32 Dev Module"). Firmware version is `FW_VERSION` in `config.h` (1.0.5 at the time of writing). Libraries: Elechouse PN532 (`PN532` , `PN532_SPI`), rweather Crypto (Ed25519), ArduinoJson. The Tools > Partition Scheme must be one of the "with OTA" schemes or firmware updates cannot be installed.

Pins (`config.h`)

Function	GPIO	Notes
PN532 SS (chip select)	21	10 k pull-up to 3V3
PN532 MOSI / MISO / SCK	19 / 23 / 18	MISO and MOSI are the opposite of the ESP32 defaults; do not "fix" them
PN532 IRQ	4	Wired; interrupt currently not attached
PN532 reset (RSTPD_N)	13	Driven low 150 ms to reset the reader
LEDs red / green / yellow / white	12 / 14 / 27 / 26	Active high
Main relay / blast-gate relay / aux relay	32 / 33 / 25	Active high; aux is set low and not used

Function	GPIO	Notes
Current sensor input	36	ADC1 channel 0, current transformer with 220 ohm burden
Main override switch / blast override switch	17 / 16	Active low, internal pull-up

A bulk capacitor of 470 uF or more from 3V3 to ground, close to the ESP32, is recommended: the PN532 self-test and RF start-up draw about 150 mA and marginal supplies cause start-up failures.

Tasks (FreeRTOS)

Task	File	Role
<code>task_led</code>	<code>led_ctrl.cpp</code>	Drives the four LEDs; flashes all twice at power-up
<code>task_rfid</code>	<code>rfid_task.cpp</code>	PN532 start-up and card polling; reads cards; sets the shared session state; handles config cards
<code>task_override</code>	<code>override_task.cpp</code>	Reads and debounces the two override switches (20 ms sampling, 3 samples)
<code>task_relay</code>	<code>relay_ctrl.cpp</code>	The only code that writes the relay pins; runs at 50 Hz
<code>task_session</code>	<code>session_task.cpp</code>	Counts starts and stops, accumulates machine run time and average current
<code>task_wifi</code>	<code>wifi_task.cpp</code>	Connects WiFi, sends INSERT and REMOVE messages, acts on the reply, posts diagnostics
<code>task_ota</code>	<code>ota_task.cpp</code>	Checks for and installs new firmware
current-sense task	<code>current_sense.cpp</code>	Samples the ADC through I2S DMA at 20 kHz on Core 1 and computes RMS current
diag heartbeat	<code>diag.cpp</code>	Records what the firmware was doing, for reboot diagnosis

Start-up order matters. `setup()` starts the current sensor, LED task, RFID task (which waits), override, relay and session tasks, then releases the RFID task so it can reset and initialise the PN532. WiFi is started only after the PN532 is initialised (up to 30 s wait), because radio noise during the reader's RF set-up causes intermittent failures on weak supplies. OTA starts last.

Shared state. All tasks share one `g_session` record (card active, member ID, authorized flag, start time, run time, average current, starts, stops, override flags) guarded by a mutex. Each hardware resource has one owner: the relay pins belong to `task_relay`, the PN532 to `task_rfid`, the override switches to `task_override`, and the ADC to the current-sense task.

Saved settings. The machine number (1 to 128; default 1) and blast-gate run-on time (default 30 s) are stored in flash (NVS, namespace `woodshop`) and change only through a signed config card.

Build modes. `DEV_BUILD` (commented out in `config.h`) disables the brown-out detector and stretches the watchdog for bench work. Leave it off for installed units so resets are logged rather than silent.

9. Client: cards, sessions, server veto, relays

Member card layout (v2, 52 bytes, unsigned)

Cards are NTAG215 tags written by `rfid_write.py` (companion to Lee Robertshaw's `WriteNTAG215.py`). The client reads them and never writes. Data starts at page 4.

Bytes	Field
0 to 3	Member ID as four ASCII digits, for example <code>0042</code>
4 to 19	Permission bitmap, 128 bits; bit 0 of byte 0 is machine 1
20 to 35	First name, ASCII, null-padded
36 to 51	Last name, ASCII, null-padded
52 onward	Zero

Member cards carry no signature, so the client trusts what is written on the card. Config cards (type byte 0x02, machine number, blast-gate delay in 10 s units, Ed25519 signature) are verified against the server's public key before they change the saved machine number or blast delay. A card whose first four bytes are not digits and is not a config card is rejected as unrecognised.

What happens when a card is presented

1. `task_rfid` polls the reader every 250 ms. On a new card it waits 150 ms, reads 120 bytes, and parses the member ID.
2. It checks the card's own permission bit for this machine (bit machine number minus 1). The result becomes the session's `authorized` flag, and the session is marked active.
3. If the card permits the machine: green LED on, yellow LED on. If not: green LED flashes fast and the machine stays off.
4. `task_relay` turns the main relay on at once when `active` and `authorized` are both true. This local grant works even if the server or network is down.
5. `task_wifi` notices the new session within 200 ms and sends an INSERT to the server.
6. If the reply status is non-zero, `task_wifi` clears `authorized` (the relay drops within one 20 ms tick) and marks the session as denied.
7. When the card has been absent for 500 ms, the session ends, all LEDs go off, and `task_wifi` sends a REMOVE with run time, average current, starts and stops. For a denied session it reports machine-on time, current, starts and stops as 0, but still sends how long the card was in.

If the server cannot be reached, nothing revokes the local grant and the machine keeps running (fail open).

Relays

Relay	On when
Main	(session active and authorized) or main override switch
Blast gate	1.5 s after the main relay turns on from a card (<code>BLAST_START_HOLD_MS</code>), or immediately with the main override; also while the blast override switch is on; also for the run-on time after the machine turns off

The 1.5 s hold-off lets the server's deny arrive before the blast gate starts, so a rejected card never runs the dust collector. The run-on timer (default 30 s, set by config card) starts only if the blast gate had actually been running.

Session statistics (`task_session`)

Every 50 ms while a card is present the task checks whether current is above 0.20 A (with hysteresis; it drops out at 80 percent of that). It counts starts and stops (each capped at 255), adds 50 ms to machine run time while the machine is on, and keeps a running mean of RMS current, ignoring the first 100 ms after each start to skip motor inrush.

10. Client: LEDs, sensing, overrides, updates, diagnostics

LED meanings

All four LEDs flash twice at power-up. Blink speeds: fast 400 ms period, medium 800 ms, slow 2 s.

LED	State	Meaning
Green	On	Card accepted locally; machine allowed
Green	Fast flash	Card denied, unreadable or unrecognised; also a rejected config card
Yellow	On	Card present

LED	State	Meaning
Yellow	Medium blink	No network (WiFi not connected); a card tap can briefly override it, and it re-asserts about every 5 s
Green and yellow	Fast flash for 2 s	Config card accepted
Red	Fast flash	Main override switch is on, or the card reader failed to start
White	Medium flash	Blast override switch is on
Red and white	Fast flash for 30 s	A firmware download or flash failed

Current sensing

A 1000:1 current transformer with a 10-turn primary and a 220 ohm burden resistor feeds GPIO36. The ESP32 samples it at 20 kHz through I2S DMA on Core 1 and keeps a fast RMS value and a slow DC-bias value. The machine counts as on above 0.20 A (idle noise is about 77 mA), with hysteresis so it does not chatter. The constants are in `config.h` (`CURRENT_*`).

Override switches

The two switches on GPIO17 (main) and GPIO16 (blast) bypass the card. The main override turns the main relay and blast gate on without a card; the blast override turns only the blast gate on. The state is sent to the server in the override byte of every message.

Firmware updates (OTA)

1. Build with Sketch > Export Compiled Binary. Copy it to the server's `firmware/` folder as `firmware.bin` and put the new version in `firmware/version.txt`. Raise `FW_VERSION` in `config.h` to match.
2. Run `python3 set_ota.py true`. It sets `UPDATE_AVAILABLE = True` in `master_server.py` and restarts the service, so every server reply carries the update flag.
3. Each client checks on its next card event, or on its own timer every 10 minutes, fetches `/firmware/manifest.json`, and does nothing if the version already matches its own.
4. If different, it downloads into the spare flash partition, checks the MD5, and reboots only after no card session is open, so power is never dropped mid-cut.

A client that is already current ignores the flag, so it can stay on for the whole rollout. Turn it off with `set_ota.py false` when done. Enabling bootloader rollback in the Arduino core is recommended so a bad image returns to the previous one.

Reboot diagnostics

At every boot the client records why it restarted (reset reason) and what it was doing just before (a breadcrumb kept in RTC memory), in a 16-entry ring buffer in flash. When WiFi is up it posts any pending record to `/diag/report` on the server, and the web app's Diagnostics page lists them. If most records show a brown-out or power-on reset, suspect the 3V3 supply rather than the code.

Changing machine number or blast delay

Present a signed config card to the machine. The server's private key signs these cards. The client checks the signature, the version byte (1) and the range (blast delay up to 150 s), then saves the values to flash.

11. Test and support tools

Tool	Runs on	Purpose
<code>BruceTestSender.py</code>	Any computer with Python 3	Reference sender for the kiosk format. <code>python BruceTestSender.py 192.168.0.5</code> sends 8 messages (4 logins, 4 logouts for members 403, 497, 9999 and 100, including a long-name truncation test), one second apart
<code>BruceTestSender_esp32.py</code>	ESP32 with MicroPython (Thonny)	The same test sequence ported to MicroPython: connects WiFi, syncs time over NTP, converts the 2000-based clock to Unix time, pads names without <code>1just</code>

Tool	Runs on	Purpose
<code>rfid_write.py</code>	Raspberry Pi with a PN532 on SPI	Writes member cards. Example: <pre>python3 rfid_write.py --id 42 --first Jane --last Doe -- machines 1,3,5 . Accepts ranges (1-10,20), all or none ; member ID 0 to 9999; names up to 16 ASCII characters; --dry-run shows the bytes without a card; it verifies by reading back. Needs adafruit- circuitpython-pn532 , Blinka and a GPIO library, and SPI enabled</pre>
<code>esp32_client.py</code>	ESP32 with MicroPython	Obsolete. Sends the earlier 52-byte ASCII format, which the server no longer accepts
<code>set_ota.py</code>	Server	Turns the firmware-update flag on or off and restarts the TCP service. Edits the UPDATE_AVAILABLE line at the top of master_server.py (true, false or status), restarts the woodshop-tcp service with sudo, and kills any stale process still holding port 35487. Its help text says nodes download on their next reboot; in practice they act on the next card event or within 10 minutes

The card writer's permission bitmap is 16 bytes, four little-endian 32-bit words, with machine 1 at bit 0. It matches the client's reader.

12. Building the system

Nothing is compiled on the server. Only the client firmware is built.

Server: what to assemble

The server package is a folder of plain files plus a Python environment.

Include	Notes
<code>master_server.py</code> , <code>app.py</code>	The current versions of both
<code>set_ota.py</code>	Firmware-update switch; run it from the server folder, it edits <code>master_server.py</code> in place
<code>firmware/</code>	<code>firmware.bin</code> and <code>version.txt</code> , only if you use over-the-air updates
<code>data/users.json</code> , <code>data/machines.json</code> , <code>data/admin_creds.json</code>	Optional starting data. If left out, the web app creates demo data on first start
Service files	<code>woodshop.service</code> and <code>woodshop-tcp.service</code> (not supplied)

Do not include `master.log`, `woodshop.db`, `data/access_log.csv`, `data/logs/`, `venv/`, test senders or backup copies; the programs create what they need.

Python packages are listed in `requirements.txt`: Flask 2.3 or later (below 3) and gpiozero 2.0 or later. Install them with `./venv/bin/pip install -r requirements.txt`. For the status LEDs gpiozero also needs a GPIO driver (`RPi.GPIO` or `lgpio`); without one it prints a fallback warning and uses its experimental native driver, and the server still runs if the LEDs cannot start. Everything else is in the Python standard library. The code was run under Python 3.13.

Client: build the firmware

1. Install Arduino IDE 2.3.10 and the Espressif ESP32 board package (an ESP-IDF 5.x based release).
2. Install the libraries: the Elechouse PN532 library (the `PN532` and `PN532_SPI` folders; install from its GitHub release if it is not in the Library Manager), `Crypto` by rweather, and `ArduinoJson` by bblanchon.
3. Create a folder named `Client` holding `Client.ino` and the other 21 files (`config.h`, and a `.h` and `.cpp` pair for each of `diag`, `node_config`, `led_ctrl`, `current_sense`, `rfid_task`, `override_task`, `relay_ctrl`, `session_task`, `wifi_task` and `ota_task`). Leave out `current_sensor_task.c` and `current_sensor_dsp.c`; Arduino compiles every `.c` and `.cpp` file in the folder.

4. Edit `config.h`: set `WIFI_SSID` and `WIFI_PASSWORD`, check `SERVER_HOST_BYTE` (5 gives 192.168.0.5), set `MACHINE_NUMBER` (used only on a unit's first boot), and raise `FW_VERSION` for each release. Keep `DEV_BUILD` commented out for installed units.
5. In Tools choose board **ESP32 Dev Module** and a **Partition Scheme with OTA** (two app slots). Without it, over-the-air updates fail with "not enough space".
6. Click Verify to compile. For an over-the-air release also choose Sketch > Export Compiled Binary; the `.ino.bin` it produces becomes `firmware.bin`.

Release checklist

Step	Where
Bump <code>FW_VERSION</code>	Client <code>config.h</code>
Compile and export the binary	Arduino IDE
Copy it to <code>firmware/firmware.bin</code> and put the same version in <code>firmware/version.txt</code>	Server
Run <code>python3 set_ota.py true</code>	Server
Watch <code>master.log</code> , <code>GET /firmware/manifest.json</code> and the white LED to see clients download	Server
Run <code>python3 set_ota.py false</code> once every machine reports the new version	Server

`set_ota.py` must sit in the same folder as `master_server.py`, because it rewrites the `UPDATE_AVAILABLE = ...` line (kept at the start of a line) in that file. It runs `sudo systemctl restart woodshop-tcp`, so run it as a user with sudo rights. If you start `master_server.py` by hand instead of as that service, the restart step prints a warning and you must restart the program yourself. `python3 set_ota.py status` shows the current setting.

13. Installing the system

Install in this order: server, kiosk connection, then each machine client.

Server (Raspberry Pi 2B, DietPi)

- 1. Network.** Connect the Pi by Ethernet (eth0) to the shop network. It takes a DHCP lease, then `derive-static-ip.sh` keeps the first three octets and changes the last to 5 (192.168.0.5 on the current network); clients assume that address. The script (`/usr/local/sbin/derive-static-ip.sh`, with `IFACE="eth0"` and `LAST_OCTET="5"`) is run by `derive-static-ip.service` and a timer that fires 15 s after boot and every 5 minutes, so the address is re-applied if DHCP changes it. It is installed by running the supplied `DHCPDExitHook.sh` once on the Pi, which writes the script and both units, then runs `systemctl enable --now derive-static-ip.timer`. Check with `ip a show eth0`.
- 2. User and folder.** The service account is `woodshop` (home `/home/woodshop`, no login shell, created with `useradd --create-home --shell /usr/sbin/nologin woodshop`) and the files live in `/home/woodshop/woodshop`. The recommended route is `deploy/bootstrap.sh` (see Bootstrap below), which does this step, the Python step, authbind and the services in one go. The manual steps that follow are for an install without git.
- 3. Python.** Create the environment and install packages:

```
cd ~/woodshop
python3 -m venv venv
./venv/bin/pip install -r requirements.txt
```

- 4. Permission to set the clock** (optional but recommended): add `woodshop ALL=(root) NOPASSWD: /bin/date` with `sudo visudo -f /etc/sudoers.d/woodshop-date` (section 6).
- 5. Services.** Install `woodshop.service` (runs `app.py`; it must be allowed to listen on port 80) and `woodshop-tcp.service` (runs `master_server.py`), both as user `woodshop` using `~/woodshop/venv/bin/python`. Then enable and start them:

```
sudo systemctl daemon-reload
sudo systemctl enable --now woodshop woodshop-tcp
```

Port 80 needs authbind for the non-root user: `sudo touch /etc/authbind/byport/80` then `sudo chown woodshop /etc/authbind/byport/80`; the unit starts `app.py` through authbind. `bootstrap.sh` does this for you.

- 6. LEDs** (optional): wire the status LEDs to GPIO 25, 20, 5, 26 and 27 as in section 3.

7. Firmware folder (if using updates): create `~/woodshop/firmware/` with `firmware.bin` and `version.txt`.

Bootstrap, updates and what stays outside git

Bootstrap. Push the server tree to your git repository (`AttilaTheHunBruce/Woodshop-Server`), set `REPO_URL` in `deploy/bootstrap.sh` (or export `WOODSHOP_REPO_URL`), then on the Pi run `curl -fsSL https://raw.githubusercontent.com/AttilaTheHunBruce/Woodshop-Server/main/deploy/bootstrap.sh | bash`. It installs git, python3-venv, authbind and sqlite3; creates the `woodshop` user; clones the repo (or fetches and hard-resets it) into `/home/woodshop/woodshop`; rebuilds the venv from `requirements.txt` (Flask 2.3+, plus gpiozero for the LEDs); creates `data/` and `firmware/` without overwriting; sets up authbind; and installs and restarts the two systemd units. The same command is the rebuild after any code change and is safe to repeat.

Quick update. If only Python changed: `cd /home/woodshop/woodshop`, `git pull`, `sudo systemctl restart woodshop woodshop-tcp`.

Outside git (per Pi, never touched by a rebuild). `data/users.json`, `data/machines.json`, `data/admin_creds.json`, `data/active_sessions.json`, `data/diag/`, `access_log.csv`, `master.log`, `woodshop.db`, and `firmware/firmware.bin` with `firmware/version.txt`.

Delete before pushing. `server_card_writer.py`, `requirements-nfc.txt` and `deploy/gen_key.py` are deprecated stubs. The server no longer writes cards or signs anything, and `cryptography` is not a dependency.

OTA flag. `sudo venv/bin/python set_ota.py true|false|status` from `/home/woodshop/woodshop`.

Testing note. Run the programs as scripts (`python app.py`), as the units do. Pasting them into the Python 3.13 interactive shell can point `__file__`, and so every data path, at the REPL launcher.

Reference copies on the Pi. So the whole project can be found years from now, the Pi holds the source and documentation: `~/woodshop/` is the running server source; `~/reference/Client/` is the client Arduino sketch (open `Client.ino`); `~/reference/Docs/` is this document as PDF and Markdown; `~/README.txt` lists these, the two services and the three GitHub repositories (`Woodshop-Server`, `Woodshop-Client`, `Woodshop-Docs`, all public). The last step of `bootstrap.sh` clones the Client and

Docs repositories into `~/reference/` (or fetches and hard-resets them if already there), so every bootstrap run refreshes all three copies. If a clone fails, for example because the Pi has no internet, the script prints a warning and carries on, since the server does not depend on them. Do not edit the files under `~/reference/`; the next run overwrites them. Live data in `~/woodshop/data/` is not in git, so back it up separately.

Public repository and credentials

The three GitHub repositories are public, so the source contains placeholders instead of live credentials. **Before building or installing, edit these:**

- **WiFi name and password (client).** In `config.h`, set `WIFI_SSID` and `WIFI_PASSWORD`. The repository holds `YOUR_SSID` and `YOUR_PASSWORD`. Every client needs the real values, so a newly built unit joins the network only after this edit. Also check `MACHINE_NUMBER` and raise `FW_VERSION` for each release.
- **Same network on the server side.** The server holds no WiFi credentials. The Pi is wired (eth0) and takes its address from DHCP; section 13 explains how `derive-static-ip.sh` sets the last octet to 5. The WiFi access point must put the clients on the same subnet as the Pi.
- **Web admin login (server).** `app.py` creates `admin / woodshop` the first time it runs, if `data/admin_creds.json` is missing. This is a default, not a secret: change it at once on the Admin password page. The stored login is a hash in `data/admin_creds.json`, which is not in git.
- **Test tools.** `BruceTestSender_esp32.py` (MicroPython) has its own `WIFI_SSID` and `WIFI_PASSWORD` lines; fill them in the same way. `esp32_client.py` is obsolete and should not be distributed.
- **Not secret.** The Ed25519 public key in `config.h` is meant to be public. The server's private signing key is not part of this project.

Where the real values are. Keep the live SSID and password in a private place (the private copy of this document, a sealed note in the shop, or the router's own settings). Anyone rebuilding the system years from now needs three things: the WiFi name and password, the Pi's admin login, and the GitHub account that owns the repositories. If the WiFi password changes, every client must be rebuilt with the new value and reflashed over USB, because a unit that cannot join WiFi cannot receive an over-the-air update.

First-run checks on the server

Check	How	Expect
Ports are open	<code>ss -ltn grep -E "35487 45432 :80"</code>	Three LISTEN lines
Startup messages	<code>tail ~/woodshop/master.log</code>	"Database initialized", "Login listener started ... 45-byte binary messages", "Woodshop Master Server started"
Web login	Browse to <code>http://192.168.0.5</code> and sign in as <code>admin / woodshop</code>	The Active page
Change the password	Admin password page	New password works
Load real data	Users and Machines pages, CSV import (template columns in section 5)	Members and machines listed

Kiosk

Point the kiosk at 192.168.0.5, port 45432, and make it send the 45-byte message in section 2. Prove it with `python BruceTestSender.py 192.168.0.5` and look for `LOGIN` and `LOGOUT` lines in `master.log` and rows on the Logs page.

Each machine client

1. Wire the board as in the pin table in section 8, with the 470 uF capacitor on 3V3. Mount the card reader so cards sit about 32 mm (1.25 inch) from the antenna.
2. Flash the first time over USB from the Arduino IDE. Open the Serial Monitor at 115200 baud; the banner shows the firmware version, `[cfg] first boot` and the machine number.
3. Set the machine number and blast-gate delay: either edit `MACHINE_NUMBER` before flashing, or present a signed config card (open item 4 in section 14 notes that the card-making route needs confirming).
4. After WiFi connects the yellow no-network blink stops. Present a member card: the Serial Monitor prints the card, and `master.log` shows an `INSERT` line.

Later updates go over the air (section 10); no USB cable is needed.

Member cards

Write cards on a Raspberry Pi with a PN532 reader on SPI, using `rfid_write.py` (install the Adafruit PN532 and Blinka packages, enable SPI, and add your user to the `gpio` and `spi` groups, or run it from its own virtual environment). Use `--dry-run` first.

Acceptance test

#	Test	Expected
1	Send the kiosk test sequence	Rows appear for each LOGIN and LOGOUT; the Active page lists members while signed in
2	Sign a member in, tap their card on a machine they may use	Machine starts; <code>Status=0x0000</code> in <code>master.log</code>
3	Sign the member out, tap the same card	Machine drops out within a second; <code>NOT AUTHORIZED</code> and <code>Status=0x0004</code> logged; blast gate never starts
4	Tap a card without permission for the machine	Green LED flashes fast; machine stays off
5	Press Refresh on the Logs page	Same page, newest data
6	Next morning	A <code>log<yyyy><MMM><dd>.csv</code> file for the previous day on the Log Files page

14. Open items and assumptions

#	Item	Detail
1	Machine numbering	Permission bits are 1-based (machine 1 is the first character). The server's <code>MACHINES</code> name table is 0-based, so machine 1 currently logs as "Band Saw". Confirm whether the controllers are numbered from 0 or 1 and fix the names or the bits to match

#	Item	Detail
2	LEDs after a server denial	When the server vetoes a card, the relay drops but the green LED stays on and the yellow LED stays solid for the rest of the session. <code>rfid_task.cpp</code> comments describe a server-confirmation routine <code>(_attempt_server_confirmation())</code> with a 30 s retry that is not in the current <code>wifi_task.cpp</code>. Decide whether to add a denial indication and the retry
3	Fail-open policy	If the server is unreachable the machine keeps running on the card's local grant. This is deliberate in the current design; say so if you want it changed to fail closed
4	Config cards	The client accepts only Ed25519-signed config cards. DEPLOY.md says the server no longer creates them (no <code>/admin/config-card</code>, no <code>server_card_writer.py</code>, no signing key), and <code>rfid_write.py</code> cannot sign them either. How config cards are produced now is still unknown; setting <code>MACHINE_NUMBER</code> before flashing avoids needing one
5	Unsigned member cards	The client trusts the member ID and permissions written on a card. The server's own check (signed in, active, permitted) is the real gate
6	Server comments	The header comment of <code>master_server.py</code> still describes an older 16-byte layout with event-type and auth-status bytes. The code, and section 2 of this document, use the layout the client actually sends
7	Services	Resolved by DEPLOY.md: <code>woodshop</code> (web app) and <code>woodshop-tcp</code> (server) are systemd units installed by <code>bootstrap.sh</code>, running as user <code>woodshop</code>. Confirm they are enabled on your Pi with <code>systemctl is-enabled woodshop woodshop-tcp</code>

#	Item	Detail
8	Default admin login	<code>admin / woodshop</code> is created if the credentials file is missing. Change it
9	Unused files	<code>current_sensor_task.c</code> and <code>current_sensor_dsp.c</code> are not referenced by the sketch; the build uses <code>current_sense.cpp</code> . <code>esp32_client.py</code> is obsolete
10	Not yet reviewed	<code>diag.cpp</code> , <code>ota_task.cpp</code> and <code>current_sense.cpp</code> were read for their header descriptions, not line by line
11	Kiosk sends only eligible members	The server assumes that Login never sends a message for a member who has not paid dues. If Login were to send ineligible members the server would log them in and enrol them with full access. To be confirmed with Lee Robertshaw

This document describes the code as supplied on the date above, including the changes made in this project: the 45-byte kiosk parser, kiosk rows in the web log, the live permission lookup with bit 0 = machine 1, members added automatically with full access on their first kiosk login, expiry no longer checked by the server, the server-veto handling and 1.5 s blast hold-off in the client, the yellow-only no-network LED, the Refresh menu item, the daily log files and download page, and the daily NTP job.

15. Index

Numbers are section numbers.

Term	Sections
access decision (grant or deny)	3, 9
access_log.csv	4, 6
acceptance test	13
Active page	5
active_members table	3, 4

Term	Sections
admin login and password	4, 5, 13
app.py (web app)	5, 7, 12
Arduino IDE and libraries	12
authbind (port 80)	13
backup (daily log files)	6
blast gate	9, 10
bootstrap.sh (git deployment)	13
building the firmware	12
card layout (member and config)	9
card writer (rfid_write.py)	11, 13
config card	8, 9, 10, 14
config.h	8, 12
connect time	2, 9
current sensing	8, 10
data stores	4
diagnostics (reboot reports)	2, 10
fail open	9, 14
firmware update (OTA)	2, 10, 12
INSERT and REMOVE messages	2, 3, 9
installation	13
kiosk (Login)	1, 2, 3, 13
LEDs, client	10
LEDs, server	3
log files, daily	6
Log Files page	5, 6

Term	Sections
Logs page	5
machine number	8, 9, 14
master_server.py	3, 7, 12
message formats	2
NTP time sync	6
override switches	8, 10
permissions (bit 0 = machine 1)	3, 5, 9
ports 35487, 45432, 80	2
public repository, credentials, placeholders	13
reference copies (client, docs)	13
Refresh menu item	5
relays	8, 9
Renew (membership)	5
restarting the programs	7
services (systemd)	7, 13, 14
session statistics	9
static IP (derive-static-ip)	2, 13
status codes	2
sudoers (setting the clock)	6, 13
test tools	11, 13
troubleshooting	7
users.json	4, 5
web app	5
woodshop.db	4