

Error Code: 0500-0300-0001-0021

Hardware incompatible, please check the laser.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0500_0300_0001_0021



Scan for article

Error Code: 0500-0300-0002-000C

HMS_0500-0300-0002-000C: Wireless hardware error: please turn off/on WiFi or restart the device.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0500_0300_0002_000C



Scan for article

**Error Codes: 0500-0300-0002-000E,
0500-0500-0001-000E, 0500-0500-0001-000F,
0500-0500-0001-0011, 0500-0500-0001-0012,
0500-0400-0001-0046, 0500-0400-0001-0047,
0500-0400-0001-0048, 0500-0400-0001-0044,
0501-0400-0001-0044, 0502-0400-0001-0044,
0503-0400-0001-0044, 0500-0500-0001-0010,
0501-0500-0001-0010, 0502-0500-0001-0010,
0503-0500-0001-0010, 0580-0500-0001-0010,
0581-0500-0001-0010, 0582-0500-0001-0010,
0583-0500-0001-0010, 0584-0500-0001-0010,
0585-0500-0001-0010, 0586-0500-0001-0010,
0587-0500-0001-0010, 0580-0400-0001-0045,
0581-0400-0001-0045, 0582-0400-0001-0045,
0583-0400-0001-0045, 0584-0400-0001-0045,
0585-0400-0001-0045, 0586-0400-0001-0045,
0587-0400-0001-0045**

HMS_0500-0300-0002-000E: Some modules are incompatible with the printer's firmware version, which may affect use. Please go to the "Firmware" page to update after connected to the internet, or you may update offline according to wiki.

https://wiki.bambulab.com/en/h2/troubleshooting/hmscode/0500_0300_0002_000E



Scan for article

Error Code: 0500-0400-0001-0001

Failed to download print job. Please check your network connection.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0500_0400_0001_0001



Scan for article

Error Code: 0700-1000-0001-0003

HMS_0700_1000_0001_0003: The AMS slot1 motor torque control is malfunctioning.The current sensor may be faulty.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_1000_0001_0003



Scan for article

Error Code: 0700-1000-0002-0002

The AMS slot1 motor is overloaded.The filament may be tangled or stuck.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_1000_0002_0002



Scan for article

Error Codes: 0700-2000-0002-0001,
0700-2100-0002-0001, 0700-2200-0002-0001,
0700-2300-0002-0001, 0701-2000-0002-0001,
0701-2100-0002-0001, 0701-2200-0002-0001,
0701-2300-0002-0001, 0702-2000-0002-0001,
0702-2100-0002-0001, 0702-2200-0002-0001,
0702-2300-0002-0001, 0703-2000-0002-0001,
0703-2100-0002-0001, 0703-2200-0002-0001,
0703-2300-0002-0001, 0704-2000-0002-0001,
0704-2100-0002-0001, 0704-2200-0002-0001,
0704-2300-0002-0001, 0705-2000-0002-0001,
0705-2100-0002-0001, 0705-2200-0002-0001,
0705-2300-0002-0001, 0706-2000-0002-0001,
0706-2100-0002-0001, 0706-2200-0002-0001,
0706-2300-0002-0001, 0707-2000-0002-0001,
0707-2100-0002-0001, 0707-2200-0002-0001,
0707-2300-0002-0001

AMS Slot filament has run out.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_2000_0002_0001



Scan for article

Error Codes: 0700-2000-0002-0002,
0700-2100-0002-0002, 0700-2200-0002-0002,
0700-2300-0002-0002, 0701-2000-0002-0002,
0701-2100-0002-0002, 0701-2200-0002-0002,
0701-2300-0002-0002, 0702-2000-0002-0002,
0702-2100-0002-0002, 0702-2200-0002-0002,
0702-2300-0002-0002, 0703-2000-0002-0002,
0703-2100-0002-0002, 0703-2200-0002-0002,
0703-2300-0002-0002, 0704-2000-0002-0002,
0704-2100-0002-0002, 0704-2200-0002-0002,
0704-2300-0002-0002, 0705-2000-0002-0002,
0705-2100-0002-0002, 0705-2200-0002-0002,
0705-2300-0002-0002, 0706-2000-0002-0002,
0706-2100-0002-0002, 0706-2200-0002-0002,
0706-2300-0002-0002, 0707-2000-0002-0002,
0707-2100-0002-0002, 0707-2200-0002-0002,
0707-2300-0002-0002

The AMS slot is empty.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_2000_0002_0002



Scan for article

**Error Codes: 0700-2000-0002-0003,
0700-2100-0002-0003, 0700-2200-0002-0003,
0700-2300-0002-0003, 0701-2000-0002-0003,
0701-2100-0002-0003, 0701-2200-0002-0003,
0701-2300-0002-0003, 0702-2000-0002-0003,
0702-2100-0002-0003, 0702-2200-0002-0003,
0702-2300-0002-0003, 0703-2000-0002-0003,
0703-2100-0002-0003, 0703-2200-0002-0003,
0703-2300-0002-0003, 0704-2000-0002-0003,
0704-2100-0002-0003, 0704-2200-0002-0003,
0704-2300-0002-0003, 0705-2000-0002-0003,
0705-2100-0002-0003, 0705-2200-0002-0003,
0705-2300-0002-0003, 0706-2000-0002-0003,
0706-2100-0002-0003, 0706-2200-0002-0003,
0706-2300-0002-0003**



Scan for article

The AMS Slot filament may be broken in AMS.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_2000_0002_0003

**Error Codes: 0700-2000-0002-0004,
0700-2100-0002-0004, 0700-2200-0002-0004,
0700-2300-0002-0004, 0701-2000-0002-0004,
0701-2100-0002-0004, 0701-2200-0002-0004,
0701-2300-0002-0004, 0702-2000-0002-0004,
0702-2100-0002-0004, 0702-2200-0002-0004,
0702-2300-0002-0004, 0703-2000-0002-0004,
0703-2100-0002-0004, 0703-2200-0002-0004,
0703-2300-0002-0004, 0704-2000-0002-0004,
0704-2100-0002-0004, 0704-2200-0002-0004,
0704-2300-0002-0004, 0705-2000-0002-0004,
0705-2100-0002-0004, 0705-2200-0002-0004,
0705-2300-0002-0004, 0706-2000-0002-0004,
0706-2100-0002-0004, 0706-2200-0002-0004,
0706-2300-0002-0004, 0707-2000-0002-0004,
0707-2100-0002-0004, 0707-2200-0002-0004,
0707-2300-0002-0004**



Scan for article

The AMS slot filament may be broken in the toolhead.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_2000_0002_0004

**Error Codes: 0700-2000-0002-0005,
0700-2100-0002-0005, 0700-2200-0002-0005,
0700-2300-0002-0005, 0701-2000-0002-0005,
0701-2100-0002-0005, 0701-2200-0002-0005,
0701-2300-0002-0005, 0702-2000-0002-0005,
0702-2100-0002-0005, 0702-2200-0002-0005,
0702-2300-0002-0005, 0703-2000-0002-0005,
0703-2100-0002-0005, 0703-2200-0002-0005,
0703-2300-0002-0005, 0704-2000-0002-0005,
0704-2100-0002-0005, 0704-2200-0002-0005,
0704-2300-0002-0005, 0705-2000-0002-0005,
0705-2100-0002-0005, 0705-2200-0002-0005,
0705-2300-0002-0005, 0706-2000-0002-0005,
0706-2100-0002-0005, 0706-2200-0002-0005,
0706-2300-0002-0005, 0707-2000-0002-0005,
0707-2100-0002-0005, 0707-2200-0002-0005,
0707-2300-0002-0005**



Scan for article

AMS Slot filament has run out, and purging the old filament went abnormally; please check whether the filament is stuck in the tool head.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_2000_0002_0005

**Error Codes: 0700-2000-0002-0006,
0700-2100-0002-0006, 0700-2200-0002-0006,
0700-2300-0002-0006, 0701-2000-0002-0006,
0701-2100-0002-0006, 0701-2200-0002-0006,
0701-2300-0002-0006, 0702-2000-0002-0006,
0702-2100-0002-0006, 0702-2200-0002-0006,
0702-2300-0002-0006, 0703-2000-0002-0006,
0703-2100-0002-0006, 0703-2200-0002-0006,
0703-2300-0002-0006, 0704-2000-0002-0006,
0704-2100-0002-0006, 0704-2200-0002-0006,
0704-2300-0002-0006, 0705-2000-0002-0006,
0705-2100-0002-0006, 0705-2200-0002-0006,
0705-2300-0002-0006, 0706-2000-0002-0006,
0706-2100-0002-0006, 0706-2200-0002-0006,
0706-2300-0002-0006, 0707-2000-0002-0006,
0707-2100-0002-0006, 0707-2200-0002-0006,
0707-2300-0002-0006**



Scan for article

PTFE tube detached during the feeding process. Please check if the PTFE tube is connected from AMS to extruder.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_2000_0002_0006

**Error Codes: 0700-2000-0003-0001,
0700-2100-0003-0001, 0700-2200-0003-0001,
0700-2300-0003-0001, 0701-2000-0003-0001,
0701-2100-0003-0001, 0701-2200-0003-0001,
0701-2300-0003-0001, 0702-2000-0003-0001,
0702-2100-0003-0001, 0702-2200-0003-0001,
0702-2300-0003-0001, 0703-2000-0003-0001,
0703-2100-0003-0001, 0703-2200-0003-0001,
0703-2300-0003-0001**



Scan for article

AMS1 Slot1 filament has run out. Please wait while old filament is purged.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_2000_0003_0001

**Error Codes: 0700-2000-0003-0002,
0700-2100-0003-0002, 0700-2200-0003-0002,
0700-2300-0003-0002, 0701-2000-0003-0002,
0701-2100-0003-0002, 0701-2200-0003-0002,
0701-2300-0003-0002, 0702-2000-0003-0002,
0702-2100-0003-0002, 0702-2200-0003-0002,
0702-2300-0003-0002, 0703-2000-0003-0002,
0703-2100-0003-0002, 0703-2200-0003-0002,
0703-2300-0003-0002**



Scan for article

AMS1 Slot1 filament has run out and automatically switched to the slot with the same filament.

https://wiki.bambulab.com/en/x1/troubleshooting/hmscode/0700_2000_0003_0002