


MAX9926 SETTINGS


1. Differential VR sensor: Connect one lead to the input resistor going to the (+) on the MAX chip and the other lead to the input resistor going to the (-).


2. Single-mode VR sensor: Connect the single lead to the input resistor going to the (-).


3. Hall sensor: Connect the output of the sensor to the input resistor going to the (-).


3. Hall sensor: Connect the resistor going not connect content of the property of the property of the content of the property of the pro



























MAX9926 SETTINGS


1. Differential VR sensor: Connect one lead to the input resistor going to the (+) on the MAX chip and the other lead to the input resistor going to the (-).


2. Single-mode VR sensor: Connect the single lead to the input resistor going to the (-).


3. Hall sensor: Connect the output of the sensor to the input resistor going to the (-).


3. Hall sensor: Connect the resistor going not connect content of the property of the property of the content of the property of the pro











| Sheet: /Aux MCU/| Files Aux, MCUsen | THEr: | Sizes Aux MCUsen Au