

Task ID	Target Vehicle	Target Vehicle	Maintnance Interval	SOP
- TA-001	- Polaris Ranger XP (PROSTAR)	- Oil change, Fuel lines replaced	- 200 Hours/4 Months	1. Move vehicle to flat/level surface, set to park 2. Disconnect negative battery terminal before working on electrical systems 3. Allow engine to cool before any further servicing 4. Dispose of used oil and filter carefully (follow owner guidelines) 5. Park tractor on flat/level surface, lower attachments, engage parking brake, shut off engine 2. Allow engine to cool for 5 - 10 minutes (when engine temp normal) 3. Place drain pan under transmission and remove drain plug 4. Remove current hydraulic filter and clean mounting surface 5. Lightly lubricate gasket 6. Install new hydraulic filter 7. Reinstall drain plug (should be tight for no leakage) 8. Refill system with Kubota Super UDTL until it reaches full mark 9. Start/warm up engine 10. operate steering and hydraulic functions to circulate fluid 11. Shut off the engine 12. check the fluid level, (add more if needed) 13. Inspect for leaks around drain plug and filter
- TA-002	- L3901 Kubota	- Change transmission fluid, replace hydraulic filter	- 1000 Hours/12 Months	1. Park mower on flat/level surface, engage parking brake, shut off engine, and remove key 2. Allow engine to cool 3. Drain old engine oil. 4. Replace oil filter. Lubricate new filter gasket before installation. 5. Reinstall drain plug. 6. Fill with SAW 10W-30 engine oil until full 7. Star engine 8. inspect for leaks 9. shut off engine and recheck oil level. 10. Use grease gun to lubricate all Blade spindle fittings until you see a tiny bit of grease ext the fitting 11. Clean spills 12. Dispose of used oil and filter properly.
- TA-003	- Kabota zero-turn mower	- Change oil, replace filter, grease pump into blade spindles	- 250 Hours/5 Months	