AESC Quick Start Guide / AESC 快速入门指南

1. Quick Inspection / 快速检查

1.1 Check appearance: no damage, no loose parts, no short circuits.
检查产品外观：确认无破损、元器件无脱落、焊点无短路。

1.2 Use a multimeter to check power terminals, ensure no short circuit.
用万用表检查电源正负极：确认无短路。

1.3 Check 3.3V to GND and 5V to GND, ensure no short circuit.
检查 3.3V 对 GND、5V 对 GND：确认无短路。

1.4 Power on with small supply: For example, 24V with a 100mA current limit. After power-up, observe whether the blue and green LEDs light up normally.
Note: Some ESCs have a button or switch; turn it on first for the ESC to power up and LEDs to light.

使用小电源上电测试：例如 24V，限流 100mA。上电后观察蓝色 LED 和绿色 LED 是否正常亮起。
注意：部分电调带有按钮或电源开关，需先打开开关或按下按钮，电调才会通电，LED 才会亮起。

2. Connect Motor, Power, and ESC / 连接电机、电源与电调

2.1. Connect per wiring diagram, ensure secure and correct.
按照接线图连接：电机线、电源线、信号线必须连接牢固，无错误。

2.2 Double-check connections before powering on: no reverse polarity, no short circuit, no loose wires.
上电前多次检查接线：确认无接反、无短路、无松动。

3. Download VESC Tool / VESC Tool 下载教程

Download VESC Tool

All Documents / 全部文档
https://baogee.net/ConfigTutorial
YouTube Video Guide:
https://www.youtube.com/@AutoroBaogeESC
(No QR needed / 无需扫码，可直接访问)

⚠ This product runs firmware V6.05, compatible with VESC Tool V6.06 and above.

"Limited Mode" or "firmware older" prompts are normal and do not affect operation.

To disable: VESC Tool: ***Edit*** → ***Preferences*** → ***UI*** → **uncheck "*Show firmware update message*" → *OK*.**

Upgrades not recommended unless necessary. For firmware upgrade support, contact us.

autoro-ch.com

4. Motor Parameter Calibration / 电机参数校准

⚠ Important: Motor calibration is required. Otherwise the motor cannot be controlled properly.
⚠ 重点：必须完成电机参数校准，否则电机无法正常控制。

Single Motor FOC Setup (EN)

单驱 FOC 设置（中文）

Dual / Multi-Motor FOC Setup (EN)

双驱/多驱 FOC 设置（中文）

5. Control Mode Setup / 控制方式设置。

5.1 PPM Control / PPM 控制

For receivers with PPM output.
适用于遥控器接收机输出 PPM 信号。

PPM Control Setup (EN)

PPM 控制设置（中文）

5.2 ADC Control / ADC 控制

For throttle grips, pedals, potentiometers, etc.
适用于油门转把、踏板、电位器等模拟信号。

ADC Control Setup (EN)

ADC 控制设置（中文）

Manufacturer: Zhuhai Baoge Technology Co., Ltd.
Support Email: Autoro.service@hotmail.com

autotech.com