

AC Main/Backup Power Automatic Switch User Manual

Model # AB220

This module is an automatic transfer switch for two AC power sources, equipped with a main power input and a backup power input. Under normal conditions, the main power supplies the load while the backup power circuit remains disconnected. When the main power fails (no output), the module automatically switches to the backup power supply. Once the main power is restored, the module automatically switches back to the main power output. The output voltage remains the same as the input voltage. This enables unattended automatic switching of the power supply, ensuring continuous operation of connected equipment.

Specifications

- Input Voltage: AC 100V - 240V.
- Maximum Output Current: 10A

Wiring Diagram



Interface Description

- Main Power Terminal: Connect to the primary power source that is normally used.
- Backup Power Terminal: Connect to the emergency backup power source.
- Load Terminal: Connect to the load (equipment to be powered).

Automatic Switching Logic

- When main power is present, only the main power supplies the load; the backup power circuit is off.
- When main power fails, the module automatically turns on the backup power supply.
- When main power is restored, the module automatically disconnects the backup power and resumes supplying from the main power.

Precautions

- This module is only suitable for AC 100V–240V applications. Do not connect power sources outside this range.
- The load current must not exceed the module's maximum rating of 10A. Prolonged overload is prohibited.
- Before any wiring or maintenance, be sure to disconnect both input power sources to avoid electric shock.
- Ensure all terminal connections are secure to prevent overheating, poor contact, or other issues caused by loose wiring.
- Do not disassemble or modify the module yourself, as this may cause equipment damage or safety hazards.

Applications

Suitable for small electrical equipment that requires uninterrupted power supply, such as surveillance equipment, small industrial control devices, low-voltage equipment, emergency lighting, and small instruments.

Contact & Support

Zhuhai Baoge Technology Co., Ltd.

Address:

509, 5th Floor, Zone D, Shucai WuliuArea, No. 77 Huawei Road, XiangzhouDistrict, Zhuhai City-519070,Guangdong, China

Email:

For cooperation, contact: Autoro.sales@hotmail.com

For technical support, contact: Autoro.service@hotmail.com

Mobile/WhatsApp: [+86 13823023406](tel:+8613823023406)

Website: <https://www.autorotech.com>

