

CONFIGURE EXTENDED NMEA MESSAGE INTERVAL – Configure extended NMEA message Interval of GNSS receiver (ID: 0x64, SID: 0x2)

This is a request message which will set NMEA message interval configuration. This command is issued from the host to GNSS receiver and GNSS receiver should respond with an ACK or NACK. The payload length is 15 bytes.

Structure:

<0xA0,0xA1>< PL><64><02>< message body><CS><0x0D,0x0A>

Example:

A0 A1 00 0F 64 02 01 01 03 01 01 01 01 00 00 00 00 01 64 0D 0A
 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

Field	Name	Example(hex)	Description	Type	Unit
1	Message ID	64		UINT8	
2	Message Sub-ID	02		UINT8	
3	GGA Interval	01	0 ~255, 0: disable	UINT8	second
4	GSA Interval	01	0 ~255, 0: disable	UINT8	second
5	GSV Interval	03	0 ~255, 0: disable	UINT8	second
6	GLL Interval	01	0 ~255, 0: disable	UINT8	second
7	RMC Interval	01	0 ~255, 0: disable	UINT8	second
8	VTG Interval	01	0 ~255, 0: disable	UINT8	second
8	ZDA Interval	01	0 ~255, 0: disable	UINT8	second
10	GNS Interval	00	0 ~255, 0: disable	UINT8	second
11	GBS Interval	00	0 ~255, 0: disable	UINT8	second
12	GRS Interval	00	0 ~255, 0: disable	UINT8	second
13	DTM Interval	00	0 ~255, 0: disable	UINT8	second
14	GST Interval	00	0 ~255, 0: disable	UINT8	second
15	Attributes	01	0: update to SRAM 1: update to both SRAM & FLASH	UINT8	
Payload Length : 15 bytes					