

Parts of LG Front Load Washer

- Door: Loading and unloading clothes.
- Detergent Drawer: Add detergent/softener.
- Control Panel: Buttons, cycle selector.
- Drain Pump Filter: Bottom front, behind flap.
- Inlet Hose: At the back, connects to tap.
- Drum: Stainless steel inner tub.
- Child Lock: Hold Temp + Rinse buttons for 3 sec.