

LG Washing Machine – Maintenance Tips & Quick Fixes
(Prototype content for your "Companion AI" knowledge base)
Sources: LG Owner's Manual (uploaded), LG Error Codes guide (uploaded).
Citations in this document refer to your uploaded files.

SAFETY FIRST

- Always unplug the appliance before cleaning or performing maintenance.
穀filecite學turn1file6係
- Never use harsh chemicals or abrasive cleaners on the cabinet or seals.
穀filecite學turn1file6係
- Keep children away while performing maintenance and when the door is open.
穀filecite學turn1file6係

QUICK CHECKLIST (what the user can do right away)

Daily / After every wash

1. Remove all clothing from drum immediately after the cycle finishes.
穀filecite學turn1file3係
2. Wipe the door glass and rubber door seal to remove moisture and trapped lint.
穀filecite學turn1file3係
3. Leave the door slightly open for ventilation so the drum can dry.
穀filecite學turn1file3係
4. Wipe exterior surfaces with a dry cloth to remove water or detergent drips.
穀filecite學turn1file3係

Weekly

- Inspect the detergent dispenser drawer and remove any visible residue. Rinse the drawer and inserts under warm water if needed. Let them dry before reinserting. (Do this 1-2x per month or more if residue appears.)
穀filecite學turn1file1係

Monthly

- Run the "Tub Clean" / "Drum Clean" program once a month to remove residue and odour:
 - 1) Remove clothing.
 - 2) Open dispenser and add anti-limescale powder to the main wash compartment (or place a tablet directly into the drum).
 - 3) Close the drawer. Turn the machine on, press Delay End + Pre Wash together for 3 seconds, then Start/Pause to run the Tub Clean cycle.
 - 4) Leave the door open afterwards to fully air-dry the drum.穀filecite學turn1file13係

Every 6 Months

- Clean the water inlet filter:
 - 1) Turn off the water tap and unplug the machine.
 - 2) Unscrew the inlet hose from the back of the appliance.
 - 3) Remove the inlet filter from the hose/valve using small pliers and clean with a medium-bristle brush.
 - 4) Reinstall hose securely. 穀filecite學turn1file0係
- Clean the drain pump filter and perform emergency water evacuation (recommended every 6 months or if draining is slow):
 - 1) Unplug the appliance.
 - 2) Open the cover cap and pull out the small drain tube.
 - 3) Remove the drain plug and drain water into a bucket. Slowly unscrew the drain pump filter and remove debris.
 - 4) Reinsert and screw back the filter and plug. Close cover cap.穀filecite學turn1file0係
- Clean the detergent dispenser drawer fully (remove, rinse, clean recess).
穀filecite學turn1file1係

Annually / Every 5 Years

- Inspect inlet and drain hoses for cracks or stiffness and replace if damaged. The manual recommends replacing fill hoses after about 5 years.
穀filecite學turn1file17係
- Check and re-level the appliance if it's vibrating or noisy; secure levelling

feet and lock nuts. Use anti-slip sheets on slippery floors.

穀filecite學turn1file8像

COMMON ERROR CODES (quick fixes)

- OE / DE (Water outlet / Draining error): Check for kinked drain hose, ensure drain hose is not higher than recommended, or clean the drain filter.

穀filecite學turn1file2像

- UE (Unbalance): Redistribute load, add a similar-sized item to balance, then restart. 穀filecite學turn1file2像

- 1E / IE (Inlet error): Ensure taps are open, hose is not kinked, and inlet filter is clean. 穀filecite學turn1file0學turn0file0像

- FE (Overflow): Turn off the water tap, unplug and call service.

穀filecite學turn1file2像

- dE / Door errors and tE / heating errors: Generally call service if they persist. 穀filecite學turn0file0學turn1file2像

TOOLS & PARTS TO KEEP AT HOME (small kit)

- Medium-bristle brush (toothbrush), small pliers, bucket or bowl, thin cloths, torch/phone light.

- Replacement inlet hose, spare drain hose clamps, small screwdriver set, rubber gloves.

- Anti-limescale powder/tablets for Tub Clean. 穀filecite學turn1file13像

DETAILED STEP-BY-STEP REFERENCE (copy-friendly)

A) How to clean the drain pump filter (exactly as manual suggests)

1. Unplug the appliance. (Safety). 穀filecite學turn1file0像

2. Open the cover cap and pull out the drain tube.

3. Remove the drain plug first and drain water into a bucket.

4. Slowly unscrew the drain pump filter to drain remaining water, then remove any debris (threads, coins, buttons).

5. Clean the filter and the recess, then carefully reinsert and screw the filter back in clockwise to avoid cross-threading.

6. Reinsert the plug into the drain tube, replace the tube into its holder and close the cover cap. 穀filecite學turn1file0像

B) How to clean the inlet water filter

1. Turn off the water taps and unplug the machine.

2. Unscrew the inlet hose at the machine inlet.

3. Remove the small inlet filter and clean it with a medium bristle brush.

Reassemble. 穀filecite學turn1file0像

C) How to run Tub/Drum Clean

1. Remove clothes and close the door.

2. Add anti-limescale powder to main wash compartment (or a tablet in drum).

3. Turn on power, press Delay End + Pre Wash together for 3 seconds to select Tub Clean, then start.

4. Leave door open to dry after cycle. 穀filecite學turn1file13像

BEST PRACTICES (to prevent faults & smells)

- Do not overload the drum. Mix large and small items to help balance the load.

穀filecite學turn1file18像

- Use the correct detergent amount – too much causes oversudsing and poor rinse.

穀filecite學turn1file22像

- Remove foreign objects from pockets to prevent damage/noise.

穀filecite學turn1file18像

- Wipe and dry the door seal regularly to avoid mildew. Run Tub Clean more often if you detect smells. 穀filecite學turn1file13像

- If the machine sits unused for long periods, turn off water taps to relieve hose/valve pressure. 穀filecite學turn1file13像

WHEN TO CALL SERVICE (from manual)

- Persistent electronic/control errors (tE, PE, FE), motor locked, water leakage, or if you find evidence of internal damage – contact authorised LG service. 穀filecite學turn0file0學turn1file2像

END OF DOCUMENT