area counter 1.1.1 — quick guide

SketchUp 2024 / 2025 / 2026 extension: floor, building and complex areas by top face or by section, a table via the clipboard

1 Install

SketchUp → **Window** → **Extension Manager** → **Install Extension** → pick `area-counter-1.1.1-eng.rbz` → restart SketchUp. A “Calculate area” button appears on the “area counter” toolbar, plus the **Extensions** → **area counter** menu. Remove any earlier version before installing.

2 Calculate

1. Select a building, a complex or the floors themselves — groups or components.
2. Toolbar button or **Extensions** → **area counter** → **Calculate area** — the results window opens.
3. On the right, **What is selected**: *Floors* — the floors themselves, *Building* — floors one level down, *Complex* — two levels down. Each floor counts as a whole, with everything nested in it.
4. **Method**: *Top face* — fast, by the horizontal faces at the top elevation; *Section* — a horizontal cut through the floor, area by the **outer contour** including facade relief and windows. **Height above floor bottom** — where to cut, 1000 mm by default.

The section closes gaps between facade pieces up to 20 mm, skips hidden objects and does not subtract inner courtyards. If the cut lands on a slab it moves 2 mm up; if a doorway breaks the facade ring, the plugin picks another height and writes it in the status. Hover over a setting for a hint.

3 Table and statuses

A complex → building → floor tree with areas in m². After a calculation it is collapsed to the top level: the ▸ chevron on a row expands it, the ▸ chevron in the **Object** header expands the whole tree at once. Click a name to zoom to the object. calculated — can be trusted; caveat — calculated, but the height moved or separate pieces were found; problem — cannot be trusted, the reason is in the pill. problems only leaves the red ones, Highlight outlines the results in the viewport (Esc to turn off).

4 Copy to a spreadsheet

On the right, **Copy**: *Floors* (for checking), *Buildings* or *Complexes*. The Copy button puts the table on the clipboard — press Ctrl+V in Google Sheets / Excel: columns land by themselves, numbers use a decimal point, upper-level areas are in the same rows.

Note. Separate section pieces (over 0.1 m²) are not included in the floor area — the status mentions them. Window settings are remembered; Reset restores the defaults. Version and authors — **Extensions** → **area counter** → **About...**

Authors: Ruslan Tkachenko and Maksar Sanjeev · Apache 2.0 · B&A community

github.com/B-A-community/area-counter