



area counter 1.0 — quick guide

SketchUp 2024 / 2025 / 2026 extension: floor, building and complex areas by top face or by section, a table via the clipboard, section faces in the model

1 Install

SketchUp → **Window** → **Extension Manager** → **Install Extension** → pick `area-counter-1.0-eng.rbz` → restart SketchUp. A “Calculate area” button appears on the “area counter” toolbar, plus the **Extensions** → **area counter** menu. Remove any earlier test build before installing.

2 Calculate

1. Select a building, a complex or the floors themselves — groups or components.
2. Toolbar button or **Extensions** → **area counter** → **Calculate area** — the results window opens.
3. On the right, **What is selected**: *Floors* — the floors themselves, *Building* — floors one level down, *Complex* — two levels down. Each floor counts as a whole, with everything nested in it.
4. **Method**: *Top face* — fast, by the horizontal faces at the top elevation; *Section* — a horizontal cut at a height above the floor bottom (1000 mm by default), area by the **outer contour** including facade relief and windows.

Section settings: **gaps** up to 20 mm between facade pieces are closed, **point weld** 1 mm, hidden objects are skipped, inner courtyards are **not subtracted** by default (“subtract courtyards” box). If the cut lands on a slab it moves 2 mm up; if a doorway breaks the facade ring, the plugin picks another height and writes it in the status.

3 Table and statuses

A complex → building → floor tree with areas in m². Click a row to zoom to the object. **calculated** — can be trusted; **caveat** — calculated, but the height moved or separate pieces were found; **problem** — cannot be trusted, the reason is in the pill.

problems only leaves the red ones, **Highlight** outlines the results in the viewport (**Esc** to turn off).

4 Copy to a spreadsheet

On the right, **Copy**: *Floors* (for checking), *Buildings* or *Complexes*. The **Copy** button puts the table on the clipboard — press **Ctrl+V** in Google Sheets / Excel: columns land by themselves, numbers use a decimal point, upper-level areas are in the same rows.

5 Output sections

After calculating with the “Section” method, **Output sections** puts a group “**area counter: sections**” on the **AC_Sections** tag into the model, with the same hierarchy. Each floor group holds one flat face along the outer contour at the cut height: click it and **Entity Info** shows the area. Running again replaces the floor’s previous section. Source floors are not changed; undo — **Ctrl+Z**.

6 A single floor

Select one floor group → **Extensions** → **area counter** → **Floor section...** → set the cut height, gaps and courtyards → OK. The plugin builds the face and shows the area in the window.

Note. Separate section pieces (over 0.1 m²) are not included in the floor area — the status mentions them. Window settings are remembered; **Reset** restores the defaults. Version and authors — **Extensions** → **area counter** → **About...**