LV: Yellow High Voltage Precharge Relay (Contable Resistor Circuit Indicator DC-DC Discharge Accumulator Indicators Converters Circuit Charging **TSMPs** Energy Meter HV Control HV_Fuse Positive AIR (Contact) Relay (Contact) 225A HV_CTL_P0 NCP785AH120T1GOSCT-ND RES '\\\\' 270 VSK-S5-12UA Accumulator Current Sensor Isolation Batteries Relays NCP785AH120T1GOSCT-ND PTSA 4 Pos 55588 - 424 PTSA PTSA_2 Pos × 2 2 Energy Meter VSK-S5-12UA C(N) +Vo 3 C(L) -Vo 4 HV Disconnect Negative AIR (Contact) 1997 Low Voltage HV - Control AMS Coils Indicators 1N4007 PTSA 2 Pos 1N4007 FUSE PTSA 6 Pos Negative AIR (Coil) SWITCHDPDT Positive AIR (Coil)

HV: Orange