

The autojoin function on the device is available for 1 hour after initial power up. In order to reactivate the 1 hour autojoin function the device requires a power cycle. Alternatively a manual join can be attempted using the following process:

SDODAuthServlet?path=45588061&ACTION=FILE

Press A	All segment display check		Press A	View power log?	Power Log? A = No B = Yes
Press A	This offers the installer a chance to unlock PIN protected items. This is not necessary for commissioning. This will only be offered if a PIN has previously been set.	Enter PIN? A = No B = Yes	Press A	Manage ALCS	ALCS? A = No B = Yes
Press A	Credit mode status display	Credit Mode Bal  £ 0.00	Press A	Manage HAN	HAN? A = No B = Yes
Hold B	Customer Menu -> Manage PIN dialogue	Manage PIN? A = No B = Yes	Press B	Re-join (Join) HAN?	Rejoin HAN? A = No B = Yes
Press A	View event Log?	Events Log? A = No B = Yes	Press B	'HAN Joining' message	HAN Joining...