

L&G 4T ESME – “IST” Display During Power-On or Commissioning

If, during power-on or commissioning of an **L&G 4T ESME**, the meter display shows **“IST”**, this indicates the **Initial Self Test** mode.

This screen is **not an error** and **does not require any engineer intervention** unless they specifically wish to complete the self-tests. It is a standard manufacturer option designed for diagnostic purposes.

- **Action:** The “IST” prompt can be safely ignored.
- **Purpose:** The meter will proceed normally once bypassed, and this does not impact functionality, safety, or commissioning results.

If the engineer wishes to progress the meter to display the **initial meter readings** instead:

1. **Press the “A” button repeatedly** to cycle through the display screens.
2. When prompted, **press the “B” button** to confirm and exit the self-test sequence.

The meter will then continue through its normal startup and display the initial readings ready for commissioning.