MICROCONTROLLER MEMORY MAPS

w/o bootloader   w/ bootloader

RESET VECTOR
INTERRUPT VECTORS
USER PROGRAM

FIRMWARE BOOTLOADER	0x8000
RESET VECTOR INTERRUPT VECTORS USER PROGRAM	...
	0x1FFFF