Android / Google TV — Use Remote Help

Start a staff-requested screen share, approve TV permissions, communicate and end remote help safely.

1. Prepare and enter the TV code

01 Prepare the correct TV

Switch on the TV and open BM Remote Helper. Leave it open so the current six-digit code is visible. If remote control is needed, complete the installation/setup guide first. The Amazon phone Enabler is not required on Android/Google TV.

02 Open your existing help conversation

On your phone or computer, sign in to BM Support. For a ticket, open Tickets and select your own ticket. For a sale, open your own order and its secure checkout; enter that order’s password if asked. Return to the original conversation, not the staff TV Remote page.

03 Wait for staff to invite you

Ask the staff member in that conversation to request a screen share. The request must belong to this ticket or order. An invitation/code-entry action appears in the conversation. If it is missing, ask staff to send the request; do not use a standalone TV-helper page.

04 Enter the TV code

Open the screen-share invitation. In the pop-up, enter all six digits exactly as shown in BM Remote Helper, including any leading zero, then press Connect TV. Use the code from the TV you actually want help with. If the code is rejected, reopen the helper to check the current code and try again.

Android / Google TV — Using remote help

2. Approve sharing and work with staff

05 Wait for the staff member to answer

Keep BM Remote Helper open on the TV while staff answers the request. Code entry links the TV to this help request; it does not replace the TV’s permission prompts. Do not start another request while this one is connecting.

06 Approve the connection on the TV

When BM Remote Helper asks to allow the staff connection, check the request and choose Allow. If the TV asks to start recording or casting, choose Start now or Start. Android wording varies. Decline if you did not request help. Staff cannot see your screen until the required sharing approval is given.

07 Check the Screen share tab

Once connected, your ticket/order switches to Screen share. Ask staff in the same conversation to confirm that they can see your TV picture. Keep the TV awake and the helper running. The ticket’s original conversation remains available; its chat pop-out can be used while the share is open.

08 Let staff help you

If remote control was enabled during setup, staff can operate the TV during the session. Without that permission, staff may only see the screen and talk you through actions. Follow their guidance using your normal remote when needed. Tell them before opening private information.

Android / Google TV — Using remote help

3. End safely and reconnect

09 Finish the session

Use End session on the customer Screen share view when help is finished; staff can also end the session. Check that the sharing/connected indicator clears. If the page is unavailable or the indicator does not clear, stop sharing in BM Remote Helper on the TV or close the helper to stop the picture.

10 Start a later session

A new session needs a new staff invitation through your ticket/order and the current TV code, followed by the TV’s permission prompts. An old code or invitation must not be treated as permission for ongoing access.

11 If there is no picture

Keep the helper open and the TV awake; confirm you approved both Allow and the recording/casting prompt. Ask staff whether they have joined this exact ticket/order. If the picture remains black, end the session on both sides, reopen the helper, and repeat with a fresh invitation/code. Do not reinstall or reset the TV before speaking to staff.

12 If control or code entry fails

No code box: ask staff to send/re-send the screen-share invitation in this conversation. Rejected code: verify all six digits and the correct TV. Picture but no control: check Settings > Accessibility and confirm BM Remote Control is enabled. Lost internet: reconnect and ask staff for a new session. Ordinary TV restarts do not normally require reinstalling the apps.

Only share with BM Support staff through your own support ticket or secure order. Do not post your TV code publicly. Anything visible on the TV may be seen by staff: close banking, payment, password and other private screens first. You can decline a request or end a session.