Windows PC — Use Screen-share Support

Using remote help · Windows PC · Amazon Fire TV / Android / Google TV

Install Windows Enabler and log in

1. Check what you need

Use a Windows 10 or 11, 64-bit PC and an Amazon Fire TV/Stick or Android/Google TV. The PC and TV must be on the same home network, not isolated guest Wi-Fi. Keep both awake; disconnect a VPN if it prevents local connections. BM TV Enabler runs on the PC, not on the TV, iPhone or iPad.

2. Download from BM Support

Sign in at bmsupport.uk, open Install Guides > Set up a device and choose your TV type. In the Windows PC card, download BM TV Enabler. The same Windows download is also shown in ticket Remote setup. Use the official download button for the latest installer.

3. Install and open

Open the downloaded BM-TV-Enabler-Setup installer and follow its installation prompts. The Windows installer is unsigned, so Windows may show a publisher warning. Check that it came from BM Support. If your PC blocks it or you are unsure, ask staff; do not disable antivirus or security protection.

4. Enter your account PIN

Open Settings > BM TV Enabler PIN on the website, or reveal the PIN in ticket Remote setup. Enter the six-digit PIN in BM TV Enabler, press Log in, then Get started. The app asks for the PIN on every launch; use the current PIN, which changes after 24 hours. This login PIN is not the later Enabler reference or a TV pairing code. If no current PIN exists, press Get BM TV Enabler PIN; if a PIN is already allocated, press Reveal PIN and use it.

Connect through the Enabler

5. Open your support ticket

Sign in to BM Support and open your own ticket > Remote setup. For remote installation help with a paid order, use its help button to raise a ticket during office hours; continue through that ticket. Do not go to the staff TV Remote page or send staff your login PIN.

6. Choose Screen-share support

After Get started select Screen-share support and your TV type. The next page enables debugging and connects to your TV; then the Enabler installs/checks Helper and remote control.

Prepare debugging and select the TV

7. Choose your TV type

Select Amazon Fire TV / Stick or Android / Google TV. Follow only the instructions for the TV you are using. The website cannot discover or connect to your home TV itself: BM TV Enabler does this from your PC.

8. Amazon Fire TV / Stick

On the TV open Settings > My Fire TV > About. Highlight the device name and press Select seven times to reveal Developer options. Go Back to My Fire TV > Developer options and turn ADB debugging ON. If Developer options already exists, use it directly. Leave the TV awake.

9. Android / Google TV

On the TV open Settings > System > About (some TVs use Device Preferences > About). Highlight Android TV OS build and press Select seven times. Return to System > Developer options and enable Network debugging, or Wireless debugging where offered. Menu names vary by TV. Do not expose debugging ports to the internet.

10. Pair Wireless debugging where required

On Android/Google TV select Wireless debugging > Pair device with pairing code. In Windows expand Android / Google TV with Wireless debugging: pair with code. Enter the TV’s six-digit pairing code and pairing port. In TV address enter the main Wireless debugging screen’s IP address and connection port; these ports can differ. Press Pair with code and set up my TV. After successful pairing setup continues. Network debugging TVs do not need this extra pairing step.

11. Find and connect

Press I’ve switched debugging on — next. Choose Find my Fire TV or Find my Android TV, select the correct named TV and check its address. If it is missing, enter the address from the TV’s network settings. Press Connect to this TV. On the TV, press Allow for debugging and tick Always allow from this computer if offered. Keep the Enabler open.

12. Keep the Helper open

Leave BM TV Enabler open on the PC. When BM Remote Helper opens on the TV, keep it in front for permission prompts. Do not press Home or close the Helper while waiting to approve sharing. If the TV asks to allow the connection or start recording/casting, approve only the help you requested.

13. Get the sharing reference

Wait for the Enabler’s successful TV check and sharing reference; press Get my confirmation code if one is not displayed. Use that reference, not the login PIN, a Wireless debugging pairing code or the Helper’s six-digit TV code. The Enabler transfers the Helper connection details automatically; you do not type the TV’s Helper code into the website. Watch the TV: if Helper asks for Start sharing or recording/casting approval, use the TV remote to approve the help you requested. The Enabler cannot approve sharing consent for you. The reference has six letters/numbers displayed in two groups of three, separated by a hyphen; it is not a six-digit PIN.

Link the reference, share and finish

14. Enter the Enabler reference

Type the sharing reference shown by BM TV Enabler into your own ticket’s Remote setup reference box and confirm it. Each reference belongs to one ticket/order while valid. If another ticket/order already used it, get New code in the Enabler. If your PC shows a different reference from the website, use Change reference number and enter the current one. Enter the six-character reference in Type the code from BM TV Enabler, then press Confirm.

15. Connect and approve

If the website first needs a fresh TV connection, keep BM TV Enabler open on the same network and press Send to BM TV Enabler or Ask my TV again. When it says Waiting for you to press Allow on your TV, approve the requested TV prompt and wait for the page to advance. When Connect my screen appears, press it. Watch Helper on the TV and approve any requested Allow, Start sharing and system recording/casting prompt using the TV remote. Enabler does not accept these for you. A reference or green readiness tick is not sharing consent; do not repeatedly press Connect while waiting.

16. Work with staff

Your ticket’s Screen share opens when connected. Ask staff to confirm they can see the TV. Keep the PC Enabler open, the TV awake and the Helper running while the connection is being established. Use the ticket conversation to speak with staff. Tell staff before opening private screens; enabled remote control allows them to operate the TV during the session.

17. End and request a fresh reference

End the session from the sharing controls or ask staff to end it. Once the linked screen share ends, its sharing reference expires and the website setup clears. The Enabler clears the expired reference when it receives the server update; press New code and complete a fresh TV check before sharing again. Closure of the ticket/order also expires it; otherwise its maximum lifetime is 24 hours. Install reference and login PIN are unaffected.

Reconnect and solve problems

18. Reopen or switch sections

Every app launch requires the current account PIN. After login, valid saved references can be resumed without extending expiry. Return to home switches between Install our apps and Screen-share support while retaining TV details and each section’s valid reference. A network error alone does not erase a reference.

19. Restart website setup

Restart setup clears the ticket’s setup and releases its still-valid reference so you can type the reference the Enabler currently shows again. It does not make an expired sharing reference valid. After a share ends, ask for New code in the Enabler. Reset setup inside the app is a separate confirmed action which clears local TV details and both references; the next code takes over.

20. No picture or no permission box

Keep BM Remote Helper in front on the TV and approve the requested prompts. Check the PC and TV still share the same network. Ask staff to confirm they joined this ticket. If no picture appears, tell staff before ending and retrying with a fresh reference. Do not factory-reset or reinstall the TV as your first troubleshooting step.

21. Pairing or control problems

Android Wireless debugging may require the TV’s separate pairing code and pairing port as well as its main connection address/port. If control is unavailable or Accessibility remains blocked, report the Enabler’s error to staff rather than disabling TV security. Follow the TV prompts the app provides; installation alone does not grant permanent staff access.

Privacy and safety
Only share with BM Support staff through your own support ticket. Close banking, payment, password and other private screens on the TV first. You can decline a request or end a session. Never publish your PIN or reference.