

OPERATION & MAINTENANCE MANUAL

Enviro-Pak Filter Assembly

Models EPFA-24 through EPFA-144

Model No.	EPFA-_____
Serial No.	_____
Ship Date	_____

⚠ READ BEFORE INSTALLING OR SERVICING

Installation must be performed by a qualified professional who has read and understands these instructions. This document belongs to the equipment owner and is required for future maintenance — leave it with the owner when installation or service is complete.



EPFA UNIT — TYPICAL INSTALLATION VIEW WITH FIRE
SUPPRESSION CONNECTION, MONITOR PANEL, ACCESS DOORS

DOCUMENT EPFA-OM-2026 • REV. A • SUPERSEDES 10-2019

Contents

1	System Overview	3
2	Mechanical Installation	4
3	Electrical & Monitoring	5
4	Fire Suppression	6
5	Start-Up & Switch Adjustment	7
6	Operation	8
7	Maintenance & Filter Replacement	9
8	Warranty	10
9	Owner's Acknowledgement	11
10	Contractor's Check-Off List	12

Safety

- ⚠ Installation and service by qualified professionals only.
- ⚠ Install in accordance with all federal, state, and local codes. The installing contractor is responsible for local code compliance.
- ⚠ The owner is responsible for maintaining and servicing this equipment. Improper maintenance voids the warranty and defeats the purpose of the equipment.

Receiving & Inspection

On delivery, inspect the unit inside and out for damage and report any damage to the carrier immediately. Verify all accessory items (status panel, hardware) are present and undamaged.

1. System Overview

The UL Listed Enviro-Pak Filter Assembly (EPFA) is a fully welded 18 Ga Type 304 stainless steel housing with channels holding pre-filters and high-efficiency filters that remove particulate and grease vapor from kitchen exhaust air. Removable doors access all filters and fire-suppression components.



LABELED SIDE VIEW — AIR INLET · F1 PRE-FILTERS (ORANGE) ·
F2/F3 HIGH-EFFICIENCY (GREEN) · ACCESS DOORS · CONTROLS
ENCLOSURE · AIR OUTLET

- Air inlet (from kitchen hood)
- Row F1: **MERV 9 pre-filters (ORANGE)**
- Rows F2/F3: **MERV 14 high-efficiency filters (GREEN)**; F3 optionally carbon
- Removable access doors
- Controls enclosure (outlet end): 2 pressure switches, Mini-Helic gauge, terminal block, 115 VAC junction box, 115/24 VAC transformer
- Air outlet (to exhaust fan)

REMOTE COMPONENT — SYSTEM STATUS PANEL

Wall-mounted stainless enclosure, 12" W × 8" H × 2 $\frac{5}{8}$ " D, with green and red indicator lights. Mount indoors where staff see it daily (kitchen or office).

2. Mechanical Installation

Location & direction. Install in the grease duct between the kitchen exhaust hood and the exhaust fan, welded to the duct at both ends. The location must be accessible. Airflow direction is mandatory: inlet end faces the kitchen, outlet end faces the fan.

Exhaust fan. UL Listed for kitchen exhaust, backward-inclined utility type with easily adjustable RPM, sized for [CONFIRM: 2.5" WG SP per manual / 1.54" WG initial per drawing] plus hood and duct static losses.

Support. Two 4"-high full-width stainless channels are welded to the unit bottom. Roof installations: code-approved curb by installing contractor. Suspended installations: use the ½"-13 corner hanger points with spring hangers and threaded rods (by others). Above-ceiling installations require a permanent service platform (by others) level with the unit bottom — the unit is serviced every four weeks.

Clearances

SIDE	MINIMUM
Service access side	30" free space
Other sides, to combustibles / building insulation	18"
Other sides, to non-combustibles	0"

Drains. Connect the three 1½" cleaning drains to a common drain routed to the grease interceptor (by others).

3. Electrical & Monitoring Installation

1. Bring a 115 VAC supply (by others) to the junction box on the controls enclosure. This powers the 115/24 VAC transformer.
2. Run low-voltage wiring (black, white, red — 3-wire 18 Ga plenum cable, by others) from the terminal block below the air gauge to the wall-mounted System Status Panel.
3. Mount the Status Panel indoors, visible to staff daily.



WIRING DIAGRAM — REDRAW FROM ORIGINAL MANUAL:
TRANSFORMER, TERMINAL BLOCK, BOTH PRESSURE SWITCHES,
PANEL LIGHTS



CONTROLS ENCLOSURE WITH COVER REMOVED — PRESSURE
SWITCHES, MINI-HELIC GAUGE, TERMINAL BLOCK

4. Fire Suppression Connection

Option A — Building Sprinkler (Water)

Connect the EPFA's ¾" water pipe connection to the building sprinkler system (by others).

Option B — Ansul (In Lieu of Water)

Where local code requires, the EPFA is factory pre-piped with Ansul nozzles. The on-site Ansul installer is responsible for final hook-up, permits, drawing submittals, and final testing, and provides tanks, agent, piping from tanks to the pre-piped nozzles, regulated actuators, and cartridges. Detectors are mechanical fusible-link, not electric.



FIRE SUPPRESSION CONNECTION POINTS — SPRINKLER COUPLING
LOCATION / ANSUL PRE-PIPED NOZZLE LAYOUT

5. Start-Up & Static Pressure Switch Adjustment

⚠ BEFORE START-UP

Complete the Contractor's Check-Off List (page 12) BEFORE the factory representative performs start-up.



STATIC PRESSURE SWITCH ADJUSTMENT PROCEDURE — CARRY OVER FROM ORIGINAL MANUAL PAGE 6: ADJUSTING THE HIGH STATIC PRESSURE SWITCH (RANGE 2–5" WG) AFTER SYSTEM START-UP, WITH MINI-HELIC GAUGE REFERENCE READINGS FOR CLEAN FILTERS

Normal Indications After Start-Up

Green light on with fan running; red light off.

Gauge reading, clean filters (record for future reference)	_____ " WG
Date recorded	_____
Recorded by	_____

6. Operation — Reading the Status Panel



GREEN — steady

Exhaust system is on. Normal operation. Nothing to do.



RED — flashing

Static pressure has exceeded the high-limit setting: airflow is dropping because filters are grease-laden. **Service is required now.** Inspect all filters and replace any that are loaded (Section 7). A flashing red light ignored is smoke out the stack and a code complaint waiting to happen.

DAILY HABIT

Check the panel daily. It is the system's only voice.

7. Maintenance & Filter Replacement

Schedule. Inspect filters every four weeks. Replace as often as loading requires. Steam-clean the housing interior to remove grease buildup during filter service.

Use matching filters. Replacements must match the original manufacturer and specification. Molitron accepts no responsibility for escape of visible contaminants if substitute filters are used or filters are installed incorrectly. Reorder: molitron.com · cleanair@molitron.com · 303-969-8888

Replacement Procedure

1. Shut down the exhaust fan. Open the access doors.
2. Remove grease-laden filters. Note the row order:
Row 1 (inlet): ORANGE MERV 9 multi-pocket pre-filters on rigid support grid
Rows 2 & 3: GREEN MERV 14 multi-pocket filters (Row 3 optionally carbon)
3. Apply a ¼" closed-cell neoprene gasket to ONE side of each new filter before installation.
4. Push each filter INDIVIDUALLY into the upper and lower channels, fully toward the wall opposite the access doors — this prevents overlapped filters and bypass gaps.
5. Add additional neoprene gasket to the final filter's vertical side as needed so the row fits TIGHTLY when the door closes.

⚠ TIGHT FIT IS EVERYTHING

Gaps around filters leak visible contaminants and defeat the entire assembly.

6. Seat access doors firmly against their gaskets and close.
7. Restart the fan; confirm green light and record the clean-filter gauge reading.

8. Warranty

PLAIN-LANGUAGE SUMMARY (FULL TERMS BELOW GOVERN)

12 months from ship date, parts only, covering the EPFA, static pressure enclosure, and system monitor. Labor, freight damage, and contractor-caused damage are not covered. No returns. The warranty is void if the unit is improperly installed, installed against code, misused, neglected, operated beyond published capacity, or if the invoice is unpaid.

Product Warranty — Full Terms

The EPFA and component parts are warranted to be free from defects in material and workmanship for a period of twelve (12) months from date of shipment. Component parts are: the static pressure enclosure and the system monitor.

This warranty does not cover parts damaged by freight carrier from factory to ultimate destination or parts damaged by the installing contractor.

This warranty shall not apply if: the EPFA is not installed by a qualified installer per the factory's installation instructions shipped with the product; the EPFA is not installed in accordance with federal, state, and local codes and regulations; the EPFA is misused or neglected; the EPFA is not operated within its published capacity; or the invoice is not paid within the terms of the sales agreement.

The factory shall not be liable for incidental and consequential losses and damages potentially attributable to malfunctioning equipment. Should any part of the equipment prove to be defective in material or workmanship within the 12-month warranty period, upon examination by the factory, such part will be repaired or replaced by the factory at no charge for parts only. All labor costs incurred in connection with such repair or replacement are not included under the warranty period. The factory does not accept returns of Molitron products.

This warranty will be activated once the Owner's Acknowledgement is signed and returned to the factory.

⚠ ACTIVATE YOUR WARRANTY

Sign and return the Owner's Acknowledgement (next page) to the factory. Unsigned = inactive.

9. Owner's Acknowledgement

Regarding required maintenance

I have read the required maintenance instructions for the Molitron Enviro-Pak Filter Assembly and accept full responsibility for maintaining the equipment in accordance with these instructions, with the full knowledge that if this equipment is not adequately and properly maintained, it will not satisfactorily perform its intended purpose and will void this warranty.

Owner's signature: _____

Printed name: _____

Establishment: _____

Address: _____

City & state: _____

Telephone: _____ Email: _____

Ship date: _____

Model number: EPFA- _____ Serial number: _____

RETURN TO FACTORY

Scan and email this signed page to cleanair@molitron.com — or mail to Molitron Co Inc, Arvada, Colorado.

10. Installing Contractor's Check-Off List

Complete before factory-representative start-up

- ☐ Installed accessibly, correct direction: inlet from kitchen, outlet to exhaust fan
- ☐ 30" free space on service access side
- ☐ 18" clearance to combustibles/insulation (0" to non-combustibles) on all other sides
- ☐ Fire protection connected: ¾" water to building sprinkler system — OR — all Ansul connections to building Ansul system
- ☐ All 3 cleaning drains connected to building drain with grease trap
- ☐ Filters in proper order from inlet: **orange pre-filters**, then two rows of **green multi-pocket filters** (or carbon in row 3)
- ☐ Access doors seated tight against gaskets
- ☐ System Monitor Panel wired and mounted visibly for daily monitoring by kitchen staff

Contractor's signature: _____

Printed name: _____

Establishment: _____

Model number: EPFA- _____ **Serial number:** _____

WARRANTY REMINDER

Follow the Maintenance Instructions (Section 7) to maintain the 1-year manufacturer warranty.

© 2026 Molitron Company. Document EPFA-OM-2026 Rev. A. Supersedes 10-2019. UL and the UL Mark are trademarks of UL LLC. Ansul is a trademark of Johnson Controls.