

Stratus Redundant Linux Release 3.1.0.2 Release Notes

These Release Notes (updated at 12:29 PM on 6/30/2026) are for Stratus Redundant Linux Release 3.1.0.2, which runs on ztC Edge systems.

Caution: Upgrade Stratus Redundant Linux Release 3.1.0.1 to Release 3.1.0.2 Immediately. Stratus Redundant Linux Release 3.1.0.2 corrects for critical installation, upgrade, and repair scenarios identified in Release 3.1.0.1. Stratus Redundant Linux Release 3.1.0.1 configurations are not able to replace or recover nodes at the matching version. To avoid the risk of irrecoverable system state during failure, inability to repair or rebuild, and potential extended outages, you must upgrade Stratus Redundant Linux 3.1.0.1 systems to Release 3.1.0.2. For more information, see [PUB0003344](#).

See the following sections:

- [New Features and Enhancements](#)
- [Features No Longer Supported](#)
- [Bug Fixes](#)
- [CVE Fixes](#)
- [Important Considerations](#)
- [Known Issues](#)
- [Accessing Stratus Knowledge Base Articles](#)
- [Getting Help](#)

New Features and Enhancements

New in Stratus Redundant Linux Release 3.1.0.2

Stratus Redundant Linux Release 3.1.0.2 includes bug fixes (see [Bug Fixes](#)) and new guest operating system support for Red Hat Enterprise Linux 9.6 (see [Tested Guest Operating Systems](#) for full list).

For a list of features introduced in:

- ztC Edge Release 3.1.0.1 — See [Stratus Redundant Linux Release 3.1.0.1 Release Notes](#).
- ztC Edge Release 3.1.0.0 — See [Stratus Redundant Linux Release 3.1.0.0 Release Notes](#).
- ztC Edge Release 3.0.0.0 — See [Stratus Redundant Linux Release 3.0.0.0 Release Notes](#).

Features No Longer Supported

No features were removed in Stratus Redundant Linux Release 3.1.0.2. For a list of features removed in:

- ztC Edge Release 3.1.0.1 — See [Stratus Redundant Linux Release 3.1.0.1 Release Notes](#).
- ztC Edge Release 3.1.0.0 — See [Stratus Redundant Linux Release 3.1.0.0 Release Notes](#).
- ztC Edge Release 3.0.0.0 — See [Stratus Redundant Linux Release 3.0.0.0 Release Notes](#).

Bug Fixes

Bugs Fixed in Stratus Redundant Linux Release 3.1.0.2

GPG Key Expiration Prevents Proper Installation and Upgrade

ZTC-30193: A GNU Privacy Guard (GPG) key that is integrated into the product ISO expired on March 7, 2026. The expiration of this key prevents the proper installation of, or upgrade to, ztC Edge Release 3.1.0.1. ztC Edge Release 3.1.0.2 fixes the GPG key expiration issue, and includes all bug fixes and enhancements that were part of Release 3.1.0.1.

For more information, see [PUB0003338](#) on the **Penguin Solutions Customer Service Portal** at <https://support.penguinolutions.com>.

Upgrade Fails with GRUB Error

ZTC-30244: Upgrade from Stratus Redundant Linux Release 2.3.x.x systems to Release 3.1.x.x could fail with the error `Unable to locate grub configuration` when Advanced Programmable Interrupt Controller Virtualization (APICv) was enabled. This has been fixed in Stratus Redundant Linux Release 3.1.0.2, allowing affected systems to upgrade successfully.

Bugs Fixed in Stratus Redundant Linux Release 3.1.0.1

For information, see [Bug Fixes in Stratus Redundant Linux Release 3.1.0.1](#).

Bugs Fixed in Stratus Redundant Linux Release 3.1.0.0

For information, see [Bug Fixes in Stratus Redundant Linux Release 3.1.0.0](#).

CVE Fixes

Stratus Redundant Linux Release 3.1.0.2 contains no CVE fixes. For a list of CVE fixes in previous releases, see [Fixed CVEs](#).

Important Considerations

Apply Patch Before Upgrading from Release 3.1.0.0 to Release 3.1.0.2

If Windows 11 Virtual Machines (VMs) are present in your environment, you must apply the Stratus patch `win11_patch_1.0.tar.gz` before upgrading from Release 3.1.0.0 to Release 3.1.0.2. Without the patch, if a Physical Machine (PM) shuts down or fails, the VM migrates to the second PM, but the VM does not restart automatically.

The win11_patch_1.0.tar.gz patch, and instructions for its use, are available at the **Penguin Solutions Customer Service Portal** Knowledge Base. See [KB0017169](#).

Note: All PMs and VMs must be in good health before applying the patch. Examine the ztC Edge Availability Console to verify that there are no alerts indicating PM or VM problems.

After applying the patch, proceed with the upgrade to ztC Edge Release 3.1.0.2.

Requirements for Upgrading Windows 10 VM Guest Systems to Windows 11

Before you can upgrade a Windows 10 guest system to Windows 11, the following requirements must be met on the Windows 10 guest system:

- BIOS Mode must be set to Unified Extensible Firmware Interface (UEFI).
- Secure Boot State and virtual Trusted Platform Module (vTPM) security must be enabled.

If the guest system does not meet any of these requirements, contact ztC Edge Customer Support for assistance.

For information about enabling Secure Boot State and vTPM security, see [Understanding Windows 11 Virtual Machine Differences from Other VMs](#).

Restriction on Number of Virtual CPUs in Windows 11 Environments

In Windows 11 guest environments, the number of vCPUs must not exceed 8. Exceeding this limitation may result in system hangs or data corruption.

Upgrading to Release 3.1.0.2

To upgrade from Stratus Redundant Linux Release 3.0.x.x to Release 3.1.0.2, see [Upgrading Stratus Redundant Linux Software Using an Upgrade Kit](#).

To upgrade from Stratus Redundant Linux Release 2.x to Release 3.1.0.2, follow the upgrade path for the release that is running on your system:

- Releases 2.3.4.1, 2.3.4.0, 2.3.3.0, 2.3.2.0, 2.3.1.0, and 2.3.0.0—Upgrade directly to Release 3.1.0.2 by following the instructions in [Upgrading from Stratus Redundant Linux Release 2.x to 3.x or Higher](#).
- Releases earlier than Release 2.3.0.0—Upgrade to Release 2.3.4.0 or later, and then upgrade to Release 3.1.0.2. For information on upgrading to Release 2.3.4.x, see the [Release 2.3.4.0 Release Notes and Help](#).

SNMP Disabled by Default on ztC Edge Systems

SNMP is disabled by default on ztC Edge systems. Starting with Stratus Redundant Linux Release 2.3.0.0 or higher, the SNMP process is also stopped in the console operating system on each node. For security reasons, if you need to enable SNMP, you should disable SNMP v1 and v2, and enable only v3 by using the SNMP **Restricted** configuration. For details, see [Configuring SNMP Settings](#) and [Security Hardening](#), as well as [KB0015428](#).

Deploying Spare Nodes with Stratus Redundant Linux Release 3.0.0.0 or Higher

If you have a factory-fresh node installed with Stratus Redundant Linux Release 3.0.0.0 or higher, you can deploy the node as a single-node system, or as the second node or replacement node in a dual-node system if the running node is already running either Release 2.3.x.x or Release 3.x.x.x.

If you need to use a spare node that is imaged with any release prior to Release 3.0.0.0, you must exchange it for a factory-imaged Release 3.x.x.x node to support pairing with any Release 3.x.x.x primary node. Contact your authorized Penguin Solutions service representative for assistance.

To deploy, add, or replace nodes that meet these requirements, see [Deploying the System](#), [Adding a Node to a Single-Node System](#), and [Replacing Physical Machines \(Automated\)](#).

Using Intel Active Management Technology (AMT) for Lights-Out Support

ztC Edge systems incorporate Intel Active Management Technology (AMT) lights-out support for remote power management, remote console, and remote media. For important information about AMT configuration and restrictions, see [KB0014200](#).

Deploying ztC Edge Nodes at Separate Physical Sites

When you deploy a ztC Edge system in a redundant, dual-node configuration, you must deploy both nodes at the same site and directly connect the A-links between the blue (**A2**) and yellow (**A1**) network ports of each node. If you want to set up a ztC Edge system in an automated local site recovery (ALSR) configuration, where each node is located at a separate physical site for increased redundancy, contact your authorized Penguin Solutions service representative for assistance. Because of the geographic separation, an ALSR configuration requires careful planning of component placement and networking topologies.

Tested Guest Operating Systems

For a list of the guest operating systems tested with the current release, see [Tested Guest Operating Systems](#). For information on guest operating systems tested or supported in previous releases, go to <http://ztcedgedoc.stratus.com>, select the appropriate release, and then search for the guest operating system.

Known Issues

Lost Communication Message When Adding Second Node

When adding a second node to a single-node ztC Edge configuration, the cluster IP address on the primary node (node0) is deleted, then added again after about three minutes. This is expected behavior.

However, the deletion of the primary node cluster IP address causes the ztC Edge Availability Console to display the message **Lost Communication** in the banner. Disregard this message. Taking action to recover the lost connection could interrupt and break the pairing process. The pairing process continues after three minutes, when the primary node cluster IP address is re-added. The **Lost Communication** message is removed.

A-Links Appear Disconnected After Upgrading

After upgrading ztC Edge, the **Networks** page of the ztC Edge Availability Console may indicate a broken A-Link condition. The alert appears when node1 comes online; it indicates that System Management does not recognize the link as connected.

If you encounter this error, see [KB0017335](#) on the **Penguin Solutions Customer Service Portal**.

Failed to Import Third Party OVF with Multiple Disks Using REST API

Attempts to import third-party Open Virtualization Format (OVF) files containing multiple disks using the Representational State Transfer (REST) API fail on all guest types (Linux and Windows). The issue occurs regardless of platform and affects the `/restapi/v2/import/importvm` endpoint.

To work around this issue, use the user interface to import third-party VMs with multiple disks. This issue will be addressed in the next release.

System Loses DNS Server Settings After Upgrading from Release 3.0.0.x to 3.1.0.2, or from Release 3.1.0.0 to 3.1.0.2

After upgrading from Stratus Redundant Linux Release 3.0.0.x to 3.1.0.2, or from Release 3.1.0.0 to 3.1.0.2, the system loses its Primary DNS and Secondary DNS settings and might switch to DNS settings provided by DHCP, or blank DNS settings if there is no DHCP server. If possible, make note of the DNS settings on the **Preferences** page of the ztC Edge Console before starting the upgrade and restore the settings after the upgrade.

Host OS Reverts to Default root Password After Upgrading from Release 3.0.0.x to 3.1.0.2, or from Release 3.1.0.0 to 3.1.0.2

When you upgrade from Stratus Redundant Linux Release 3.0.0.x to 3.1.0.2, or from Release 3.1.0.0 to 3.1.0.2 the root password for the Ubuntu host operating system of each PM reverts to the default password, `KeepRunning`. When you log on to the host operating system as described in [Accessing the Host Operating System](#), the system automatically prompts you to set a new password. To secure the system, set a new root password in the host operating system of each PM as soon as possible after the upgrade.

Upgrading from Release 2.x to 3.x Does Not Preserve System Logs from Original 2.x System

When you upgrade from Stratus Redundant Linux Release 2.x to 3.x, the upgrade process does not preserve the system logs from the original Release 2.x (CentOS) system. To preserve the log data before upgrading, create a diagnostic file as described in [Creating a Diagnostic File](#) and download it to a management PC.

Node1 Loses Static IP Address After Upgrading from Release 2.x to 3.x

After upgrading from Stratus Redundant Linux Release 2.x to 3.x, **node1** might switch from a static IP address to one provided by DHCP, or a blank IP address if there is no DHCP server. For information about locating and recovering the previous static IP address that was configured, see [KB0017111](#).

Windows Server Guest Stuck in Booting State After Upgrading from Release 2.x to 3.x

After upgrading from Stratus Redundant Linux Release 2.x to 3.x, in rare cases, a Windows Server guest might remain stuck in the **booting** state, waiting for its storage to be ready. As a workaround, stop and start the VM to allow it to continue booting.

Lengthy VM Volume Synchronization After Upgrading from Release 2.x to 3.x

After upgrading from Stratus Redundant Linux Release 2.x to 3.x, the volumes associated with some VMs might take longer than normal to synchronize between nodes because the system performs a full mirror copy of each volume instead of a delta mirror copy. The amount of time required for synchronization varies by system hardware, overall system load, and guest disk activity.

Guest Monitoring Alerts Persist After Upgrading from Release 2.x to 3.x

After upgrading from Stratus Redundant Linux Release 2.x to 3.x on a system where Windows guest OS monitoring was previously enabled, the **Alert History** page might still contain guest alerts from Release 2.x even though guest monitoring is no longer supported in Release 3.x. You must manually remove these alerts from the **Alert History** page to allow the system to reach a healthy state and clear alerts from the **Dashboard** page and the masthead of the ztC Edge Console.

ztC Edge 100i/110i System Power Button Cannot Shut Down Primary Node

On ztC Edge 100i/110i systems, if you press the power button on the primary node, it does not shut down the node as expected. If you need to shut down the primary node for maintenance, use the ztC Edge Console as described in [Shutting Down a Physical Machine](#).

ztC Edge 100i/110i System SYS LED Cannot Flash to Identify Node

For ztC Edge 100i/110i systems, if you click **Identify** on the **Physical Machines** page of the ztC Edge Console, the SYS LED does not flash to identify the node.

False System Clock Error on Alert History Page When Product License Expires

When the ztC Edge product license expires, the timestamps on the **Alert History** page revert to a previous date and time, and the page displays an alert that the **System Clock is more than 1 week behind actual time**. This issue affects only the **Alert History** page; the actual system clock and timestamps on the **Audit Log** page remain correct. When you activate the new product license, the timestamps return to normal.

To check the status of the product license, see [Managing the Product License](#).

Cannot Properly Manage Some System Preferences and Features

In rare cases, you might see the following behavior related to the ztC Edge Console system preferences and features:

- On the **Preferences** page of the ztC Edge Console, some settings including **Owner Information**, **Mail Server** (SMTP), or **SNMP Configuration** do not display properly, or the console displays errors when you attempt to save changes.
- Features including e-Alerts, support notifications (call-home alerts), and SNMP monitoring do not work.

- You cannot save and restore preferences, as described in [Saving and Restoring System Preferences](#).

For information about diagnosing and resolving this issue, see [KB0017113](#).

VM Backup Cannot Start with a CIFS Mount Point

If you back up a VM as described in [Backing Up a Running Virtual Machine](#), select **Mount device via Windows Share (CIFS/SMB)**, and enter the **Repository** (share) name with standard backslashes (\), the backup fails. As a workaround, enter the **Repository** name with forward slashes (/) for a successful backup. For example, if the share is \\10.71.253.9\Data\Users\Backup\, enter the share as //10.71.253.9/Data/Users/Backup/.

VM Backup Is Unreliable If Primary Node Fails Over While Backup is Running

If you back up a VM as described in [Backing Up a Running Virtual Machine](#), and the network is disrupted causing a primary node failover, the backup might fail, prematurely report success, or hang. For example:

- The backup might fail even though the **Virtual Machines** page of the ztC Edge Console displays a message that the **Backup completed successfully** on the **Summary** tab for the VM. It might be possible to confirm that the backup failed if the **Volumes** tab for the VM is missing volumes or contains incomplete or empty volumes. If you were to recover the VM as described in [Recovering a Virtual Machine from a Backup](#), the recovered VM might not start; therefore, it is best to delete the VM and any associated volumes, and repeat the process when the network has recovered.
- The backup hangs and cannot be canceled by clicking **Cancel** on the **Summary** tab of the VM. For information about resolving this issue, see [KB0017114](#).

VM Recovery Fails If Primary Node Reboots

If you recover a VM backup as described in [Recovering a Virtual Machine from a Backup](#), and the primary node reboots during the recovery process, the recovery fails. If needed, delete the partially recovered VM and any associated volumes, and repeat the recovery steps.

If the **Import/Restore/Recover** button remains disabled and prevents you from repeating the recovery, see [KB0017109](#) for information about reactivating the button.

VM Recovery Displays Warning "Unable to fetch the current status"

If you recover a VM backup as described in [Recovering a Virtual Machine from a Backup](#), and the recovery lasts longer than 1.5 hours, the ztC Edge Console displays a warning message on the **Summary** tab of the **Virtual Machines** page that the system is **Unable to fetch the current status. Please log out and log back in to retrieve the current status**. To display the current status, log out of the ztC Edge Console, log back in again, and check the **Virtual Machines** page. The VM recovery continues in the background and completes successfully.

VM Recovery Fails Despite In Progress or Completed Status

If you recover a VM backup as described in [Recovering a Virtual Machine from a Backup](#), the recovery might fail even though the **Virtual Machines** page of the ztC Edge Console displays messages of **Recovery in progress** or **Recovery**

completed successfully.

For example, if the recovery source is on a USB device, and the device disconnects before the recovery is complete, the **Virtual Machines** page might continue to report the recovery status as **Recovery in Progress** even though the system cannot finish copying the volumes.

You can determine if the VM recovery was unsuccessful if the recovered VM cannot start, or if the **Volumes** tab of the recovered VM on the **Virtual Machines** page is missing volumes with no apparent progress. If needed, click **Cancel** to cancel the recovery and delete the VM, and then restart the recovery process.

Cannot Attach USB Device to Unprotected VM

If you try to attach a USB device to an unprotected VM on the **Virtual Machines** page of the ztC Edge Console, the operation fails. For more information about unprotected VMs, see [Unprotected Operation](#).

Cannot Restore Console Inactivity Logout Preferences

On a system recently upgraded from Stratus Redundant Linux Release 2.x to Release 3.0.0.0 or higher, when restoring system preferences as described in [Saving and Restoring System Preferences](#), the ztC Edge Console displays a **Failed** status for the **Console Inactivity Logout** preference. This is expected behavior because the Console Inactivity Logout is a new feature in Release 3.0.0.0 or higher, and there is no preference data to restore from the previous 2.x release. For more information about this new feature, see [Configuring the Console Inactivity Logout](#).

Incomplete Messages When Creating or Importing a Windows 11 Guest with the BIOS Boot Type

When you create or import a VM with the Windows 11 guest operating system, the VM must have the UEFI boot type as described in [Understanding Windows 11 Virtual Machine Differences from Other VMs](#). If you create or import a Windows 11 guest with the BIOS boot type, the system appears to create the new VM successfully, but the VM cannot start. If you attempt to start the VM, the system automatically shuts down the VM and displays a message on the **Summary** tab of the **Virtual Machines** page to explain that the **VM name cannot start because it has a misconfigured boot type BIOS. To select the correct boot type (UEFI), you must delete the VM and create a new one.**

When this happens, the **Dashboard** and **Alert History** page might display incomplete information, such as a blank message, or a message that incorrectly states **VM name failed to boot and will be restarted** though the VM will be shut down. The messages also fail to explain how to create a VM with the correct boot type (UEFI).

Graphical Installation Fails to Start When Installing Debian 11 Guest

If you install the Debian 11 guest operating system, the guest fails to start the graphic installation utility and the installation terminates with a fatal error. To resolve this issue, see [KB0017036](#).

Windows Server 2016 Guest Stuck in Booting State After Installation in Localized German Language

After installing Windows Server 2016 with the localized German version of the Windows Installer (ISO) in a VM with a single virtual network adapter, the VM is stuck in the **booting** state because its network is not working. To resolve this

issue, see [KB0017023](#).

P2V Client Cannot Boot on VM with UEFI Boot Mode

If you attempt to boot the P2V client (**virt-p2v**) ISO file on a VM with the UEFI boot mode, the P2V client is unable to start and the system ends up at a shell prompt.

P2V Client Does Not Support Migration of Windows Server 2025 Systems

The version of the P2V client (**virt-p2v**) ISO file available with Stratus Redundant Linux Release 3.1.0.0 does not support migration of Windows Server 2025 systems. If you attempt to migrate a Windows Server 2025 PM or VM with the P2V client, the migration fails.

Removable Media and Migrating a PM or VM Using the P2V Client

Before migrating a PM or VM using the bootable P2V client (**virt-p2v**) ISO file, check if any removable media (for example, floppy disks, DVD drives, or external USB disks) are attached to the source image. If removable media are attached to the source image when you attempt to migrate a PM or VM, the error message **Conversion failed** appears. To prevent this issue, deselect the media in the **virt-p2v** window before starting the migration. To do so, access the **virt-p2v** window with the sections **Target properties** and **Fixed hard disks**, and then beneath **Fixed hard disks**, uncheck the box in the **Convert** column next to the removable media. See [Migrating a Physical Machine or Virtual Machine to a System](#), particularly the section **To migrate a PM or VM to the ztC Edge system**, for more information on using **virt-p2v**.

"The VM *name* has failed to start" Alert While Running the P2V Client Is Normal

While using the P2V client to migrate a VM from an everRun or ztC Edge system, it is normal if the source system displays the alert "The VM *name* has failed to start" during the migration process, because although the source VM is powered on and running the P2V client, the guest operating system does not start.

Importing VM from OVA File May Succeed Despite Failure Message

When you import a VM from an OVA file, the import might appear to fail with the error message **Failed to import OVA**; however, if you are able to manually start the VM, the import was successful. If the VM does not start, delete the VM and its volumes and retry the import.

Unknown Error in ztC Edge Console When Importing an Unprotected VM

When you import an unprotected VM (see [Unprotected Operation](#)), the ztC Edge Console might display an alert that "An unknown error has occurred." You can safely ignore this message and click **OK** to continue the import.

Maximum Path Length When Importing a VM

When you import a VM using the **Import/Restore Virtual Machine** wizard, the maximum length of the path to the VM, including the VM name, is 4096 characters for the import options **Import from remote/network Windows Share(CIFS/SMB)** and **Import from remote/network NFS**.

REST API Restrictions for Importing a VM

If you import a virtual machine by using the **POST /v2/import/importvm** method of the REST API, observe the following restrictions:

- You can import a single OVF file only one time. If you try to import the same OVF a second time, the import fails.
- The **importvm** method will support only an NFS import. It will not support a PC, USB, or CIFS/SMB import.
- The REST API cannot validate input to the **importvm** methods. Input to the REST API will be submitted as is. If the input is incorrect, the system will return an error message.
- If you import a Windows 11 VM, it must have the UEFI boot type, as described in [Understanding Windows 11 Virtual Machine Differences from Other VMs](#).

Maximum Resolution of a UEFI VM Console Session

On the **Virtual Machines** page of the ztC Edge Console, you can open a VM console session to display the console of the guest operating system running in the VM. When you open a console session to access a guest VM with a UEFI boot type, the console session may have a maximum resolution of 800x600. If needed, you can configure a higher resolution in the BIOS setup utility, as described in [KB0017168](#).

Creating VCD Fails When Console Browser Is Microsoft Edge

When you are using Microsoft Edge as the browser for the ztC Edge Console, you cannot create a VCD: the process will fail. Instead, use another compatible browser (see [Compatible Internet Browsers](#)).

In a Single-Node System, VM Creation Wizard Display of Added vCPUs Is Incorrect

When you create a VM on a system configured for one node, the **VM Creation Wizard** displays that it is adding two vCPUs to the number vCPUs you specify. However, once the VM is created, the user-specified number of vCPUs is attached to the VM. The additional two (incorrectly displayed) vCPUs are not added.

Mapping of Japanese Keyboards 106 and 109 for Console in Firefox May Be Incorrect

The mapping of the Japanese keyboards 106 and 109 may be incorrect when using Firefox to access the ztC Edge Console. Use Chrome or remote connection software (VNC or RDP), instead.

Cannot Enable SNMP Requests Without Traps

If you create an SNMP request in the ztC Edge Console, you must also create a trap; otherwise, the ztC Edge Console displays the error "Problem encountered updating SNMP. Make sure your settings are correct. Error: Configure SNMP failed." As a workaround, when creating a new SNMP request, click **Enable SNMP Requests** and **Enable SNMP traps**, do not define a Version 3 user, keep the default of **Restricted** requests, and specify at least one trap recipient. Adding a Version 3 user or clicking **Unrestricted** during the initial configuration might cause the configuration to fail. After the initial configuration is complete, you can then modify it to specify any settings that you require.

System Fails to Generate SNMPv3 Traps When Authentication Is Enabled

If you configure an SNMPv3 user and send SNMP traps with authentication enabled, the system fails to generate the SNMP traps.

VMs Reported as Broken Instead of Degraded When A-Link Is Offline

If an A-link cable or network is disconnected on one node, the state of a VM on that node may be reported as broken (✖) in the ztC Edge Console, even though the VM still has another active A-link connection. The availability of the VM is unaffected.

Ejected VCD Still Displayed in a Linux-based VM Console

If you use the ztC Edge Console to eject a VCD from a VM running a Linux-based guest operating system, the VCD may still be displayed in the guest operating system. If needed, you can eject the VCD in the guest operating system to stop displaying the VCD.

Some Browsers Unable to Connect a VNC When Using https

If you are connected to the ztC Edge Console using an **https** URL in some browsers, including the Mozilla[®] Firefox[®] browser, and you click **Console** after selecting a running VM from the **Virtual Machines** page, the message **VNC: Unable to connect, retrying in n seconds** may appear. To enable the VNC connection, click the https link to the VNC console page in the upper right-hand corner of the masthead. In the Firefox browser, when the **Your connection is not secure** window appears:

1. Click **Advanced**. A message about an invalid security certificate appears.
2. Click **Add Exception**. The **Add Security Exception** dialog box appears with the console's location in **Location**.
3. Click **Confirm Security Exception**.

The VNC console appears.

Some Browsers Unable to Connect a VNC When Using http

If you are connected to the ztC Edge Console using an **http** URL in some browsers, including the Google[®] Chrome[™] browser, and you click **Console** after selecting a running VM from the **Virtual Machines** page, the message **VNC: Unable to connect, retrying in n seconds** may appear. If you cannot establish a connection, try using either the Mozilla Firefox or Microsoft Edge browser.

Reboot Required When Changing Node IP Address or Netmask Network Settings

When you change the IP address or netmask settings of a node as described in [Configuring IP Settings](#), both the old and new settings are in effect until you reboot the node. Having both settings active may cause routing or connection issues.

Accessing Stratus Knowledge Base Articles

The **Penguin Solutions Customer Service Portal** provides a searchable **Knowledge Base** with technical articles about all Stratus products, including ztC Edge. In some cases, the online Help directly references these Knowledge Base articles

(for example, KBnnnnnnnn). You can access the **Penguin Solutions Customer Service Portal** and its Knowledge Base by using your existing portal credentials, or by creating a new user account, as follows.

To access the Knowledge Base

1. Log on to the **Penguin Solutions Customer Service Portal** at <https://support.penguinsolutions.com>.

If needed, create a new account as follows:

- a. Click **Register**.
- b. Enter your contact information including your company email address and registration code, and then click **Submit**.

Your company email address must include a domain name (for example, stratus.com) for a company that is a registered customer of Stratus. The portal sends an email to administrators of the company's account to approve the request.

- c. Upon approval, click the link in the email that you receive from Stratus.
- d. Enter a new password and finish configuring your account.

If you need assistance creating an account, contact your authorized Penguin Solutions service representative.

2. In the portal, do one of the following:

- In the **Search** box, enter keywords or the KB article number (KBnnnnnnnn) associated with the information you need, and then click the search button.
- Click **Knowledge**, click the name of a product, and then browse available articles.

Getting Help

If you have a technical question about ztC Edge systems, you can find the latest technical information and online documentation at the **Downloads** page at <https://www.penguinsolutions.com/services-support/downloads/?tab=ztcedge>. You can also search the **Knowledge Base** in the **Penguin Solutions Customer Service Portal** at <https://support.penguinsolutions.com>.

If you cannot resolve your questions with these online resources, and the system is covered by a service agreement, contact your authorized Penguin Solutions service representative. For information, see the **ztC Edge Support** page at <https://www.stratus.com/services-support/customer-support/?tab=ztcedge>.

[Product Support and Downloads](#)

[About Penguin Solutions](#)

[Product Documentation \(PDF Format\)](#)

[About Help](#)