

RUN THE SCREEN

- 1 Check the **Die** box names the tool actually mounted on this machine – the cavity rows below come from it.
- 2 On each cavity row, pick the **Part**. Every cavity running the same part? Press **Copy part to empty rows**.
- 3 Scan the **LTT Barcode** from the basket into that row.
- 4 Press **OPEN BASKETS** to open every row you filled in.

If the die is wrong or empty – stop and tell a supervisor. Do not work around it.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
 Wrong name up top? Tap **Operator:** to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

✂ cut here ✂

RUN THE SCREEN

- 1 Pick your **Reporting shift**.
- 2 Enter **Shots this entry** – that is die-wide, not per cavity.
- 3 Press **Compute / Preview** to break it down by cavity.
- 4 Press **Add scrap reason** on any cavity that had scrap. **Good (pc)** updates on its own as you log it.
- 5 Lost a whole shot? Pick a reason and qty under **Shot loss (all cavities)** and press **Register shot loss** before you submit.
- 6 Press **SUBMIT SHIFT OUTPUT** when the rows look right.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
 Wrong name up top? Tap **Operator:** to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

Die Cast | Lot Release

Release · Void

RUN THE SCREEN

- 1 **Release** – press it on a basket that is full. It leaves the cavity, moves on to its next step, and frees the cavity for a new basket.
- 2 **Void** – only shows on an empty basket. It discards that basket.

WATCH THE RIGHT-HAND RAIL

Shots this shift · Good parts this shift · Scrap this shift · Die total shots (count / limit). If it reads **Approaching shot limit** or **OVER SHOT LIMIT**, tell a supervisor before you open the next basket.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
Wrong name up top? Tap **Operator:** to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

✂ cut here ✂

Trim | Check IN

Scan · Move

RUN THE SCREEN

- 1 If this press is shared, pick it from the **cell picker** at the top of the screen first.
- 2 Scan the **LTT** – the LOT, item, and eligibility show up for you to check.
- 3 Press **Move** to commit it to this cell.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
Wrong name up top? Tap **Operator:** to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

RUN THE SCREEN

- 1 Tap the LOT's card in the **Trim inventory** list, or scan its **LTT Barcode**.
- 2 Enter the **Lot count**.
- 3 Tap a reason under **Scrap reasons** to add one piece. Press **More reasons** if the one you need is not on the short list.
- 4 Press **Trim OUT** to release the LOT out of Trim.

Trim OUT always moves the whole LOT together – there is no split here.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
 Wrong name up top? Tap **Operator:** to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

✂ cut here ✂

Machining IN

RUN THE SCREEN

- 1 Scan the LTT on the casting you picked up.
- 2 Check the LOT, item, and piece count shown are the right ones.
- 3 Press **Start Machining**. It moves onto **Active machined LOT** below.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
 Wrong name up top? Tap **Operator:** to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

Machining OUT

Mint from the queue

RUN THE SCREEN

- 1 The oldest casting is already selected. Tap **Select** only to work a different one.
- 2 Enter how many **Pieces** to mint – it pulls from the whole queue, not just one casting.
- 3 Add scrap lines if any, then press **Submit**.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
Wrong name up top? Tap **Operator:** to switch.



Tap the ? in the corner
of any screen for
step-by-step help on
that exact screen.

DOWNTIME

Machine down or waiting on something? Press
Downtime up top.

✂ cut here ✂

Assembly IN

Scan components

RUN THE SCREEN

- 1 Scan or enter the LTT on the machined component.
- 2 Press **Scan In**. It is added to **Components at this cell** below.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
Wrong name up top? Tap **Operator:** to switch.



Tap the ? in the corner
of any screen for
step-by-step help on
that exact screen.

DOWNTIME

Machine down or waiting on something? Press
Downtime up top.

Assembly | Non-Serialized

[Fill · Complete](#)

RUN THE SCREEN

- 1 Check **Now producing** and the components staged at this cell.
- 2 **By Count** lines: enter the count and press **Complete Tray** when full. **By Weight / By Vision**: the scale or camera closes it – nothing to press.
- 3 On a By Count line, once enough trays are in, press **Complete** under **Container Completion Gate**.

A single-tray container ships on its own – you will not see the gate for it.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
Wrong name up top? Tap **Operator**: to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

✂ cut here ✂

Assembly | Serialized

[Watch · Complete](#)

RUN THE SCREEN

- 1 This line is MIP-integrated – watch **Current Tray**. It closes on its own; nothing to press per piece.
- 2 Once enough trays are in, press **Complete** under **WorkOrder Completion Gate** to finish and ship it.

A failed AIM post shows a warning and retries on its own – no action needed from you.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
Wrong name up top? Tap **Operator**: to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

RUN THE SCREEN

- 1 Check the **Machine** box at the top is the one that stopped; pick it from the list if not.
- 2 Press **Start Downtime** as soon as it stops – do not wait until you know why. It opens with no reason.
- 3 Pick the **Reason** on the row once you know it.
- 4 Press **End** on the row when work resumes. No supervisor sign-in needed.

Add Past Event logs downtime you missed. **Edit** and **Void** both ask for a supervisor sign-in – Void is permanent.

START · SIGN IN

Type your 5-digit **PIN**. Wrong digit? **Re-type PIN**.
Register New User is first-time only.
Wrong name up top? Tap **Operator:** to switch.



Tap the ? in the corner
of any screen for
step-by-step help on
that exact screen.

DOWNTIME

Machine down or waiting on something? Press
Downtime up top.

✂ cut here ✂

ROOM FOR ONE MORE

Add a card here for the next terminal type, or leave
this half blank on the printed sheet.