

Die Cast

Open · Record · Release

RUN THE SCREEN

- 1 Check the **Die** box names the tool actually mounted on this machine.
- 2 On **Open Basket**: pick the Part, scan the LTT, press **OPEN BASKETS**.
- 3 On **Record Shift Output**: pick your shift, enter the shot count, **Compute / Preview**, log any scrap, **SUBMIT SHIFT OUTPUT**.
- 4 On **Lot Release**: press **Release** on any basket that is full.

If the die is wrong or empty – stop and tell a supervisor. Do not work around it.

START · SIGN IN

Type your initials, press **Enter**. Not recognized? Press **Register New User**.
Wrong name showing? Tap **Operator**: up top to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

✂ cut here ✂

Trim

Check IN · Trim OUT

RUN THE SCREEN

- 1 If this press is shared, pick it from the top of the screen first.
- 2 On **Check IN**: scan the LTT, review the LOT shown, press **Move**.
- 3 On **Trim OUT**: tap the LOT's card (or scan its LTT), enter the **Lot count**.
- 4 Add scrap reasons if any, then press **Trim OUT** to release the whole LOT.

START · SIGN IN

Type your initials, press **Enter**. Not recognized? Press **Register New User**.
Wrong name showing? Tap **Operator**: up top to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

Machining IN

[Scan · Confirm](#)

RUN THE SCREEN

- 1 Scan the LTT on the casting you picked up.
- 2 Check the LOT, item, and piece count shown are the right ones.
- 3 Press **Start Machining**. It moves onto **Active machined LOT** below.

START · SIGN IN

Type your initials, press **Enter**. Not recognized? Press **Register New User**.
Wrong name showing? Tap **Operator**: up top to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

✂ cut here ✂

Machining OUT

[Mint from the queue](#)

RUN THE SCREEN

- 1 The oldest casting is already selected. Tap **Select** only to work a different one.
- 2 Enter how many **Pieces** to mint – it pulls from the whole queue, not just one casting.
- 3 Add scrap lines if any, then press **Submit**.

START · SIGN IN

Type your initials, press **Enter**. Not recognized? Press **Register New User**.
Wrong name showing? Tap **Operator**: up top to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

Assembly IN

[Scan components](#)

RUN THE SCREEN

- 1 Scan or enter the LTT on the machined component.
- 2 Press **Scan In**. It is added to **Components at this cell** below.

START · SIGN IN

Type your initials, press **Enter**. Not recognized? Press **Register New User**.
Wrong name showing? Tap **Operator**: up top to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

✂ cut here ✂

Assembly · Non-Serialized

[Fill · Complete](#)

RUN THE SCREEN

- 1 Check **Now producing** and the components staged at this cell.
- 2 **By Count** lines: enter the count and press **Complete Tray** when full. **By Weight / By Vision**: the scale or camera closes it – nothing to press.
- 3 On a By Count line, once enough trays are in, press **Complete** under **Container Completion Gate**.

A single-tray container ships on its own – you will not see the gate for it.

START · SIGN IN

Type your initials, press **Enter**. Not recognized? Press **Register New User**.
Wrong name showing? Tap **Operator**: up top to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

Assembly · Serialized

[Watch · Complete](#)

RUN THE SCREEN

- 1 This line is MIP-integrated – watch **Current Tray**. It closes on its own; nothing to press per piece.
- 2 Once enough trays are in, press **Complete** under **WorkOrder Completion Gate** to finish and ship it.

A failed AIM post shows a warning and retries on its own – no action needed from you.

START · SIGN IN

Type your initials, press **Enter**. Not recognized? Press **Register New User**.
Wrong name showing? Tap **Operator**: up top to switch.



Tap the ? in the corner of any screen for step-by-step help on that exact screen.

DOWNTIME

Machine down or waiting on something? Press **Downtime** up top.

✂ cut here ✂

ROOM FOR ONE MORE

Add a card here for the next terminal type, or leave this half blank on the printed sheet.