# Lab 2

Rafik Zitouni
ECE Paris
rafik.zitouni@ece.fr



#### **Timers of Contiki**

Trigger events at a given time as **blinking a LED every 5 seconds** 

- **Simple Timer:** The application can check manually if the timer has expired. You can see for more details: **core/sys/timer.h**
- **Simple Timer:** When a timer expires it can callback a given function **core/sys/ctimer.h**
- Event timer: Application trigger an event after timer expires. core/sys/etimer.h
- Real Time Timer: It handles the scheduling and execution of real time tasks core/sys/rtimer.h

### **Example 1 : Timers**

When timer expires, an application changes its behavior → Event Timer

**CLOCK\_SECOND** is a value related to the number of the microcontroller's ticks per second. **CLOCK\_SECOND** also differs.

**PROCESS\_WAIT\_EVENT()** waits for any event to happen.

```
#include "contiki.h"
#include "dev/leds.h"
#include <stdio.h>
/*_____
#define SECONDS 2
PROCESS(test_timer_process, "Test timer");
AUTOSTART_PROCESSES(&test_timer_process);
PROCESS_THREAD(test_timer_process, ev, data)
 PROCESS_BEGIN();
 static struct etimer et;
 while(1) {
   etimer_set(&et, CLOCK_SECOND*SECONDS);
   PROCESS_WAIT_EVENT();
  if(etimer_expired(&et)) {
    printf("Hello world!\n");
    etimer_reset(&et);
 PROCESS_END();
```

### **Exercise 1:**

- 1) Print the value of CLOCK\_SECOND to count how many ticks you have in one second?
- Blink a LED for a certain number of seconds.
- 3) Add an application related to your timer and button. The timer starts only when the button is pressed and stops when the button is pressed again.

#### Sensors

Electrical and optical signals are the output of a sensed variable.

Contiki implements sensors as follow:

SENSORS\_SENSOR (sensor, SENSOR\_NAME, value, configure, status);

The method **configure** the **sensor**, poll the sensor **status** and request a **value**. The sensor structure contains pointers to these functions. The arguments for each function are shown below.

```
struct sensors_sensor {
   char * type;
   int (* value) (int type);
   int (* configure) (int type, int value);
   int (* status) (int type);
};
```

For analog sensors: platform/zoul/dev/adc-sensors.c

### **Phidget Sensors**

%Enable or configure the sensor

SENSORS\_ACTIVATE(sensor)

%Desable the sensor SENSORS\_DEACTIVATE(sensor)

%Request a type of value to the sensor (tempertature sensor.value(type);



RE-Mote allows up to **6 analog sensors** to be connected, but only **two phidget connectors** can be soldered at the same time.

It is possible to connect **3,3V** and **5V** analog sensor with ADC1 and ADC 3, respectively.

### Parameter of a Phidget light sensor

Parameter	Value
Sensor type	Light
Light level min	1 lux
Supply Voltage Min	2.4 V
Supply Voltage Max	5.5 V
Max current consumption	5mA
Light level max (3.3 V)	660 lux
Light level max (5 V)	1000 lux

One lux is equal to one lumen per square meter

 $1 \text{ Ix} = 1 \text{ Im/m}^2$ 

To read data from an attached sensor (as we did in the previous example)

```
ANALOG_GROVE_LIGHT
In the case of light sensor

ADC driver header

Choose which ADC channel to enable (here all channels)

#include "dev/zoul-sensors.h"

adc_sensors.configure(SENSORS_HW_INIT, REMOTE_SENSORS_ADC_ALL);

printf("Phidget ADC2 = %d raw\n", adc_sensors.value(REMOTE_SENSORS_ADC2));

printf("Phidget ADC3 = %d raw\n", adc_sensors.value(REMOTE_SENSORS_ADC3));

Request a sensed value
```

example/zolertia/zoul/zoul-demo.c gives more details.

See also the example: example/zolertia/zoul/test-grove-light-sensor.c

### **Exercise 2:**

- 1) Make the sensor take readings as fast as possible.
- 2) Print to the screen the ADC raw values and the millivolts (as this sensor is linear, the voltage corresponds to the luxes). What are the max and min values you can get?
- 3) What is the average light value of the room?
- 4) Create an application that turns the red LED on when it is dark and the blue LED on when the room is bright. In between, all the LEDs should be off. Add a timer and measure the light every 10 seconds.
- 5) Send the reading of the sensor to a mote connected to the PC (Sink). You should choose
  - 1) Unicast application
  - 2) Broadcast application